


Fuel Injection Pump - VE Type




Type Single Plunger With Rotary Distributor
 Rotation Clockwise (When Looking At Drive Gear)
 Mounting Left Hand Side Of Engine
 Drive Gear Drive At 1/2 Engine Speed
 Governor Internal Hydraulic
 Lubrication Fuel Oil Under Pressure
 Hand Primer Pump (Tractors With XL Cab Only) Before Fuel Filters


Tractor Model	Engine Type/ Identification N°.	Injection Pump Identification N°. (See Individual Specifications)
385	D-155 3 Cylinder	Bosch EP/VE3/10F 1100 R276-1 (Case Part N°. 1 329 101 C91)
485	D-179 3 Cylinder	Bosch EP/VE3/10F 1090 R276-2 (Case Part N°. 1 329 100 C91)
585	D-206 4 Cylinder	Bosch EP/VE4/10F 1150RV 10 484-6 (Case Part N°. 1 329 137 C1)
685	D-239 4 Cylinder	Bosch EP/VE4/10F 1150RV 10 484-3 (Case Part N°. 1 329 127 C1)
685 NAO	D-239 4 Cylinder	Bosch EP/VE4/10F 1200RV 10 484-4 (Case Part N°. 1 329 128 C1)
785	D-246 4 Cylinder	Bosch EP/VE4/11F 1200RV 10 459-3 (Case Part N°. 1 329 169 C1)
885	D-268 4 Cylinder	Bosch EP/VE4/11F 1200 R-277 (Case Part N°. 1 329 107 C91)
248	D-179 3 Cylinder	Bosch EP/VE3/10F 1090 R276-2 (Case Part N°. 1 329 100 C91)
258	D-206 4 Cylinder	Bosch EP/VE4/10F 1150RV 10 484-6 (Case Part N°. 1 329 137 C1)
380B	D-179 3 Cylinder	Bosch EP/VE3/10F 1090 R276-2 (Case Part N°. 1 329 100 C91)

ENGINE TROUBLESHOOTING CHART

GIVE A SUMMARY OF THE PROBLEM
AND FIND THE EXACT SIGNS.




STEP 24




Remove the rocker arm cover.

STEP 25




Remove the rocker arm pedestal bolts.

STEP 26




Lift off the rocker arm shaft assembly.

STEP 27



Remove the push rods.


STEP 28



Remove the cylinder head bolts.

NOTE: The cylinder head bolts are of two different lengths. The two outer rows are shorter than the two inner rows.

STEP 29



Attach the cylinder head to a lifting hoist and lift off the cylinder head.

SEPARATING THE TRACTOR

IMPORTANT: Remove front ballast weight and any front mounted equipment before separating the tractor.

STEP 1




Move the tractor onto level ground then apply the parking brake.

STEP 2




Put blocks in front of and behind the rear tires.

STEP 3




Remove the hood panel to have access to the battery.

STEP 4




Disconnect the cables from the negative (-) and then the positive (+) battery terminals.

STEP 5 Tractors With Vertical Muffler




Loosen the muffler clamp nuts.

STEP 32



Repeat the procedure to install the fan guard on the left hand side.

STEP 33




Remove the plug from the inlet manifold. Fit the air tube then tighten the clip.

STEP 34




Install the air cleaner and inlet tube.

STEP 35




Install and evenly tighten the two nuts and spring washers onto the bracket bolts.

STEP 36



Tighten the clip on the air outlet tube from the air cleaner.

STEP 37



Move the splitting frame rearwards to support the engine then remove the axle stands from the bolster plates. If removed, install the rear guide rail of the splitting frame.


AIR REMOVAL

STEP 6




Make sure there is fuel in the fuel tank.

STEP 7




On Non Cab (ROPS) and L Cab Tractors open the fuel shut off valve.

STEP 8



Loosen the air removal screw above the filter head. On XL Tractors actuate the hand primer pump. Close the air removal screw when clear fuel with no air bubbles flows from the screw.

STEP 9




Loosen the union screw on the fuel injection pump. On XL Tractors actuate the hand primer pump. Close the air removal screw when clear fuel with no air bubbles flows from the screw. Actuate hand primer pump five more times to finish the air removal.

NOTE: If the hand primer pump cannot be actuated turn engine over until the pump can be actuated.


STEP 79

Tractors Without XL Cab




Fit the throttle rod to the lever on the injection pump.

STEP 80




Fit the split pin.

STEP 81




Fit the engine stop cable onto the injection pump.

STEP 82



Tighten the locknut.


STEP 83



Open the fuel tap under the right hand fuel tank.

STEP 84


All Tractors



Fit a new rocker cover gasket onto the cylinder head.


Automatic Hitch Lock Warning Switch

STEP 92




Pull the knobs from the hydraulic control levers.

STEP 93




Remove the screws that hold the console in position then remove the console to have access to the automatic hitch lock warning switch.

STEP 94




When the testing is complete, fit the console into position. Install and evenly tighten the console screws.

STEP 95



Fit the knobs onto the hydraulic control levers.

FUSE LOCATIONS



1	2	3	4	5
				
35A	10A	35A	35A	35A


FUSE CIRCUIT(S) AND RATINGS

FUSE NO.	CIRCUIT(S)	FUSE RATING
1	ETHER START/HORN	35 AMP
2	GAUGE AND LIGHT CLUSTER	10 AMP
3	FLASHER/TURN SWITCH	35 AMP
4	CIGAR LIGHTER (IF FITTED)	35 AMP
5	HEADLIGHTS/TAIL LIGHTS	35 AMP

NOTE: DO NOT try to repair a fuse. If a fuse fails, it must be replaced with a new one of the rating specified in the above table AFTER the cause of the failure has been located and corrected.


IMPORTANT: Before assembly, lubricate all parts with clean transmission oil of the correct specification.

STEP 40




If removed, fit a new o-ring onto the union. Install the union into the pump body and tighten.

STEP 41




Fit the relief valve into the pump body. Make sure that the end with the large diameter is outwards.

STEP 42



Install the relief valve spring.


STEP 43



Inspect the locking material on the adjusting plug threads. If there is damage install a new adjusting plug. Use a key to turn the plug into its original position.


IMPORTANT: The relief valve pressure must be set before operating the steering system. Refer to Section 5025 for correct testing and adjusting procedure when the steering hand pump is installed on the tractor.

STEP 87




Install the three nuts and bolts through the steering arm and stub axle.

STEP 88




Evenly tighten the bolts to a torque of 160 to 180 lb ft (217 to 244 Nm).

STEP 89




Install the bottom grease fitting through the steering arm into the stub axle.

STEP 90




Use a grease gun to lubricate the king pin and bushes through both grease fittings. Do this until grease flows from the stub axle at the front axle 'joints'.

STEP 91



Install the front wheel and wheel bolts.

STEP 92





Remove the axle stands and wedges from the axle.

STEP 66


Repeat the test on the other end of the cylinder with the wheels turned fully to the right.

STEP 67




Check the oil level on the dipstick. Add transmission oil of the correct specification if the level is low.

STEP 75



Install the floor inspection panel


STEP 76



Install the cab floor cover and insulator.


Tractors Without Cab (ROPS) Or With Cab

STEP 77




Install the clevis on the rod.

STEP 78




Install the rod and clevis.


STEP 79




Install the pin.

STEP 153


Install the special tool.

STEP 154


Use a punch to push down the spring and detent ball, and push the special tool fully in.

STEP 155


Install the 3rd/4th selector fork into the speedbox, making sure the selector fork slides onto the synchroniser ring.

STEP 156

Push the selector shaft through the selector fork pushing out the special tool.

STEP 157

Turn the selector shaft half a turn until the detent balls locate in the detents in the shaft.

STEP 158


Line up the roll pin holes and drive in the roll pin.

BASE PLATE AND REGULATOR VALVE Removal

STEP 1


The regulator valve and baseplate can be removed from the tractor without removing the speed box from the tractor. All other steps require the speed box to be removed from the tractor.

STEP 2




Engage the parking brake.

STEP 3



Put blocks in front of and behind the rear wheels.


STEP 4



Remove the battery access panel and disconnect the battery terminals.

NOTE: *Negative (-) terminal first.*


STEP 5




Put a suitable container under the transmission drain plug, remove the drain plug and drain the transmission fluid. After draining install and tighten the transmission drain plug.

STEP 6


If fitted with MFD, see section 6485 for instructions on removing the drive shaft.

STEP 79

Install and tighten the cover or seal housing.

STEP 80

Clean the faces, fit a new gasket and install the P.T.O. clutch assembly cover.

STEP 81

Install and tighten the P.T.O. clutch assembly cover bolts.

STEP 82

Install the correct amount and grade of transmission oil to the tractor. Refer to the Operator's Manual.

STEP 83


Start the engine and check the operation of the hydraulic system, brakes and clutch and P.T.O.. Check for leaks and road test the tractor.




CAUTION: Put all the operating controls in neutral before turning the engine over. Engage the parking brake. Put blocks in front of and behind the rear wheels.



WARNING: Never operate the engine in a closed building. Proper ventilation is required under all circumstances.

STEP 120

Check transmission oil level. Add oil if required. Refer to Operator's Manual.

STEP 121

Install and tighten the transmission filler plug.

STEP 123

Start the engine and check the operation of the hydraulic system, braking system, engine clutch and P.T.O. Check for leaks and road test the tractor.




CAUTION: Put all the operating controls in neutral before turning the engine over. Engage the brake. Put blocks under the wheels.




WARNING: Never operate the engine in a closed building. Proper ventilation is required under all circumstances.

STEP 81



Install the two screws from both sides of the instrument panel.

STEP 82



Install the front panel.

STEP 83




Press in the lockpin to secure the front panel (both sides).

STEP 84




Connect the cables to the positive (+) and then the negative (-) battery terminals.

STEP 85




Install the battery cover.

STEP 86




Install the two wing nuts on the battery cover and tighten.


Hydraulic Oil Static and Dynamic Check




NOTE: The priority circuit contains:
Steering, power shift, MFD, F/R, PTO, oil cooling, brakes and transmission lubrication.

STEP 122


Fit a new nylon seal into the groove in the MCV body.

STEP 123

If a union has been removed fit a new o-ring onto the union. Lubricate the o-ring with clean transmission oil. Fit the union into its original position then tighten the locknut.


STEP 124

Lubricate the priority flow divider with clean transmission oil. Install the priority flow divider into the MCV body.


STEP 125

Check the spring for the priority flow divider with a spring compression tester. The spring must have the following specifications.


Free length		.3.253 inch (82.63 mm)
O.D.		.0.500 inch (12.7 mm)
Wire diameter		0.072 inch (1.83 mm)
Number of coils		.22.5
Compress to		.2.017 inch (51.23 mm)
		29.70 lb (132 N)

STEP 126


Fit a new o-ring onto the plug. Lubricate the o-ring with clean transmission oil. Install the spring and plug into the MCV.

STEP 57

Carefully hold the clevis in a vice fitted with soft jaw plates. Loosen the locknut.


STEP 58

Remove the assembly from the vice. Remove the clevis from the threads.

STEP 59

Use a spring compressor to compress the spring. Make a note of the position of the locknut on the threads. Hold the rod then remove the locknut.

NOTE: The draft valve spring is strong. Take care when releasing the pressure on the spring.

STEP 60

Remove the assembly from the spring compressor. Remove the collar and spring.




FIGURE 1

HAND SIGNALS


For communication under noise conditions and for special operations, a system of standard hand signals has been devised which can decrease time loss and prevent accidents.

Start the Engine



Move arm in a circle at waist level.

This Far To Go



Put your hands in front of your face with the backs of your hands outward. Move your hands in or out as an indication of how far to go.

Stop the Engine




Move your right arm across your neck from left to right.

Move Out



Face in the required direction of travel. Put your arm straight out behind you, then swing your arm over your head and forward until your arm is straight out in front of you with the back of your hand up.

Move Toward Me - Follow Me



Look toward the person or vehicle you need to move. Hold one hand in front of you with the back of the hand toward the machine and move your arm from the elbow to the fingers backward and forward.

PREVIEW ONLY

You're viewing 23 of 1716 pages

The full manual includes:

- All 1716 pages, complete
 - Searchable PDF (find any keyword)
 - No watermarks
 - Instant download
 - Print-ready quality
-

GET FULL MANUAL NOW

Case 380B Service Manual



Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual