


STANDARD TORQUE DATA FOR CAP SCREWS AND NUTS

Tightening of cap screws, nuts

Tighten alternately so that tightening torque can be applied evenly. The numbers in the figure below indicate the order of tightening.



JS00481A

Cap screws which have had Loctite used (white residue remains after removal) should be cleaned with light oil or suitable cleaning solvent and dried. Apply 2-3 drops of Loctite to the thread portion of the cap screw and then tighten.

Torque table

Tighten cap screws and nuts according to the table below if there are no other special instructions.

Cap Screw Name Size (Size)			M6	M8	M10	M12	M14	M16	M18	M20
Hexagon Screw	Spanner	[mm]	10	13	17	19	22	24	27	30
		[in.]	0.39	0.51	0.67	0.75	0.87	0.95	1.06	1.18
	Tightening torque	[Nm]	6.9	19.6	39.2	58.8	98.1	156.9	196.1	294.2
		[lb-ft]	5.1	14.5	28.9	43.4	72.3	115.7	144.6	217
Hexagon Socket Head Cap Screw	Spanner	[mm]	5	6	8	10	12	14	14	17
		[in.]	0.20	0.24	0.32	0.39	0.47	0.55	0.55	0.67
	Tightening torque	[Nm]	8.8	21.6	42.1	78.5	117.7	176.5	245.2	343.2
		[lb-ft]	6.5	15.9	31.1	57.9	86.9	130.2	181	253.2

SPECIFICATIONS

Main data

Model name.....CX290B Hydraulic Excavator
 Operating weight.....29800 kg (65698 lbs)
 Engine output.....154 kW / 1800 rpm

Performance

Swing speed.....10.2 Tr/min.
 Travel speed.....Low Speed 3.2 km/h (1.99 mph)
High Speed 5.6 km/h (3.48 mph)
 Maximum drawbar pull.....233.2kN (52425.45 lbf)
 Grade ability.....70% (35°)
 Ground pressure.....56 kPa (600 mm (23.62 in) grouser shoe)
49 kPa (700 mm (27.56 in) grouser shoe)
43 kPa (800 mm (31.50 in) grouser shoe)

Complete machine dimensions


	Arm (dipper)		
	3180 mm (125.20 in)	2650 mm (104.33 in)	3600 mm (141.73 in)
Lenght (without attachment)	5590 mm (220.08 in)	5590 mm (220.08 in)	5590 mm (220.08 in)
Lenght (with attachment)	10450 mm (411.4 in)	10480 mm (412.6 in)	10470 mm (412.2 in)
Height (with attachment)	3260 mm (128.35 in)	3340 mm (131.5 in)	3460 mm (136.22 in)

Main body dimensions

Main body width.....See machine overall dimensions
 Upper side swing body width.....2870 mm (112.99 in)
 Cab width.....1000 mm (39.37 in)
 Main body height.....3110 mm (122.44 in)
 Engine displacement.....3160 mm (124.41 in)
 Swing body tail distance.....3150 mm (124.01 in)
 Swing body rear section bottom height.....1190 mm (46.85 in)
 Distance between tumblers.....3980 mm (156.69 in)
 Overall track length.....4850 mm (190.94 in)
 Width of track shoe.....800 mm (31.50 in) (Optional: 600 mm (23.62 in) 700 mm (27.56 in)
 Minimum ground clearance.....470 mm (18.50 in) (To bottom of lower frame)













ENGINE SUMMARY

1. Engine System Diagram




1. Air cleaner
2. Fuel cooler
3. Inter cooler
4. Radiator
5. Turbo
6. Compressor side
7. Turbine side
8. Engine
9. Injector
10. Common rail
11. Supply pump
12. EGR cooler
13. Muffler
14. Fuel main filter
15. Fuel tank
16. Fuel prefilter
17. Charge fuel pump

Stand-Alone Parts Diagram

Name	No.	Shape	Circuit	Remarks
Safety relay	K8			Model: 24 V DC
Battery relay	K7			For +24 V DC
Starter motor	M1	CX210B model 		5.0 kW-24 V
Alternator	G2	CX210B model 		50 A-24 V
Battery	G1			
Washer motor	M4			

CX290B EXCAVATOR
HYDRAULIC SCHEMATIC




CX290B EXCAVATOR
HYDRAULIC SCHEMATIC
Number 87601004NA

HYDRAULIC PUMP FLOW MEASUREMENT PROCEDURE

Work preparations

1. Check that the main unit is in its work posture (arm-vertical).




RST-09-02-001B

2. Bleed out the pressure. (See the details on Bleeding Pressure in the Pressure Measurement and Adjustment Procedures.)


NOTE: Check the swing stop.

3. Use a spanner (17 mm, 0.67 in) to remove the feed port cover (2).




RST-09-02-001C

4. Use the bolts removed in step 3 to install the hydraulic oil tank lid (3).




RST-09-02-001D

5. Install the vacuum pump (4) on the hydraulic oil tank lid (3).
6. After setting the vacuum pump (4), switch on the power. (If the cable is too short, use an extension cable.)



RST-09-02-001F

7. Use a hexagon wrench (8 mm, 0.31 in) to remove the split flange and hydraulic hose. (This explanation uses flow measurement at the P2 pump.)




RST-09-02-001G

2) Digital output / output monitor

CHK	H/W -B	2	- 4 -	○○○○
DO1	○○○○	DOM1	○○○○	
DO2	○○○○	DOM2	○○○○	
DO3	○○○○	DOM3	○○○○	

Input /output state (○ = OFF, ● = ON)



1	Solenoid; Lever lock
2	Rotating light and bucket lock
3	Buzzer; Crane

3) Potentio-meter voltage

CHK	H/W -B	3	Pot4	0000	v
Pot1	0000	v	Pot5	0000	v
Pot2	0000	v	Pot6	0000	v
Pot3	0000	v	Pot7	0000	v

- Pot1 : Sensor; Angle boom
- Pot2 : Sensor; Angle arm
- Pot3 : Sensor; Angle offset
- Pot4 : Sensor; Pressure bottom
- Pot5 : Sensor; Pressure rod
- Pot6 : *
- Pot7 : *


4) Potentio-meter and sensor voltage (resistance)

CHK	H/W -B	4	Sn1	0000	v
Pot8	0000	v	Sn2	0000	v
Pot9	0000	v	Sn1	0000	Ω
Pot10	0000	v	Sn2	0000	Ω

- Pot8 : *
- Pot9 : *
- Pot10 : *
- Sn1 : *
- Sn2 : *
- Sn1 : *
- Sn2 : *

Air Conditioning troubleshooting

The blow temperature does not go down



**CRAWLER EXCAVATOR
CX290B
SCHEMATIC SET
LEP 87637610A**

TABLE OF CONTENTS

SECTION	SECTION No.	REFERENCE No.
Safety, General Information and Standard Torque Data	1001	7-27691NA
General Specifications and Special Torque Settings	1002	SC290B1002-0NA
Electrical and Engine Functions & Service Support.....	4001	SC210B4001-1NA
Electrical Equipment and Electrical Circuit Diagrams	4020	SC210B4020-0NA
Specifications, Troubleshooting, Checks and Hydraulic Pressure Settings	8001	SC290B8001-0NA
Hydraulic Functions.....	8020	SC290B8020-0NA
Hydraulic Component Functions	8030	SC290B8030-0NA
Air Conditioner Functions and Troubleshooting	9006	SC210B9006-0NA
Large Size Hydraulic Schematics	Pocket	87601004A
Large Size Electrical Schematics.....	Pocket	87601010A

NOTE: CNH Company reserves the right to make changes in the specification and design of the machine without prior notice and without incurring any obligation to modify units previously sold.

The description of the models shown in this manual has been made in accordance with the technical specifications known as of the date of design of this document.

SAFETY



This symbol means ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED. The message that follows the symbol contains important information about safety. Carefully read the message. Make sure you fully understand the causes of possible injury or death.

To prevent injury always follow the Warning, Caution and Danger notes in this section and throughout the manual.

Put the warning tag shown below on the key for the keyswitch when servicing or repairing the machine. One warning tag is supplied with each machine. Additional tags Part Number 331-4614 are available from your service parts supplier



WARNING: Read the operator's manual to familiarize yourself with the correct control functions.



WARNING: Operate the machine and equipment controls from the seat position only. Any other method could result in serious injury.



WARNING: This is a one man machine, no riders allowed.



WARNING: Before starting engine, study Operator's Manual safety messages. Read all safety signs on machine. Clear the area of other persons. Learn and practice safe use of controls before operating.

It is your responsibility to understand and follow manufacturers instructions on machine operation, service and to observe pertinent laws and regulations. Operator's and Service Manuals may be obtained from your Case dealer.



WARNING: If you wear clothing that is too loose or do not use the correct safety equipment for your job, you can be injured. Always wear clothing that will not catch on objects. Extra safety equipment that can be required includes hard hat, safety shoes, ear protection, eye or face protection, heavy gloves and reflector clothing.



WARNING: When working in the area of the fan belt with the engine running, avoid loose clothing if possible, and use extreme caution.



WARNING: When doing checks and tests on the equipment hydraulics, follow the procedures as they are written. DO NOT change the procedure.



WARNING: When putting the hydraulic cylinders on this machine through the necessary cycles to check operation or to remove air from a circuit, make sure all people are out of the way.

Section

1001

SAFETY, GENERAL INFORMATION AND TORQUE SPECIFICATIONS

2. Solenoid Sticking Prevention

a) Target solenoid


- Travel high-speed switchover solenoid
- Boost solenoid
- Option switchover solenoid
- Fan reverse solenoid (only for models with hydraulic drive fan)
- Free swing solenoid
- Bucket lock solenoid (only lift crane application machines)

Because the swing brake, power save solenoid, and electromagnetic proportional solenoid go ON and OFF frequently in regular work, they are not subject to control.

b) Operation

When key ON, switched ON / OFF for 0.25 second.


After that, control is normal control. Control ends before the engine starts, so the machine does not operate accidentally.



2) Digital output / output monitor

CHK	H/W -A	2	-4-	○○○○
DO1	○○○○	DOM1	○○○○	
DO2	○○○○	DOM2	○○○○	
DO3	○○○○	DOM3	○○○○	

Input /output state (○ = OFF, ● = ON)



1	Solenoid; Power save	6	Solenoid; Option line switchover
2	Solenoid; Boost	7	Solenoid; Free swing (North America)
3	Solenoid; Travel high-speed switchover	8	Solenoid; Fan reverse (large machine only)
4	Solenoid; Swing brake	9	Relay; Feed pump
5	Buzzer; Travel Alarm (North America)		

3) Potentio-meter voltage

CHK	H/W -A	3	Pot4	0000	v
Pot1	0000	v	Pot5	0000	v
Pot2	0000	v	Pot6	0000	v
Pot3	0000	v	Pot7	0000	v


Pot1 : Sensor pressure P1
 Pot2 : Sensor pressure P2
 Pot3 : Sensor pressure N1
 Pot4 : Sensor pressure N2
 Pot5 : Sensor pressure Swing
 Pot6 : Sensor pressure Upper
 Pot7 : Sensor pressure Travel

4) Potentio-meter and sensor voltage (Resistance)

CHK	H/W -A	4	Sn1	0000	v
Pot8	0000	v	Sn2	0000	v
Pot9	0000	v	Sn1	0000	Ω
Pot10	0000	v	Sn2	0000	Ω




Pot8 : Sensor pressure Arm in
 Pot9 : Sensor throttle
 Pot10 : Sensor pressure Overload
 Sn1 : Sensor temperature Hydraulic oil
 Sn2 : Sensor level Fuel
 Sn1 : Sensor temperature Hydraulic oil
 Sn2 : Sensor level Fuel

b) CX210B, CX240B



1	Electromagnetic fuel pump	8	Power save
2	P1 pressure sensor	9	Lever lock
3	P2 pressure sensor	10	N1 pressure sensor
4	5-way solenoid valve	11	P1 flow control proportional valve
5	Boosted pressure	12	Horsepower control proportional valve
6	Travel speed	13	N2 pressure sensor
7	Swing lock	14	Oil temperature sensor


Cab




RST-04-01-001E

1	Travel remote control valve
2	Upper operation remote control valve


Swing Parking Circuit (lever in neutral)






2. 5 Stack Solenoid Valve Operation Explanation

1) External shape diagram (Figure 1) and configuration diagram (Figure 2)



External shape diagram (Figure 1)



Normal closed type Solenoid; SP, S1, S3

Structural diagram (Figure 2)

RST-04-02-001by

1	Electromagnetic switch valve
2	body

2) Main component parts

This valve is made up of the body and the electromagnetic switch valve.

PREVIEW ONLY

You're viewing 18 of 488 pages

The full manual includes:

- All 488 pages, complete
 - Searchable PDF (find any keyword)
 - No watermarks
 - Instant download
 - Print-ready quality
-

GET FULL MANUAL NOW

Case CX290B Repair Manual



Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual