




REPAIR MANUAL



CX75SR
CX80

Contents

INTRODUCTION
DISTRIBUTION SYSTEMS
POWER PRODUCTION
TRAVELLING
BODY AND STRUCTURE
FRAME POSITIONING
WORKING ARM
TOOLS AND COUPLERS

A
B
D
E
F
H
J

PREVIEW - YOUFIXTHIS.COM

Torque (- A.90.A.10)


CX75SR

Order of tightening nuts and cap screws.

Tighten alternately so that torque setting remains even.

Cap screws which are fitted with Loctite (look for traces of a white residue on the thread after removal), must be cleaned with a thin oil or a suitable solvent, then dried.

Add two or three drops of Loctite to the cap screw thread, then fit the screw.



CRIL03H012E01

CRIL03H012E01 1

The numbers in the diagrams represent the order of tightening.

Tightening torque

Where there are no special instructions, tighten cap nuts screws to the torques given in the table below.

Standard torque setting table.

Designation of cap screws (dimensions)		M6	M8	M10	M12	M14	M16	M18	M20
Cap screw	Wrench in mm	10	13	17	19	22	24	27	30
	Torque setting in Nm	6,9	19,6	39,2	58,8	98,1	157,2	196	274
Socket head screw	Wrench in mm	5	6	8	10	12	14	14	17
	Torque setting in Nm	8,8	21,6	42,1	78,4	117,6	176,4	245	343

SPECIAL TORQUE SETTINGS

No.	Component	Screw diameter	Wrench in mm	Tightening torque
(1)*	Travel moto-reduction gear	M16	24	267 - 312 Nm
(2)*	Sprocket	M14	22	173 - 202 Nm
(3)*	Idler wheel	M10	17	63 - 73 Nm
(4)*	Upper roller	M16	24	267 - 312 Nm
(5)*	Lower roller	M20	30	521 - 608 Nm
(6)	Track pad	M14	22	220 - 270 Nm
(7)	Counterweight	M24	36	850 - 992 Nm
(8)	Turntable bearing (chassis and upperstructure)	M16	24	252 - 283 Nm
(9)*	Swing moto-reduction gear	M16	24	267 - 312 Nm
(10)*	Engine	M16	24	265 - 313 Nm
(11)*	Engine mounts	M10	17	64 - 74 Nm
(12)	Radiator	M12	19	36 - 44 Nm
(13)*	Hydraulic pump	M10	17	64 - 74 Nm
(14)*	Hydraulic pump support	M12	Hex	109 - 126 Nm
(15)*	Hydraulic reservoir	M12	19	69 - 78 Nm
(16)*	Fuel tank	M10	17	36 - 44 Nm

PRIMARY HYDRAULIC POWER SYSTEM - General specification

(A.10.A - D.40.A.10)

CX75SR

Capacities

Total hydraulic circuit	95 L
Hydraulic fluid reservoir	50 L
Coolant only	3.5 L

Main hydraulic pump

Variable flow twin pump, with axial pistons.

Maximum flow	2 x 71.4 L/min
Displacement	2 x 34 cm ³

Hydraulic control pump

Fixed flow pump

Maximum flow	22,5 L/min
Displacement	10.7 cm ³

Secondary hydraulic pump

Fixed flow pump

Maximum flow	25.4 L/min
Displacement	12.1 cm ³

Calibration pressure

Pilot circuit main relief valve (± 1 bar)	42 bar
Main relief valve (standard) (± 3 bar)	294 bar
Main relief valve (option) (± 3 bar)	226 bar
Secondary relief valve (boom, dipper and bucket) (± 5 bar)	319 bar
Secondary relief valve (swing) (± 4 bar)	226 bar
Secondary relief valve (travel) (± 5 bar)	294 bar
Secondary relief valve (dozer blade) (± 5 bar)	255 bar
Secondary relief valve (backhoe offset) (± 5 bar)	333 bar
Secondary relief valve (boom and dipper) (± 5 bar)	314 bar

Boom cylinder

Barrel diameter	110 mm
Rod diameter	70 mm
Stroke	911 mm

Dipper cylinder


Barrel diameter	95 mm
Rod diameter	60 mm
Stroke	797 mm

Bucket cylinder

Barrel diameter	85 mm
Rod diameter	110 mm
Stroke	665 mm

PRIMARY HYDRAULIC POWER SYSTEM - Dynamic description (A.10.A - C.30.A.10)

CX75SR, CX80



CRIL031020G01 1

Controls in neutral position

In neutral with the engine running, some of the flow from the low pressure pump (1) is fed to (PP) and is divided by a calibrated restrictor bridge. One fraction passes through the two travel spools, and the other passes through all the other spools before rejoining the general return circuit. When the spools are moved, these circuits will be locked, which will close the upper pilot (B26) and travel pilot (B27) pressure switches.

- (1) Low pressure pump
- (2) Calibrated restrictor bridge
- (B26) Upper pilot pressure switch
- (B27) Travel pilot pressure switch

Contents

DISTRIBUTION SYSTEMS - A

ELECTRICAL POWER SYSTEM - 30.A

TECHNICAL DATA

ELECTRICAL POWER SYSTEM - General specification (A.30.A - D.40.A.10) CX75SR, CX80	4
ELECTRICAL POWER SYSTEM - Special tools (A.30.A - D.20.A.40) CX75SR WE, CX80 WE	4
ELECTRICAL POWER SYSTEM - Special tools (A.30.A - D.20.A.40) CX75SR NA, CX80 NA	10

Battery

Battery - General specification (A.30.A.83 - D.40.A.10) CX75SR, CX80	16
---	----

FUNCTIONAL DATA

ELECTRICAL POWER SYSTEM - Static description (A.30.A - C.30.A.20) CX75SR, CX80	17
ELECTRICAL POWER SYSTEM - Overview (A.30.A - C.10.A.10) CX75SR	18
ELECTRICAL POWER SYSTEM - Overview (A.30.A - C.10.A.10) CX80	22

Fuse and relay box

Fuse and relay box - Overview (A.30.A.80 - C.10.A.10) CX75SR, CX80	26
Fuse and relay box - Detailed view (A.30.A.80 - C.10.A.50) CX75SR	28
Fuse and relay box - Detailed view (A.30.A.80 - C.10.A.50) CX80	29

Alternator

Alternator - Electronic schema (A.30.A.82 - C.20.A.50) CX75SR, CX80	30
--	----

Circuit breaker

Circuit breaker - Electronic schema (A.30.A.85 - C.20.A.50) CX75SR, CX80	31
---	----

SERVICE

Battery

Battery - Visual inspection (A.30.A.83 - F.40.A.10) CX75SR, CX80	32
Battery - Disconnect (A.30.A.83 - F.10.A.11) CX75SR, CX80	33
Battery - Remove (A.30.A.83 - F.10.A.10) CX75SR, CX80	34
Battery - Check (A.30.A.83 - F.40.A.11) CX75SR, CX80	35

Download full manual at youfixthis.com
27088 2 14/12/2004
A.30.A / 5

Battery - Charging (A.30.A.83 - F.60.A.30) CX75SR, CX80	36
Battery - Overhaul (A.30.A.83 - F.10.A.40) CX75SR, CX80	37
Battery - Install (A.30.A.83 - F.10.A.15) CX75SR, CX80	38
Battery - Connect (A.30.A.83 - F.10.A.16) CX75SR, CX80	39
Alternator	
Alternator - Tension adjust (A.30.A.82 - F.45.A.40) CX75SR, CX80	40

PRIMARY HYDRAULIC POWER SYSTEM - Troubleshooting (A.10.A - G.40.A.10)

CX75SR, CX80

NOTE: This table summarises the main symptoms relating to the hydraulic circuit in general.

Problem	Possible Cause	Correction
The hydraulic system is not operating or is operating incorrectly.	Oil level in reservoir too low	Refill the tank
	Insufficient pilot pressure	Refer to HYDRAULIC COMMAND SYSTEM - Troubleshooting (A.14.A - G.40.A.10)
	Pump faulty	Check the pressures Test the pump
	Main relief valve faulty	Refer to Relief valve - Troubleshooting (A.10.A.16 - G.40.A.10)
	Cylinder faulty	Check for leaks, traces of flaking or scratches on the cylinder rods.
	Pump charge pressure too high	Check the pressure
	Valves or control valve cracked	Replace cracked components
	Spool stroke incomplete	Refer to Stack valve - Troubleshooting (A.10.A.18 - G.40.A.10)
	Filter clogged in the circuit	Clean and replace filters
	Blockage in the system	Locate and remove the cause of the blockage

Stack valve - Troubleshooting (A.10.A.18 - G.40.A.10)

CX75SR, CX80

NOTE: This table summarises the main symptoms relating to the control valve block in general.

Problem	Possible Cause	Correction
The spool does not move	Abnormal rise in oil temperature (flow is encountering resistance in the lines)	Eliminate the cause of the flow resistance
	Contaminated hydraulic oil	Clean the circuit and replace the hydraulic oil
	Lines with over-tightened port unions	Loosen and retighten the unions to the required torque
	Control valve body deformed during installation	Loosen the fixing screws and inspect
	Excessive pressure	Check the inlet (pump side) and supply pressures
	Spool not straight	Replace the control valve assembly
	Return spring damaged	Replace the spring
	Spring or cap deformed	Loosen the cap fixing screws and retighten them to the required torque
	Uneven temperature distribution in the control valve	Warm up the oil by operating all the controls
	Control valve obstructed by oil pollution	Clean out the control valve and the hydraulic circuit
	Insufficient pilot pressure	Check the pilot circuit main relief valve
		Check the spool
Does not hold the load	Oil leak in the spool	Check the spool
	Leak in the main relief valve	Remove the valve and clean the seats of the valve and the control valve
	Leak in the load holding valve	Remove the valve and clean the seats, replacing them if necessary
	Leak in the cylinder	Check that the cylinder rings are not leaking

Hydraulic pump - Remove (A.10.A.20 - F.10.A.10)


CX75SR, CX80

Prior operation: PRIMARY HYDRAULIC POWER SYSTEM - Drain fluid (A.10.A - F.35.A.20)

Prior operation: Rear ballasting - Remove (F.20.B.61 - F.10.A.10)


Prior operation: Silencer - Remove (B.40.A.36 - F.10.A.10)

1. Remove the fixing screws (1) and washers (2) from the silencer bracket (3), then remove the silencer bracket (3).




CRIL03J005A01 1

2. Mark all the hoses connected to the main pump and the control pump.
3. Remove and plug the inlet pipe (1) on the main pump (2). Disconnect and plug the hoses (3) and (4) on the main pump (2). Disconnect and plug the pilot hose (5) from the main pump (2). Disconnect and plug the hose (6) from the control pump (7).



CRIL03J005A02 2

4. Install a suitable lifting device with sling to support the flange and pump assembly (1). Do not allow any slack in the sling so that the lifting device supports the flange and pump assembly (1) immediately it is removed.



CRIL03J006A01 3


5. Remove the screws (2) and washers (3) which secure the flange and pump assembly (1) to the engine.
6. Gently pull the flange and pump assembly (1) horizontally away from the flexible coupling secured to the engine flywheel. Set the flange and pump assembly (1) down on a clean workbench.

PRIMARY HYDRAULIC POWER SYSTEM - Depressurising (A.10.A - F.35.A.51)

CX75SR, CX80

IMPORTANT: This operation must be carried out before any work is done on the hydraulic circuit.

1. Park the machine on hard, flat ground.
2. Open the bucket until the cylinder rod is completely retracted.
3. Extend the dipper until the cylinder rod is completely retracted.
Lower the boom so that the end of the dipper is resting on the ground.
Lower the tool to the ground.
Lower the dozer blade to the ground
4. Reduce the engine speed to idle for **30 seconds**, then shut down the engine.
5. Turn the starter switch key to "ON" without starting the engine.
6. Lower the pilot control cancellation lever.
7. Operate each control more than 10 times in both directions to release all pressure in the circuits.
8. Press the button **(1)** located on the hydraulic reservoir breather to release all pressure in the reservoir.




CRIL031122A01 1

Stack valve Inlet section - Assemble (A.12.A.18.10 - F.10.A.20)

CX75SR, CX80

1. Install and tighten to a torque of **61 - 82 Nm** plug **(32)** fitted with a new seal.



2. Install and tighten to a torque of **59 - 69 Nm** the main relief valve **(79)** on the inlet plate **(78)**.


Battery - Connect (A.30.A.83 - F.10.A.16)

CX75SR, CX80

1. Clean the battery connections and cables.
2. Clean and grease the negative and positive terminals on the battery.
3. Reconnect the battery cable (**+12 volts**) to the POSITIVE terminal, indicated by **(+)** on the battery.
4. Reconnect the battery cable (**0 volts**) to the NEGATIVE terminal, indicated by **(-)** on the battery.
5. Install the terminal connection covers to the battery cable connections, taking care to match the correct polarity colours.
6. Fold back the protective mat.

PREVIEW - YOUFIXTHIS.COM

14. Attach a sling to the lower end of the track.
Start the engine.
Reverse the machine, moving the dipper out at the same time.
When the track is free of the sprocket, stop the machine from reversing further.
Continue moving the dipper out until the track is pulled away from the machine.
Stop the engine, move the track to be replaced away from the machine.



CRIL03G132A00

CRIL03G132A00


7. VALVE BANK COVER SUPPORT

Remove fixing screws (1) and bracket (2).

Remove fixing screw (3) and bracket (4).

Remove screws (5) and bracket (6).

Remove fixing screws (7), (8), (9) and brackets (10).



CRIL04E064B01 7





FRAME POSITIONING - F

TRAVELLING Travel - 10.F

CX75SR
CX80


23. Place the cylinder barrel (104) under a press. Insert the **Hydraulic motor - Special tools (F.10.F.28 - D.20.A.40)** guide between the press and the washer (110). Activate the press. Remove the snap ring (146).



CRIL03F183B01

CRIL03F183B01 15


24. Remove the washers (110) and spring (114).



CRIL03F185A00

CRIL03F185A00 16

25. Remove the swash plate (103), paying attention to the pivots (176).




CRIL03F186A00

CRIL03F186A00 17

26. Remove the pivots (176) and centring studs (177).

Command valve Cushion valve - External view (F.40.C.12.20 - C.10.A.40)

CX75SR, CX80



CRIL03F200E01

CRIL03F200E01 1

Swing pilot damper


- (A) Towards control valve
- (B) Towards control lever

Relief valve - Pressure setting (F.40.C.16 - F.45.A.70)

CX75SR, CX80

Prior operation: Relief valve - Pressure test (F.40.C.16 - F.40.A.30)

1. With a wrench, hold adjusting screw **(3)** on the main relief valve concerned in position and loosen lock nut **(2)**.



CRII031152A01 1


2. Operate and hold in position the swing control that is to be calibrated.
3. Turn adjusting screw **(3)** on the main relief valve concerned until the correct pressure is obtained.
4. With a wrench, hold adjusting screw **(3)** in position and tighten lock nut **(2)**.
5. Check the pressure again and repeat the operations if the required value is not obtained.

Control valve - Disassemble (H.20.B.14 - F.10.A.25)

CX75SR, CX80

1. Unscrew and remove screws (65) from element (80).
Remove the caps (11) and (13).
Remove the seals (12).
Remove the spool (5).
2. Disassemble the other spool in the same way.


NOTE: Mark each spool to ensure that it is returned to the correct housing during re-assembly.



3. Remove each spool as a complete sub-assembly from the body of the control valve, taking care not to damage them.

NOTE: To avoid abrasion of the spool surface during dismantling of the slide valve assembly, use a soft-jawed vice and clamp the spool as closely as possible to the head in order to avoid any deformation. If the threaded part of the screw is coated with thread lock fluid, heat the screw head with an industrial dryer until it can be removed easily (usually the temperature must be **200 - 250 °C**). If this operation causes distortion of the spring (impaired performance), replace the spring.

4. Remove the spool screws (B) on the spring side (A) of the spools.
Remove the springs (A).




5. Disassemble the parts of the load holding valve, refer to **Load holding valve - Disassemble (H.20.B.19 - F.10.A.25)**.
6. Unscrew and remove the screws (67).
Remove the load holding valve assembly (30), then remove the control valve seal (31).

Control valve - Assemble (H.20.D.14 - F.10.A.20)

CX75SR, CX80

Prior operation: Clean and check parts before assembly, refer to **Stack valve - Visual inspection (A.10.A.18 - F.40.A.10)**


1. Apply thread lock fluid to the threaded parts of the spool (83).
Clamp the spool in a soft-jawed vice.
Fit the spring (A) to the screw (B) and tighten the screw to the required torque on the spool.



CRIL03F206A01

CRIL03F206A01 1

2. Install valve (24) and spring (25).



CRIL03G185A03


CRIL03G185A03 2

3. Fit plug (81) fitted with seal (18) and tighten to the required torque.
4. Install the spool (83).
Install seals (12) on the section.
5. Install caps (11) and (13) on the section.
Engage screws (65) and tighten to the required torque.
6. Install relief valves (63), and tighten to the required torque.

Cylinder - Install (H.25.B.26 - F.10.A.15)


CX75SR MONOBLOC BOOM, CX80

1. Attach a sling to retain the cylinder rod in the cylinder barrel.



CRIL03G061A00


2. Using a suitable lifting device, lift the cylinder.
Align the cylinder foot with the boom mounting brackets.
Fit the shims (4) and pins (3).
Check the clearance between the cylinder foot and the mounting bracket, refer to **Arm - Service limits (H.25.B.50 - D.20.A.20)**.
If necessary remove the pin and add or remove shims as required to obtain the correct play, replace the pin.
Fit the plate (2) and screws (1).



CRIL03G072A01

CRIL03G072A01 2


3. Connect the lubrication hose (1) to the cylinder.



CRIL03G069A01

CRIL03G069A01 3

4. Start the vacuum pump.
Remove the plugs.
Connect the supply hoses (1).



CRIL03G068A01

CRIL03G068A01 4



PRINTED IN FRANCE

COPYRIGHT BY CNH France S.A

All rights reserved. No part of the text or illustrations of this publication may be reproduced.

CNH France S.A. company reserves the right to modify without prior notice the characteristics and the design of the machine without any obligation to carry out those modifications on machines already sold.

The description of the models shown in this manual has been made using the technical specifications known at the date on which this document was designed.

PREVIEW ONLY

You're viewing 24 of 862 pages

The full manual includes:

- All 862 pages, complete
 - Searchable PDF (find any keyword)
 - No watermarks
 - Instant download
 - Print-ready quality
-

GET FULL MANUAL NOW

Case CX75SR, CX80 Repair Manual



Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual