





RT96N036

When the key start switch is moved to the start position current flows from terminal "S" of the key start switch. This current flows through the neutral start switch and energizes the magnetic start switch. The magnetic start switch, now energized, provides B+ power to the starter solenoid on the starter motor causing the engine to turn over. At the same time the magnetic start switch provides B+ power to the fuel shut off solenoid pull coil to allow fuel into the injection pump.

Once the engine starts and the key start switch is moved to the run position the current flow marked by the dots will disappear. At the moment the engine starts the instrument cluster provides a 12 volt output to energize the fuel shut off and override relay.

Once the relay is energized keyed power flows from terminal 30 to terminal 87 of the fuel shut off and override relay. The current flows up to the diode at the shutdown override switch and to the hold coil on the fuel shut off solenoid.

When the instrument cluster detects a problem at start up it will not energize the fuel shut off and override relay. If this occurs the engine will not run unless the shutdown override switch is activated.



FLUID CAPACITIES AND TYPES

Engine Crankcase Capacity, without Filter Change	19 Litres (5 Gallons)
with Filter Change	21 Litres (5.5 Gallons)
Fluid Type	Case No. 1 Multi-Viscosity Engine Oil
Transmission/Hydraulic System Capacity	172 Litres (45.5 Gallons)
Fluid Type	Hy-Tran Plus® Fluid
Differential Housing Capacity - MFD	11 Litres (3 Gallons)
Planetary Housing Capacity - MFD (Each)	0.9 Litres (1 Quart)
Fluid Type	Case 135H EP Gear Lubricant, SAE 85W-140
Use one pint of Limited Slip additive in the differential	
Cooling System Capacity - with Cab	
8910 and 8920 (7210 and 7220 Pro)	27.6 Litres (29 Quarts)
8930 (7230 Pro)	29.4 Litres (31 Quarts)
8940 and 8950 (7240 and 7250 Pro)	31.3 Litres (33 Quarts)
Fluid Type	50 Percent Ethylene Glycol Coolant

Engine Speeds

Governed Engine Speed without Load	2370 to 2530 RPM
Rated Engine Speed	2200 RPM
Engine Idle Speed	925 to 1025 RPM

Fuses

Dome Lamp and Radio Clock	5 Amp
Fuel Shut-off	5 Amp
Shut Down Override	15 Amp
Instrument Cluster - Run Position	7.5 Amp
Instrument Cluster - Accessory Position, PTO	10 Amp
Radio	5 Amp
Electronic Hitch System	7.5 Amp
Cigar Lighter	10 Amp
Ether Starting Aid	15 Amp
Differential Lock	10 Amp
Tail Lamps	10 Amp
Warning Lamps	15 Amp
Cab Roof Work Lamps	15 Amp
Air Seat	20 Amp
Mechanical Front Drive (If Equipped) (Less 3 Point Hitch)	7.5 Amp
Mechanical Front Drive (If Equipped) (With 3 Point Hitch)	5 Amp
Creeper Drive (If Equipped)	7.5 Amp

Bulb and Lamp Replacement

Dome Lamp Bulb	K913579
Console Lamp Bulb	No. 194
Flasher Lamp Bulb	No. 1156
Head Lamps	No. H4
Front and Rear Flood Lamps	No. H3
Tail Lamp Bulbs	No. 168
Rocker Switch Bulb	No. 3141107R1
Three Point Hitch Indicator Bulb	No. 182
Instrument Cluster Illuminating Bulb	No. 161

FUEL SYSTEM SPECIFICATION DETAILS

Fuel Filters

Primary Fuel Filter	Full Flow, Turn on Type
Secondary Fuel Filter	Full Flow, Turn on Type
In-Line Fuel Filter.....	In-Line Filter
Water Trap	
Without Auxiliary Tank.....	Located in Bottom of Main Tank
With Auxiliary Tank.....	Located in Bottom of Auxiliary Tank
Filter Replacement (Primary and Secondary)	Every 500 Hours or when Loss of Horsepower Occurs
In-Line Fuel Filter.....	Every 500 Hours or when Loss of Horsepower Occurs
Fuel System Operating Pressure	140 to 172 kPa (20 to 25 PSI)

Fuel Injection Pump

Type : Inline

8910 and 8920 (7210 and 7220 Pro)	Robert Bosch, Type MW
8930 and 8940 (7230 and 7240 Pro)	Robert Bosch, Type MW
8950 (7250 Pro)	Robert Bosch, P3000
Rotation	Counterclockwise
Mounting.....	Left Hand Side of Engine
Drive	Gear Driven at 1/2 Engine Speed
Governor.....	Variable Speed, Part of Pump
Backlash :	
Camshaft to Injection Pump Gear	0.152 to 0.254 mm (0.005 to 0.009 inch)

Fuel Injectors

Type.....	Robert Bosch, 17 mm
Opening Pressure :	
New and Serviced	260 to 268 Bar (3770 to 3887 PSI)
Used.....	234 to 268 Bar (3394 to 3887 PSI)
Variation Between each Cylinder.....	1034 kPa (150 PSI)
Valve Leakage Rate	No Leakage Permissible Slight Moistening of Nozzle Tip Permissible

Special Torques

Fuel Filters.....	Hand Tighten 1/2 Turn Past Gasket Contact Loosen and Tighten 3/4 Turn Past Contact
Fuel Air Removal Bolt.....	8 Nm (6 lb ft)
Fuel Filter Inlet Nut.....	15 Nm (11 lb ft)
Fuel Filter Inlet Bolt.....	32 Nm (24 lb ft)
Fuel Line Fitting (High Pressure).....	24 Nm (18 lb ft)
Fuel Line Fitting (Low Pressure).....	15 Nm (11 lb ft)
Injection Pump Drive Gear Nut:	
Robert Bosch, Type MW.....	104 Nm (77 lb ft)
Robert Bosch, P3000	195 Nm (144 lb ft)
Injection Pump Retaining Nuts	43 Nm (32 lb ft)
Injector Leak Off Bolt	8 Nm (6 lb ft)
Injector Retaining Bolt	24 Nm (18 lb ft)

SPECIFICATIONS


Pump Minimum Capacity at Engine 2200 RPM	27 GPM (102 LPM)
Pump Pressure.....	2750 to 2800 PSI (18960 to 19303 kPa)
Standby Pressure Setting	340 to 390 PSI (2344 to 2689 kPa)
Piston to Shoe Maximum End Play	0.005 inch (0.127 mm)
Shoe Face Thickness (all shoe sizes within)	0.001 inch (0.0254 mm)
Cam Bearing Preload	0.007 to 0.009 inch (0.178 to 0.229 mm)
Driveshaft Bearing Preload.....	0.001 to 0.003 inch (0.025 to 0.076 mm)

SPECIAL TORQUES


Swashplate Bearing Cover Bolts	170 to 190 lb in (19 to 21 Nm)
Compensator Valve Mounting Bolts.....	60 to 70 lb in (7 to 8 Nm)
Compensator Valve Orifice	15 to 20 lb in (1.7 to 2.3 Nm)
Compensator Valve Inlet Port Plug.....	15 to 20 lb in (1.7 to 2.3 Nm)
Valve Plate Mounting Bolts - Initial	5 lb in (0.565 Nm)
Valve Plate Mounting Bolts - Final	23 to 26 ft lbs 31 to 35 Nm)

ELECTRONIC HITCH ELECTRICAL SCHEMATIC

ELECTRONIC HITCH CONTROL



NAO LIGHTING SCHEMATICS



PREVIEW ONLY

You're viewing 6 of 1231 pages

The full manual includes:

- All 1231 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Case IH 7200 Pro and 8900 Series Service Manual



Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual