

Contents

Air Inlet And Exhaust System

Basic Engine

Cooling System

Electrical And Starting System

Engine Arrangement

Frame And Body

Fuel System

Hydraulic System

Implements

Lubrication System

Machine Arrangement

Operator Station

Power Train

Schematic

Service Equipment And Supplies

Torque Specifications

Undercarriage

Work Tools Arrangement

Work Tools

BASIC ENGINE

Systems Operation

3064 and 3066 Engines for Caterpillar Built Machines - SENR5546

- [Basic Engine](#)

Testing and Adjusting

3064 and 3066 Engines for Caterpillar Built Machines - SENR5546

- [Finding Top Center Position for No. 1 Piston](#)
- [Fuel Injection Nozzle - Test](#)
- [Gear Group \(Front\) - Time](#)
- [Engine Crankcase Pressure \(Blowby\) - Test](#)
- [Compression - Test](#)
- [Engine Valve Lash - Inspect/Adjust](#)
- [Valve Guide - Inspect](#)
- [Excessive Bearing Wear - Inspect](#)
- [Piston Ring Groove - Inspect](#)
- [Connecting Rod - Inspect](#)
- [Connecting Rod Bearings - Inspect](#)
- [Main Bearings - Inspect](#)
- [Cylinder Block - Inspect](#)
- [Cylinder Head - Inspect](#)
- [Piston Height - Inspect](#)
- [Flywheel - Inspect](#)
- [Flywheel Housing - Inspect](#)

320C Excavator Hydraulic System - RENR3895

- [Engine Performance - Test - Engine Speed](#)

Specifications / Disassembly and Assembly

BELT TIGHTENER GP - Specifications

3064 and 3066 Engines for Caterpillar Built Machines - SENR5545

- [Belt Tension Chart](#)
- [Belt Tightener](#)

CAMSHAFT GP - Specifications

3064 and 3066 Engines for Caterpillar Built Machines - SENR5545

- [Camshaft](#)

CAMSHAFT GP - Disassembly and Assembly

3064 and 3066 Engines for Caterpillar Built Machines - SENR5553

COOLING SYSTEM

Systems Operation

3064 and 3066 Engines for Caterpillar Built Machines - SENR5546

- [Cooling System](#)

Testing and Adjusting

3064 and 3066 Engines for Caterpillar Built Machines - SENR5546

- [Cooling System - Check - Overheating](#)
- [Cooling System - Inspect](#)
- [Cooling System - Test](#)
- [Engine Oil Cooler - Inspect](#)
- [Water Temperature Regulator - Test](#)

Specifications / Disassembly and Assembly

COOLER GP - Disassembly and Assembly

3064 and 3066 Engines for Caterpillar Built Machines - SENR5553

- [Engine Oil Cooler - Remove](#)
- [Engine Oil Cooler - Disassemble](#)
- [Engine Oil Cooler - Assemble](#)
- [Engine Oil Cooler - Install](#)

FAN GP - Disassembly and Assembly

320C Excavator 3066 Engine Supplement - RENR9406

- [Fan - Remove and Install](#)

LINES GP-WATER - Specifications

3064 and 3066 Engines for Caterpillar Built Machines - SENR5545

- [Water Temperature Regulator](#)

LINES GP-WATER - Disassembly and Assembly

3064 and 3066 Engines for Caterpillar Built Machines - SENR5553

- [Water Temperature Regulator - Remove and Install](#)

320C Excavator 3066 Engine Supplement - RENR9406

- [Water Temperature Regulator - Remove and Install](#)

PUMP GP-WATER - Specifications

3064 and 3066 Engines for Caterpillar Built Machines - SENR5545

- [Water Pump](#)

PUMP GP-WATER - Disassembly and Assembly

3064 and 3066 Engines for Caterpillar Built Machines - SENR5553

- [Water Pump - Remove](#)
- [Water Pump - Disassemble](#)
- [Water Pump - Assemble](#)

ELECTRICAL AND STARTING SYSTEM

Systems Operation

3064 and 3066 Engines for Caterpillar Built Machines - SENR5546

- [Electrical System](#)

312C, 315C, 318C, 319C, 320C, 321C, 322C, 325C, 330C and M325C Excavators and 325C MHPU and 330C MHPU Mobile Hydraulic Power Units Engine and Pump Control - V2 - RENR3814

- [General Information \(Electrical System\)](#)
- [Power Circuit](#)
- [Start and Stop Circuit](#)
- [Starting Aid Circuit](#)
- [Charging Circuit](#)
- [Low Current Circuit](#)
- [General Information \(Electronic Control System\)](#)
- [Engine and Pump Regulation](#)
- [Pump Regulation](#)
- [Engine Speed Control](#)
- [Automatic Engine Control](#)
- [One Touch Low Idle](#)
- [Tool Control](#)
- [Straight Travel Control](#)
- [Engine Speed Protection](#)
- [Swing Lock System](#)
- [Backup System](#)
- [Engine and Hydraulic Pump Controller](#)
- [Switches](#)
- [Sensors](#)
- [Senders](#)
- [Solenoid Valves](#)
- [Related Components](#)

320C Excavator Hydraulic System - RENR3816

- [Electronic Control System](#)
- [Solenoid Valve \(Proportional Reducing\) - Power Shift System](#)

320C, 322C and 325C Excavators Tool Control System - RENR3823

- [Implement Electronic Control Module \(Tool\)](#)

Product: EXCAVATOR

Model: 320C EXCAVATOR GLA

Configuration: 320C, 320C L, 320C LN Excavators GLA00001-UP (MACHINE) POWERED BY 3066 Engine

Systems Operation

EquipmentManager Dealer Administrator Manual

Media Number -KENR6304-08

Publication Date -01/05/2010

Date Updated -18/05/2010

103319401

General Information

SMCS - 7600; 7606

Use of this Manual

EquipmentManager provides valuable information that allows remote monitoring of either a single machine or a fleet of machines. Customers can perform the following tasks if the customer can provide the location of the machine, Service Meter Unit (SMU), and information about the health of the machine:

- Manage the location and the basic usage of engines and machines.
- Schedule maintenance that is planned and schedule major repairs.
- Manage fault codes or diagnostic codes.
- Detect problems before problems cause a major component failure.
- Increase the availability and the productivity for the machines by avoiding unexpected downtime for repairs.
- Identify the need for training in order to improve the efficiency of the operator.

EquipmentManager is part of Dealer Web site and works with other applications such as PartStore and EquipmentManager. EquipmentManager enables customers to remotely manage fleets. The customer is alerted to only those machines that need immediate attention.

The "EquipmentManager Dealer Administrator Manual" includes the following information:

- Setting up Product Link Modules (PLM)
- Registering PLM
- Setting up and maintaining the accounts of the customer
- Customizing EquipmentManager for optimum use
- Managing EquipmentManager functions

Product: EXCAVATOR

Model: 320C EXCAVATOR GLA

Configuration: 320C, 320C L, 320C LN Excavators GLA00001-UP (MACHINE) POWERED BY 3066 Engine

Testing and Adjusting

3064 and 3066 Engines for Caterpillar Built Machines

Media Number -SEN5546-15

Publication Date -01/07/2013

Date Updated -30/07/2013

102686950

Alternator - Test

SMCS - 1405-081

Table 1

Required Tools		
Part Number	Part Name	Qty
237-5130	Digital Multimeter	1
225-8266	Ammeter Tool Gp	1

1. Put the positive lead "+" of the multimeter on the "Bat" terminal of the alternator. Put the negative "-" lead on the ground terminal or on the frame of the alternator. Put the ammeter around the positive output wire of the alternator.
2. Turn off all electrical accessories. Turn off the fuel to the engine. Crank the engine for 30 seconds. Wait for two minutes in order to cool the starting motor. If the electrical system appears to operate correctly, crank the engine again for 30 seconds.

Note: Cranking the engine for 30 seconds partially discharges the batteries in order to do a charging test. If the battery has a low charge, do not perform this step. Jump start the engine or charge the battery before the engine is started.

3. Start the engine and run the engine at full throttle.
4. Check the output current of the alternator. The initial charging current should be equal to the minimum full load current or greater than the minimum full load current. Refer to Specifications, "Alternator and Regulator" for the correct minimum full load current.

Table 2

Fault Conditions And Possible Causes			
Current At Start-up	The Voltage Is Below Specifications After 10 Minutes.	The Voltage Is Within Specifications After 10 Minutes.	The Voltage Is Above Specifications After 10 Minutes.

ENGINE ARRANGEMENT

Systems Operation

3064 and 3066 Engines for Caterpillar Built Machines - SENR5546

- [General Information](#)

Testing and Adjusting

3064 and 3066 Engines for Caterpillar Built Machines - SENR5546

- [Troubleshooting](#)
- [Engine Speed - Check](#)

320C Excavator Hydraulic System - RENR3895

- [Engine Performance - Test - Engine Speed](#)

Specifications / Disassembly and Assembly

ENGINE AR - Specifications

3064 and 3066 Engines for Caterpillar Built Machines - SENR5545

- [Engine Design](#)
- [Engine Design](#)

ENGINE AR - Disassembly and Assembly

320C Excavator 3066 Engine Supplement - RENR9406

- [Hydraulic System Pressure - Release](#)
- [Engine - Remove](#)
- [Engine - Install](#)

FRAME AND BODY

Systems Operation

320C Excavator Hydraulic System - RENR3816

- [Swing Hydraulic System](#)

Testing and Adjusting

320C Excavator Hydraulic System - RENR3895

- [Swing Bearing Movement - Measure](#)

Specifications / Disassembly and Assembly

COUNTERWEIGHT GP - Disassembly and Assembly

320C Excavator Machine Systems - RENR3826

- [Counterweight - Remove and Install](#)

DRIVE GP-SWING - Disassembly and Assembly

320C Excavator Machine Systems - RENR3826

- [Swing Drive - Remove](#)
- [Swing Drive - Disassemble](#)
- [Swing Drive - Assemble](#)
- [Swing Drive - Install](#)

FRAME GP - Specifications

320C Excavator Machine System Specifications - RENR3815

- [Upper Frame](#)
- [Upper Frame](#)

FRAME GP - Disassembly and Assembly

320C Excavator Machine Systems - RENR3826

- [Undercarriage Frame - Remove](#)
- [Undercarriage Frame - Install](#)

GEAR & BEARING GP - Specifications

320C Excavator Machine System Specifications - RENR3815

- [Swing Gear and Bearing](#)

GEAR & BEARING GP - Disassembly and Assembly

320C Excavator Machine Systems - RENR3826

- [Swing Gear and Bearing - Remove](#)
- [Swing Gear and Bearing - Install](#)

GUARD GP - Disassembly and Assembly

320C Excavator Machine Systems - RENR3826

- [Travel Motor Guard - Remove and Install](#)

HOOD GP - Disassembly and Assembly

320C Excavator 3066 Engine Supplement - RENR9406

- [Hood - Remove and Install](#)

FUEL SYSTEM

Systems Operation

3064 and 3066 Engines for Caterpillar Built Machines - SENR5546

- [Fuel System](#)

312C, 315C, 318C, 319C, 320C, 321C, 322C, 325C, 330C and M325C Excavators and 325C MHPU and 330C MHPU Mobile Hydraulic Power Units Engine and Pump Control - V2 - RENR3814

- [Governor Actuator Control](#)

ZEXEL FUEL SYSTEM - SENR6572

- [Systems Operations](#)

Testing and Adjusting

3064 and 3066 Engines for Caterpillar Built Machines - SENR5546

- [Fuel System - Inspect](#)
- [Air in Fuel - Test](#)
- [Fuel Injection Nozzle - Test](#)
- [Fuel Injection Timing - Check](#)
- [Fuel Quality - Test](#)
- [Fuel System - Prime](#)
- [Fuel System Pressure - Test](#)
- [Governor - Adjust - In-line Fuel Pump](#)
- [Low Idle RPM - Adjust](#)
- [High Idle RPM - Adjust](#)

312C, 315C, 318C, 319C, 320C, 321C, 322C, 325C, 330C and M325C Excavators and 325C MHPU and 330C MHPU Mobile Hydraulic Power Units Engine and Pump Control - V2 - RENR3814

- [Check of Governor Actuator - Troubleshoot - CID 91 - 315C, 318C, 319C, 320C, 321C, And 322C](#)
- [Check of Feedback Signal From Governor Actuator - Troubleshoot - CID 587](#)
- [Governor Actuator Sweep - Test](#)
- [Governor Actuator - Replace](#)
- [Governor Actuator - Calibrate](#)

320C, 322C and 325C Excavators Tool Control System - RENR3823

- [Governor Actuator - Calibrate](#)

ZEXEL FUEL SYSTEM - SENR6572

- [Testing and Adjusting](#)

Specifications / Disassembly and Assembly

FUEL SYSTEM - Disassembly and Assembly

ZEXEL FUEL SYSTEM - SENR6572

- [Governor](#)

HYDRAULIC SYSTEM

Systems Operation

320C Excavator Hydraulic System - RENR3816

- [General Information](#)
- [Main Hydraulic System](#)
- [Pilot Hydraulic System](#)
- [Gear Pump \(Pilot\)](#)
- [Hydraulic Filter \(Pilot\)](#)
- [Relief Valve \(Pilot\)](#)
- [Accumulator \(Pilot\)](#)
- [Solenoid Valve \(Hydraulic Lockout\)](#)
- [Pilot Valve \(Joystick\)](#)
- [Solenoid Valve \(Proportional Reducing\) - Power Shift System](#)
- [Main Hydraulic Pump](#)
- [Pump Control \(Main Hydraulic\) - Main Pump Regulator](#)
- [Main Control Valve](#)
- [Negative Flow Control System](#)
- [Relief Valve \(Main\)](#)
- [Relief Valve \(Line\)](#)
- [Check Valve \(Load\)](#)
- [Boom Hydraulic System](#)
- [SmartBoom Hydraulic System](#)
- [Boom Drift Reduction Valve](#)
- [Control Valve \(Boom Lowering\)](#)
- [Stick Hydraulic System](#)
- [Stick Drift Reduction Valve](#)
- [Bucket Hydraulic System](#)
- [Cylinders \(Boom, Stick and Bucket\)](#)
- [Swing Hydraulic System](#)
- [Swing Motor](#)
- [Pilot Valve \(Swing Parking Brake\)](#)
- [Relief Valve \(Swing\)](#)

IMPLEMENTS

Systems Operation

320C Excavator Hydraulic System - RENR3816

- [SmartBoom Hydraulic System](#)

Specifications / Disassembly and Assembly

BOOM GP - Specifications

320C Excavator Machine System Specifications - RENR3815

- [Boom](#)
- [Boom](#)
- [Boom - Fore Boom](#)
- [Boom - Stub Boom](#)
- [Boom](#)

BOOM GP - Disassembly and Assembly

320C Excavator Machine Systems - RENR3826

- [Boom - Remove](#)
- [Boom Bearings and Seals - Remove and Install](#)
- [Boom - Install](#)

LINKAGE GP - Specifications

320C Excavator Machine System Specifications - RENR3815

- [Bucket Linkage - C-Family](#)
- [Bucket Linkage - B-Family](#)
- [Bucket Linkage](#)

LINKAGE GP - Disassembly and Assembly

320C Excavator Machine Systems - RENR3826

- [Bucket Linkage - Remove](#)
- [Bucket Linkage Bearings and Seals - Remove](#)
- [Bucket Linkage Bearings and Seals - Install](#)
- [Bucket Linkage - Install](#)

STICK GP - Specifications

320C Excavator Machine System Specifications - RENR3815

- [Stick](#)
- [Stick](#)
- [Stick](#)
- [Stick](#)
- [Stick](#)
- [Stick](#)

STICK GP - Disassembly and Assembly

LUBRICATION SYSTEM

Systems Operation

3064 and 3066 Engines for Caterpillar Built Machines - SENR5546

- [Lubrication System](#)

Testing and Adjusting

3064 and 3066 Engines for Caterpillar Built Machines - SENR5546

- [Engine Crankcase Pressure \(Blowby\) - Test](#)
- [Engine Oil Pressure - Test](#)
- [Engine Oil Pump - Inspect](#)
- [Excessive Engine Oil Consumption - Inspect](#)
- [Increased Engine Oil Temperature - Inspect](#)

Specifications / Disassembly and Assembly

BREATHING GP - Disassembly and Assembly

3064 and 3066 Engines for Caterpillar Built Machines - SENR5553

- [Crankcase Breather - Remove and Install](#)

FILTER GP-ENGINE OIL - Specifications

3064 and 3066 Engines for Caterpillar Built Machines - SENR5545

- [Engine Oil Bypass Valve](#)

FILTER GP-ENGINE OIL - Disassembly and Assembly

3064 and 3066 Engines for Caterpillar Built Machines - SENR5553

- [Engine Oil Filter Base - Remove](#)
- [Engine Oil Filter Base - Install](#)

320C Excavator 3066 Engine Supplement - RENR9406

- [Engine Oil Filter and Oil Filter Base - Remove](#)
- [Engine Oil Filter Base - Disassemble](#)
- [Engine Oil Filter Base - Assemble](#)
- [Engine Oil Filter and Oil Filter Base - Install](#)

LINES GP-ENGINE OIL - Specifications

3064 and 3066 Engines for Caterpillar Built Machines - SENR5545

- [Engine Oil Relief Valve](#)

LINES GP-ENGINE OIL - Disassembly and Assembly

3064 and 3066 Engines for Caterpillar Built Machines - SENR5553

- [Engine Oil Relief Valve - Remove and Install](#)

PUMP GP-ENGINE OIL - Specifications

3064 and 3066 Engines for Caterpillar Built Machines - SENR5545

- [Engine Oil Relief Valve](#)
- [Engine Oil Pump](#)

MACHINE ARRANGEMENT

Systems Operation

All Products Air Conditioning and Heating R134a for All Caterpillar Machines - SENR5664

- [Service Intervals](#)

Testing and Adjusting

All Products Air Conditioning and Heating R134a for All Caterpillar Machines - SENR5664

- [Heating and Air Conditioning Service Publications](#)

PREVIEW - YOUFIXTHIS.COM

OPERATOR STATION

Systems Operation

312C, 315C, 318C, 319C, 320C, 321C, 322C, 325C, 330C and M325C Excavators and 325C MHPU and 330C MHPU Mobile Hydraulic Power Units Engine and Pump Control - V2 - RENR3814

- [Monitoring System](#)

- [Operator Monitor](#)

312C, 315C, 318C, 319C, 320C, 322C, 325C and 330C Excavators Air Conditioning and Heating - RENR3763

- [General Information](#)
- [Air Conditioning System](#)
- [Refrigerant Compressor](#)
- [Refrigerant Condenser](#)
- [Refrigerant Receiver-Dryer](#)
- [Pressure Switch \(Refrigerant Pressure Cutoff\)](#)
- [Refrigerant Expansion Valve](#)
- [Blower Motor](#)
- [Motor \(Air Conditioner Control\)](#)
- [Air Conditioning and Heating System Sensor Operation](#)
- [Control Panel \(Air Conditioner and Heater\)](#)
- [Control Module - Heating and Air Conditioning](#)
- [Speed Control - Blower Linear Control \(BLC\)](#)
- [Air Conditioning System Schematic](#)
- [Heater System \(Cab\)](#)
- [Heater Core \(Cab\)](#)

320C Excavator Hydraulic System - RENR3816

- [Pilot Valve \(Travel\)](#)
- [Control Valve \(Straight Travel\)](#)
- [Pilot Valve \(Straight Travel\)](#)

320C, 322C and 325C Excavators Tool Control System - RENR3823

- [Monitor Overview](#)

All Products Air Conditioning and Heating R134a for All Caterpillar Machines - SENR5664

- [General Information](#)
- [Identifying the Refrigerant](#)
- [Identifying the Air Conditioning System](#)

POWER TRAIN

Systems Operation

320C Excavator Hydraulic System - RENR3816

- [Final Drive](#)

Testing and Adjusting

320C Excavator Hydraulic System - RENR3895

- [Travel on Level Ground - Test - Optional Test](#)
- [Travel on Level Ground - Test](#)

Specifications / Disassembly and Assembly

POWER TRAIN - Disassembly and Assembly

320C Excavator Machine Systems - RENR3826

- [Duo-Cone Conventional Seals - Install](#)

DRIVE GP-FINAL - Disassembly and Assembly

320C Excavator Machine Systems - RENR3826

- [Duo-Cone Conventional Seals - Install](#)
- [Final Drive - Remove](#)
- [Final Drive - Disassemble](#)
- [Final Drive - Assemble](#)
- [Final Drive - Install](#)

MOTOR GP - Specifications

320C Excavator Machine System Specifications - RENR3815

- [Fasteners - Travel Motor](#)

SPROCKET GP - Disassembly and Assembly

320C Excavator Machine Systems - RENR3826

- [Sprocket - Remove and Install](#)

TRACK GP - Specifications

320C Excavator Machine System Specifications - RENR3815

- [Track Shoe Bolts](#)

TRACK GP - Disassembly and Assembly

320C Excavator Machine Systems - RENR3826

- [Track Roller - Remove](#)
- [Track Roller - Install](#)
- [Track - Separate](#)
- [Track - Connect](#)

SCHEMATIC

- [320C Excavator Hydraulic System - Attachment - Fine Filtration \(Interactive\) 188-6617-00](#)
 - [320C Excavator Hydraulic System - Attachment - Medium Pressure \(Interactive\) 224-3215-02](#)
 - [320C Excavator and 320C Material Handler Electrical System \(Interactive\) 239-0010-01](#)
 - [320C and 322C Excavator Hydraulic System - Attachment - Stick Lowering Control Valve \(Interactive\) 177-2751-01](#)
 - [320C Excavator Hydraulic System \(Interactive\)](#)
 - [Air Conditioning Electrical System \(320C and 322C\)](#)
 - [320C Excavator Hydraulic System - Attachment - VA Boom with Combined Function 254-5446-01](#)
 - [320C II Excavator Attachment \(Medium Pressure Circuit\) Electrical System](#)
 - [320C Excavator Hydraulic Schematic \(Attachment\) - Boom Float](#)
 - [320C Excavator Hydraulic System \(Attachment\) VA Boom](#)
 - [320C Excavator Electrical Schematic \(Attachment\) Combined Function](#)
 - [320C Excavator Electrical Schematic \(Attachment\) Medium Pressure](#)
 - [320C and 325C Excavators Hydraulic System - attachment System 17:Combined Function/Auxiliary Pump/Joystick with Slide Control](#)
-

- [Fluid Power and Electrical Graphic Symbols](#)

SERVICE EQUIPMENT AND SUPPLIES

Systems Operation

All Products Air Conditioning and Heating R134a for All Caterpillar Machines - SENR5664

- [Cab Pressurization and Filtration System](#)

Testing and Adjusting

312C, 315C, 318C, 319C, 320C, 322C, 325C and 330C Excavators Air Conditioning and Heating - RENR3763

- [Required Tools](#)
- [Manifold Gauge Set \(Refrigerant\) - Install](#)
- [Manifold Gauge Set \(Refrigerant\) - Remove](#)

All Products Air Conditioning and Heating R134a for All Caterpillar Machines - SENR5664

- [Manifold Gauge Set \(Refrigerant\) - Install](#)
- [Manifold Gauge Set \(Refrigerant\) - Remove](#)
- [Heating and Air Conditioning Service Publications](#)

Troubleshooting

All Products Air Conditioning and Heating R134a for All Caterpillar Machines - SENR5664

- [Required Tools](#)

Specifications / Disassembly and Assembly

FILTERS - Specifications

3064 and 3066 Engines for Caterpillar Built Machines - SENR5545

- [Fuel Filter and Water Separator](#)
- [Fuel Filter and Water Separator](#)

320C Excavator Machine System Specifications - RENR3815

- [Hydraulic Tank and Filter](#)
- [Oil Filter \(Return\)](#)
- [Oil Filter \(Return\)](#)

FILTERS - Disassembly and Assembly

320C Excavator 3066 Engine Supplement - RENR9406

- [Fuel Filter \(Primary\) and Fuel Filter Base - Remove and Install](#)
- [Water Separator - Remove and Install](#)
- [Air Cleaner - Remove and Install](#)

LUBRICANTS & FLUIDS - Disassembly and Assembly

320C Excavator 3066 Engine Supplement - RENR9406

- [Engine Oil Filter and Oil Filter Base - Remove](#)
- [Engine Oil Filter and Oil Filter Base - Install](#)

SHIPPING GP - Disassembly and Assembly

TORQUE SPECIFICATIONS

- [General Information 01/01/2013](#)
 - [Introduction to Torque 01/01/2013](#)
 - [Torque-Turn 01/01/2013](#)
 - [Torque Sequence 01/01/2013](#)
- [Metric \(ISO\) Fasteners 01/01/2013](#)
 - [Metric \(ISO\) Nuts and Bolts 01/01/2013](#)
 - [Metric \(ISO\) Taperlock Studs 01/01/2013](#)
 - [Metric \(ISO\) Machine Screws 01/01/2013](#)
 - [Hex Button Head Screw and Set Screws 01/01/2013](#)
- [English \(SAE\) Fasteners 01/01/2013](#)
 - [English \(SAE\) Nuts and Bolts 01/01/2013](#)
 - [English \(SAE\) Taperlock Studs 01/01/2013](#)
 - [English \(SAE\) Machine Screws 01/01/2013](#)
 - [Hex Button Head Screw and Set Screws 01/01/2013](#)
- [Ground Engaging Tool \(G.E.T.\) Fasteners 01/01/2013](#)
- [Installation of Fittings 01/01/2013](#)
 - [Installation of Hydraulic Four Bolt Flange 01/01/2013](#)
 - [Installation of Adjustable STOR Fittings 01/01/2013](#)
- [Straight Thread O-Ring Fittings 01/01/2013](#)
- [Plugs 01/01/2013](#)
 - [Straight Thread O-Ring Plugs 01/01/2013](#)
 - [Drain Plugs with Straight Threads 01/01/2013](#)
- [O-Ring Face Seal Fittings 01/01/2013](#)
- [Bulkhead Nuts 01/01/2013](#)
- [Flare Fittings 01/01/2013](#)
 - [37 Degree Flare Fittings 01/01/2013](#)
 - [45 Degree Flare and Inverted Flare Fittings 01/01/2013](#)
- [Air Conditioning Fittings 01/01/2013](#)
- [Air Brake Fittings 01/01/2013](#)
- [Tapered Pipe Thread Fittings 01/01/2013](#)
- [Miscellaneous Fittings 01/01/2013](#)
 - [Hi Duty Tube Fittings \(Shear Sleeve\) 01/01/2013](#)
 - [SAE Flareless Fittings 01/01/2013](#)
 - [Installing a New Flareless Fitting 01/01/2013](#)
 - [Installing a Used Flareless Fitting 01/01/2013](#)
 - [Flex Fittings 01/01/2013](#)
- [Hose Clamps 01/01/2013](#)
 - [Worm Drive Band Type Clamps 01/01/2013](#)
 - [Constant Torque Hose Clamps 01/01/2013](#)

UNDERCARRIAGE

Systems Operation

All Products Air Conditioning and Heating R134a for All Caterpillar Machines - SENR5664

- [Cab Pressurization and Filtration System](#)

Testing and Adjusting

312C, 315C, 318C, 319C, 320C, 322C, 325C and 330C Excavators Air Conditioning and Heating - RENR3763

- [Required Tools](#)
- [Manifold Gauge Set \(Refrigerant\) - Install](#)
- [Manifold Gauge Set \(Refrigerant\) - Remove](#)

All Products Air Conditioning and Heating R134a for All Caterpillar Machines - SENR5664

- [Manifold Gauge Set \(Refrigerant\) - Install](#)
- [Manifold Gauge Set \(Refrigerant\) - Remove](#)
- [Heating and Air Conditioning Service Publications](#)

Troubleshooting

All Products Air Conditioning and Heating R134a for All Caterpillar Machines - SENR5664

- [Required Tools](#)

Specifications / Disassembly and Assembly

FILTERS - Specifications

3064 and 3066 Engines for Caterpillar Built Machines - SENR5545

- [Fuel Filter and Water Separator](#)
- [Fuel Filter and Water Separator](#)

320C Excavator Machine System Specifications - RENR3815

- [Hydraulic Tank and Filter](#)
- [Oil Filter \(Return\)](#)
- [Oil Filter \(Return\)](#)

FILTERS - Disassembly and Assembly

320C Excavator 3066 Engine Supplement - RENR9406

- [Fuel Filter \(Primary\) and Fuel Filter Base - Remove and Install](#)
- [Water Separator - Remove and Install](#)
- [Air Cleaner - Remove and Install](#)

LUBRICANTS & FLUIDS - Disassembly and Assembly

320C Excavator 3066 Engine Supplement - RENR9406

- [Engine Oil Filter and Oil Filter Base - Remove](#)
- [Engine Oil Filter and Oil Filter Base - Install](#)

SHIPPING GP - Disassembly and Assembly

WORK TOOL ARRANGEMENT

Systems Operation

320C Excavator Hydraulic System - RENR3816

- [Medium Pressure Hydraulic System](#)

PREVIEW - YOUFIXTHIS.COM

WORK TOOLS

Specifications / Disassembly and Assembly

BUCKET GP - Specifications

320C Excavator Machine System Specifications - RENR3815

- [Bucket Adjuster](#)
- [Bucket Adjuster](#)

BUCKET GP - Disassembly and Assembly

320C Excavator Machine Systems - RENR3826

- [Bucket - Remove](#)
- [Bucket - Install](#)

COUPLER GP-QUICK - Specifications

320C Excavator Machine System Specifications - RENR3815

- [Quick Coupler \(Hydraulic\)](#)
- [Quick Coupler \(Mechanical\)](#)
- [Quick Coupler \(Spindle\)](#)

Product: EXCAVATOR

Model: 320C EXCAVATOR GLA

Configuration: 320C, 320C L, 320C LN Excavators GLA00001-UP (MACHINE) POWERED BY 3066 Engine

Systems Operation

3064 and 3066 Engines for Caterpillar Built Machines

Media Number -SEN5546-15

Publication Date -01/07/2013

Date Updated -30/07/2013

i01563814

Air Inlet and Exhaust System

SMCS - 1050




Illustration 1

g00549374

Air Inlet and Exhaust System Schematic

- (1) Exhaust manifold
- (2) Inlet manifold
- (3) Engine cylinder

Product: EXCAVATOR

Model: 320C EXCAVATOR GLA

Configuration: 320C, 320C L, 320C LN Excavators GLA00001-UP (MACHINE) POWERED BY 3066 Engine

Testing and Adjusting

Product Link 121S/300

Media Number -REN7911-10

Publication Date -01/06/2013

Date Updated -27/06/2013

i04907011

Electronic Control Module (ECM) - Flash Program

SMCS - 7610-591

Perform the following procedure in order to flash program Product Link. Product Link is flashed in order to upgrade the software. Flash programming of Product Link must also be done if Product Link has been replaced. The Caterpillar Electronic Technician (Cat ET) contains the program WinFlash[®]. WinFlash is used in order to load software into Product Link.

Refer to Systems Operation, Troubleshooting, Testing and Adjusting, "Configuration" in order to configure the following products:

- PL121SR
- PL300

Note: Two communications adapters are available in order to flash program the electronic control modules. The **7X-1700** Communications Adapter can be used, or the **171-4400** Communication Adapter II can be used.

PL321SR - The **171-4400** Caterpillar Communications Adapter II hardware is connected between the service connector for the machine and the PC serial port or the PC parallel port. The Cat ET "Communications Interface Device" is configured for "Caterpillar Communications Adapter II (RP1210)".

PL121SR - The **245-7310** Serial Service cable is to be used only for the configuration of the PL121SR radio system.

Note: Only the **171-4400** Caterpillar Communications Adapter II is to be used for the PL321SR (PL121SR plus PL300) system configurations.

Note: DO NOT USE the **171-4400** Caterpillar Communications Adapter II for the PL121SR system.

Note: DO NOT USE the **245-7310** Serial Service cable for the PL321SR system.

PL121SR System

Flash Program the PL121SR Radio Module

The following steps explain the flash procedure for the PL121SR. **RADIO ONLY** system

1. Procedure to connect a laptop computer to the machine

- a. Connect the **245-7310** Serial Service cable between the laptop computer and the serial service connector on the wiring harness of the machine.

Previous Screen

Product: EXCAVATOR

Model: 320C EXCAVATOR GLA

Configuration: 320C, 320C L, 320C LN Excavators GLA00001-UP (MACHINE) POWERED BY 3066 Engine

Troubleshooting

320C, 322C and 325C Excavators Tool Control System

Media Number -REN3823-15

Publication Date -01/02/2013

Date Updated -25/02/2013

102581769

MID 06A - CID 1596 - FMI 05

SMCS - 5479-038-QY

Conditions Which Generate This Code:




Illustration 1

g00797188

Schematic of the Retract Solenoid Valve for Auxiliary Stem 1

This diagnostic code is associated with the retract solenoid valve for auxiliary stem 1. This diagnostic code is recorded when the implement ECM reads the current of the solenoid as being below normal. There is an open circuit.

The possible causes of this diagnostic code are listed:

- The signal circuit of the solenoid is open.




Illustration 1

g00698602

2. Lower the temperature of sleeve bearings (5) that will be installed in the closed end of power link (2) to $-40\text{ }^{\circ}\text{C}$ ($-40\text{ }^{\circ}\text{F}$).
3. Use Tooling (A) to install sleeve bearings (5) in the closed end of power link (2). Install the sleeve bearings until Dimension (X) is achieved.
4. Use the following table to determine the correct Dimension (X).

Table 2

Table for Dimension (X)	
Bucket Family	Dimension (X)
B-Family	$7.5 \pm 0.8\text{ mm}$ ($0.30 \pm 0.03\text{ inch}$)
C-Family	$5.0 \pm 0.3\text{ mm}$ ($0.20 \pm 0.01\text{ inch}$)

PREVIEW ONLY

You're viewing 25 of 5954 pages

The full manual includes:

- All 5954 pages, complete
 - Searchable PDF (find any keyword)
 - No watermarks
 - Instant download
 - Print-ready quality
-

GET FULL MANUAL NOW

Caterpillar 320C Repair Manual



Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual