

## Section 10

# General

### CONTENTS OF THIS SECTION

#### GROUP 00 — SPECIFICATIONS AND SPECIAL TOOLS

|                                                         | Page  |
|---------------------------------------------------------|-------|
| Specifications .....                                    | 00-3  |
| Serial numbers .....                                    | 00-3  |
| Model numbers .....                                     | 00-3  |
| Engine .....                                            | 00-3  |
| Engine clutch .....                                     | 00-4  |
| Cooling system .....                                    | 00-4  |
| Fuel system .....                                       | 00-5  |
| Electrical system .....                                 | 00-5  |
| Synchronized transmission .....                         | 00-6  |
| Collar shift transmission .....                         | 00-6  |
| Hi-Lo shift unit .....                                  | 00-6  |
| Creeper transmission .....                              | 00-6  |
| Differential and final drives .....                     | 00-7  |
| Differential lock .....                                 | 00-7  |
| PTO .....                                               | 00-7  |
| Mechanical front wheel drive .....                      | 00-7  |
| Hydrostatic steering .....                              | 00-8  |
| Power steering .....                                    | 00-8  |
| Manual steering .....                                   | 00-8  |
| Foot brakes .....                                       | 00-8  |
| Handbrake .....                                         | 00-8  |
| Hydraulic system .....                                  | 00-8  |
| Capacities .....                                        | 00-8  |
| Travel speeds .....                                     | 00-9  |
| Front and rear wheels .....                             | 00-9  |
| Dimensions and weights .....                            | 00-9  |
| Predelivery, delivery and after-sales inspections ..... | 00-10 |
| Lubrication and service .....                           | 00-11 |
| Tune-up .....                                           | 00-13 |
| Tractor separation .....                                | 00-14 |
| Standard torques .....                                  | 00-16 |
| Special tools .....                                     | 00-18 |

#### GROUP 05 — PREDELIVERY, DELIVERY AND AFTER-SALES INSPECTIONS

|                              | Page  |
|------------------------------|-------|
| Tractor storage .....        | 05-1  |
| Predelivery inspection ..... | 05-2  |
| Delivery inspection .....    | 05-11 |
| After-sales inspection ..... | 05-11 |

#### GROUP 10 — LUBRICATION AND SERVICE

|                               |      |
|-------------------------------|------|
| Lubrication and service ..... | 10-1 |
|-------------------------------|------|

#### GROUP 15 — TUNE-UP

|                                    |      |
|------------------------------------|------|
| Preliminary engine testing .....   | 15-1 |
| Dynamometer test .....             | 15-1 |
| Testing compression pressure ..... | 15-2 |
| Tune-up .....                      | 15-2 |
| Checking tractor operation .....   | 15-7 |
| Standard torques .....             | 15-8 |

#### GROUP 20 — TRACTOR SEPARATION (Tractors without Increased Lifting Capacity)

|                                                       |       |
|-------------------------------------------------------|-------|
| Separating between engine and tractor front end ..... | 20-1  |
| Removal and installation of engine .....              | 20-7  |
| Removal and installation of clutch housing .....      | 20-11 |
| Removal and installation of final drives .....        | 20-15 |
| Removal and installation of rockshaft .....           | 20-21 |
| Removal and installation of operator's cab .....      | 20-24 |

## Section 20

# Engine

### CONTENTS OF THIS SECTION IN GROUPS

*NOTE: The engines for these tractors have model designation 4239 DL 03/04 or 06 and are dealt with in Technical Manual — Engines 3179, 4239 and 6359.*

#### GROUP 00 — SPECIFICATIONS

Specifications ..... <sup>Page</sup> 00-3

#### GROUP 05 — RADIATOR

|                               | Page |
|-------------------------------|------|
| General information .....     | 05-1 |
| Diagnosing malfunctions ..... | 05-2 |
| Inspection .....              | 05-2 |
| Removal .....                 | 05-3 |
| Installation .....            | 05-3 |

## Section 30

# Fuel and Air Intake System

## CONTENTS OF THIS SECTION

*NOTE: The fuel transfer pump, fuel filter, Roto Diesel fuel injection pump and injection nozzles of these tractors are dealt with in Technical Manual – Engines 3179, 4239 and 6359.*

### GROUP 00 – SPECIFICATIONS AND SPECIAL TOOLS

|                                | Page |
|--------------------------------|------|
| Specifications .....           | 00-3 |
| Thermostart starting aid ..... | 00-3 |
| Speed control linkage .....    | 00-3 |
| Air cleaner .....              | 00-3 |
| Special tools .....            | 00-4 |

### GROUP 05 – GENERAL INFORMATION, DIAGNOSING MALFUNCTIONS

|                               |      |
|-------------------------------|------|
| General information .....     | 05-1 |
| Diagnosing malfunctions ..... | 05-1 |

### GROUP 10 – FUEL TANK AND WATER TRAP

|                           |      |
|---------------------------|------|
| Fuel tank .....           | 10-1 |
| General information ..... | 10-1 |
| Removal .....             | 10-1 |
| Repair .....              | 10-1 |
| Installation .....        | 10-2 |
| Water trap .....          | 10-2 |

### GROUP 15 – COLD WEATHER STARTING AIDS

|                                | Page |
|--------------------------------|------|
| Ether starting fluid aid ..... | 15-1 |
| General information .....      | 15-1 |
| Removal .....                  | 15-2 |
| Repair .....                   | 15-2 |
| Installation .....             | 15-3 |
| Thermostart aid .....          | 15-3 |
| General information .....      | 15-3 |
| Repair .....                   | 15-4 |

### GROUP 20 – SPEED CONTROL LINKAGE

|                                 |      |
|---------------------------------|------|
| General information .....       | 20-1 |
| Removal and disassembly .....   | 20-1 |
| Repair .....                    | 20-5 |
| Assembly and installation ..... | 20-5 |
| Adjustment .....                | 20-7 |

### GROUP 25 – AIR CLEANER

|                                    |      |
|------------------------------------|------|
| Air pre-cleaner .....              | 25-1 |
| General information .....          | 25-1 |
| Repair .....                       | 25-1 |
| Dry-type air cleaner .....         | 25-1 |
| Operation .....                    | 25-1 |
| Inspecting air intake system ..... | 25-2 |
| Removal .....                      | 25-3 |
| Repair .....                       | 25-3 |
| Installation .....                 | 25-3 |

## Section 40

# Electrical System

### CONTENTS OF THIS SECTION

#### GROUP 00 – SPECIFICATIONS AND SPECIAL TOOLS

|                      | Page |
|----------------------|------|
| Specifications ..... | 00-3 |
| Special tools .....  | 00-6 |

#### GROUP 05 – DESCRIPTION, DIAGNOSING MALFUNCTIONS AND TESTS

|                                    |       |
|------------------------------------|-------|
| Description .....                  | 05-1  |
| How to read a wiring diagram ..... | 05-3  |
| Diagnosing malfunctions .....      | 05-4  |
| Tests .....                        | 05-9  |
| Components .....                   | 05-9  |
| Circuits .....                     | 05-18 |

#### GROUP 10 – WIRING HARNESSSES

|                                    |       |
|------------------------------------|-------|
| General information .....          | 10-1  |
| Replacing a wiring connector ..... | 10-16 |

#### GROUP 15 – CONTROLS AND INSTRUMENTS

|                                                                               |       |
|-------------------------------------------------------------------------------|-------|
| Dash panel .....                                                              | 15-1  |
| Instrument cluster (on tractors without operator's cab or with OPU cab) ..... | 15-3  |
| General information .....                                                     | 15-3  |
| Repair .....                                                                  | 15-4  |
| Instrument control panel (on tractors with SG2 cab) .....                     | 15-5  |
| General information .....                                                     | 15-5  |
| Repair .....                                                                  | 15-6  |
| Circuit breakers ("Sealed Beam" system) ..                                    | 15-9  |
| Fuses ("Bilux" system) .....                                                  | 15-10 |
| Main switch ("Sealed Beam" system) .....                                      | 15-13 |
| Alternator indicator light .....                                              | 15-14 |
| Start safety switch .....                                                     | 15-14 |
| Magnetic sending unit for engine and tractor speed meter .....                | 15-14 |
| Radio, tape player and aerial .....                                           | 15-15 |

#### GROUP 20 – LIGHTING SYSTEMS

|                                                    | Page |
|----------------------------------------------------|------|
| General information .....                          | 20-1 |
| Main switch ("Bilux" system) .....                 | 20-2 |
| Dipper and full-beam switch ("Bilux" system) ..... | 20-2 |
| Light switch ("Sealed Beam" system) ..             | 20-3 |
| Replacing bulbs .....                              | 20-4 |
| "Bilux" system                                     |      |
| Work and headlights .....                          | 20-4 |
| Tail, stop and turn-signal lights .....            | 20-5 |
| Turn-signal lights .....                           | 20-6 |
| Clearance lights .....                             | 20-6 |
| Registration plate light .....                     | 20-6 |
| Cab interior light .....                           | 20-7 |
| "Sealed Beam" system                               |      |
| Worklight with tail light and headlight .....      | 20-8 |
| Hazard warning lights .....                        | 20-9 |
| Tail lights .....                                  | 20-9 |

#### GROUP 25 – WIRING DIAGRAMS

|                                                                                             |       |
|---------------------------------------------------------------------------------------------|-------|
| Wiring diagram ("Bilux" system) on tractors without cab .....                               | 25-1  |
| Wiring diagram ("Bilux" system) on tractors with OPU cab .....                              | 25-9  |
| Wiring diagram ("Bilux" system) on tractors with low profile OPU cab .....                  | 25-19 |
| Wiring diagram ("Bilux" system) on tractors with SG2 cab (up to serial no. 486 078 L) ..... | 25-25 |
| Wiring diagram ("Bilux" system) on tractors with SG2 cab (from serial no. 486 079 L) .....  | 25-39 |
| Wiring diagram ("Sealed Beam" system) on tractors without SG2 cab .....                     | 25-55 |
| Wiring diagram ("Sealed Beam" system) on tractors with SG2 cab .....                        | 25-61 |

## Section 50

# Power Train

### CONTENTS OF THIS SECTION

|                                                                 | Page  |                                                                                                                              | Page  |
|-----------------------------------------------------------------|-------|------------------------------------------------------------------------------------------------------------------------------|-------|
| <b>GROUP 00 – SPECIFICATIONS AND SPECIAL TOOLS</b>              |       | <b>GROUP 15 – ENGINE CLUTCHES</b>                                                                                            |       |
| Specifications . . . . .                                        | 00-5  | Diagnosing malfunctions . . . . .                                                                                            | 15-1  |
| Special tools . . . . .                                         | 00-40 | Engine single-stage clutch<br>(1640, 1840 and 2040 up to<br>serial no. 463 068 L) . . . . .                                  | 15-2  |
| <b>GROUP 05 – DESCRIPTION, OPERATION AND LUBRICATING SYSTEM</b> |       | General information . . . . .                                                                                                | 15-2  |
| Description . . . . .                                           | 05-2  | Removal . . . . .                                                                                                            | 15-3  |
| Operation . . . . .                                             | 05-2  | Disassembly . . . . .                                                                                                        | 15-3  |
| Engine and engine clutch . . . . .                              | 05-2  | Repair . . . . .                                                                                                             | 15-4  |
| Hi-Lo shift unit . . . . .                                      | 05-3  | Assembly . . . . .                                                                                                           | 15-5  |
| Creep transmission . . . . .                                    | 05-3  | Adjustment . . . . .                                                                                                         | 15-6  |
| Collar shift transmission . . . . .                             | 05-3  | Installation . . . . .                                                                                                       | 15-7  |
| Synchronized transmission . . . . .                             | 05-4  | Engine single-stage clutch (2040 S<br>up to serial no. 416 039 L) . . . . .                                                  | 15-8  |
| Independent PTO . . . . .                                       | 05-4  | General information . . . . .                                                                                                | 15-8  |
| Front wheel drive . . . . .                                     | 05-4  | Removal . . . . .                                                                                                            | 15-8  |
| Differential . . . . .                                          | 05-5  | Disassembly . . . . .                                                                                                        | 15-8  |
| Final drives . . . . .                                          | 05-5  | Repair . . . . .                                                                                                             | 15-9  |
| Lubricating system . . . . .                                    | 05-6  | Assembly . . . . .                                                                                                           | 15-11 |
| Operation . . . . .                                             | 05-7  | Adjustment . . . . .                                                                                                         | 15-11 |
| <b>GROUP 10 – CLUTCH OPERATING LINKAGES</b>                     |       | Installation . . . . .                                                                                                       | 15-12 |
| Hydraulic clutch operating linkage . . . . .                    | 10-1  | Engine single-stage clutch<br>(1640 and 2040 from serial<br>no. 463 069 L and 2040 S<br>from serial no. 416 040 L) . . . . . | 15-13 |
| General information . . . . .                                   | 10-1  | General information . . . . .                                                                                                | 15-13 |
| Removal and repair . . . . .                                    | 10-1  | Removal . . . . .                                                                                                            | 15-13 |
| Installation and adjustment . . . . .                           | 10-3  | Repair . . . . .                                                                                                             | 15-15 |
| Filling and bleeding system . . . . .                           | 10-7  | Installation . . . . .                                                                                                       | 15-18 |
| Mechanical clutch operating linkage . . . . .                   | 10-9  | Engine dual-stage clutch . . . . .                                                                                           | 15-19 |
| General information . . . . .                                   | 10-9  | General information . . . . .                                                                                                | 15-19 |
| Removal and repair . . . . .                                    | 10-9  | Removal . . . . .                                                                                                            | 15-20 |
| Installation . . . . .                                          | 10-10 | Disassembly . . . . .                                                                                                        | 15-20 |
| Adjustment . . . . .                                            | 10-10 | Repair . . . . .                                                                                                             | 15-20 |
|                                                                 |       | Assembly . . . . .                                                                                                           | 15-22 |
|                                                                 |       | Adjustment . . . . .                                                                                                         | 15-23 |
|                                                                 |       | Installation . . . . .                                                                                                       | 15-24 |
|                                                                 |       | Adjusting externally . . . . .                                                                                               | 15-25 |

# Section 60

# Steering System and Brakes

## CONTENTS OF THIS SECTION

### GROUP 00 – SPECIFICATIONS AND SPECIAL TOOLS

|                                         | Page  |
|-----------------------------------------|-------|
| Specifications .....                    | 00-3  |
| Hydrostatic steering .....              | 00-4  |
| Power steering .....                    | 00-5  |
| Manual steering .....                   | 00-6  |
| Hydraulic foot brakes .....             | 00-7  |
| Handbrake .....                         | 00-8  |
| Parts for hydraulic trailer brake ..... | 00-8  |
| Special tools .....                     | 00-10 |

### GROUP 05 – HYDROSTATIC STEERING

(Operating Pressure: 12000 kPa;  
120 bar; 1740 psi)

|                                                                                                                                                                              |       |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------|
| Steering column .....                                                                                                                                                        | 05-1  |
| Description .....                                                                                                                                                            | 05-2  |
| Operation .....                                                                                                                                                              | 05-3  |
| Diagnosing malfunctions .....                                                                                                                                                | 05-9  |
| Removal .....                                                                                                                                                                | 05-12 |
| Disassembly .....                                                                                                                                                            | 05-17 |
| Repair .....                                                                                                                                                                 | 05-21 |
| Assembly .....                                                                                                                                                               | 05-22 |
| Installation .....                                                                                                                                                           | 05-27 |
| Checking and adjusting safety<br>valves in valve block .....                                                                                                                 | 05-28 |
| Pressure reduction valve .....                                                                                                                                               | 05-30 |
| General information .....                                                                                                                                                    | 05-30 |
| Removal .....                                                                                                                                                                | 05-31 |
| Repair .....                                                                                                                                                                 | 05-31 |
| Installation .....                                                                                                                                                           | 05-32 |
| Checking and adjustment .....                                                                                                                                                | 05-32 |
| Steering cylinders (on tractors without<br>mechanical front wheel drive and on<br>tractors with mechanical front wheel<br>drive up to tractor serial<br>no. 449 999 L) ..... | 05-33 |
| General information .....                                                                                                                                                    | 05-35 |
| Removal .....                                                                                                                                                                | 05-35 |
| Disassembly .....                                                                                                                                                            | 05-37 |
| Repair .....                                                                                                                                                                 | 05-40 |
| Assembly .....                                                                                                                                                               | 05-41 |
| Installation .....                                                                                                                                                           | 05-41 |
| Checking steering cylinder for leakage .....                                                                                                                                 | 05-43 |

|                                                                                                                  |       |
|------------------------------------------------------------------------------------------------------------------|-------|
| Steering cylinders (on tractors with<br>mechanical front wheel drive from<br>tractor serial no. 450 000 L) ..... | 05-45 |
| General information .....                                                                                        | 05-45 |
| Remove tie rod .....                                                                                             | 05-45 |
| Disassemble steering cylinder .....                                                                              | 05-46 |
| Disassemble piston .....                                                                                         | 05-49 |
| Specifications .....                                                                                             | 05-51 |
| Assemble piston .....                                                                                            | 05-52 |
| Assemble inner and outer piston<br>rod guides .....                                                              | 05-53 |
| Assemble piston rod with piston,<br>sleeve and inner guide .....                                                 | 05-54 |
| Install steering cylinder assembly<br>in axle housing .....                                                      | 05-55 |
| Install outer piston rod guide .....                                                                             | 05-55 |
| Adjustment .....                                                                                                 | 05-56 |
| Install tie rods .....                                                                                           | 05-57 |
| Connect hydraulic lines .....                                                                                    | 05-57 |

### GROUP 06 – HYDROSTATIC STEERING

(Operating Pressure: 15000 kPa;  
150 bar; 2180 psi)

|                                                   |      |
|---------------------------------------------------|------|
| General information .....                         | 06-1 |
| Steering valve, sectional view .....              | 06-2 |
| Hydraulic symbols (ISO 1219) .....                | 06-3 |
| Operation .....                                   | 06-4 |
| Function of safety valves .....                   | 06-7 |
| Removing steering wheel .....                     | 06-7 |
| Removing dash cover from bracket .....            | 06-7 |
| Removing steering valve .....                     | 06-8 |
| Removing metering unit .....                      | 06-8 |
| Removing check valves and<br>suction valves ..... | 06-8 |
| Removing shock valves .....                       | 06-8 |

## Section 70

# Hydraulic System

### CONTENTS OF THIS SECTION

#### GROUP 00 – SPECIFICATIONS AND SPECIAL TOOLS

|                                       | Page  |
|---------------------------------------|-------|
| Specifications .....                  | 00-3  |
| Tests .....                           | 00-3  |
| Hydraulic pumps                       |       |
| 12 cm <sup>3</sup> (0.7 cu.in.)       |       |
| 23 cm <sup>3</sup> (1.4 cu.in.) ..... | 00-5  |
| 40 cm <sup>3</sup> (2.4 cu.in.) ..... | 00-7  |
| 50 cm <sup>3</sup> (3.0 cu.in.) ..... | 00-9  |
| Rockshaft .....                       | 00-12 |
| Selective control valves .....        | 00-14 |
| Remote cylinder .....                 | 00-16 |
| Special tools .....                   | 00-17 |

#### GROUP 05 – DESCRIPTION, DIAGNOSING MALFUNCTIONS AND TESTS

|                                      |       |
|--------------------------------------|-------|
| Description .....                    | 05-3  |
| Operation .....                      | 05-4  |
| Diagnosing malfunctions .....        | 05-6  |
| Tests .....                          | 05-12 |
| Special tools .....                  | 05-12 |
| Specifications .....                 | 05-13 |
| Test index .....                     | 05-14 |
| Preliminary tests .....              | 05-15 |
| Preparations for tests .....         | 05-16 |
| Test sequence .....                  | 05-20 |
| Hydraulic testing record sheet ..... | 05-41 |

#### GROUP 10 – OIL RESERVOIR, FILTER, VALVES AND OIL COOLER

|                                                                     |      |
|---------------------------------------------------------------------|------|
| Main oil reservoir, transmission oil filter and intake screen ..... | 10-1 |
| General information .....                                           | 10-1 |
| Repair .....                                                        | 10-2 |
| Hydrostatic steering oil filter .....                               | 10-2 |
| General information .....                                           | 10-2 |
| Repair .....                                                        | 10-2 |
| By-pass valve of transmission oil filter .....                      | 10-3 |
| General information .....                                           | 10-3 |
| Repair .....                                                        | 10-3 |

#### GROUP 10 – OIL RESERVOIR, FILTER VALVES AND OIL COOLER (Contd.)

|                                                                      | Page |
|----------------------------------------------------------------------|------|
| Surge relief valve in clutch housing .....                           | 10-4 |
| General information .....                                            | 10-4 |
| Repair .....                                                         | 10-4 |
| Hydrostatic or power steering pressure control valve .....           | 10-5 |
| General information .....                                            | 10-5 |
| Repair .....                                                         | 10-6 |
| Auxiliary oil reservoir .....                                        | 10-7 |
| General information .....                                            | 10-7 |
| Repair .....                                                         | 10-7 |
| Oil cooler .....                                                     | 10-7 |
| General information .....                                            | 10-7 |
| Testing and repair .....                                             | 10-8 |
| Flow control valve for attached implement with hydraulic motor ..... | 10-8 |
| General information .....                                            | 10-8 |
| Repair .....                                                         | 10-8 |
| Check valve in hydraulic pump inlet line .....                       | 10-9 |
| General information .....                                            | 10-9 |
| Repair .....                                                         | 10-9 |

#### GROUP 15 – HYDRAULIC PUMPS

|                                                                                                                          |      |
|--------------------------------------------------------------------------------------------------------------------------|------|
| 12 cm <sup>3</sup> (0.7 cu.in.) and *23 cm <sup>3</sup> (1.4 cu.in.) hydraulic pumps (*Tractors without front PTO) ..... | 15-1 |
| General information .....                                                                                                | 15-2 |
| Operation .....                                                                                                          | 15-2 |
| Removal .....                                                                                                            | 15-3 |
| Repair .....                                                                                                             | 15-4 |
| Installation .....                                                                                                       | 15-9 |
| Adjustment .....                                                                                                         | 15-9 |

## Section 80

# Miscellaneous

### CONTENTS OF THIS SECTION

#### GROUP 00 — SPECIFICATIONS

|                             | Page |
|-----------------------------|------|
| Specifications .....        | 00-3 |
| Front axle .....            | 00-3 |
| Belt pulley .....           | 00-5 |
| Front and rear wheels ..... | 00-5 |
| Axla trailer hitch .....    | 00-6 |
| Special tools .....         | 00-6 |

#### GROUP 05 — FRONT AXLE

|                                   |      |
|-----------------------------------|------|
| General information .....         | 05-4 |
| Removal .....                     | 05-4 |
| Repair .....                      | 05-5 |
| Assembly .....                    | 05-5 |
| Installation and adjustment ..... | 05-6 |
| Check and adjust toe-in .....     | 05-8 |

#### GROUP 10 — BELT PULLEY

|                                                                     |      |
|---------------------------------------------------------------------|------|
| General information .....                                           | 10-1 |
| Removal and disassembly .....                                       | 10-1 |
| Repair .....                                                        | 10-2 |
| Assembly and adjustment .....                                       | 10-4 |
| Measuring and adjusting<br>gear backlash .....                      | 10-5 |
| Checking and adjusting end<br>play of drive gear hub assembly ..... | 10-5 |
| Adjusting drive shaft drag<br>torque .....                          | 10-5 |

#### GROUP 15 — FRONT AND REAR WHEELS

|                                      | Page |
|--------------------------------------|------|
| Front wheels .....                   | 15-1 |
| Repair .....                         | 15-1 |
| Adjusting front wheel bearings ..... | 15-2 |
| Rear wheels .....                    | 15-2 |
| General information .....            | 15-3 |
| Removal .....                        | 15-3 |
| Repair .....                         | 15-3 |
| Installation .....                   | 15-3 |

#### GROUP 20 — AXLA TRAILER HITCH

|                    |      |
|--------------------|------|
| Removal .....      | 20-2 |
| Repair .....       | 20-2 |
| Installation ..... | 20-2 |
| Adjustment .....   | 20-3 |

## Section 90

# Operator's Cabs

### CONTENTS OF THIS SECTION

#### GROUP 00 – SPECIFICATIONS AND SPECIAL TOOLS

|                               | Page |
|-------------------------------|------|
| Specifications .....          | 00-3 |
| Air conditioning system ..... | 00-3 |
| OPU cab .....                 | 00-4 |
| SG2-cab .....                 | 00-5 |
| Special tools .....           | 00-5 |

|                                               |       |
|-----------------------------------------------|-------|
| Regulatory controls .....                     | 05-56 |
| Expansion valve .....                         | 05-56 |
| Thermostatic temperature control switch ..... | 05-57 |
| Compressor relief valve .....                 | 05-59 |

#### GROUP 10 – VENTILATION AND HEATING

#### GROUP 05 – AIR CONDITIONING SYSTEM

|                                                |       |
|------------------------------------------------|-------|
| General information .....                      | 05-1  |
| Operation .....                                | 05-2  |
| Safety precautions .....                       | 05-5  |
| Preliminary checks .....                       | 05-7  |
| Diagnosing malfunctions .....                  | 05-8  |
| Checks and diagnosing sequence .....           | 05-10 |
| Flow chart for diagnostic checks .....         | 05-27 |
| Electrical testing .....                       | 05-28 |
| Service and checking .....                     | 05-30 |
| Compressor .....                               | 05-35 |
| General information .....                      | 05-35 |
| Removal .....                                  | 05-37 |
| Leak testing compressor .....                  | 05-37 |
| Disassembly .....                              | 05-39 |
| Assembly .....                                 | 05-43 |
| Checking and adding compressor oil .....       | 05-46 |
| Installation .....                             | 05-47 |
| Refrigerant couplings .....                    | 05-48 |
| General information .....                      | 05-48 |
| Service .....                                  | 05-49 |
| Condenser, receiver-dryer and evaporator ..... | 05-50 |
| Condenser .....                                | 05-50 |
| Receiver-dryer .....                           | 05-51 |
| Evaporator .....                               | 05-53 |

|                           |      |
|---------------------------|------|
| General information ..... | 10-1 |
| Removal .....             | 10-2 |
| Repair .....              | 10-4 |
| Installation .....        | 10-8 |
| Air filter .....          | 10-9 |

#### GROUP 15 – OPERATOR'S SEATS

|                                            |       |
|--------------------------------------------|-------|
| Personal posture seat .....                | 15-1  |
| General information .....                  | 15-1  |
| Armrest assembly .....                     | 15-2  |
| Removal .....                              | 15-2  |
| Repair .....                               | 15-2  |
| Installation .....                         | 15-2  |
| Cushions and seats belts .....             | 15-3  |
| Removal .....                              | 15-3  |
| Repair .....                               | 15-4  |
| Installation .....                         | 15-4  |
| Seat support assembly .....                | 15-4  |
| Removal .....                              | 15-4  |
| Repair .....                               | 15-5  |
| Installation .....                         | 15-5  |
| Suspension assembly .....                  | 15-6  |
| Removal .....                              | 15-6  |
| Repair .....                               | 15-9  |
| Installation .....                         | 15-9  |
| De Luxe seats and Super De-Luxe seat ..... | 15-12 |
| General information .....                  | 15-17 |
| Repair .....                               | 15-17 |
| Standard seat .....                        | 15-17 |
| General information .....                  | 15-17 |
| Repair .....                               | 15-17 |

## On Tractors with SG2 Cab




Fig. 11 — Separating between Clutch Housing and Transmission Case, Right-Hand Side

- |                                 |                                |
|---------------------------------|--------------------------------|
| 1 Retaining strap               | 3 Hydraulic pump pressure line |
| 2 Attaching cap screws (8 used) | 4 Line to trailer brake valve  |

1. Disconnect ends of hydraulic pump pressure line 3 (fig. 11) and remove.
2. Disconnect retaining straps 1 of heater hoses and pull out heater hoses to the front.
3. *When equipped:* Disconnect line 4 to trailer brake valve at T-piece.

## On all Tractors

1. Disconnect leak-off and breather line 1 (fig. 9) at transmission shift cover.

2. Disconnect cable 7 (fig. 12) of transmission oil pressure warning switch.
3. Remove cap screws 2 and lift off shift cover 1 together with cover 4.

**NOTE:** After removing complete shift cover assembly, do not move shaft 5, otherwise detent balls may drop out of cover 4.





Fig. 12 — Removing Transmission Shift Cover (Tractor with Center Shift Shown)

- |                                |                                                     |
|--------------------------------|-----------------------------------------------------|
| 1 Transmission shift cover     | 6 Operating rod                                     |
| 2 Shift cover attaching screws | 7 Cable of transmission oil pressure warning switch |
| 3 Connecting rod               | 8 Transmission case attaching screws                |
| 4 Cover                        | 9 Transmission oil pressure warning switch          |
| 5 Shaft                        |                                                     |

## REMOVING ROCKSHAFT




L112319-LA41025AE-101285

## REMOVING SG2 CAB

Refer to "Removing SG2 Cab".

Disconnect battery ground straps.



L110 906


L110906-LA11025CE-151085

## DISCONNECTING LEFT-HAND ROCKSHAFT LIFT CYLINDER

Disconnect start safety switch cable (A).

Remove hollow bolt (B) and pressure hose.

Drive out spring pins (C) and then pull out pins (D).




L110 918

L110918-LA11025AE-080885

**Blower Switch - Resistor Test**

1. Connect ohmmeter to terminals 1 and 3 for "Low" speed (see fig. 15). Resistance must be approx. 0.8 ohms.
2. Connect ohmmeter to terminals 1 and 2 (medium speed). Resistance must now be approx. 0.4 ohms.




L104 381

Fig. 15 — Blower Switch-Resistor Test

**Air Conditioning - Compressor Clutch**

1. Turn key switch to "ON" position
2. Turn air conditioning system switch to "ON" position
3. Turn on blower switch
4. There must be an audible "click" in the electromagnetic compressor clutch when turning on or off one of the above switches.



L104 382

Fig. 16 — Air Conditioning Compressor Clutch




Fig. 26 — Radio Installed, Sectional View

- 1 Console
- 2 Self-tapping screw (6 used)
- 3 Bracket

- 4 Hex. nut
- 5 Radio
- 6 Spring clamp (6 used)

- 7 Inner cover
- 8 Hex. nut (2 used)
- 9 Self-tapping screw

## REMOVAL AND INSTALLATION

### Radio or Radio/Tape Player

1. Remove the six self-tapping screws 2 (fig. 26) and lift out radio 5 together with console 1 from cab roof.
2. Disconnect power supply cable (red/black), ground cable (brown), loudspeaker cable and aerial cable at radio.
3. Remove bracket 3 and hex. nut 8 and lift radio 5 out of console 1.

4. Install radio, reversing removal procedure.

### Aerial




1. Remove the two cap screws from top and three at front of roof.
2. Remove cab roof.
3. Remove cover plate for windshield wiper motor.

| No.  | Cables and Wires |       |              | Component         | from |              | Component                                         | to  |              |
|------|------------------|-------|--------------|-------------------|------|--------------|---------------------------------------------------|-----|--------------|
|      | mm <sup>2</sup>  | Gauge | Color        |                   | No.  | Terminal No. |                                                   | No. | Terminal No. |
| 96*  | 1                | 16    | green        | Plug (radio)      | 101  | 5            | Loud-speaker, right-hand                          | 68  |              |
| 97** | 1                | 16    | grey/black   | Switch for fan    | 85   | C            | Thermostat switch                                 | 88  |              |
| 98** | 1                | 16    | yellow       | Thermostat switch | 88   |              | Plug                                              | 53  | 1            |
| 99** | 2.5              | 14    | yellow       | Plug              | 53   | 1            | Plug                                              | 13  | 6            |
| 100  | 2.5              | 14    | black        | Plug              | 54   | 1            | Start safety switch                               | 57  |              |
| 101  | 2.5              | 14    | black        | Plug              | 54   | 2            | Start safety switch                               | 57  |              |
| 102  | 1                | 16    | green/yellow | Plug              | 54   | 4            | Solenoid for front wheel drive                    | 55  |              |
| 103  | 1                | 16    | green/white  | Plug              | 54   | 5            | Transmission oil pressure warning switch          | 58  |              |
| 104  | 4                | 11    | brown        | Plug              | 54   | 7            |                                                   |     | Ground       |
| 105  | 1                | 16    | brown/white  | Plug              | 54   | 3            | Sending unit for Hi-Lo shift unit indicator light | 56  |              |
| 106  | 1                | 16    | orange/black | Plug              | 53   | 4            | Plug                                              | 67  |              |
| 107  | 1                | 16    | orange       | Plug              | 53   | 9            | Plug                                              | 67  |              |
| 108  | 1                | 16    | brown/white  | Plug              | 53   | 5            | Plug                                              | 66  |              |
| 109  | 1.5              | 15    | black        | Plug              | 53   | 2            | Plug                                              | 66  |              |
| 110  | 1                | 16    | black        | Plug              | 53   | 2            | Plug                                              | 75  |              |
| 111  | 1                | 16    | grey         | Plug              | 53   | 6            | Plug                                              | 75  |              |

\* When equipped

\*\* On tractors with air conditioning only

Mechanical Front Wheel Drive (from Tractor Serial No. 450 000 L)

| Tool                                                                                                                            | Description and Part No.                       | Use                                                                                                                                                             |
|---------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <br>L 30977<br>Fig. 33 — Spring Compressor      | Spring compressor<br>KML 10 005                | Removing and installing<br>Belleville springs                                                                                                                   |
| <br>L 30987<br>Fig. 34 — Blind Hole Puller Set | Blind hole<br>puller set<br>D-01061 AA         | Removal of drive<br>shaft bushings                                                                                                                              |
| <br>L 30988<br>Fig. 35 — Bearing Puller       | Bearing puller<br>D-01218 AA<br><br>D-01274 AA | Removing drive pinion<br>taper roller bearing cone<br>and differential taper roller<br>bearing cone<br><br>Removing ring gear with<br>differential casing cover |

## Installation and Adjustment

### CONSOLE AND CENTER SHIFT

*NOTE: Install shifter mechanism from the front with transmission bearing quill installed. Install shifter fork for range I and reverse on shift sleeve before installing transmission bearing quill. Coat detent balls and springs with grease prior to installation. Coat shifter shaft bores with oil.*

### CONSOLE SHIFT

1. Drive in bushings 44 and 41 (fig. 3) until flush with inner face of transmission case.
2. Attach shifter shaft housing 18 with gasket 19 to transmission case.
3. Press bushings 17 to a depth of 9 mm (0.35 in.) into shifter shaft housing 18 and install seal rings 16.
4. Press bushings 9 to a depth of 8 mm (0.31 in.) into shifter shafts 8 and 14 and install seal rings 10.
5. Press bushings 45 to a depth of 13 mm (0.51 in.) into shifter shafts 8 and 14.
6. Install plastic washers 15 on shifter shafts 8 and 14 and plastic washers 11 on shifter shafts 12 and 13.
7. Coat bushings and seals with Molykote grease type "G" before installing shifter shafts.

**IMPORTANT! Screw set screws and positioning screws in respective bores of shift levers and shifter forks before installation.**

8. Guide pre-assembled shifter shaft 14 in lower bore of shifter shaft housing 18. Install shift lever 23, noting marks made when removed. Coat set screws 22 with Loctite 242 (L41475) and tighten.

*NOTE: When installing a new shifter shaft 14, make sure that the groove in shifter lever 23 is aligned with tooth shaped section of shifter shaft 14.*

9. Position shifter shafts 13 and 14 parallel and install shift lever 24 so that the shift cams on shifter levers 23 and 24 are aligned.

10. Check axial play of shifter shaft 13. Play must be less than 1 mm (0.04 in.). When necessary, install a further plastic washer 11.

11. Guide shifter shaft 25 in bore of transmission bearing quill.

12. Press detent ball 43 and spring 42 downward and slide shifter shaft in bore.

13. Slide shifter fork 27 on shifter shaft 25. Insert shift lever 23 in groove of shifter shaft.

14. Place shifter shaft 25 in neutral position.

15. Place two detent balls 43 into cross-bore between the two shifter shafts.

16. Guide shifter shaft 28 in bore of transmission bearing quill.

17. Press detent ball 43 and spring 42 downward and slide shifter shaft 28 up to shifter fork 33.

18. Slide shifter fork 33 on shifter shaft 28.

19. Guide shift lever 24 in groove of shifter shaft 28.


*NOTE: Adjustment of shifter forks is carried out by means of positioning screws 26 or 34 (fig. 3). The shifter forks may be shifted laterally on the shifter shafts by turning positioning screws in or out.*

20. Adjust 1st and 2nd gear shifter fork 27 as follows:

Place shifter shaft 25 in neutral position; slide hollow shaft in direction of bevel gear. Adjust shifter fork so that shifter collar contacts hollow shaft evenly and without tension.

21. Adjust 3rd and 4th gear shifter fork 33 as follows:

Place shifter shaft 28 and synchronizer shifter collar in neutral position. Adjust shifter fork so that it is located exactly in the center of shifter collar.



L 111188

Fig. 13 — PTO Operating Linkage, Exploded View (Tractors with SG2 Cab)

- 1 PTO indicator light sending unit\*
- 2 Console\*
- 3 Link\*
- 4 Lock plate\*
- 5 Shifter knob\*
- 6 Shift lever assembly\*
- 7 Shift console\*
- 8 Lever
- 9 Rod

- 10 Cover
- 11 Wavy washer
- 12 Lever
- 13 Spacer bushing
- 14 Washer
- 15 Snap ring
- 16 O-ring
- 17 Shifter fork
- 18 Guide shoes

- 19 Shifter sleeve
- 20 Stop lever
- 21 Shifter fork stop
- 22 Woodruff key
- 23 Shifter shaft
- 24 End cap
- 25 Shift console\*\*
- 26 PTO indicator light sending unit\*\*
- 27 Shift lever assembly

\* On earlier tractor series

\*\* On later tractor series




Fig. 56 — Checking Rolling Drag Torque of Hub Bearings

- 1 Wheel hub  
2 Spring scale

10. Use special socket spanner KML-10011 to tighten first slotted nut 19 (fig. 55) until a rolling drag torque of 4 to 7 Nm (3 to 5 ft-lb) has been obtained. This value equals a pull on spring scales of 35 to 65 N (8 to 15 lb) measured at circumference of wheel hub (see fig. 56).
11. Install lock plate 20 (fig. 55) and tighten second slotted nut 19.
12. Secure both slotted nuts with lock plate.
13. Install sun gear 18 on drive shaft 16 and snap ring 17.
14. Using two suitable levers, check radial and axial play of drive shaft with knuckle housings turned as during steering (see fig. 57).

*NOTE: The drive shaft must be free to move axially and radially when knuckle housings are turned as during steering.*




Fig. 57 — Checking Radial Play of Drive Shaft

*NOTE: When radial free play can be felt when lifting or lowering the universal joint of shaft, this indicates correct adjustment.*

15. If there is no noticeable radial play, then either upper or lower king pin 2 (fig. 52) must be tightened or loosened.

**IMPORTANT!** However the previously determined rolling drag torque (see fig. 51) must remain unaltered.

16. Secure right-hand steering arm 4 (fig. 52) to axle knuckle housing, tightening cap screws to 230 Nm (170 ft-lb) torque.

*NOTE: To determine axial play of drive shaft 16 (fig. 55), preassemble wheel hub 30 and planetary carrier 2 as far as possible.*

17. Turn axle knuckle housing up to stop and make sure that drive shaft turns freely.
18. In this position measure and note distance between hub face to axle shaft end face using a depth gauge (see fig. 58).




Fig. 29 — Pressing Out Leaf Springs

13. Press leaf springs 16 completely out of slot.




Fig. 30 — Removing Leaf Springs

16    Leaf springs

14. Take out leaf springs from valve spool.

15. Using a suitable tool, remove remaining seal ring 24 from pump housing.




Fig. 31 — Removing Seal Ring

24    Seal ring

#### STEERING COLUMN (Tractors with SG2 Cab)

1. Remove snap ring 8 (fig. 32) and washer 15 from upper steering shaft 1.
2. Remove hollow screw 10 out of steering column tube 14. Remove lower thrust bearing.
3. Remove complete steering shaft assembly downward out of steering column tube.
4. Disassemble steering shaft assembly, using fig. 32 as a guide.

## Tractors with SG2 Cab



Fig. 4 — Handbrake Lever, Installed

- |                   |                       |
|-------------------|-----------------------|
| 1 Handbrake lever | 3 Cover               |
| 2 Cap screw       | 4 Self-tapping screws |

1. Raise platform mat and remove self-tapping screws 4 (fig. 4) of cover 3.
2. Lift out cover 3 and remove handbrake lever shaft cap screw. Remove handbrake lever.
3. Remove rear dash panel cap screws and lift out rear dash panel.
4. Remove side dash panel cap screw 2 and lift out dash panel.




Fig. 5 — Brake Valve Assembly, Installed

- |               |                      |
|---------------|----------------------|
| 1 Inlet line  | 5 Cap screws         |
| 2 Return line | 6 Snap ring (2 used) |
| 3 Brake lines | 7 Brake pedals       |
| 4 Connectors  |                      |

5. *When equipped*, pull off connectors 4 (fig. 5) at stop light switch.
6. Disconnect inlet line 1, return line 2 as well as brake lines 3 at brake valve assembly. Immediately cap or plug all lines and connections to prevent dirt from entering the system.
7. Remove both cap screws 5 securing brake valve assembly to dash panel support and lift out brake valve assembly.
8. Remove snap ring 6, drive out brake pedal shaft and lift out brake pedals 7.

**IMPORTANT!** Remove brake pedal shaft and pedals carefully so that brake piston springs are relieved slowly. Sudden expulsion of brake pistons under spring tension can cause damage to the valves.

**STEP 21**

1. When equipped, repeat Step 20 with second selective control valve.
2. Adjust pressure control valve of hydrostatic or power steering (see section 70, group 10).
3. Remove shims to decrease pressure.
4. Add shims to increase pressure.

*NOTE: One shim will alter pressure approximately 250 kPa (2.5 bar; 36 psi).*

5. If it is not possible to obtain the correct pressure there is a restriction in the:
  - valve housing
  - connecting oil lines or couplers
  - selective control valve

6. To recheck the adjustment:

*Repeat Step 20*

**STEP 22**

Check complete lift cycle of rockshaft.

1. Run engine at 2100 rpm.
2. Move rockshaft control lever to "MIN" position (position "D" on earlier tractor series).
3. Raise rockshaft lift arms from lowest to highest position.

Period required to fully raise or lower rockshaft lift arms. . . . . 1.8 to 2.3 secs.

4. With correct lifting cycle,

*Proceed with Step 38*

5. Lifting cycle too slow,

*Proceed with Step 23*

**STEP 23**

Adjust rockshaft pressure control valve.




**Fig. 47 — Rockshaft Pressure Control Valve**


1. Additional washers increase rockshaft speed.
2. Repeat lifting cycle check.
3. When lifting time is now correct.

*Proceed with Step 24*

4. When the specified lifting time cannot be reached,

*Proceed with Step 38*

## Load Control Mechanism



L 23742


Fig. 22 — Load Control Mechanism, Exploded View

- |                      |                                         |                                 |                     |
|----------------------|-----------------------------------------|---------------------------------|---------------------|
| 1 Cap screw*         | 7 Cover (without rockshaft)             | 13 Lock nuts                    | 18 Spring pin       |
| 2 Lock nut*          | 8 Spacer bushings                       | 14 Pivot pin                    | 19 Cam follower     |
| 3 O-ring*            | 9 Seal rings                            | 15 Snap rings                   | 20 Return spring    |
| 4 Rear pin*          | 10 Seal rings (when equipped)           | 16 Cam follower adjusting screw | 21 Special pin      |
| 5 Front pin*         | 11 Bushings                             | 17 Extension                    | 22 Load control arm |
| 6 Load control shaft | 12 Load control arm negative stop screw |                                 | 23 Special pin      |

\* On tractors with combined, Independent 540/1000 rpm PTO only

## REPAIR

1. Remove 3-point hitch.
2. Remove rockshaft assembly. see section 10, group 20.
3. Remove left-hand final drive, see section 10, group 20, so that control arm pivot shaft 14 (fig. 25) supporting control arm can be withdrawn.
4. Remove return spring 20 of cam follower.
5. Withdraw control arm pivot pin 14 far enough to lift control arm out of transmission case.
6. Push both spacer bushings 8 from load control shaft. Drive load control shaft out of transmission case or bushings, using a suitable driver.



L23664

Fig. 2 — Remote Cylinder, Exploded View

- 1 Stop rod packing adapter
- 2 V-packing (3 used)
- 3 Stop rod packing adapter
- 4 Stop rod packing spring
- 5 Remote cylinder
- 6 Washer
- 7 Stop rod spring
- 8 Stop rod washer
- 9 Stop rod
- 10 Snap rings
- 11 Stop valve
- 12 Stop valve spring

- 13 Oil passage seal (2 used)
- 14 Seal ring
- 15 Remote cylinder end cap
- 16 Spring washer (4 used)
- 17 Cap screw (4 used)
- 18 Self locking nut
- 19 Back-up rings
- 20 O-ring
- 21 Piston
- 22 Piston rod guide gasket
- 23 Piston rod guide
- 24 Groove pin

- 25 Stop rod arm
- 26 Adjusting lever
- 27 Special washer
- 28 Stop screw
- 29 Piston rod stop
- 30 Spring pin
- 31 Piston rod with yoke
- 32 Oil seal
- 33 Back-up ring
- 34 O-rings
- 35 Cap screw (3 used)
- 36 Plug

## Repair

### DISASSEMBLY

1. Remove end cap 15 (fig. 2).
2. Push rod assembly completely into cylinder and remove stop valve 11.
3. Insert a rod through yoke of piston rod 31 and unscrew self locking nut 18 from piston rod. Pull piston 21 and rod 31 out of cylinder.
4. Push stop 29 from piston rod 31 and, if necessary, remove adjusting lever 26, washer 27 and stop screw 28.
5. Push stop rod 9 all the way into cylinder to prevent distortion of stop rod while driving groove pin 24 from stop rod arm 25.
6. Remove piston rod guide 23. Rod 9 can be used to drive packing adapters 1 and 3, together with the three V-packings 2, out of the cylinder.

1. Close shut-off valve on dispensing valve FKM 10001-10\* (see fig. 9) and attaching dispensing valve to refrigerant container FKM 10001-9\*.
2. Attach yellow hose to dispensing valve.
3. Loosen yellow hose connector at gauge manifold and crack dispensing shut-off valve to purge air from yellow hose. Tighten hose connection at gauge manifold.




Fig. 9 — Charging the System

- 1 Manifold gauge set FKM 10001-6
- 2 Service valves
- 3 Yellow hose
- 4 Refrigerant container FKM 10001-9
- 5 Dispensing valve FKM 10001-10

4. Invert container to allow refrigerant to enter system in fluid form.
5. Open high-pressure gauge manifold hand valve. Both gauges should no longer show a vacuum.

**NOTE:** A blockage in the system is indicated should low pressure gauge remain stationary. Check system and remove blockage.

6. Close high-pressure manifold hand valve as soon as pressure stops rising.
7. Start engine and run at 1500 rpm with temperature control set for maximum cooling.
8. Invert container so that dispensing valve is now at the top and open low-pressure manifold hand valve. By this means further refrigerant in gas form will be drawn from the container.

**IMPORTANT!** Refrigerant fluid must not enter the compressor, otherwise this will cause internal damage.

9. If need be, use several containers until system is charged with the specified amount. Make sure that the yellow hose is purged of air when each refrigerant container is replaced.

**NOTE:** System charging can be quickened by placing refrigerant container in a container filled with water heated to a maximum temperature of 50°C (120°F).



**CAUTION!** Under no account exceed maximum temperature of 50°C (120°F), otherwise refrigerant container may explode.

10. Close dispensing valve when charging is completed.
11. Check system for full refrigerant charge at sight glass. Should bubbles appear, top up with refrigerant until sight glass is clear.

**NOTE:** On tractors with OPU, control receiver-dryer sight glass by removing rubber plug on cab roof.

# PREVIEW ONLY

You're viewing 24 of 1256 pages

---

## The full manual includes:

- All 1256 pages, complete
  - Searchable PDF (find any keyword)
  - No watermarks
  - Instant download
  - Print-ready quality
- 

**GET FULL MANUAL NOW**

**John Deere 1640, 1840, 2040, 2040S Technical Service Repair  
Manual**

---



Scan or click anywhere  
[youfixthis.com](https://youfixthis.com)

*Click anywhere on this page to get the full manual*