

- c. Adjusting contact condition at the heel (Fig. 2-370).  
Move some shims from the crown wheel side to the opposite side to bring the crown wheel closer to the drive pinion.  
Then, increase shim thickness at the bearing cage and move the drive pinion away from the crown wheel.




Fig. 2-370

- e. Adjusting contact condition at flank (Fig. 2-372).  
Increase shim thickness at the bearing cage to move the drive pinion away from the crown wheel.  
Then, move some shims from the crown wheel side to the opposite side to bring the crown wheel closer to the drive pinion.




Fig. 2-372

- d. Adjusting contact condition at face (Fig. 2-371).  
Reduce the shim thickness at the bearing cage to bring the drive pinion closer to the crown wheel.  
Then, move some shims from the side other than the crown wheel side to the opposite side to move the crown wheel away from the drive pinion.




Fig. 2-371

g) **Installing the brake assembly.**

1. Install the brake piston ring in the center housing (bearing retainer).




Fig. 2-373

**ATTACHMENT HYDRAULIC SYSTEM**

Sealed type with anti-cavitation and safety valves.

- Flow at rated speed ..... 165 lt/min
- 2 or 3 spool control valve

Mechanical or piloted control

Hydraulic double-acting cylinders:

- Boom control ..... 2
- Bore x stroke ..... 120 x 665 mm
- Bucket control cylinder
- Bore x stroke ..... 150 x 431 mm
- Pressure relief valve setting ..... 210 ± 10 bar
- Lift safety valve setting ..... 230 ± 10 bar
- Bucket roll-back safety valve setting ..... 230 ± 10 bar
- Bucket roll-out safety valve setting ..... 160 ± 10 bar

Three-position control switch as follows:

**Position 0:** disengaged

**Position 1:** LTS engaged with speeds exceeding 5 kph

**Position 2:** (to be used only for maintenance or repair) LTS engaged at all times, even with speed lower than 5 kph.

- Accumulator safety valve setting ..... 120 bar

**ELECTRICAL SYSTEM**

Operating voltage ..... 24 V

Batteries in series ..... 2

- maintenance -free type

BOSCH starter motor

Rated power ..... 4 KW

BOSCH alternator with voltage regulator ..... 55 A

**OPTIONS**

Electronic anti-pitch LTS (Load Travel Stabiliser) system.


**WEIGHT**

Loader weight with 17.5 R25 tyres, 2 m<sup>3</sup> bucket, fully filled with fluids and operator kg.

**MAIN DIMENSIONS**

Dimensions taken with machine with the loader fitted with 17.5 R25 tyres and 2 m<sup>3</sup> load capacity bucket.

Unit of measure: mm



Carefully read personal and machine SAFETY PRECAUTIONS (at the beginning of this manual)

PREVIEW - YOUFIXTHIS.COM

PAGE LEFT INTENTIONALLY BLANK

**c) Installing the differential assembly.**

1. If the differential bearing was replaced with a new one, press bearing cups on the 2 bearing retainers.
3. Install the box rings and shims on the 2 bearing retainers. Use shims of the same size as was removed during disassembly.




Fig. 2-354




Fig. 2-356

2. Lift the reassembled differential assembly with a hoist and put it in the center housing, aligning the crown wheel with the notch in the center housing.
4. Install the bearing retainers at the right and left sides of the center housing to hold the differential case. Temporarily install the bearing retainer mounting bolts (8 off).




Fig. 2-355




Fig. 2-357

Carefully read personal and machine SAFETY PRECAUTIONS at the beginning of this Manual

# SERVICE MANUAL

Wheel Loaders LW110 - LW130 - LW130TC



**NEW HOLLAND**  
**CONSTRUCTION**

**e) Removing and Disassembling Converter Wheels (LW110)**

1. Remove the eight bolts securing the input plate and remove the plate.




**Fig. 2-62**

3. Remove the snap ring from the turbine shaft and remove the turbine, holding the rivet head with pliers.




**Fig. 2-64**

2. Remove the 24 bolts securing the front cover and remove the cover with two puller bolts.




**Fig. 2-63**

4. Remove the snap ring. Remove the stator wheel and collar.




**Fig. 2-65**

Carefully read personal and machine SAFETY PRECAUTIONS (at the beginning of this manual)

To convert models LW110 and LW130/130TC from the mechanical transmission version into the automatic transmission version, it is necessary to perform the following operations: JP1

- 1) An automatic transmission neutraliser switch is mounted on the instrument control panel. 
- 2) Install a proximity sensor on the accelerator pedal.
- 3) Remove the plug on the transmission and insert the second sensor.
- 4) The transmission control ATC electronic unit is installed.
- 5) Disconnect connection "N" and connect it to "N-N".
- 6) Add wire 76042597 connected as in fig. 2-40.
- 7) Remove relays RL9 - RL6.

- 8) Position switches SW1 and SW2 on the logic board, in the positions indicated here below:

#### MECHANICAL MODE SELECTION (BASE)

##### SW1

- 1 ON
- 2 OFF
- 3 OFF
- 4 OFF

##### SW2

- 1 OFF
- 2 ON
- 3 OFF
- 4 OFF

##### JP1

BRIDGE  
2-3

#### MECHANICAL MODE SELECTION (VARIANT)

##### SW1 (LW110)

- 1 OFF
- 2 ON
- 3 OFF
- 4 ON

##### SW2

- 1 ON
- 2 OFF
- 3 ON
- 4 ON

##### SW1 (LW130/130TC)

- 1 OFF
- 2 ON
- 3 OFF
- 4 OFF

##### JP1

BRIDGE  
1-2




Fig. 2-41 Self-diagnosis of troubles on automatic transmission



## **SAFETY PRECAUTION INFORMATION**

**UNSAFE OPERATING PRACTICES AND IMPROPER USE OF THE MACHINE AND ITS ATTACHMENTS ON THE PART OF THE OPERATOR OR SERVICE TECHNICIAN CAN RESULT IN INJURIES. OBSERVE THE FOLLOWING SAFETY PRECAUTIONS AT ALL TIMES:**

- 1. FOR SERVICING, THE LOADER SHOULD BE ON LEVEL TERRAIN, ENGINE STOPPED WITH THE WHEELS BLOCKED OR THE ENTIRE MACHINE SOLIDLY SUPPORTED WITH THE WHEELS OFF THE GROUND BEFORE SERVICING ANY COMPONENT OF THE DRIVETRAIN.**
- 2. FOR SERVICING UNDER THE OPERATOR'S SEAT, RAISE THE SEAT AND PAN ASSEMBLY TO THE RAISED LATCHED POSITION AND SECURELY LATCH.**
- 3. DO NOT OPERATE THE MACHINE UNLESS THE SEAT IS LATCHED IN THE OPERATE POSITION.**
- 4. DO NOT SERVICE THE MACHINE WITH A RAISED BOOM UNLESS THE BOOM IS RESTING ON BOOM LOCK PINS OR CYLINDER LOCKING TOOLS OR FIXTURES.**
- 5. DO NOT SERVICE THE LOADER WITH THE ENGINE RUNNING UNLESS THE LOADER IS PROPERLY AND SECURELY SUPPORTED WITH ALL FOUR WHEELS OFF THE GROUND.**
- 6. USE CAUTION WHEN SERVICING THE UNIT AROUND MOVING PARTS.**
- 7. DO NOT TILT THE BOOM AND CAB WITHOUT PROPER INSTRUCTION.**
- 8. DO NOT TILT THE BOOM AND CAB WITHOUT USING THE PROPER CAB TILTING TOOL.**
- 9. REINSTALL ALL SHIELDS REMOVED FOR SERVICE.**
- 10. NEVER LOOSEN ANY HYDRAULIC CONNECTIONS BEFORE RELIEVING THE PRESSURE IN THE HYDRAULIC SYSTEM.**
- 11. WEAR EYE PROTECTION SUCH AS GOGGLES, ETC.**
- 12. WEAR EAR PROTECTION SUCH AS EARPLUGS, ETC. WHEN YOU FEEL THE NOISE LEVEL IS UNCOMFORTABLE.**
- 13. IF ANY SERVICING OR ADJUSTMENTS REQUIRE THE BATTERY TO BE DISCONNECTED, DISCONNECT THE (-) NEGATIVE GROUND CABLE.**
- 14. WHEN SERVICING ELECTRICAL COMPONENTS, DISCONNECT THE (-) NEGATIVE GROUND CABLE.**
- 15. IF AN ELECTRONIC INSTRUMENT CLUSTER (EIC) REQUIRES REMOVAL FROM THE DASH AREA OR THE MACHINE, DISCONNECT THE (-) NEGATIVE GROUND BATTERY CABLE. THIS WILL SHUT OFF POWER TO THE EIC AND PREVENT DAMAGE TO THE EIC BOARD OR BLOWING FUSES IF THE BOARD IS ACCIDENTALLY GROUNDED.**
- 16. IF WELDING IS REQUIRED ON THE MACHINE, DISCONNECT THE (-) NEGATIVE GROUND CABLE. FAILURE TO DISCONNECT THE BATTERY MAY RESULT IN DAMAGE TO THE EIC (ELECTRONIC INSTRUMENT CLUSTER) MONITORING SYSTEM AND OTHER ELECTRICAL COMPONENTS.**
- 17. IF WELDING IS REQUIRED ON AN ATTACHMENT, REMOVE THE ATTACHMENT FROM THE MACHINE.**

©2000 NEW HOLLAND CONSTRUCTION

## OWNER ASSISTANCE

We at New Holland Construction and your New Holland Construction dealer want you to be completely satisfied with your investment. Normally any problems with your equipment will be handled by your dealer's Service Department. Sometimes, however, misunderstandings can occur. If your problem has not been handled to your satisfaction, we suggest the following:

1. Contact the owner or General Manager of the dealership, explain the problem, and request assistance. When additional assistance is needed, your dealer has direct access to our office.

2. If you cannot obtain satisfaction by doing this, contact the New Holland Construction office and provide them with:

- Your name, address, and telephone number
  - Machine model and serial number
  - Dealership name and address
  - Machine purchase date and amount of use
  - Nature of problem

### NEW HOLLAND CONSTRUCTION

245 E. North Ave

Carol Stream, IL 60188-2021

Tel. No. (630) 260-4000

When contacting New Holland, be aware that your problem will likely be resolved in the dealership using the dealer's facilities, equipment, and personnel. So it is important that your initial contact be with the dealer.

### MANUAL CORRECTIONS

If a page in this manual is found to need correction, please fax a marked page to (630)260-4565.

### SPARE PARTS

To maintain operating efficiency, use NEW HOLLAND original spare parts. When ordering parts, give the following informations:

- Machine model
- Machine and engine serial numbers
- Part number from the Parts Catalog

©2000 NEW HOLLAND CONSTRUCTION

## 1.8 LUBRICATION SYSTEM

Lubrication: ..... Forced  
 Lubrication pump: ..... Gear type, driven by crankshaft  
 Filtering: ..... Total flow and by-pass combined system  
 Cooling: ..... Built-in water-oil heat exchanger  
 Oil pressure regulation: ..... Plunger with spring  
 Quantity of lubricant oil (1<sup>st</sup> filling): ..... 14.5 kg (31 lb)

The engine parts are lubricated by a forced circulation using an hydraulic pump. The pump sucks the engine oil from the sump and sends it, under pressure, through an oil filter and the heat exchanger, to a manifold in the cylinder block, to be distributed to the various organs of the engine, before returning to the oil sump. Eventual engine oil pressure malfunctions are signalled by the pressure switch or the filter clogging switch, and an indicator light located on the instrument panel in the operator compartment.




Fig. 1-5 Lubrication system

- |                           |                                 |
|---------------------------|---------------------------------|
| 1. OIL FILLER PLUG        | 9. OUTER OIL RETURN PIPING      |
| 2. ROCKER ARM SHAFT       | 10. LUBRICATION MAIN DUCT       |
| 3. CAMSHAFT               | 11. DELIVERY PIPING             |
| 4. OIL FILTER             | 12. CRANKSHAFT                  |
| 5. LOW PRESSURE SWITCH    | 13. MESH FILTER ON SUCTION LINE |
| 6. TURBO CHARGER          | 14. DRAIN PLUG                  |
| 7. OUTER LUBRICATION DUCT | 15. RELIEF VALVE                |
| 8. OIL DIPSTICK           | 16. OIL PUMP                    |

Carefully read personal and machine SAFETY PRECAUTIONS (at the beginning of this manual)

## OPERATION

The modulating valve in this control valve changes the time required to increase the oil pressure to the clutch engagement value, i.e. it changes the pressure increment curve, in accordance with the transmission speeds, allowing a smooth gear shifting.

The intervention of the modulating valve is represented in the diagram by points **A - E**. The intervention of the solenoid valves and the manual spool (emergency travel spool) is explained in the pages to follow.




Fig. 2-24 Variation curves of clutches engagement oil pressure

3. Move the gear a little outward with a chisel (to engage the puller claw with the gear).




Fig. 2-126

5. Remove the bearing from inside the hub gear with a jig.




Fig. 2-128

4. Remove the hub gear with a puller.




Fig. 2-127

6. Remove the snap ring from the clutch drum inner groove with a screwdriver.

**Warning:** Pay attention to the end plates which might pop out due to the return spring between the plates.




Fig. 2-129

Carefully read personal and machine SAFETY PRECAUTIONS (at the beginning of this manual)

## 2.6.3. Troubleshooting guide


## 2.6.3.1 Torque converter

| Problem                      | Cause                            | Inspection                                             | Corrective Action                 |
|------------------------------|----------------------------------|--------------------------------------------------------|-----------------------------------|
| Overheat or lower horsepower | Low oil level                    | Check oil level with oil level gauge                   | Add oil to the specified level    |
|                              | Improper oil used                | Check oil type                                         | Change for the specified oil      |
|                              | Malfunction of cooler line       | Check cooling water for dirt                           | Clean                             |
|                              | Defective oil seal ring          | Measure oil pressure at inlet port of torque converter | Disassemble and replace parts     |
|                              |                                  | Check breather for oil flash                           | Disassemble and replace parts     |
|                              | Malfunction of safety valve      | Measure oil pressure at inlet port of torque converter | Disassemble and replace parts     |
|                              | Broken bearing                   | Observe foreign material in transmission drain         | Disassemble and replace parts     |
|                              |                                  | Check line filter and oil                              | Disassemble and replace parts     |
|                              | Low discharge from charging pump | Check transmission strainer for clogging               | Clean                             |
|                              |                                  | Measure oil pressure at inlet port of torque converter | Replace pump                      |
|                              |                                  | Measure oil pressure of transmission clutch            | Replace pump                      |
| Oil leak (from flywheel)     | Defective oil baffle oil seal    | Check for oil leak to flywheel                         | Replace parts                     |
|                              | Defective O-ring of oil baffle   | Check for oil leak to flywheel                         | Replace parts                     |
| Unusual noises               | Broken bearing                   | Observe foreign material in transmission drain         | Disassemble and replace           |
|                              |                                  | Check line filter and oil                              | Disassemble and replace parts     |
|                              | Broken gear or improper backlash | Check with sound checker                               | Disassemble and replace parts     |
|                              | Broken pump or drive unit        | Check with sound checker                               | Replace pump                      |
|                              | Air in oil                       | Check oil for air mixed                                | Retighten piping or replace parts |
|                              | Improper oil used                | Check oil type                                         | Change for the specified oil      |
|                              |                                  | Refer to "2.6.3.2 TRANSMISSION"                        |                                   |

Carefully read personal and machine SAFETY PRECAUTIONS (at the beginning of this manual)

The measurement position of the height difference (Y) is shown in Fig. 2-386.

5. Install the selected shim on the axle shaft and the retainer plate in this order. Tighten the bolt.

 65.7 kgm




Fig. 2-386




Fig. 2-388

4. Select a shim which is 0.03 to 0.10 mm thicker than the height difference (Y).




Fig. 2-387

Carefully read personal and machine SAFETY PRECAUTIONS at the beginning of this Manual

### Fig. 4-2 STEERING SYSTEM DIAGRAM

Double feeding pump:  
- Equipment-steering section: Q = 165 ltr/min (LW110), 173 ltr/min (LW130/130TC)  
- Brakes section: Q = 26 ltr/min

1. Main priority valve (setting = 12 bar)  
2. Steering valve OSPL 520 LS  
3. Cushion valve  
4. Safety and anti cavitation valve (setting = 230 - 250 bar)  
5. Valves block OVPL 24  
6. Main relief valve (setting = 175 bar)  
7. Spool  
8. Plug with pressurising valve  
9. Oil filter on return from control valve (10 µ)  
10. By-pass valve on hydraulic oil filter

FROM EQUIPMENT CONTROL VALVE


FROM EQUIPMENT

TO EQUIPMENT VALVE

FROM BRAKE VALVE

TO BRAKE VALVE

1. Double feeding pump:
  - Equipment-steering section:  $Q = 165 \text{ ltr/min}$  (LW110),  $Q = 26 \text{ ltr/min}$  (LW110)
  - Brakes section
2. Main priority valve (setting = 12 bar)
3. Steering valve OSPL 520 LS
4. Steering cylinders
5. Cushion valve
6. Safety and anti cavitation valve (setting = 230 - 250 bar)
12. Valves block OVPL 24
14. Main relief valve (setting = 175 bar)
15. Spool
17. Plug with pressurising valve
18. Oil filter on return from control valve (10  $\mu$ )
19. By-pass valve on hydraulic oil filter



### 6.3.1 INSPECTION AND REPAIR OF EQUIPMENT - STEERING PUMP

When disassembling, mark all components so that they can be re-installed in the correct position.  
After cleaning each individual item, inspect all the parts of the pump.

#### 1) Gear plate

One of the methods to obtain a better volumetric efficiency of a gear pump is a design allowing the end of the teeth stay in contact with the inner wall of the chamber containing the gear itself. Consequently, once the pump starts running, marks left by the gear teeth are shown around the suction port (fig. 6-6)

The contact mark is normal as long as it is less than 1/2 the inner circumference of the gear cavity.

Dimension **a** of the mark depth (fig. 6-7) is normal if it is as about 0.5 mm (.00196 in). When dimension **a** exceeds 0.15 mm (0.00589 in) also the shaft and bearings can wear out. Thus, these items as well, must be thoroughly checked.

If **a** is  $\bullet$  0.15 mm (0.00589 in), replace the pump with a new one.




Fig. 6-6 Gear intermediate plate




Fig. 6-7 Dimension of mark depth

#### 2) Driving and driven gear

In case the shaft or the gear surface shows roughness felt by running a finger nail, or in case the surface of the teeth shows excessive wear zones, it is necessary to replace the item.

If the shaft diameter **d** is less than 31.627 mm (1.2451 in), replace the set of gears with a new one.




Fig. 6-8

### 7.3 CONNECTORS

The connectors (**A-B-C-D**) are located in the lower part of the cab, connecting the main wiring to the logic board (**S**).

The coloured wires arrive from the upper side, the numbered wires from the lower side.


On connectors **A-B-C** (fig. connectors) there are 24

connecting points, whereas on connector **D** (fig. connector **D**) there are 18. The description and the function of each wire on the connector has a corresponding number/colour, as it can be found in the description of each connector.

| Reference on connector | Description - Function    | Colour | Wire |
|------------------------|---------------------------|--------|------|
| 1)                     | SIGNAL BOOM KICKOUT       | —      | 980  |
| 2)                     | SIGNAL BUCKET POSITIONER  | —      | 981  |
| 3)                     | POWER BOOM KICKOUT        | —      | 995  |
| 4)                     | PROXIMITY                 | S-N    | 980  |
| 5)                     | SIGNAL BOOM KICKOUT       | S-G    | 994  |
| 6)                     | POWER BUCKET POSIT. PROX. | V-B    | 981  |
| 7)                     | SIGNAL BUCKET POSITIONER  | V-N    | 103  |
| 8)                     | RIGHT TURNING LIGHT       | A      | 109  |
| 9)                     | LEFT TURNING LIGHT        | L      | 339  |
| 10)                    | LEFT HEAD LIGHT           | G      | 330  |
| 11)                    | RIGHT HEAD LIGHT          | G-N    | 231  |
| 12)                    | LEFT LOW BEAM             | H      | 223  |
| 13)                    | RIGHT LOW BEAM            | H-N    | V    |
| 14)                    | RIGHT HIGH BEAM           | V      | 219  |
| 15)                    | LEFT HIGH BEAM            | V-R    | —    |
| 16)                    | *                         | —      | —    |
| 17)                    | HORN POWER                | C-N    | 138  |
| 18)                    | GND                       | N      | 000  |
| 19)                    | EVENTUAL LTS              | Z-N    | 956  |
| 20)                    | GND EVENTUAL LTS          | B-N    | 954  |
| 21)                    | *                         | —      | —    |
| 22)                    | *                         | —      | —    |
| 23)                    | EMERGENCY STEERING PRESS. | —      | 844  |
| 24)                    | *                         | —      | —    |


\* NOT CONNECTED

CONNECTOR A






Symbol of wires

|     |            |     |        |
|-----|------------|-----|--------|
| C = | Orange     | N = | Black  |
| A = | Light blue | S = | Pink   |
| B = | White      | R = | Red    |
| L = | Blue       | V = | Green  |
| G = | Yellow     | Z = | Violet |
| H = | Grey       |     |        |



A-B-C-D. Connectors

Carefully read personal and machine SAFETY PRECAUTIONS (at the beginning of this manual)

[illegible]

Download full manual at [youfixthis.com](http://youfixthis.com)

# PREVIEW ONLY

You're viewing 18 of 417 pages

---

## The full manual includes:

- All 417 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

---

**GET FULL MANUAL NOW**

**New Holland LW110, LW130, LW130TC Service Manual**



Scan or click anywhere  
[youfixthis.com](https://youfixthis.com)

*Click anywhere on this page to get the full manual*