


2WD-4WD SYSTEM Hydraulic	D.14.C
STEERING Hydraulic	D.20.C
STEERING Autoguidance	D.20.E
SERVICE BRAKE Hydraulic	D.30.C
SERVICE BRAKE Pneumatic	D.30.E
PARKING BRAKE Mechanical	D.32.B
PARKING BRAKE Electronic	D.32.D
BRAKE CONNECTION Hydraulic	D.34.C
SUSPENSION Hydraulic	D.40.C
WHEELS AND TRACKS Wheels	D.50.C
FRAME AND CAB	E
FRAME Primary frame	E.10.B
SHIELD	E.20.A
USER CONTROLS AND SEAT	E.32.A
USER PLATFORM	E.34.A
ENVIRONMENT CONTROL Heating, ventilation and air-conditioning	E.40.D
HITCH AND WORKING TOOL	H
HITCH Front hitch	H.10.B
HITCH Rear hitch	H.10.C
HITCH Electronic draft control	H.10.D


Remote control valve - Disassemble

1. Remove the remote control valve quick release coupling manifolds (1).
The couplers are serviced as an assembly and should not be disassembled.




BVE0474A 1

2. Remove the remote control valve control cable retaining bracket.




BVE0483A 2


3. Remove the remote control valve end cover retaining nuts.
Remove the remote control valve end cover.



BVE0484A 3



SS08N080 17



BRI4416B


BRI4416B-01 18

BEHIND INSTRUMENT CLUSTER

X185 Rotating Beacon Left Hand


POS.	COLOR	WIRE NUMBER	CIRCUIT REFERENCE
1	VT	4012	ROTATING BEACON FEED
2	BK	57	EARTH (ALL)

NOTE: For the wiring color code refer to, **Wiring harness - Identification (A.30.A)**.



SS11C073 7

REAR LEFT HAND CAB ROOF




SS08F177

SS08F177 8

X186 Door Switch Left Hand


POS.	COLOR	WIRE NUMBER	CIRCUIT REFERENCE
1	VT	3052	DOME LAMP TO DOOR SWITCH

NOTE: For the wiring color code refer to, **Wiring harness - Identification (A.30.A)**.



SS08K219 9

TOP REAR LEFT HAND CAB DOOR



BRI4437B

BRI4437B 10


Connector - Component diagram 62

X620 ISO BUS Front

POS.	COLOR	WIRE NUMBER	CIRCUIT REFERENCE
1	BL / OR	5980 / 5970	ISO BUS ECU SIGNAL
2	OR / BL	5970 / 5980	ISO BUS IMPLEMENT SIGNAL
3	PK	2250	PTO FRONT - SUPPLY


NOTE: For the wiring color code refer to, *Wiring harness - Identification (A.30.A)*.

T7.170, T7.185, T7.200, T7.210 Auto Command
T7.170, T7.185, T7.200, T7.210 Range / Power Command - With Sidewinder




SS08K387 1

FRONT RIGHT HAND CAB FLOOR




SS08J065 2

T7.170, T7.185, T7.200, T7.210 Range / Power Command - Without Sidewinder



INA 3

FRONT RIGHT HAND CAB FLOOR





SS08J065 4

X914 SCR Controller

POS.	COLOR	WIRE NUMBER	CIRCUIT REFERENCE
1	BR	9272	24V FUSED SUPPLY
2	BR	9230	ECU B+ OUTPUT (EDC7_)
3	GN	9272	24V FUSED SUPPLY
4	GN	9272	24V FUSED SUPPLY
7	YE	5400	CAN H
8	GN	5420	CAN L
11	OR	9262	ECU TO DOSING VALVE RETURN
12	YE	9261	ECU TO DOSING VALVE
14	BK	57	EARTH (ALL)
15	BK	57	EARTH (ALL)
17	YE	9250	ECU TO CATALYST TEMP SENSOR (UPTREAM) RETURN
18	YE	9246	SIGNAL REDUCTION LEVEL AGENT SENSOR
19	BL	9247	GROUND REDUCTION LEVEL AGENT SENSOR
23	YE	9254	ECU TO BLOW BY 3 WAY VALVE
24	GN	9272	24V FUSED SUPPLY
25	YE	9252	ECU TO CATALYST TEMP SENSOR (DOWNSTREAM) RET
26	YE	9251	ECU TO CATALYST TEMP SENSOR (DOWNSTREAM)
28	YE	9249	ECU TO CATALYST TEMP SENSOR (UPSTEAM)
29	YE	9248	REDUCTION AGENT LEVEL TEMP SENSOR
31	PK	ISOK2	


NOTE: For the wiring color code refer to, **Wiring harness - Identification (A.30.A)**.



LEFT HAND TOP OF FUEL TANK

T7.170, T7.185, T7.200, T7.210 Range Command - With Sidewinder

Component	Connector	Description	
A-080	X950, X952, X953, X954, X955, X956, X957	Universal Controller (UCM)	
B-029	X290	Transmission Oil Temperature Sensor	
B-036	X273	System Oil Pressure Sensor	
R-038	X666	Slow/Fast Potentiometer	
R-039	X667	Med/Rev Potentiometer	
R-005	X002	Clutch Potentiometer	
R-008	X632	Creeper Potentiometer	
S-003	X001	Clutch Switch	
S-090	X012	Park Switch	
S-091	X012	Neutral- Switch	
S-092	X012	Deadman Switch	
S-093	X012	Not Park- Switch	
S-094	X012	FWD- Switch	
S-095	X012	REV- Switch	
Y-039	X631	Creeper Solenoid	
Y-053	X637	Solenoid Clutch C	
Y-054	X638	Solenoid Clutch D	
Y-055	X639	Solenoid Clutch E	
Y-058	X643	High Range Solenoid	
Z-062	X012	Shuttle Lever	
Additional Connectors: X020, X022, X633			
Wire Colour Codes			
BK Black	GN Green	PK Pink	BL Blue
TN Light Brown	BR Brown	OR Orange	LG Light Green
RD Red	GY Grey	LB Light Blue	
WH White	YE Yellow	VT Violet	



Control module Electronic park lock (EPL) controller - Electronic schema

T7.170 AutoCommand, T7.185 AutoCommand, T7.200 AutoCommand, T7.210 AutoCommand, T7.170 Range Command with Sidewinder, T7.170 Power Command with Sidewinder, T7.185 Range Command with Sidewinder, T7.185 Power Command with Sidewinder, T7.200 Range Command with Sidewinder, T7.200 Power Command with Sidewinder, T7.210 Range Command with Sidewinder, T7.210 Power Command with Sidewinder


Component Identification	
1.	Electronic Park Brake (EPL) Unit (Module and Motor assembly)
2.	EPL Motor
3.	Trailer Brake Relay
4.	Sensor Ground
5.	Chassis Ground
6.	Power Ground

Scroll through the available options using the "h" or "m" button.

"Factory" (F) - factory error mode, displays all error codes for a period of 6 minutes then reverts to error code reduction (ECR).

"ECR" (E) - error code reduction mode, only displays critical errors.

"Live" (L) live error code mode, displays all error codes.




BAIL06CCM417AVA

BAIL06CCM417AVA 4

Depress and hold the "h" or "m" button to store the selection, an audible tone will be heard to confirm the selection. Depress the "dimming" button to continue navigating through the "HH" menus.

Steering Sensor Selection Options

Select the steering sensor sub-system by depressing the "dimming" button.




BAIL10CVT215AVA

BAIL10CVT215AVA 5

NOTE: The default setting is "No" without steering sensor.

Scroll through the available options using the "h" or "m" button.

Depress and hold the "h" or "m" button to store the selection, an audible tone will be heard to confirm the selection. Depress the "dimming" button to continue navigating through the "HH" menus.




BAIL10CVT216AVA

BAIL10CVT216AVA 6


Rear EHR Calibration Values

Use the "h", "m" and "dimming" buttons on the instrument cluster to navigate the HH menus to H2 and the rear EHR symbol on the U1 controller.



BAIL10CVT057AVB 13

The lower central display will show "Ch_ _"




BAIL06CCM446AVA

BAIL06CCM446AVA 14

The required channel can be selected by using the "h" and "m" buttons.

After displaying the channel number, the stored calibration value for each lever position is displayed, (refer to the table below for a description of each channel).




BAIL09HHP097AVA

BAIL09HHP097AVA 15


Channel Number	Item		Display	Value Range
Ch 1	Lever number 1	Neutral position	nxxx	520 to 560
		Float position	Fxxx	0 to 20
		Raise position	rxxx	160 to 220
		Lower position	Lxxx	890 to 930
Ch 2	Lever number 2	Neutral position	nxxx	520 to 560
		Float position	Fxxx	0 to 20
		Raise position	rxxx	160 to 220
		Lower position	Lxxx	890 to 930
Ch 3	Lever number 3	Neutral position	nxxx	520 to 560
		Float position	Fxxx	0 to 20
		Raise position	rxxx	160 to 220
		Lower position	Lxxx	890 to 930

Press and hold the downshift button to display the 'Low' position as a percentage of the potentiometer movement. The lower central display will show 'A' followed by a value of approximately **25 %**




BAIL10CVT166AVF 16

Press and hold the upshift button to display the 'High' position as a percentage of the potentiometer movement. The lower central display will show 'C' followed by a value of approximately **75 %**




BAIL10CVT166AVG 17

Press and hold both buttons to return the syncro to the neutral position. The lower central display will show 'n' followed by a value of approximately **50 %**




BAIL10CVT166AVE 18

Release the clutch pedal. If the display shows 'Err' when the clutch pedal is released then depress the pedal and ensure that the low/high synchroniser is in the neutral position.




BAIL10CVT331AVK 19


Install the diagnostic connector **380000843** into the diagnostic socket (1).



Use the "h" "m" and "dimming" buttons on the instrument cluster to navigate the HH menus to H1 and the differential lock symbol on the RY controller. The lower central display will show "CAL".




Press and hold the automatic differential lock switch for two seconds.



The lower central display will show "ScP" followed by the current steering sensor reading.


NOTE: If the display indicates the number "-1", the steering angle sensor option must be activated with the H3 menu, before the steering angle sensor can be calibrated, for further information refer to **Control module Central Control Unit - H3 - Configurations and options (A.50.A)**.

NOTE: If the display shows "-2" then this indicates an error with the steering angle sensor input to the instrument cluster. Review associated instrument cluster error codes to determine the fault.



Turn the steering wheel so the front wheels are in line with the driveline.

The lower central display will display "ch - -".



BAIL06CCM534AVA

BAIL06CCM534AVA 3

The required channel can be selected by using the "h" and "m" buttons.


Refer to the table below for the available channels.

After a delay the value will be displayed.

Channel	Description	Typical Reading	Notes
0	Not used		
1	Not used		
2	Not used		
3	Not used		
4	Not used		
5	Not used		
6	Not used		
7	Not used		
8	Not used		


Depress the "dimming" button to continue navigating through the "HH" menus.

26. Remove the right-hand fuel tank retaining straps.



BAIL10CVT516AVA 23

27. Remove the right-hand fuel tank retaining bolt.



BAIL10CVT517AVA 24


28. Remove the selective catalytic reduction (SCR) muffler, for additional information refer to **Selective Catalytic Reduction (SCR) SCR muffler - Remove (B.40.B)**.

29. **⚠ WARNING**

Heavy objects!
Lift and handle all heavy components using lifting equipment with adequate capacity. Always support units or parts with suitable slings or hooks. Make sure the work area is clear of all bystanders. Failure to comply could result in death or serious injury.


W0398A

With the aid of an assistant or suitable lifting equipment, remove the SCR muffler mounting bracket.




BAIL10CVT518AVA 25

30. With the aid of an assistant or trolley jack remove the right-hand fuel tank.



BAIL10CVT519AVA 26


12. Manoeuvre the reversible fan and shroud to the left-hand side of the vehicle to allow the reversible fan to be removed.



BAIL10CVT559AVA 12


PREVIEW - YOUFIXTHIS.COM

9. Install a new master clutch housing seal.




BAIL08APH010AVA 9

10. When installing the centering springs in step 11, make sure that:
- the open ends of the springs (1) are all aligned with the same tooth in the clutch housing
 - the ends of the springs are oriented towards the piston (2)
 - the locating pin (3) fits into the groove




BAIL08APH157FVB 10



Gear level F1

The power train from the summing planetary gear / planetary carrier via the gear wheel pair (**F1**) to clutch (**B**) is engaged. The swivel angle of the swash plate in the hydrostat is adjusted in the direction of the positive swivel angle (+) in order to increase the travelling speed.



BSD2302A 29
PTO Clutch Assembly

- | | |
|-------------------------------|-----------------------------|
| 1 End Plate | 2 Spring Separator |
| 3 Clutch Plate | 4 Clutch Plate Separator |
| 5 Bearing | 6 Circlip |
| 7 Spacer | 8 Drive Gear 540 rpm |
| 9 Circlip | 10 Spacer |
| 11 Drive Gear 1000 rpm | 12 Retainer |
| 13 Bearing | 14 Sealing Rings (3 off) |
| 15 Clutch Housing | 16 Piston |
| 17 Washer | 18 Belleville Springs |
| 19 Spacer | 20 Retaining Ring |
| 21 Hub | 22 Retaining Ring |

Next operation:

Adjust the PTO brake band, for further information, refer to **PTO brake - Adjust (C.40.C)**.

Next operation:

Adjust the PTO speed selection, for further information, refer to **REAR PTO Mechanical - Adjust (C.40.B)**.




SERVICE MANUAL

AXLES, BRAKES AND STEERING




**T7.170 AutoCommand , T7.170 Power Command , T7.170 Range Command ,
T7.185 AutoCommand , T7.185 Power Command , T7.185 Range Command ,
T7.200 AutoCommand , T7.200 Power Command , T7.200 Range Command ,
T7.210 AutoCommand , T7.210 Power Command , T7.210 Range Command**

10. Using special tool **380000268 (1)** to hold the pinion nut and special tool **380000257 (2)** to rotate the pinion counter clockwise, slowly tighten the pinion to **392 N·m (289 lb ft)**.



BAIL08APH166AVA 10


11. Using a suitable torque wrench, check that the rolling torque of the pinion shaft bearings is between **0.49 N·m (0.3614 lb ft)** and **0.98 N·m (0.7228 lb ft)**.



BAIL08APH162AVA 11


12. Stake the pinion nut.

13. Using special tool **380200042 (1)**, install the pinion shaft seal **(2)**.



BAIL08APH175AVA 12

14. Using special tool **380200041 (1)**, install the pinion shaft seal protector **(2)**.



BAIL08APH176AVA 13

Assemble	52
Remove - 4WD Clutch removal without splitting the transmission	55
Install 4WD Clutch Installation Procedure	62


DIAGNOSTIC

2WD-4WD SYSTEM Hydraulic

Troubleshooting	76
-----------------------	----

PREVIEW - YOUFIXTHIS.COM


7. Loosen the relevant bleed nipple (right-hand side shown).



BAIL11CCM195AVA 7

8. Install the piston into the rear axle housing.


NOTICE: Soak the piston assembly in transmission oil before installation.



BAIL09APH220BVC 8

9. Measure the distance between the outer face of the piston and the mating surface of the rear axle housing (P).

NOTICE: If measurement (P) is less than 11 mm the piston has not seated correctly.



BAIL09APH225AVA 9


Symbol on display	Indicator light	Warning light	Acoustic warning	Cause	Signal
	-	-	Action required	Electrical park brake (EPL) is not engaged. Request to engage park brake - see TRANSMISSION Continuously Variable Transmission (CVT) - Dynamic description (C.20.G)	CAN message from EPL
	-	-	Action required	Electrical park brake (EPL) is not disengaged. Request to disengage park brake.	CAN message from EPL
		 illuminates	Non-critical	The automatic engagement of the EPL was deactivated for towing the tractor.	CAN message from UCM CAN message from TCM
		 flashes 4 s/ illuminates	Non-critical	Pressure in air brake container: < 5.4 bar (78.3 psi) warning "on" > 6 bar (87 psi) warning "off". Or equipped with hydr. trailer brake, Italy version: hydraulic pressure < 10 bar (145 psi)	Switch in sensor *B-040 switches to ground < 5.4 bar (78.3 psi) . (*B-040 pressure sensor for air brake system) ground *S-027 (*S-027 brake line pressure switch 1/2)
	-	 flashes 4 s/ illuminates	-	Brake fluid too low: Tractor moving > 2 min Tractor stationary > 5 s	+ 12 V *S-029 (*S-029 switch, brake fluid level)
	-	 flashes	Critical	Hydraulic pressure for brake force amplification too low: This warning is displayed if the engine is running and the pressure is < 15 bar (217.5 psi) .	+ 12 V *S-008 (*S-008 switch, exhaust brake)
		 flashes	-	Hydraulic pressure for brake force amplification too low: This warning is displayed if the engine is turned off and the pressure is < 15 bar (217.5 psi) .	+ 12 V *S-008 (*S-008 switch, exhaust brake)

Transmission

Symbol on display	Indicator light	Warning light	Acoustic warning	Cause	Signal
	-	-	Action required	Transmission oil too cold. Heat transmission oil - see TRANSMISSION Continuously Variable Transmission (CVT) - Dynamic description (C.20.G)	CAN message from UCM CAN message from TCM
Cp	-	-	Action required	Driver's seat switch was disengaged for more than 5 s and driver attempts to select a direction of travel. Press clutch pedal once.	CAN message from UCM CAN message from TCM


Assembly

4. Fit the heat valve using the mounting screws (3). Attach the connector to the electric heat valve (2).



SS08D020 4


5. Mount the cover plate of the heating and air conditioning unit.



BAIS06CCM383AVA

BAIS06CCM383AVA 5

6. Fit the cab heating hoses (1).



SS08D110 6

Next operation:

Install the heating and air conditioning unit - see **ENVIRONMENT CONTROL Heating, ventilation and air-conditioning - Install (E.40.D)**. To do this, carry out only Step 4 and Step 8 and Steps 20 to 23.

PREVIEW ONLY

You're viewing 25 of 3129 pages

The full manual includes:

- All 3129 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

New Holland T7.170, T7.185, T7.200, T7.210 Service Manual



Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual