Instructions for Parts Books

The heading at the top of the page will be the same for the picture of the parts at it is for the page with the part numbers.

Definition of column headings on part number pages:

REF.No → The number refering to the part on the picture page of the parts book.

Part No. → The number assigned to this part at the time of printing the parts book.

Description → Discription of part.

Q'ty → Quanity of part used on that page.

S.No. → Serial number range of the equipment that this part will fit.
>= Your serial number should be greater than or equal to the number shown.
<= Your serial number should be lesser than or equal to the serial number shown.

I/C → Interchangeability of part shown.
←→ The part shown will work for the older and later serial number.
The part shown is not interchangable with the other serial number.
← new for old
→ old for new

Remarks → Notes about this particulart part. Sometimes this may say except [FR] or [CA]

Note about Country Codes:

The parts books we use in the United States of America may also contain information about a part that would be different in another country. It is important that you are aware of the country codes in some instances.

Symbol	Country
A	United States of America
CA	Canada
FR	France
GR	Greece
PO	Portugal
AU	Australia

If the remarks column says for example EXCEPT [FR] this part works in all countries except France.
That means it will work here in the USA.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Item	Part No.	Description	Book
ENGINE	01E001	CRANKCASE	100K0098
	01E002	CRANKCASE	100K0098
	01E003	OIL PAN	100K0098
	01E004	CYLINDER HEAD	100K0098
	01E005	GEAR CASE	100K0098
	01E006	GEAR CASE	100K0098
	01E007	MAIN BEARING CASE	100K0098
	01E008	CYLINDER HEAD COVER	100K0098
	01E009	MANIFOLD	100K0098
	01E010	VALVE/ROCKER ARM	100K0098
	01E011	CAMSHAFT	100K0098
	01E012	PISTON/CRANKSHAFT	100K0098
	01E013	FLYWHEEL	100K0098
	01E014	INJECTION PUMP	100K0098
	01E015	NOZZLE HOLDER	100K0098
	01E016	ENGINE STOP LEVER	100K0098
	01E017	SPEED CONTROL PLATE	100K0098
	01E018	GOVERNOR	100K0098
	01E019	HYDRAULIC PUMP	100K0098
	01E020	DYNAMO	100K0098
	01E021	DYNAMO	100K0098
	01E022	WATER FLANGE	100K0098
	01E023	WATER PUMP	100K0098
	01E024	INJECTION PUMP [SECTION PARTS]	100K0098
	01E025	NOZZLE HOLDER [SECTION PARTS]	100K0098
	01E026	DYNAMO [SECTION PARTS]	100K0098
	01E027	DYNAMO [SECTION PARTS]	100K0098
	01E028	HYDRAULIC PUMP [SECTION PARTS]	100K0098
TRANSMISSION	01T001	TRANSMISSION CASE	100K0098
	01T002	PTO COVER	100K0098
	01T003	COVER	100K0098
	01T004	CASE COVER	100K0098
REAR AXLE/REAR WHEEL	01T005	REAR AXLE CASE	100K0098
CLUTCH	01T006	CLUTCH ROD	100K0098
	01T007	CLUTCH	100K0098
TRANSMISSION	01T008	2ND SHAFT	100K0098
	01T009	3RD SHAFT	100K0098
	01T010	4TH SHAFT,5TH SHAFT	100K0098
	01T011	SPIRAL BEVEL SHAFT	100K0098
	01T012	PTO SHAFT	100K0098
	01T013	REVERSE SHAFT	100K0098
REAR AXLE/REAR WHEEL	01T014	REAR DIFFERENTIAL	100K0098
	01T015	REAR AXLE	100K0098
	01T017	REAR WHEEL (7-16)	100K0098
	01T018	REAR WHEEL (8-16)	100K0098
	01T019	REAR WHEEL (29 X 12.00-15)	100K0098
	01T021	REAR WHEEL HUB	100K0098
SPEED CHANGE LEVER	01T022	SPEED CHANGE FORK	100K0098
	01T023	MAIN SPEED CHANGE	100K0098
	01T024	AUX. SPEED CHANGE	100K0098
	01T025	ROTARY SPEED CHANGE FORK	100K0098
BRAKE	01T026	BRAKE	100K0098
HYDRAULIC SYSTEM	01T028	HYDRAULIC PIPE	100K0098
	01T029	HYDRAULIC BLOCK	100K0098
	01T031	HYDRAULIC 2	100K0098
STEERING	01T032	STEERING	100K0098
SPEED CHANGE LEVER	01T033	SPEED CHANGE LEVER	100K0098
BRAKE	01T034	BRAKE ROD	100K0098
	01T035	PEDAL	100K0098
TRANSMISSION	01T036	RELEASE ROD	100K0098

PREVIEW ONLY YOUFIXTHIS.COM
Download full manual at youfixthis.com

CRANKCASE


S.No.;<=369054

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	15381-01010	COMP.CRANKCASE	1				0	0
020	06311-75015	PLUG	3				0.002	0.0044
030	06311-75040	PLUG	1				0.02	0.044
040	15321-96260	CAP,SEALING	5				0.014	0.0308
050	15221-03490	CAP,SEALING	1				0.02	0.044
060	15261-96010	PLUG	6				0.002	0.0044
070	15521-96020	PLUG	3				0.003	0.0066
080	15521-96030	PLUG	1				0.007	0.0154
090	05012-00609	PIN,STRAIGHT	2				0.003	0.0066
100	05012-00814	PIN,STRAIGHT	2				0.006	0.0132
110	15221-33650	PIN,PIPE	1				0.004	0.0088
120	15231-33960	PIN,PIPE	2				0.001	0.0022
130	15221-72880	PIPE,WATER	1				0.115	0.253
140	15901-02310	LINER,CYLINDER	3				0.398	0.8756
150	15221-33700	O RING	1				0.001	0.0022
160	15261-73910	COVER,WATER	1				0.13	0.286
170	15261-73920	GASKET,WATER COVER	1				0	0
180	01023-50618	BOLT	2				0.006	0.0132
190	15261-35010	ASSY PUMP,OIL	1				0.32	0.704
200	15261-35150	GASKET,OIL PUMP	1				0	0
210	15261-91022	BOLT	4				0.012	0.0264
220	15954-35660	GEAR,OIL PUMP DRIVE	1				0.14	0.308
230	05712-00410	KEY,FEATHER	1				0.001	0.0022
240	02016-50100	NUT	1				0.009	0.0198
250	04211-50100	WASHER,CLAW	1				0.002	0.0044
260	15231-39010	SWITCH,OIL	1				0	0


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW ONLY FIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Item	Part No.	Description	Book
HOOD (BONNET)/CHASSIS	01T037	SEAT	100K0098
LABELS	01T038	LABEL	100K0098
CLUTCH	01T039	CLUTCH HOUSING/STEP/STARTER	100K0098
HOOD (BONNET)/CHASSIS	01T040	FRONT AXLE FRAME	100K0098
COOLING WATER SYSTEM	01T041	RADIATOR	100K0098
HOOD (BONNET)/CHASSIS	01T042	FENDER	100K0098
	01T043	HOOD	100K0098
ELECTRICAL SYSTEM	01T044	BATTERY	100K0098
ENGINE	01T046	MUFFLER AND MUFFLER PIPE [A],[CA]	100K0098
FUEL SYSTEM	01T047	FUEL TANK	100K0098
	01T048	FUEL PIPE	100K0098
	01T049	FUEL FILTER	100K0098
ELECTRICAL SYSTEM	01T050	PANEL	100K0098
	01T051	PANEL SWITCH	100K0098
FUEL SYSTEM	01T052	DECOMPRESS WIRE AND ENGINE STOP WIRE	100K0098
ELECTRICAL SYSTEM	01T053	FLASHER LIGHT/TAIL LIGHT/HEAD LAMP	100K0098
FUEL SYSTEM	01T054	AIR CLEANER	100K0098
FRONT AXLE/FRONT WHEEL	01T060	FRONT AXLE CASE	100K0098
	01T061	FRONT GEAR CASE	100K0098
	01T062	KNUCKLE ARM	100K0098
	01T063	FRONT DIFFERENTIAL	100K0098
	01T064	FRONT WHEEL HUB	100K0098
	01T065	DRIVE SHAFT	100K0098
	01T073	FRONT WHEEL (6-12B) B6200D-GP-[A][CA], B7200D-P-[A][AU]	100K0098
	01T074	FRONT WHEEL (5-12) B6200D-P-[A]	100K0098
	01T079	FRONT WHEEL (20.5 X 8.00-10)	100K0098
HYDRAULIC SYSTEM	01T080	3-POINT LINKAGE	100K0098
ELECTRICAL SYSTEM	01T081	DYNAMO 1 [OPTION]	100K0098
	01T082	DYNAMO 2 [OPTION]	100K0098
HYDRAULIC SYSTEM	01T084	HYDRAULIC OUTLET [OPTION]	100K0098
ENGINE	01T085	HORIZON MUFFLER [OPTION]	100K0098
ELECTRICAL SYSTEM	01T086	WORKING LIGHT [OPTION]	100K0098
TRANSMISSION	01T087	FLANGE F.PTO [OPTION]	100K0098
HYDRAULIC SYSTEM	01T090	CONTROL VALVE [SECTION PARTS]	100K0098
ELECTRICAL SYSTEM	01T091	STARTER [SECTION PARTS]	100K0098
	01T092	DYNAMO [SECTION PARTS]	100K0098
ACCESSORIES	01T095	ACCESSORIES AND SERVICE PARTS	100K0098

PREVIEW YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 12 of 198 pages

The full manual includes:

- All 198 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Kubota B6200D Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual