Instructions for Parts Books

The heading at the top of the page will be the same for the picture of the parts at it is for the page with the part numbers.

Definition of column headings on part number pages:

REF.No → The number refering to the part on the picture page of the parts book.

Part No. → The number assigned to this part at the time of printing the parts book.

Description → Discription of part.

Q'ty → Quanity of part used on that page.

S.No. → Serial number range of the equipment that this part will fit.
>= Your serial number should be greater than or equal to the number shown.
<= Your serial number should be lesser than or equal to the serial number shown.

I/C → Interchangeability of part shown.
←→ The part shown will work for the older and later serial number.
The part shown is not interchangable with the other serial number.
← new for old
→ old for new

Remarks → Notes about this particulart part. Sometimes this may say except [FR] or [CA]

Note about Country Codes:


The parts books we use in the United States of America may also contain information about a part that would be different in another country. It is important that you are aware of the country codes in some instances.

Symbol	Country
A	United States of America
CA	Canada
FR	France
GR	Greece
PO	Portugal
AU	Australia

If the remarks column says for example EXCEPT [FR] this part works in all countries except France.
That means it will work here in the USA.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



LABEL


ACCESSORIES AND SERVICE PARTS

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


Item	Part No.	Description	Book
ENGINE	01E001	CRANKCASE	100K0326
	01E002	OIL PAN	100K0326
	01E003	CYLINDER HEAD	100K0326
	01E004	GEAR CASE	100K0326
	01E005	OIL FILTER	100K0326
	01E006	MAIN BEARING CASE	100K0326
	01E007	MANIFOLD	100K0326
	01E008	VALVE AND ROCKER ARM	100K0326
	01E009	CYLINDER HEAD COVER	100K0326
	01E010	CAMSHAFT	100K0326
	01E011	PISTON AND CRANKSHAFT	100K0326
	01E012	FLYWHEEL AND STARTER	100K0326
	01E013	INJECTION PUMP	100K0326
	01E014	FUEL CAMSHAFT	100K0326
	01E015	NOZZLE AND GLOW PLUG	100K0326
	01E016	GOVERNOR	100K0326
	01E017	SPEED CONTROL PLATE	100K0326
	01E018	COMPENSATOR	100K0326
	01E019	IDLING APPARATUS	100K0326
	01E020	DYNAMO AND FAN	100K0326
	01E021	THERMOSTAT	100K0326
	01E022	WATER PUMP	100K0326
ELECTRICAL SYSTEM	01T005	BATTERY SUPPORT	100K0326
FRONT AXLE	01T006	FRONT AXLE BRACKET	100K0326
CLUTCH	01T007	CLUTCH (DUAL CLUTCH)	100K0326
	01T008	CLUTCH (SINGLE CLUTCH)	100K0326
	01T009	CLUTCH LEVER (DUAL CLUTCH)	100K0326
	01T010	CLUTCH LEVER (SINGLE CLUTCH)	100K0326
	01T011	CLUTCH PEDAL (DUAL CLUTCH)	100K0326
	01T012	CLUTCH PEDAL (SINGLE CLUTCH)	100K0326
	01T013	CLUTCH PEDAL STOPPER (DUAL CLUTCH)	100K0326
STEERING	01T014	POWER STEERING	100K0326
	01T01401	POWER STEERING (SECTION PARTS)	100K0326
	01T015	STEERING WHEEL TILT LEVER	100K0326
	01T016	STEERING WHEEL	100K0326
	01T017	DRAG LINK	100K0326
	01T018	POWER STEERING OIL LINE (MANUAL SHUTTLE)	100K0326
	01T019	POWER STEERING OIL LINE (HYD.SHUTTLE)	100K0326
	01T020	POWER STEERING OIL TANK	100K0326
ENGINE CONTROL	01T021	THROTTLE LEVER	100K0326
	01T022	THROTTLE PEDAL	100K0326
CHASSIS	01T023	FRONT ROOF	100K0326
	01T024	FRONT GRILLE	100K0326
	01T025	HOOD 1	100K0326
	01T026	HOOD 2	100K0326
	01T027	SEAT	100K0326
	01T028	HOOD CUSHION	100K0326
CLUTCH	01T029	MAIN CLUTCH CASE	100K0326
TRANSMISSION	01T030	MAIN S-CHANGE CASE	100K0326
	01T031	1 ST SHAFT (MANUAL SHUTTLE)	100K0326
	01T032	1 ST SHAFT (HYDRAULIC SHUTTLE)	100K0326
	01T033	2 ND SHAFT (MANUAL SHUTTLE)	100K0326
	01T034	2 ND SHAFT (HYDRAULIC SHUTTLE)	100K0326
	01T035	MAIN SHAFT	100K0326
	01T036	COUNTER SHAFT	100K0326
	01T037	HI-LO S-CHANGE SHAFT	100K0326
PTO	01T038	PTO SHAFT	100K0326
TRANSMISSION	01T039	TRANSMISSION CASE	100K0326
	01T040	REAR DIFFERENTIAL	100K0326
	01T041	DIFF.BEARING SUPPORT	100K0326

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Item	Part No.	Description	Book
TRANSMISSION	01T042	SPEED CHANGE COVER	100K0326
	01T043	SHIFT FORK	100K0326
	01T044	MAIN GEAR SHIFT LEVER	100K0326
	01T045	HI-LO GEAR SHIFT LEVER	100K0326
PTO	01T046	PTO GEAR SHIFT LEVER	100K0326
TRANSMISSION	01T047	SHUTTLE SHIFT LEVER (MANUAL)	100K0326
	01T048	SHUTTLE SHIFT LEVER (HYDRAULIC)	100K0326
	01T049	DIFF.LOCK PEDAL	100K0326
REAR AXLE	01T050	PLANETARY GEAR	100K0326
	01T051	REAR AXLE	100K0326
BRAKE	01T052	BRAKE	100K0326
	01T053	BRAKE PEDAL	100K0326
	01T054	PARKING BRAKE LEVER	100K0326
CHASSIS	01T055	FENDER	100K0326
	01T056	FLOOR SEAT	100K0326
	01T057	STEP	100K0326
ELECTRICAL SYSTEM	01T058	PANEL BOARD	100K0326
	01T059	SWITCH AND REGURATOR	100K0326
	01T060	LIGHT	100K0326
	01T061	BATTERY	100K0326
	01T062	ELECTRICAL WIRING	100K0326
ENGINE CONTROL	01T063	FUEL TANK	100K0326
	01T064	FUEL TANK SUPPORT	100K0326
	01T065	FUEL LINE	100K0326
	01T066	FUEL FILTER	100K0326
	01T067	FUEL FILTER (SECTION PARTS)	100K0326
HYDRAULIC SYSTEM	01T068	RELIEF VALVE	100K0326
	01T069	HYDRAULIC CYLINDER	100K0326
	01T070	HYDRAULIC CYLINDER COVER	100K0326
	01T071	LIFT ARM	100K0326
	01T072	HYDRAULIC CONTROL VALVE	100K0326
	01T073	FEED BACK LEVER	100K0326
	01T074	DRAFT CONTROL VALVE	100K0326
	01T075	DRAFT CONTROL VALVE (SECTION PARTS)	100K0326
	01T076	DRAFT AND POSITION LEVER 1	100K0326
	01T077	DRAFT AND POSITION LEVER 2	100K0326
	01T078	FLEXIBLE SHAFT	100K0326
	01T079	TOP LINK BRACKET	100K0326
	01T080	HYDRAULIC PUMP (MANUAL SHUTTLE)	100K0326
	01T081	HYDRAULIC PUMP (HYDRAULIC SHUTTLE)	100K0326
	01T082	HYDRAULIC OIL LINE (SUCTION)	100K0326
	01T083	HYDRAULIC OIL LINE (DELIVERY MANUAL SHUTTLE)	100K0326
	01T084	HYDRAULIC OIL LINE (DELIVERY HYD.SHUTTLE)	100K0326
	01T085	HYDRAULIC SHUTTLE OIL LINE	100K0326
	01T086	HYDRAULIC SHUTTLE VALVE	100K0326
	01T087	HYDRAULIC SHUTTLE VALVE (SECTION PARTS 1)	100K0326
	01T088	HYDRAULIC SHUTTLE VALVE (SECTION PARTS 2)	100K0326
	01T089	SWING DRAWBAR	100K0326
ENGINE CONTROL	01T090	MUFFLER	100K0326
	01T091	AIR CLEANER (DOUBLE)	100K0326
	01T092	AIR CLEANER (SECTION PARTS)	100K0326
	01T093	RADIATOR	100K0326
	01T094	ENGINE STOP SOLENOID	100K0326
LABEL	01T095	LABEL 1	100K0326
	01T096	LABEL 2	100K0326
HYDRAULIC SYSTEM	01T097	3-POINT LINKAGE 1	100K0326
	01T098	3-POINT LINKAGE 2	100K0326

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	32530-14600	ASSY PLATE PRESSURE	1				11.5	25.3
020	32530-14300	COMP.DISK CLUTCH	1				0	0
030	01123-50820	BOLT	12				0.011	0.0242
040	05012-00612	PIN STRAIGHT	2				0.003	0.0066

PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	32530-20180	GEAR	1				1.25	2.75
020	32530-20190	GEAR	1				0.88	1.936
030	32530-20210	SHAFT	1				0	0
040	03410-50606	SCREW	2				0.001	0.0022
050	08101-06206	BEARING BALL	1				0.196	0.4312
060	08151-06206	BEARING BALL	1				0.2	0.44
070	38450-21990	COLLAR	1				0	0
080	38430-25540	CIR-CLIP EXTERNAL	1				0.004	0.0088
090	32530-20220	BEARING NEEDLE	2				0.05	0.11
100	32530-20230	RACE INNER	2				0.04	0.088
110	32530-20470	COLLAR THRUST	4				0.04	0.088
120	32530-20240	CASE CLUTCH	1				2.39	5.258
130	35370-14240	DISK CLUTCH	10				0.06	0.132
140	35370-14250	STEEL PLATE	10				0	0
150	32530-20250	PLATE	2				0.1	0.22
160	35370-14270	CIR-CLIP INTERNAL	2				0.05	0.11
170	35370-14190	PISTON	2				0.43	0.946
180	35370-14210	O RING	2				0.005	0.011
190	32530-20290	SPRING	2				0.11	0.242
200	35370-14230	WASHER	2				0.03	0.066
210	04612-00480	CIR-CLIP EXTERNAL	2				0.002	0.0044
220	32530-20270	SEALING	3				0.002	0.0044
230	32530-20280	CASE SEAL	1				0.83	1.826
240	07715-03207	BALL	3				0.001	0.0022
250	04811-10560	O RING	1				0.002	0.0044
260	04811-00080	O RING	3				0.001	0.0022
270	01123-50825	BOLT	3				0.013	0.0286
280	01123-50845	BOLT	1				0.02	0.044


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW BY YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 12 of 275 pages

The full manual includes:

- All 275 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Kubota L4150DT Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual