
OPERATOR'S MANUAL

ENGLISH

KUBOTA
DIESEL ENGINE

MODELS **V3600-E3 · V3600-T-E3 · V3800-DI-T-E3 · V3300-E3BG · V3600-T-E3BG · V3800-DI-T-E3BG**



B-1554

1J411-8911-4

READ AND SAVE THIS MANUAL

Download full manual at youfixthis.com

Kubota

REVIEW - YOUFIXTHIS.COM

ENGLISH

CONTENTS

⚠SAFE OPERATION 1

SERVICING OF THE ENGINE 1

NAMES OF PARTS 2

PRE-OPERATION CHECK 3
- BREAK-IN 3
- DAILY CHECK 3

OPERATING THE ENGINE 4
- STARTING THE ENGINE(NORMAL) 4
- COLD WEATHER STARTING 5
- STOPPING THE ENGINE 6
- CHECKS DURING OPERATION 6
  - Radiator Cooling water(Coolant) 6
  - Oil pressure lamp 6
  - Charge lamp 6
  - Fuel 7
  - Color of exhaust 7
  - Immediately stop the engine if; 7
- REVERSED ENGINE REVOLUTION AND REMEDIES 7
  - How to tell when the engine starts running backwards 7
  - Remedies 7

MAINTENANCE 8
- SERVICE INTERVALS 9

PERIODIC SERVICE 12
- FUEL 12
  - Fuel level check and refueling 12
  - Air bleeding the fuel system 13
  - Checking the fuel pipes 14
  - Cleaning the fuel filter pot 14
  - Fuel filter cartridge replacement 15
- ENGINE OIL 15
  - Checking oil level and adding engine oil 15
  - Changing engine oil 16
  - Replacing the oil filter cartridge 17
- RADIATOR 17
  - Checking coolant level, adding coolant 18
  - Changing coolant 19
  - Remedies for quick decrease of coolant 19
  - Checking radiator hoses and clamp 19
  - Precaution at overheating 19
  - Cleaning radiator core(outside) 19
  - Anti-freeze 20
  - Radiator cement 20

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


SAFE OPERATION

Careful operation is your best assurance against an accident. Read and understand this section carefully before operating the engine. All operators, no matter how much experience they may have, should read this and other related manuals before operating the engine or any equipment attached to it. It is the owner's obligation to provide all operators with this information and instruct them on safe operation.

Be sure to observe the following for safe operation.

1. OBSERVE SAFETY INSTRUCTIONS

- Read and understand carefully this "OPERATOR'S MANUAL" and "LABELS ON THE ENGINE" before attempting to start and operate the engine.
- Learn how to operate and work safely. Know your equipment and its limitations. Always keep the engine in good condition.
- Before allowing other people to use your engine, explain how to operate and have them read this manual before operation.
- DO NOT modify the engine. UNAUTHORIZED MODIFICATIONS to the engine may impair the function and/or safety and affect engine life. If the engine does not perform properly, consult your local Kubota Engine Distributor first.



1AAACAAAP008B

2. WEAR SAFE CLOTHING AND PERSONAL PROTECTIVE EQUIPMENT (PPE)

- DO NOT wear loose, torn or bulky clothing around the machine that may catch on working controls and projections or into fans, pulleys and other moving parts causing personal injury.
- Use additional safety items-PPE, e.g. hard hat, safety protection, safety goggles, gloves, etc., as appropriate or required.
- DO NOT operate the machine or any equipment attached to it while under the influence of alcohol, medication, or other drugs, or while fatigued.
- DO NOT wear radio or music headphones while operating the engine.


1AEAAAAAP0130

REVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

ENGLISH

OPERATING THE ENGINE

STARTING THE ENGINE(NORMAL)

CAUTION


To avoid personal injury:

- **Do not allow children to approach the machine while the engine is running.**
- **Be sure to install the machine on which the engine is installed, on a flat place.**
- **Do not run the engine on gradients.**
- **Do not run the engine in an enclosed area. Exhaust gas can cause air pollution and exhaust gas poisoning.**
- **Keep your hands away from rotating parts (such as fan, pulley, belt, flywheel etc.) during operation.**
- **Do not operate the machine while under the influence of alcohol or drugs.**
- **Do not wear loose, torn or bulky clothing around the machine. It may catch on moving parts or controls, leading to the risk of accident. Use additional safety items, e.g. hard hat, safety boots or shoes, eye and hearing protection, gloves, etc., as appropriate or required.**
- **Do not wear radio or music headphones while operating engine.**
- **Check to see if it is safe around the engine before starting.**
- **Reinstall safeguards and shields securely and clear all maintenance tools when starting the engine after maintenance.**

IMPORTANT :

- Do not use ether or any starting fluid for starting the engine, or a severe damage will occur.
- When starting the engine after a long storage (of more than 3 months), first set the stop lever to the "STOP" position and then activate the starter for about 10 seconds to allow oil to reach every engine part.


1. Set the fuel lever to the "ON" position.



(1) Fuel lever
(A) "ON"
(B) "OFF"

2. Place the engine stop lever to the "START" position.

3. Place the speed control lever at more than half "OPERATION".



(1) Speed control lever
(2) Engine stop lever
(A) "IDLING"
(B) "OPERATION"
(C) "START"
(D) "STOP"

REVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


ENGLISH


MAINTENANCE

CAUTION

To avoid personal injury:

- **Be sure to conduct daily checks, periodic maintenance, refueling or cleaning on a level surface with the engine shut off and remove the key.**
- **Before allowing other people to use your engine, explain how to operate, and have them read this manual before operation.**
- **When cleaning any parts, do not use gasoline but use regular cleanser.**
- **Always use proper tools, that are in good condition. Make sure you understand how to use them, before performing any service work.**
- **When installing, be sure to tighten all bolts lest they should be loose. Tighten the bolts by the specified torque.**
- **Do not put any tools on the battery, or battery terminals may short out. Severe burns or fire could result. Detach the battery from the engine before maintenance.**
- **Do not touch muffler or exhaust pipes while they are hot; Severe burns could result.**


1ABAAAAAP1270


1ABAAAAAP1280

REVIEW.YOUFIXTHIS.COM

Download full manual at youfixthis.com

ENGLISH

TROUBLESHOOTING

If the engine does not function properly, use the following chart to identify and correct the cause.

■When it is difficult to start the engine

Cause	Countermeasures
Fuel is thick and doesn't flow.	* Check the fuel tank and fuel filter. * Remove water, dirt and other impurities. * As all fuel will be filtered by the filter, if there should be water or other foreign matters on the filter, clean the filter with kerosene.
Air or water mixed in fuel system	* If air is in the fuel filter or injection lines, the fuel pump will not work properly. * To attain proper fuel injection pressure, check carefully for loosened fuel line coupling, loose cap nut, etc. * Loosen joint bolt stop fuel filter and air vent screws of fuel injection pump to eliminate all the air in the fuel system.
Engine oil becomes thick in cold weather and engine cranks slow.	* Change grade of oil according to the weather (temperature.)
Battery is discharged and the engine will not crank.	* Charge battery. * In winter, always remove battery from machine, charge fully and keep indoors. Install in machine at time of use.

■When output is insufficient

Cause	Countermeasures
Fuel is insufficient.	* Check fuel system.
Overheating of moving parts	* Check lubricating oil system. * Check to see if lubricating oil filter is working properly. * Filter element deposited with impurities would cause poor lubrication. Change element.
Air cleaner is dirty	* Clean the element every 100 hours of operation.
Injection pump wear	* Do not use poor quality fuel as it will cause wear of the pump. Only use No. 2-D diesel fuel. (See "**FUEL**" in "**PERIODIC SERVICE**" section.)

■When engine suddenly stops

Cause	Countermeasures
Lack of fuel	* Check the fuel tank and refill the fuel, if necessary. * Also check the fuel system for air or leaks.
Bad nozzle	* If necessary, replace with a new nozzle.
Moving parts are overheated due to shortage of lubrication oil or improper lubrication.	* Check amount of engine oil with oil level gauge. * Check lubricating oil system. * At every 2 times of oil change, oil filter cartridge should be replaced.

■When color of exhaust is especially bad

Cause	Countermeasures
Fuel is of extremely poor quality.	* Select good quality fuel. Use No. 2-D diesel fuel only.
Nozzle is bad.	* If necessary, replace with new nozzle.

■When engine must be stopped immediately

Cause	Countermeasures
Color of exhaust suddenly turns dark.	* Check the fuel injection system, especially the fuel injection nozzle.
Bearing parts are overheated.	* Check the lubricating system.
Oil lamp lights up during operation.	* Check the lubricating system. * Check the function of the relieve valve in the lubricating system. * Check pressure switch. * Check filter base gasket.

NOTE :

- If the cause of trouble can not be found, contact your KUBOTA dealer.

REVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

SPECIFICATIONS

Model	V3600-E3	V3600-T-E3
Type	Vertical, water-cooled, 4-cycle diesel	
Number of cylinders	4	
Bore and stroke mm (in.)	98 × 120 (3.86 × 4.72)	
Total displacement L(cu.in.)	3.620 (220.9)	
Combustion type	Spherical type (E-TVCS)	
SAE NET Intermittent kW / min^{-1}(rpm) H.P. (SAEJ1349) (HP / min^{-1} (rpm))	45.8 / 2600 (61.4 / 2600)	58.8 / 2600 (78.8 / 2600)
SAE NET Continuous kW / min^{-1}(rpm) H.P. (SAEJ1349) (HP / min^{-1} (rpm))	39.8 / 2600 (29.7 / 2600)	51.1 / 2600 (68.5 / 2600)
SAE Standby kW / min^{-1}(rpm) H.P. (SAEJ1349) (HP / min^{-1} (rpm))	—	—
Maximum bare speed min^{-1}(rpm)	2800	
Maximum bare idling speed min^{-1}(rpm)	775 to 825	
Order of firing	1-3-4-2	
Direction of rotation	Counter-clockwise (viewed from flywheel side)	
Injection pump	Bosch type mini pump	
Injection pressure MPa (kgf / cm^2, psi)	13.93 (142, 2020)	
Injection timing (Before T.D.C.)	0.14 rad (8°)	0.07 rad (4°)
Compression ratio	22.6	21.8
Fuel	Diesel fuel oil No.2-D	
Lubricant (API classification)	above CF grade	
Dimension mm (in.) (length × width × height)	745 × 536 × 741.5 (29.33 × 21.10 × 29.19)	745 × 538.5 × 794 (29.33 × 21.20 × 31.26)
Dry weight kg (lbs.)	264 (582)	275 (606.3)
Starting system	Cell starter (with glow plug)	
Starting motor	12V, 3.0kW	
Charging generator	12V, 1080W(KEA), 720W(EU)	
Recommended battery capacity	12V, 136AH (400 CCA or higher) 0°F (-17.8°C) SAE rating	

NOTE :


- Specifications are subject to change without notice.

REVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

WIRING DIAGRAMS

■**V3600-E3, V3600-T-E3, V3300-E3BG, V3600-T-E3BG**



1ABADBGAP025F

REVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 8 of 44 pages

The full manual includes:

- All 44 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Kubota V3600-E3, V3600-T-E3, V3800-DI-T-E3, V3300-E3BG, V3600-T-E3BG, V3800-DI-T-E3BG Operator Manual

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual