Engine

3000038

	Unit	Value / Description
Manufacturer and type		Deutz F4M 2011
Design		four-stroke diesel engine
Type of combustion		aspirating engine with direct injection
Engine displacement	cm^3	3108
Power DIN 70 020 (at rating speed)	kW / PS	40,4 / 55.0
Rating speed (at full load)	min^{-1}	2300
Low idling speed	min^{-1}	900 $^{\pm 50}$
High idling speed	min^{-1}	2390 $^{+100}$
Firing sequence		1,3,4,2
Sense of rotation		left, looking on flywheel
Compression ratio		19 : 1
Oil pressure (at 900 min^{-1})	bars	1,4
Oil pressure (at 1800 min^{-1})	bars	2,2
Oil pressure (at 2800 min^{-1})	bars	3,0

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Hydraulic circuit diagram - Travel drive for standard version

3000106




Fig. 2

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com

Adjusting operations on hydrostatic travel drive

3000170

During all checking and adjusting operations performed on the hydrostatic travel drive, the hydraulic oil temperature must be approx. 60 - 70˚C.

Mechanical zero position

In normal conditions, the mechanical zero position setting does not change by itself. Checking and/or adjustment is therefore necessary only if:

- the pumnp had been dismantled and reassembled,
- the driver complains that the loader travels in any of the directions although the travel direction switch is set to neutral. In this case, the functioning of the travel dierection switch and of the electromagnetic switching valve (A11) should be checked **beforehand**.

To check the mechnaical zero position, install a pressure gauge (range 600 bars) on both measuring ports for travel high pressure (P_{HD}).

Attention:

The machine must now be secured by appropriate measures against moving forwards and backwards. Observe the corresponding safety instructions.

The engine is started and the travel direction selector is in neutral position.

After loosening the retaining nut (9, Fig. 10), the centering spindle (5, Fig. 10) is turned with an 5 mm Allan key until the same pressure value (in this case the feed pressure) is indicated at both ports (P_{HD}).

After the adjustment, the centering spindle (5, Fig. 10) must be secured with the retaining nut (9, Fig. 10).

The mechanical zero position is now adjusted.

Checking and adjusting the travel high pressure

The travel high pressure (P_{HD}) is limited by the high-pressure relief valves (A4) and by the pressure cut-off (A8).

Important:

Maximum high pressure can only be reached, if the displacement volume switch-over function at the hydraulic motor (A15) is deactivated. For this purpose, the regulation start setscrew (2, Fig. 10) is **turned out** by about 3 turns. After this work, the regulation start of the hydraulic motor must be readjusted. During all high pressure measuring operations, speed range 2 (road speed) must be selected at the travel direction selector.

If no readjustment of the travel motor regulation start is desired, the pressure drop caused by slipping wheels can in most cases also be avoided by pulling the handbrake when driving against block and thus by preventing the handbrake switch from cutting out the travel drive.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Adjusting cylinder (A13)




Fig. 10

Items Fig. 10

1 - Cylinder bore in pump housing
2 - Cover
3 - Adjusting piston
4 - Compression spring
5 - Centering spindle
6 - Spring cup
7 - Retaining ring
8 - Lock-nut / ring and sleeve
9 - Retaining nut
11 - Vent screw
12 - Screw plug for control pressure checking (M 12 x 1,5)
13 - Distance sleeve
14 - O-ring
15 - Bearing bush

□

PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com

Fault	Cause	Remedial action
Accumulator is permanently recharged	Not enough or too much nitrogen in accumulator	After removing the oil from the accumulators, check the nitrogen pressure in the accumulators with a suitable instrument and refill them in strict observance of the the manufacturer's operating instructions. The nitrogen pressure can be checked by measuring the pressure of the residual oil ejected from the accumulator.
Feed pump always under pressure	Pump worn out	Repair pump or replace
	Valve contaminated (10 and 20, Fig. 13)	Check valve carefully (movement of parts, condition of sealing sets and checking of connections for tightness)
Accumulators do not recharge	Functioning of priority valve blocked by foreign matter (40, Fig. 13)	Check all parts for proper movement, especially the valve at the inlet. Check the hydraulic connection. After inspection of the accumulator charging valve check the stop ring (30, Fig. 13) of the piston at the charging port for correct fit. Bleed the feed pump circuit.
Pedal heard to be knocking	Abrupt pressure variations on the discharge side	Discharge flow of brake too high. Choose a larger diameter for the discharge lines.

□

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com

Eigensch./ Klasse	Kritische/totale Eigenschaft					EIGENTUM DER CNH GLOBAL N.V. UND FILIALEN. OHNE UNSERE ZUSTIMMUNG, UEBERLASSUNG AN DRITTE PERSONEN ODER VERDEFFENTLICHUNG NACH DEN GESETZLICHEN BESTIMMUNGEN VERBOTEN.				
CNHO							Datum/Date	Name	Benennung/Description	Sach-Nr Part-No 3 004 855
Model						Bearb./Written	04.02.04	SIK	WIRING DIAGRAM	4 Blatt Sheet 2
L6.5						Appr./Checked			ENGINE	F.N. D.S.No 17 Blätter Sheets
	P4xxx	1	SIK	10.08.04		Norm/St.Check				
	ECN/CID	REV	Name	Datum/Date		Bearb.Abt./Written department: 3350			Ers. für Substitut for	Ers. durch Substituted

Eigentum einer Tochtergesellschaft von CNH Global N.V.

Ursprr./Origin.

01 General

02 Service data

03 Engine

04 Travel drive

05 Axles

06 Steering

07 Brakes

08 Working hydraulic

09 Electrical system

10 Frame

11 Fittings, pipes and hoses

12 Sealing, protective, testing and cleaning agents

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

FUNDAMENTAL SAFETY INSTRUCTIONS

2800455

Warnings and symbols

The following signs are used in the manual to designate instructions of particular importance:



Precautionary rules and measures designed to protect the machine operator and other persons from life-threatening danger or injuries and to prevent extensive damage.



Information and precautionary measures designed to prevent damage to the machine or other property.

□

Danger in the event of nonobservance of the safety instructions



This wheel loader has been built in accordance with state-of-the-art standards and the recognized safety rules.

However, operating the machine if a fault is suspected or has occurred, or carrying out repair work inexpertly may

- **endanger the lives of persons in contact with it**
- **damage the machine and other property.**

The wheel loader must be stopped immediately on any damage being suspected or occurring to ensure that the safety of the operator, of other persons at the place of use or of other material property is not compromised.

All components are carefully co-ordinated. Trouble-free operation and a long service life can only be achieved with original spare parts.

□

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

CHAPTER 01 - GENERAL

FOREWORD

2796842

This **Technical Handbook (THB)** has been written with **the servicing mechanic** in mind and contains important information required to carry out repair and servicing procedures.

Read through the **Technical Handbook**, but also the **Operating Instructions** for the **Wheel Loader** before commencing any servicing or repair work. The **Technical Handbook**, as well as the **Operating Instructions** and **Spare Parts List** should be used as a source of reference and assistance - even when the user is well acquainted with the range of the Wheel Loaders.

Using the Technical Handbook allows the experienced mechanic to carry out repair work in a correct manner.

Using the Technical Handbook

The Technical Handbook is divided into main and sub-groups that deal with the machine as actually delivered. Any auxiliary attachments or optional upgrading introduced later are not described.

The main table of contents allows to find the required information quickly.

For the sake of clarity, the illustrations have been simplified and can therefore differ slightly from the actual appearance of the machine.

Servicing and repair

Servicing and repair work should be carried out as soon as possible. This keeps overall servicing & repair costs to a minimum and increases the availabilily of the Wheel Loader.

During servicing and repair work, always follow the instructions contained in the Technical Handbook and Operating instructions.

The **After Sales Service** is always available for assistance and advice.

□

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

CHAPTER 04 - TRAVEL DRIVE

Hydraulic system, safety instructions

3000172

Read and observe "Inspection and servicing, safety instructions".

Before working on the hydraulic system make sure the system has been depressurized and that also the residual pressures have been removed.

Shut off the engine.

Secure the machine as described in the chapter "Securing the machine".

Avoid skin contact with hydraulic oils. Wear gloves and firm working clothing. Skin contact with hydraulic oils may be a health hazard.

□

Explanations of circuit diagrams and illustrations

2800487

All circuit diagrams and illustrations in this Workshop Manual form one coherent system.

Each component has its own unique part number. In some cases a letter indicating the use is assigned to the digit for improved clarity.

Meanings:

A = transmission drive,	e.g. **A7**	=	servo-valve
B = braking system,	e.g. **B1**	=	brake fluid pump
L = steering system,	e.g. **L1**	=	steering cylinder
H = working hydraulics,	e.g. **H8**	=	primary valve
T = tank, filter, cooling system	e.g. **T1**	=	hydraulic tank

Part numbers without letters designate general components, e.g. Part **1** = diesel engine.

Encircled parts, e.g. ②, designate connections. They indicate the destination or the origin of the connection lines. Example ② indicates that the connection designated in this way is connected with the dual pump.


Measuring connections are specified with rectangular boxes.

X1 designates, for example, the measuring point for control pressure.

□

PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com



Achtung!
* Angefaste "Seite" zum Deckel montieren.


Note!
* Mount chamfered side facing cover.

15




16 Lage kennzeichnen,
Befestigungsschrauben ausbauen.

Mark position,
remove fixing screws.



17 Deckel abdrücken.


Pry-off cover.




18 Teile der Hilfspumpe auf Verschleiß untersuchen.
Pumpe kann nur komplett ausgetauscht werden.

Inspect the parts of the boost pump and wear parts.
Boost pump can only be interchanged completely.

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com




20



21

Beispiel: A6VM ... HD Verstellung
Demontageposition:
Deckel Pos. 1 abbauen.

Example: A6VM ... HD control
Disassembly position:
Remove cover pos. 1




22

1. O-Ring
2. Stellölzulauf
3. Drosselstift

⚠ Einbaulage je nach Steuerteil verschieden.

1. O-ring
2. Input flow of oil control
3. Throttle pin


⚠ Installation position differs according to the control components




23

1. Stellölzulauf	1. Input flow of oil control
2. Hochdruck bzw. Niederdruck	2. High pressure / low pressure
3. Hochdruck bzw. Niederdruck	3. High pressure / low pressure
4. Lecköl	4. Leckage oil
5. Stellkolben	5. Control piston

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com




58



59 Lage vom Deckel markieren, Maß "Nullage" festhalten, Mutter lösen.

Mark position of the cover, note measure of "zero position". Loosen nut.




60 Deckel abdrehen.

Remove cover.


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



39 Oder mit Abziehvorrichtung ausdrücken.


Or press-out with extraction device.



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Specifiche dischi differenziale limited slip ***Limited slip differential disks specificatios***



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


D.4.2 Montaggio

Alcune figure che seguono potrebbero non mostrare esattamente il vostro assale, ma la procedura descritta è quella corretta.
Vedi: sezioni successive prima di montare il gruppo.

D.4.2 Assembly

Some of the following pictures may not show exactly your axle, but the indicated operations are correct anyway.
***See:** next sections before assemble this group.*


1



Montare le coppe dei cuscinetti (**4**) e (**8**) sulla gruppo differenziale (**1**).
Vedi: sezione D.5
Attenzione: non invertire le coppe dei cuscinetti se non vengono sostituiti i cuscinetti.

*Assemble the bearings cups (**4**) and (**8**) on the differential group (**1**).*
***See:** section D.5*
***Warning:** do not invert the bearing cups if the bearings are not replaced.*


2



Montare la scatola differenziale completa (**13**) sul supporto differenziale (**1**).
Attenzione: verificare il giusto lato di montaggio della corona conica.

*Position the complete differential housing (**13**) on the differential support (**1**).*
***Warning:** check the right side of the bevel crown assembly.*

3



Spostare la scatola differenziale in modo da appoggiare la corona conica al pignone.
Verificare che tutte le bussole (**9**) siano nelle relative sedi e posizionare le due semicravatte (**10**) utilizzando i segni di riferimento riportati sulle medesime e sul supporto differenziale.
Fissare le semicravatte con le viti di fissaggio (**11**).

Move the differential group so to place the bevel crown gear on the pinion.
*Check taht all bushes (**10**) are in their housings and position both half collars (**11**) on their seats using the previously traced reference marks.*
*Lock both half collars with their fastening bolts (**11**).*

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

C.3 Descrizione generale


L'assale descritto in questo manuale è costituito dai seguenti gruppi:

- MOZZO RUOTA: elementi di supporto della ruota e del riduttore epicicloidale
- RIDUTTORE EPICICLOIDALE: treno portasatelliti con elementi di riduzione
- TRAVE: struttura di supporto principale dell'assale
- SUPPORTO DIFFERENZIALE: struttura di supporto del differenziale e di registrazione della coppia conica
- DIFFERENZIALE: scatola differenziale e corona della coppia conica
- PIGNONE: pignone con gli elementi di registrazione e supporto
- FRENO: componenti del freno con gli elementi di supporto (solo per gli assali modello 28.25 FR)
- FRENO A DISCO: freno a disco con pinza ed elementi di supporto

C.3 General description

The axle described in this manual consists mainly of following groups:


- *WHEEL HUB: wheel support parts containing the epicyclic reduction gears*
- *EPICYCLIC REDUCTION GEAR: planetary carrier with reduction/transmission parts*
- *AXLE BEAM: load-bearing shell structure of the axle*
- *DIFFERENTIAL SUPPORT: differential housing with ring bevel gear adjusting system*
- *DIFFERENTIAL: differential parts with ring bevel gear*
- *PINION: pinion with adjusting and support parts*
- *BRAKE: brake components with support parts (only for 28.25 FR axles model)*
- *BRAKE DISC: brake disk with caliper and support parts*



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


4



Estrarre il controdisco freno (**14**) dal trave utilizzando una leva.

*With a lever remove the counterplate (**14**) from the axle beam.*


5



Togliere il disco freno (**13**) ed il mozzo traino (**15**).
Se necessario rimuovere l'anello d'arresto (**16**) all'interno del mozzo traino (**15**).

*Remove the brake disc (**13**) and the brake disc carrier (**15**).*
*If necessary, remove the snap ring (**16**) inside of the brake disc carrier (**15**).*


6



Svitare e togliere la vite del kit self-adjust (**11**), e del kit ritorno pistone freno (**12**).
Estrarre i relativi componenti

*Unscrew and remove the screw of the self-adjust kit (**11**) and of the brake mechanism return kit (**12**).*
Remove the relevant components.

7



Verificare le condizioni di funzionalità e lo stato di usura dei componenti dei kit (**11**) e (**12**).

*Check the operating and wear conditions of the kit components (**11**) and (**12**).*

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

A.1 Utilizzo del manuale

Destinatari

- Installatore.
- Utilizzatore.
- Manutentore.

Manutenzione

PRENDERE VISIONE DI TUTTO IL MANUALE poiché il buon funzionamento ed il rendimento degli organi meccanici dipendono principalmente da una costante e corretta manutenzione e assicurano la durata e l'integrità del prodotto.
Nell'eventualità di guasti od anomalie il tempestivo intervento da parte di personale specializzato garantisce una durata più lunga del gruppo, evitando danni maggiori nel tempo.

Riparazione

Le procedure per lo smontaggio/montaggio consentono di eseguire la revisione totale del prodotto e sono descritte in sequenza con l'ausilio di illustrazioni, per una guida completa e sicura all'esecuzione di ogni operazione.
Nella descrizione delle operazioni si presuppone che l'assale sia stato rimosso dal veicolo. Per la rimozione dell'assale dal veicolo consultare il manuale del costruttore del veicolo.

A.1 Manual use

End users

- *Installer*
- *User*
- *Maintenance operator*

Maintenance

CONSULT THIS MANUAL THOROUGHLY, as proper functioning and good efficiency of mechanical organs depends mostly on constant and correct routine maintenance ensuring product integrity and expected life duration.
In case of any damages or anomalies, quick intervention of trained operators can avoid future impairment and lengthen the working life.


Repair

The disassembly/assembly procedures have been outlined for a total product overhauling. They have also been described in sequence through photographs with relevant explanation for specific interventions, thus obtaining a complete and safe guide for each and every phase of an operation.
Operation description presumes that the axle has already been removed from the vehicle. To remove the axle from vehicle refer to manual provided from vehicle manufacturer.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


2



Per sfilare il mozzofermo corona dalla sua sede, recuperare almeno due delle viti (**1**) appena tolte ed avvitarle nei fori filettati di estrazione.

*In order to remove the wheel carrier group from its housing, screw at least two of the just removed bolts (**1**) in the threaded extraction holes*


3



Rimuovere il mozzo fermo corona (**2**) e la corona epicicloidale (**3**).

*Remove the wheel carrier together (**2**) with the ring gear (**3**).*


4



Solo se necessario, togliere le bussole di centraggio (**4**) del mozzo fermo corona con un martello e l'attrezzo CA715086.

*Only if necessary, remove the centering bushes (**4**) of the wheel carrier with a hammer and the special tool 380002223.*

5



Rimuovere l'anello d'arresto (**5**).

*Remove the lock ring (**5**).*

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

A.2 Proprietà delle informazioni

Questo manuale contiene informazioni di proprietà riservata. Tutti i diritti sono riservati.

Questo manuale non può essere riprodotto o fotocopiato, tutto o in parte, senza il preventivo consenso scritto di CARRARO S.p.A. L'uso di questo materiale documentale è consentito solo al cliente a cui il manuale è stato fornito come corredo del prodotto, e solo per scopi di uso, manutenzione e riparazione.

CARRARO S.p.A. dichiara che le informazioni contenute in questo manuale sono congruenti con le specifiche tecniche e di sicurezza della macchina a cui il manuale si riferisce. Il fabbricante non si assume alcuna responsabilità per danni diretti o indiretti a persone, cose o animali, conseguenti all'uso di questo materiale documentale o della macchina in condizioni diverse da quelle previste.

A.2 Information property

This manual should be considered as CARRARO S.p.A. confidential information. All rights reserved.

No part of this manual may be reproduced, in any form or by any means, without prior written permission of CARRARO S.p.A. Only the customer, whom the manual, together with the product, has been issued to, is allowed to use this document, and only in order to use, maintain and repair the unit.


CARRARO S.p.A. declares that the subject of this manual consists with the technical and safety specifications of the machine that the manual is referred to. The manufacturer shall not be held liable for direct or indirect damages to persons, things or animals due to an improper use of this document or of the machine or to a different use of them, which does not comply with what is provided for in this manual.

Carraro Spa
Via Olmo, 37
35011 Campodarsego (Pd) Italia
Tel. +39 049 9219111
Fax +39 049 9289111
www.carraro.com

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


4



Nota: prima di assemblare il motore idraulico (non fornito da Carraro), montare un nuovo anello OR (**3**) all'interno della scatola.
Attenzione: non rovinare l'anello OR durante l'assemblaggio.

Note: *insert a new O-Ring (**3**) in the hydraulic motor (not supplied by Carraro), before assemble the motor group to transmission box.*
Warning: *do not damage the O-Ring during assembly operation.*

5




Attenzione: sostenere il motore idraulico con una fune o con un sostegno adatto.
Montare il motore idraulico (**1**) sulla trasmissione.
Serrare la vite (**2**) alla coppia prevista (Vedere il manuale del costruttore del veicolo).

Warning: *support the hydraulic motor with a rope or other appropriate means.*
*Assemble the hydraulic motor (**1**) on the transmission box.*
*Tighten the bolts (**2**) to the prescribed torque (See manual provided from vehicle manufacturer).*

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


6



Svitare le due ghiere di registro (**3**) e (**7**) con l'attrezzo CA119030 (**a1**) ed una chiave.

*Unscrew the adjuster ring nuts (**3**) and (**7**) using tools 380000406 (**a1**) and a wrench.*


7



Svitare le 4 viti (**11**) e togliere le due semicravatte (**10**).
Nota: verificare che le bussole (**9**) rimangono nelle rispettive sedi.

*Loosen and remove the 4 screws (**11**) and remove the 2 half-collars (**10**).*
***Note:** check that the bushes (**9**) remains in their housings.*

8



Rimuovere la scatola differenziale (**13**).
Le coppe dei cuscinetti (**4**) e (**8**) vengono rimosse assieme alla scatola differenziale.
Attenzione: non invertire le coppe dei cuscinetti se non vengono sostituiti.

*Remove the differential housing (**13**).*
*The bearing cups (**4**) and (**8**) are removed together with the differential housing.*
***Warning:** do not invert the bearing cups if they are not going to be replaced.*

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Steering cylinder (L1) for LW80.B

3000079-NH




Fig. 10

Items (Fig. 10)

1	-	Cylinder barrel
2	-	Piston rod Ø 32 mm
3	-	Retaining ring
4	-	Support ring
5	-	Retaining ring
6	-	Guide bush
7	-	Piston Ø 70 mm
8	-	Hex nut

Fitting information

Stroke: 300 mm
Oil ports: L12W DIN 3 653
Connecting thread: M 18 x 1.5

□

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Lifting cylinder (H1) for LW50.B

3000033-NH




Fig. 7

Items Fig. 7

1 - Cylinder
2 - Piston rod
3 - Guide sleeve
4 - Piston
5 - Round spring ring
6 - Supporting ring
7 - Retaining ring
8 - Groove nut M 30 x 1.5
9 - Articulated bearing

Technical data

Piston Ø	:	75 mm
Rod Ø	:	45 mm
Stroke	:	574 mm
Port thread	:	M 16 x 1,5

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 25 of 826 pages

The full manual includes:

- All 826 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

New Holland LW50B, LW80B Service Manual

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual