
Toolcat™

5600

Bobcat®

Parts Manual

S/N 5205 11001 & Above



PREVIEW - YOUFIXTHIS.COM

An Ingersoll-Rand business

6902180 (3-03) Revised (11-03)

Printed in U.S.A.

© Bobcat Company 2003

Download full manual at youfixthis.com

5600 CONTENTS

MAIN FRAME 11-38
MAINTENANCE ITEMS 11-12
MAIN FRAME 13-14
FENDERS 15-16
OPERATOR CAB 17-20
* SUSPENSION SEAT 21-22
* STATIC SEAT 23-24
WIPER ASSEMBLY 25-26
BOX ASSEMBLY 27-28
TAILGATE 29-30
REAR HITCH 31-32
LIFT ARM 33-34
BOB-TACH 35-36
FUEL SYSTEM 37-38
DRIVE TRAIN 39-66
SUSPENSION 39-40
AXLE 40-41
* AXLE ASSEMBLY 42-54
DRIVE MOTOR 55-66
HYDRAULIC SYSTEM 67-96
HYDRAULIC CIRCUITRY 67-74
AUXILIARY HYDRAULICS 75-78
LIFT CYLINDER 79-80
TILT CYLINDER 81-82
BOX CYLINDER 83-84
AUXILIARY HYDRAULIC VALVE 85-86
PILOT VALVE 87-88
WORK VALVE 89-90
VALVE SECTION 91-96
HYDROSTATIC SYSTEM 97-146
HYDROSTATIC CIRCUITRY 97-106
STEERING CONTROLS 107-108
HYDROSTATIC PUMP 109-138
TRIPLE GEAR PUMP 139-140
HYDRAULIC FAN MOTOR 141-142
POWER STEERING PUMP 143-144
STEERING & BOX VALVE 145-146
ELECTRICAL SYSTEM 147-162
CAB ELECTRICAL CIRCUITRY 147-152
ENGINE ELECTRICAL CIRCUITRY 153-156
CONTROLS ELECTRICAL 157-158
STARTER 159-160
ALTERNATOR 161-162
ENGINE & ATTACHING PARTS 163-212
ENGINE & ATTACHING PARTS 163-170
ENGINE & GASKET KITS 171-172
GEARCASE 173-174
CRANKCASE 175-176
ROCKER ARM COVER 177-178
VALVE ROCKER ARM 179-180
CYLINDER HEAD 181-182
OIL PAN 183-184
PISTON & CRANKSHAFT 185-186
FUEL CAMSCHAFT 187-188
CAMSCHAFT 189-190

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Part No.	Description	Was	Code	Page
6655238	BEARING			184
6655239	BEARING			184
6655240	BEARING			184
6655241	BEARING			184
6655242	BUSHING			188
6655243	BUSHING			184
6655255	SPRING			198
6655317	SWITCH			270
6655384	CAMSHAFT			188
6655427	CAMSHAFT			188
6655498	BOLT			184
6655515	JOINT			202
6655518	O-RING			204
6655523	COLLAR			186
6655869	PLUG			174
6655870	ARM			178
6655872	HEAT SEAL			170, 206, 208
6655873	PIECE			208
6655874	CLIP			202
6655875	CAMSHAFT			186
6655876	LEVER			198
6655877	LEVER			198
6655878	SPRING			198
6655880	PIPE			192
6655884	PLUG			174
6655966	FLANGE			192
6656126	WASHER			208
6656127	WASHER			208
6656128	WASHER			208
6656129	WASHER			208
6656130	WASHER			208
6656131	WASHER			208
6656132	WASHER			208
6657299	MOTOR OIL			2, 274
6657301	MOTOR OIL			2, 274
6657303	MOTOR OIL			2, 274
6657401	GASKET KIT			170, 180
6657402	GASKET KIT			170, 174
6657409	SEAL KIT			86
6657460	NUT			208
6657463	WASHER			208
6657695	PISTON			184
6657696	RINGS			184
6657742	KIT			208
6658103	COUPLER			68, 74
6658266	GREASE			274
6658536	SNAP RING			166
6658847	RING			166
6659603	SEAL			12
6660260	INDICATOR			100
6660357	SEAL KIT			144

Code for dispostiiton of old part number

A — Use up

B — Use on other application (See PNI)

C — File PDR Report with Bobcat Parts Sales

D — Part Number Error

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

MAINTENANCE ITEMS

Ref.N°	Part N°	Description	Remarks	Serial N°	Qty.
1	6675517	FILTER	engine - See Page ENGINE & ATTACHING PARTS(2)		x
2	6667352	FILTER	See Page FUEL SYSTEM(5)		x
3	6666334	CARTRIDGE	inner - See Page AIR CLEANER(3)		x
4	6666333	CARTRIDGE	outer - See Page AIR CLEANER(3)		x
5	6668819	FILTER	Hyd./Hydro. - 10 micron - See Page HYDROSTATIC CIRCUITRY(1)		x
5	6516722	FILTER	Case Drain - See Page HYDRAULIC CIRCUITRY(1)		x
6	6674687	BATTERY	See Page ENGINE ELECTRICAL CIRCUITRY(1)		x
7	6563328	BLACK GOLD	Hyd./Hydro. Fluid - (2) 2.5 Gal. - See Page BULK ITEMS(2)		x
7	6722344	BLACK GOLD	Hyd./Hydro. - (5 Gal.) - See Page BULK ITEMS(2)		x
7	6563330	BLACK GOLD	55 Gallon Drum - See Page BULK ITEMS(2)		x
8	6657301	MOTOR OIL	10W30 CE/SG - 1 Qt. - See Page BULK ITEMS(2)		x
8	6724557	MOTOR OIL	10W30 CE/SG - 1 Gal. - See Page BULK ITEMS(2)		x
8	6674205	MOTOR OIL	10W30 CE/SG - 2.5 Gal. - See Page BULK ITEMS(2)		x
8	6657299	MOTOR OIL	15W40 CE/SG - 1 Qt. - See Page BULK ITEMS(2)		x
8	6724558	MOTOR OIL	15W40 CE/SG - 1 Gal. - See Page BULK ITEMS(2)		x
8	6674204	MOTOR OIL	15W40 CE/SG - 2.5 Gal. - See Page BULK ITEMS(2)		x
8	6657303	MOTOR OIL	30 CE/SG - 1 Qt. - See Page BULK ITEMS(2)		x
8	6724559	MOTOR OIL	30 CE/SG - 1 Gal. - See Page BULK ITEMS(2)		x
8	6674206	MOTOR OIL	30 CE/SG -2.5 Gal. - See Page BULK ITEMS(2)		x

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

MAIN FRAME

Ref.N°	Part N°	Description	Remarks	Serial N°	Qty.
1	6813025	MAIN FRAMEinD1}			1
2	6674264	RETAINER			24
3	28CM-1040	BOLT			1
4	87D-6	NUT			2
5	29CM-1225	SCREW			3
6	6813498	BRACKET	axle stop		2
7	6814010	STOP	axle		2
8	9G-620	BOLT			2
9	51DM-12	NUT			4
10	29CM-825	SCREW			4
11	6814701	STOP			2
12	6813609	BRACKET	hose		1
13	28CM-1030	BOLT			16
14	6813610	BRACKET			1
15	6812789	MOUNT			2
16	29CM-1020	BOLT			6
17	43DM-8	NUT			2
18	28CM-1060	BOLT			1
19	43DM-10	NUT			16
20	10H-25	GREASE ZERK			2
21	28CM-1020	SCREW			2
22	6675859	RETAINER			4
23	28CM-820	BOLT			4
24	26GM-10020	SCREW			7
25	6813348	COVER	hose		1
26	6815823	GUARD	front - Was 6815303 [A]		1
27	NAP	SEAL	3.5'(89mm) long - Order Ref. MAIN FRAME(28)		2
28	6659603	MOULDING	bulk - Sold Per Foot		x
29	57D-8	NUT			2
30	37C-820	BOLT			2
31	29CM-1245	BOLT			1
32	28CM-1050	SCREW			2

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

LIFT ARM

Ref.N°	Part N°	Description	Remarks	Serial N°	Qty.
1	1CM-1070	SCREW			4
2	6813410	PIN			2
3	53DM-10	NUT			5
4		CYLINDER	tilt - See Page TILT CYLINDER(3)		1
5	10H-25	GREASE ZERK			6
6	6652943	COVER, GREASE	grease		4
7	6813157	LINK ASSY			1
8	6813408	PIN			2
9	6813159	LINK ASSY			1
10	1CM-1080	BOLT			1
11	6813409	PIN			1
12	6803207	BUSHING			4
13	NAP	BOOM	*Order 6818314 - Was 6812868 [A]	& Bel	1
13	6818314	BOOM		& Abv	1
14	22J-20	SNAP RING			4
15	6532519	WASHER			4
16	6716539	BUSHING			2
17		CYLINDER	lift - See Page LIFT CYLINDER(2)		1
18	6813862	PIN			1
19	6816852	SUPPORT	boom - Was 6813934 [A]		1
20	6679130	KNOB			2
21	6731385	STUD			2

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

ENGINE & ATTACHING PARTS

Ref.N°	Part N°	Description	Remarks	Serial N°	Qty.
1	6733429	CAP			1
2	6812203	TANK	pressurized		1
3	28CM-1020	SCREW			2
4	43DM-10	NUT			12
5	5HM-35	CLAMP			2
6	5HM-20	CLAMP			1
7	6680398	CAP			1
8	6813743	HOSE			1
9	42HC-200	CLAMP			2
10	5HM-14	CLAMP			4
11	NAP	HOSE	22'(558,8mm) long - Order Ref. ENGINE & ATTACHIN G PARTS(32)		1
12	5HM-47	CLAMP			4
13	6812683	HOSE			1
14	6813352	TEE			1
15	710706	CLAMP			1
16	6812006	TUBE	radiator		1
17	6812008	HOSE			1
18	5HM-44	CLAMP			2
19	6812204	HOSE			1
20	30H-60	CLIP			1
21	NAP	HOSE	80'(2032mm) long - Order Ref. ENGINE & ATTACHIN G PARTS(32)		1
22	26GM-10020	SCREW			13
23	30H-85	CLAMP			2
24	6812005	HOSE			1
25	43DM-8	NUT			1
26	30H-37	CLAMP			1
27	29CM-816	BOLT			1
28	6679479	RADIATORinD1}'			1
28	6679506	DRAIN			1
29	6812004	SHIELD			1
30	29CM-1020	BOLT			2
31	6812007	MOUNT			2
32	6577822	HOSE	bulk - Sold Per Foot		x
33	6814679	GUARD	fan		2
34	30H-12	CLAMP			5
35	6814427	PLATE			1
36	28CM-820	BOLT			2
37	51DM-8	NUT			2
38	6815192	PLATE			1
39	6676169	NUT			2
40	NAP	SEAL	4'(101,6mm) long - Order Ref. ENGINE & ATTACHING PARTS(43)		2
41	NAP	SEAL	19'(482,6mm) long - Order Ref. ENGINE & ATTACHIN G PARTS(44)		1
42	6815193	PLATE			1
43	6654139	MOULDING	bulk - Sold Per Foot		x
44	6676396	INSULATION	bulk - Sold Per Foot		x

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

HYDRAULIC CIRCUITRY

Ref.N°	Part N°	Description	Remarks	Serial N°	Qty.
1	17KB-808	ELBOW	W/Ref. HYDRAULIC CIRCUITRY(16)		1
2	35C-410	BOLT			2
3	6814852	ELBOW	W/Ref. HYDRAULIC CIRCUITRY(16)		1
4	6682415	FILTER ASSY			1
4	6516722	FILTER			1
5	29CM-816	BOLT			4
6	43DM-10	NUT			4
7	6674264	RETAINER			4
8	6812218	MOUNT	hyd tank		1
9	28CM-1020	SCREW	$		4
10	10L-608	CONNECTOR	W/Ref. HYDRAULIC CIRCUITRY(22)		2
11	15KB-808	ADAPTER	W/Ref. HYDRAULIC CIRCUITRY(16)		1
12	6812216	TANK	hyd		1
13	6665915	SIGHT GAUGE	W/Ref. HYDRAULIC CIRCUITRY(24)		1
14	6674690	CAP	hyd - W/Ref. HYDRAULIC CIRCUITRY(23)		1
15	6587168	SCREEN			1
16	79K-8	O-RING			x
17	6813702	HOSE			1
18	6814819	HOSE			1
19	6815742	HOSE	case drain - Was 6814821 [A]		1
20	6815050	HOSE			1
21	30H-56	CLAMP		& Bel	1
22	78K-8	O-RING			x
23	79K-20	O-RING			x
24	79K-12	O-RING			x

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

OPERATOR CAB

Ref.N°	Part N°	Description	Remarks	Serial N°	Qty.
1	1CM-612	SCREW			10
2	26GM-6016	BOLT			8
3	6816487	BRACKET	dash - Was 6811593 [A]		4
4	6813614	DASH COVER	R.H.		1
5	6811815	OPERATOR CABinD 1}			1
6	NAP	MOUNT	offset - Order 6816487 - Was 6811839 [A]		2
7	6813615	DASH COVER	L.H.		1
8	6815966	COVER			1
9	NAP	SEAL	17'(432mm) long - Order Ref. OPERATOR CAB(10)		1
10	6675732	SEAL	bulk - Sold Per Foot		x
11	6816122	PLATE			1
12	NAP	EDGE TRIM	7'(178mm) long - Order Ref. OPERATOR CAB(13)		1
13	6682492	EDGE TRIM	bulk - Sold Per Foot		x
14	6589675	SCREW			2
15	6676169	NUT			4
16	6588953	SAFETY TREAD			4
17	29CM-1020	BOLT			6
17	6817769	BOLT			6
18	6815098	BRACKET	seat belt		2
19	51DM-10	NUT			6
20	6682176	BELT	shoulder		2
21	29CM-820	BOLT			20
22	NAP	SEAT	suspension - Was 6680186 [A]	5205 11119 & Bel	1
22	6683334	SEAT	suspension - See Page * SUSPENSION SEAT(1)	5205 11120 & Abv	1
23	6813676	INSERT	threaded		16
24	6813656	INSULATION	rear		1
25	NAP	SEAT	static - Was 6680185 [A]	5205 12048 & Bel	1
25	6683336	SEAT	static - See Page * STATIC SEAT(2)	5205 12049 & Abv	1
26	6664566	SCREW			2
27	6680967	HANDLE	grab		1
28	6815640	NUT			2

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

AXLE ASSEMBLY

Ref.N°	Part N°	Description	Remarks	Serial N°	Qty.
1	6678762	AXLE	Ref. AXLE ASSEMBLY(2)AXLE ASSEMBLY(48)		1
2	6682080	HOUSING	R.H.		1
3	6682081	HOUSING	L.H.		1
4	6682082	GEAR ASSY			1
5	6682083	AXLE			1
6	6682084	CYLINDER	steering - See Page AXLE ASSEMBLY(6)		1
7	6682085	SPRING			1
8	6682086	RING	retaining		1
9	6682087	COUPLER	clutch		1
10	6682088	NEEDLE CAGE			1
11	6682089	O-RING			1
12	6682090	ROD			1
13	6682091	O-RING			1
14	6682092	PIN			4
15	6682093	SCREW			9
16	6682094	PLUG			3
17	6682095	BALL BEARING			2
18	6682096	BALL BEARING			2
19	6682097	BALL BEARING			2
20	6682098	SHAFT			1
21	6682099	COUPLER	clutch		1
22	6682100	SCREW	used for towing		2
22	1CM-1220	BOLT			2
23	6682101	NUT			2
24	6682102	RING GEAR			1
25	6682103	DISK	sintered		4
26	6682104	DISK	steel		3
27	6682105	PISTON	brake		1
28	6682106	SPRING	brake		12
29	6682107	COVER	spring		1
30	6682108	O-RING			1
31	6682109	O-RING			1
32	6682110	RING	retaining		1
33		DRIVE MOTOR	See Page DRIVE MOTOR(7)		1
34	6682111	WASHER			2
35	6682112	SCREW			2
36	6682116	SEAL			4
37	6682117	BUSHING			2
38	6682118	BEARING	roller		4
39	6682119	RING	scraper		4
40	6681000	SENSOR	steering - wheel position		1
41	6682120	SCREW			2
42	6682121	RING	nylon		1
43	NSS	O-RING	Order 6682148 Seal Kit		1
44	NSS	O-RING	Order 6682148 Seal Kit		1
45	6682128	O-RING			1
46	6682129	PLUG			1
47	6682131	SCREW			1
48	6682136	SENSOR	steering		1
49	6682139	KIT	box - Ref. AXLE ASSEMBLY(2)AXLE ASSEMBLY(24)		1
50	6682140	KIT	seal - Ref. AXLE ASSEMBLY(11), AXLE ASSEMBLY(13), AXLE ASSEMBLY(30), AXLE ASSEMBLY(31), AXLE ASSEMBLY(36), AXLE ASSEMBLY(39), &		1
51	6682141	KIT	brake - Ref. AXLE ASSEMBLY(25), AXLE ASSEMBLY(26), AXLE ASSEMBLY(28), AXLE ASSEMBLY(30) & AXLE ASSEMBLY(31)		1

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

ENGINE ELECTRICAL CIRCUITRY

Ref.N°	Part N°	Description	Remarks	Serial N°	Qty.
1	35C-612	BOLT			3
2	6678688	CONTROLLER			1
3	1CM-616	BOLT			2
4	30H-19	CLAMP	insulated		2
5	6681513	SOLENOID	fuel shut-off		1
6	53DM-6	NUT			2
7	6578366	BALL JOINT			1
8	66D-4	NUT			1
9	6578363	ROD END			1
10	62D-4	NUT			2
11	30HJ-512	CLIP	insulated		1
12	29CM-820	BOLT			2
13	6515603	GROMMET			1
14	6811186	HARNESSinD1x	engine		1
15	6733370	HARNESS	adapter		1
16		NUT			1
17	30H-31	CLAMP			1
18	29CM-625	BOLT			7
19	6678974	MOUNT			1
20	6815194	BRACKET			1
21	43DM-6	NUT			1
22	29CM-816	BOLT			2
23	6684037	SENSOR	engine rpm - Was 6679853 [A]		1
24	6680450	SENSOR	fuel		1
25	6718415	SWITCH	engine temp		1
26	29CM-616	SCREW			3
27	30H-37	CLAMP			2
28	6678205	ALTERNATOR	See Page ALTERNATOR(4)		1
29	30H-23	CLAMP			1
30	6727869	SENDER	hyd temp		1
31	6624289	STA-STRAP			10
32	6675154	HOLDER			1
33	51DM-6	NUT			2
34	6707040	ELBOW			1
35	6631010	SWITCH	engine oil		1
36	12D-8	NUT			1
37	6812900	CABLEinD1w	positive		1
38	6812901	CABLEinD1w	negative		1
39		NUT			2
40	6676957	STARTER	See Page STARTER(3)		1
41		BOLT			1
42	26GM-10030	SCREW			1
43	6E-6	WASHER			1
44	51DM-10	NUT			1
45	6674687	BATTERY			1
45	6630154	CAP	gang - Danger		1
45	6630155	CAP	gang - Poison		1
45	6514898	CAP	tilt-tite		6
46	1CM-860	BOLT			2
47	6715197	CLAMP			1
48	43DM-8	NUT			1
49	6815731	BRACKET	battery - Was 6812735 [A]		1
50	26GM-10020	SCREW			2
51	28CM-1020	SCREW			5
52	6815313	MOUNT	battery - Was 6812727 [A]		1

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


5600 CONTENTS

MAIN FRAME 11-38
MAINTENANCE ITEMS 11-12
MAIN FRAME 13-14
FENDERS 15-16
OPERATOR CAB 17-20
* SUSPENSION SEAT 21-22
* STATIC SEAT 23-24
WIPER ASSEMBLY 25-26
BOX ASSEMBLY 27-28
TAILGATE 29-30
REAR HITCH 31-32
LIFT ARM 33-34
BOB-TACH 35-36
FUEL SYSTEM 37-38
DRIVE TRAIN 39-66
SUSPENSION 39-40
AXLE 40-41
* AXLE ASSEMBLY 42-54
DRIVE MOTOR 55-66
HYDRAULIC SYSTEM 67-96
HYDRAULIC CIRCUITRY 67-74
AUXILIARY HYDRAULICS 75-78
LIFT CYLINDER 79-80
TILT CYLINDER 81-82
BOX CYLINDER 83-84
AUXILIARY HYDRAULIC VALVE 85-86
PILOT VALVE 87-88
WORK VALVE 89-90
VALVE SECTION 91-96
HYDROSTATIC SYSTEM 97-146
HYDROSTATIC CIRCUITRY 97-106
STEERING CONTROLS 107-108
HYDROSTATIC PUMP 109-138
TRIPLE GEAR PUMP 139-140
HYDRAULIC FAN MOTOR 141-142
POWER STEERING PUMP 143-144
STEERING & BOX VALVE 145-146
ELECTRICAL SYSTEM 147-162
CAB ELECTRICAL CIRCUITRY 147-152
ENGINE ELECTRICAL CIRCUITRY 153-156
CONTROLS ELECTRICAL 157-158
STARTER 159-160
ALTERNATOR 161-162
ENGINE & ATTACHING PARTS 163-212
ENGINE & ATTACHING PARTS 163-170
ENGINE & GASKET KITS 171-172
GEARCASE 173-174
CRANKCASE 175-176
ROCKER ARM COVER 177-178
VALVE ROCKER ARM 179-180
CYLINDER HEAD 181-182
OIL PAN 183-184
PISTON & CRANKSHAFT 185-186
FUEL CAMSCHAFT 187-188
CAMSCHAFT 189-190

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

AXLE ASSEMBLY



B-21566

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


WORK VALVE

Ref.N°	Part N°	Description	Remarks	Serial N°	Qty.
1	6678756	VALVE	work - Ref. WORK VALVE(2)WORK VALVE(7)		1
2	NSS	NUT			4
3	NSS	WASHER			8
4	6682253	VALVE	section - See Page VALVE SECTION(8)		1
5	6682254	VALVE	section - See Page VALVE SECTION(9)		1
6	6682255	VAVLE	section - See Page VALVE SECTION(10)		1
7	NSS	BOLT			4
8	6682249	KIT	mounting - Ref. WORK VALVE(2), WORK VALVE(3) & WORK VALVE(7)		1
9	6682467	SEAL KIT	complete valve		1

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

HYDROSTATIC PUMP
(Gear Pump End)




B-21581A

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

VALVE ROCKER ARM
(Kubota - V2203)



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


CAB DOORS

Ref.N°	Part N°	Description	Remarks	Serial N°	Qty.
1		ENCLOSUREinD1}B	Ref. CAB DOORS(2)CAB DOORS(35)		1
2	6813444	DOORinD1n	driver- Ref. CAB DOORS(4)CAB DOORS(18)		2
3	6812896	DOOR	passenger - Ref. CAB DOORS(4), CAB DOORS(6)CAB DOORS(9), CAB DOORS(11), CAB DOORS(12), CAB DOORS(14), & CAB DOORS(17)CAB DOORS(		1
4	6814428	RIVET			14
5	NAP	GLASS	top assy - Order 6816365 - Was 6813804 [A]	5205 11779 & Bel	1
5	6816365	GLASS	top assy - See Page NO PAGE	5205 11780 & Abv	1
6	NAP	SEAL	60'(1524mm) long - Order Ref. CAB DOORS(24)		2
7	NAP	SEAL	64'(1625,6mm) long - Order Ref. CAB DOORS(24)		2
8	6674667	HANDLE	door		2
8	6709527	KEY			1
9	17C-408	BOLT			2
10	6813625	GLASS	lower		1
11	29CM-816	BOLT			2
12	6681943	STRAP	door		2
13	6813445	DOOR	driver		1
14	6803202	SCREW			10
15	NAP	BRACKET	latch - Was 6813430 [A]	5205 11779 & Bel	1
15	7100378	BRACKET	latch	5205 11780 & Abv	1
16	6682267	LATCH			1
17	6680967	HANDLE	grab		2
18	NAP	SEAL	176'(4470,4mm) long - Order Ref. CAB DOORS(25)		2
19	NAP	GLASS	top assy - Order 6816366 - Was 6813807 [A]	5205 11779 & Bel	1
19	6816366	GLASS	top assy - See Page NO PAGE	5205 11780 & Abv	1
20	6813624	GLASS	bottom		1
21	6812895	DOOR	passenger		1
22	NAP	BRACKET	latch - Was 6812304 [A]	5205 11779 & Bel	1
22	7100377	BRACKET	latch	5205 11780 & Abv	1
23	6682266	LATCH			1
24	6681569	SEAL	bulk - Sold Per Foot		x
25	6675410	SEAL	bulk - Sold Per Foot		x
26	6654170	STRIKER BOLT	striker		2
27	6813474	BRACKET	strikerbolt		2
28	29CM-825	SCREW			4
29	51DM-10	NUT			2
30	6630207	RIVET			10
31	6684581	FRONT LATCH	driver side		1
32	6684582	REAR LATCH			2
33	6684583	KNOB CATCH			2
34	6684584	BUMPER	stop		2
35	6684585	FRONT LATCH	passenger side		1

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

* SIDE MIRROR KIT



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 18 of 307 pages

The full manual includes:

- All 307 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Bobcat 5600 Parts Manual

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual