



TRACK IDLER ASSEMBLY




TRACK DRIVE ASSEMBLY

ITEM	PART	DESCRIPTION	QTY.
1	9033014	ASS, CAST TRACK 44 LINK SER 2	1
2	9982006C	WHEEL, DRIVE 33/44 SERIES	2
3	9241401	SPACER, TRACK CENTER ALIGNMENT	2
4	9982007	WHEEL, RIBBED TRACK, MACHINED	2
5	9801401	SPROCKET, SEGMENT 6 TOOTH NEW	6
6	7121652	BOLT WHEEL 1/2-20 X 1 1/2 90 D	24
7	4889050	TIRE CAST URETHANE 14.75 X 12.25	2
8	4495006	HUB, MODEL 60 AUBURN (55:1)	1
9	4495003	HUB, MODEL 6N AUBURN NON PW	1




TRACK CHAIN ASSEMBLY



ITEM	PART	DESCRIPTION	QTY.
1	4527101	LINK, TRACK DUCTILE IRON SER 2	13
2	9636321	PIN, CAST TRACK SER 2	13
3	9149100	BUSHING, .695 ID X 1-1/8 OD HARD	26
4	9527001	LINK, CAST TRACK SER 2	24
5	9971011	WASHER, TRACK PIN RET SER 2	26
6	4704000	CASTER WHEEL FOR 33/44 TRACK	4
7	9636330	PIN, TRACK ROLLER WHEEL	2
8	7637000	PIN-BLANK ROD END 3/8 X 2-1/2	2
9	7721523	5/16"-18 X 1 HHCS	2
10	7958310	3/4 WASHER	8
11	9033014	44 LINK TRACK CHAIN ASSEMBLY	2

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




Bed Lift Cylinder

1	05070093	Hairpin Clip 3/4" Shaft	4
2	5997500	Zerk Grease Str 1/4 28	2
3	05070273	CYLINDER-HYDRAULIC 3X12	1
4	83510020	PIN-HARDENED CYLINDER	2
5	9971007	Washer 3300 Bed Cyl Anchor	2

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Hydraulic Hose Routings




Blurred on purpose. The manual you buy has this page in full quality.

PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com


AUGER CHAIN GEAR BOX



ITEM	PART	DESCRIPTION	QTY.
1.	3549754	WHITE MOTOR	2
2.	9132102	CHAIN BOX	2
3.	4175208	CHAIN #58 58 LINK	2
4.	9801281	GEAR SPROCKET	2
5.	9216103	CHIAN BOX COVER	2
6.	4437086	FLANGE	2
7.	4070010	BEARING FANIR	2
8.	4437086	FLANGE	2
9.	9791013	SPACER	2
10.	9801281	GEAR SPROCKET	2

ASPHALT GATES






ITEM	PART	DESCRIPTION	QTY.
1	9446151	3300 DRIVEN GATE LEVER	1
2	9446150	3300 DRIVING GATE LEVER	1
3	9445050	3300 GEARED KNIFE GATE	1
4	3220131	GATE CYLINDER	1
5	9528100	GEARED GATE LINKE	2
6	9149010	BUSHING .5IDX.99OD	4
7	9149011	BUSHING MILL, GATE PILOT	3
8	9974101	WASHER-GATE	4
9	4793563	THRUST WASHER GALT LINK	4
10	7561278	50JACK	7
11	7962278	0.500 LOCK WASHER FLAT	7
12	9974102	WASHER GATE GEAR	2
13	7721654	HHCS 65P 1/2-13X1 3/4	4
14	7721660	HHCS 65P 1/2-13X3	3
15	9974110	33/44 GATE RUB PLATE	1
16	5252000	END BALL SOCKET 3/4-16	1

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

3313 SPARE PARTS




Tractor

Track Drive	2
Track Chain	2
Track Runner	3
Bumper Roller	4
Bed Lift Cylinder	6
Wings Assembly	7
Auger Assembly	8
Auger Chain Box	9
Asphalt Gates	9
Left Hand Dash	10-11
Right Hand Dash	12-13
Hood	14


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



TRACK CHAIN TENSIONER

ITEM	PART #	DESCRIPTION	QTY.
1	9051000	BALL, MILL SER SPRING PIVOT	1
2	1057383	BASE-WASHER	1
3	5799700	Spring 7/8 X 6 TRACK TENSIONER	1
4	9694154	RETAINER SPRING CENTERING TRACK DR	1
5	9702540	ROD-TRACK PUSH 3300	1
6	7561340	NUT HEX 1-14	2
7	7636580	PIN COTTER 3\32X2	1




TRACK RUNNER

ITEM	PART #	DESCRIPTION	QTY.
1	9709200	RUNNER	1
2	9136700	3300 RUBBER TRACK GUARD BRACKET	2
3	9456330	3300 RUBBER TRACK GUARD	1
4	7561262	NUT HEX 3/8"-16 PLTD	2
5	7721563	HHCS G5P 3/8-16 X 1.	5
6	7962262	WASHER,LOCK 3/8 PLTD	5
7	7962294	5/8" lock washer	2
8	7561294	0.625-112	


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




STEP ASSEMBLY

ITEM	PART	DESCRIPTION	QTY.
1.	7561278	0.500-13 NUT	6
2.	7962278	0.500 LOCK WASHER FLAT	6
3.	7958278	0.500 PLTD FLAT WASHER	6
4.	9791008	SPACER, .75OD X .51ID X .375	6
5.	9636013	PIN, UNIMAT STEP LATCH	2
6.	9980102	WLDMNT, BRCE UNIMAT LH	1
7.	9980103	*WLDMNT, BRCE UNIMAT RH	1



SCREED STEPS

ITEM	PART	DESCRIPTION	QTY.
1	9853018	STOP-LOWER STEP 15UNI	2
2	9636012	PIN, LOWER STEP HINGE	2
3	9852933	STEP, LOWER LH 15 UNI	1
4	9852932	STEP, LOWER RH 15 UNI	1



3313 Page 47
Upper Screed Steps

1	83510433	Wldmnt, Unimat Upper Step Lh	1
2	9852925	Step Unimat Upper Mid	1
3	83510434	Wldmnt, Unimat Upper Step Rh	1
4	9636018	Pin Unimat Center Step Hinge	1
5	7712575	Hhcs G5P 5/16 18 X 3	8
6	08752106	Washer	8
7	83510429	Mount Unimat Step Vib	4
8	7561254	Nut Hex 5/16 18 Pltd	8

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 8 of 58 pages

The full manual includes:

- All 58 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Bomag 3313 Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual