How To Use Figure Search

1). Locate the figure list index at the beginning of manual

examples:

01A01 FRONT WHEEL ASSEMBLY - 2100,2110,2120,2150,2300,2310,3055,3100,3120,3150,3190,3300,3310,3550,4140

01A01[C] FRONT WHEEL ASSEMBLY, W/16" WHEELS - 3400, 3500, 3550, 4400, 4500, 4410, 5100, 5200, 5190, 7100, 7200

01B01 STANDARD REAR WHEELS - 2000, 4100 & 3000 EXCEPT 3550

01B01[A] STANDARD REAR WHEELS - 3500, 3550, 5000, 7000, 4000 EXCEPT 4110

01B02 POWER ADJUSTABLE REAR WHEELS - 2000, 3000, 4140

Use the “search” feature in adobe to jump to the figure number.

Press **Ctrl** key, and letter **F** on the keyboard, at the same time. This will bring up the “search” feature in Adobe Acrobat. Then simply type in the figure number you wish to locate, and press enter.

Adobe takes you immediately to that page!

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


4630 3 CYL AG TRACTOR ALL PURPOSE (3/90-7/99)

01A01 FRONT WHEEL & HUBS

Ref	Part Number	Qty	Description
1	E0NN1007LA	2	Wheel Assy., 8.00 x 16", Start Year: 03/01/1990
1	82005056	2	Wheel Assy., 5.50 x 16", use w/ 7.50 x 16" Tire, Start Year: 03/01/1990
1	82006575	2	Wheel Assy., 4.00 x 16", 6.00 x 16" Tire, Start Year: 03/01/1990
1	82006576	2	Wheel Assy., 6.00 x 15", 7.50 x 15" Tire, Start Year: 03/01/1990
1	82005057	2	Wheel Assy., 5.50 x 18", 7.50 x 18" Tire, Start Year: 03/01/1990
1	82005055	2	Wheel Assy., 8.00 x 16", 10.00 x 16" Tire, Solid Disc, Heavy Duty, Start Year: 03/01/1990
1	82005058	2	Wheel Assy., 4.50 x 19", 6.00 x 19" Tire, L/Germany Minimum Track 56", Start Year: 03/01/1990
1	82005054	2	Wheel Assy., 8.00 x 15", 11"L x 15" Tire, Start Year: 01/01/1991
1	82005060	2	Wheel Assy., 10.00 x 16", Start Year: 03/01/1990
2	310195	2	Retainer, Start Year: 03/01/1990
3	86516468	2	Bearing, Cone, Inner, w/Rollers, 1-3/8" ID x 23/32" W, Start Year: 03/01/1990
4	C9NN1104E	2	Hub Assy. Includes: Ref. 5 thru 7A, Years: 03/01/1990-05/31/1994
5	86516467	2	Bearing, Cup, Years: 03/01/1990-05/31/1994
6	81816580	12	Bolt, 1/2"-20 x 1-3/4", Front Wheel Hub, Start Year: 03/01/1990
7	36725	2	Cup, Outer, Years: 03/01/1990-05/31/1994
7A	277393	2	Fitting, 5/16", NH-E Only, Years: 03/01/1990-05/31/1994
7A	277393	2	Fitting, 5/16", NHNA Only, Years: 03/01/1990-05/31/1994
8	36724	2	Cone & Roller, Outer, Years: 03/01/1990-05/31/1994
9	81815739	12	Nut, 1/2"-20, Front Wheel Bolt, Start Year: 03/01/1990
10	957E1195	2	Washer, Years: 03/01/1990-05/31/1994
11	387930S36	2	Nut, Hex, Slotted, 3/4"-16, Years: 03/01/1990-05/31/1994
12	86523851	2	Pin, Split Cotter, 5/32" x 1-1/4", Years: 03/01/1990-05/31/1994
13	957E1139	2	Cap, Years: 03/01/1990-05/31/1994
14	4951077	2	Seal, Inner, Except 3230, Start Year: 06/01/1994
15	86512015	2	Cone & Roller Bearing Assy., Inner, OD 73.43,ID 41.27,Except 3230, Start Year: 06/01/1994
16	5166086	2	Hub, Except 3230, Start Year: 06/01/1994
17	5132343	2	Cone & Roller Bearing Assy., Outer, OD 57.15,ID 25.40,Except 3230, Start Year: 06/01/1994
18	559715	2	Washer, M20.5-32 x 2.4, Except 3230, Start Year: 06/01/1994
19	14044271	2	Nut, Hex, Special, M20-1.5, Except 3230, Start Year: 06/01/1994
20	4957312	2	Cap, Except 3230, Start Year: 06/01/1994
21		2	Bearing Set, NH-E Only, Start Year: 03/01/1990
22	D5NN1215A	2	Kit, Bearing, Includes 7 & 8, NH-E Only, Start Year: 03/01/1990
22	179080	2	Kit, Bearing, Includes 7 & 8, Start Year: 03/01/1990
23	E2155T9	2	Kit, Front Wheel Bearing, Includes Ref. 2,21 & 22, Years: 03/01/1990-05/31/1994

PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


07A01 SYNCHRONIZED TRANSMISSION, W/8 X 8, 16 X 8, L/CAB - EXCEPT 3930H



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

15A01 CAB ASSEMBLY, COMPLETE - 3430, 3930, 3930H, 4130, 4630




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Figure Search for 4630 3 CYL AG TRACTOR ALL PURPOSE (3/90-7/99)

07L02 BACK IDLE SHAFT, W/SYNCHRONIZED TRANSMISSION, W/16 X 8
07M01 OUTPUT SHAFT & GEARS, SHIFTER 1 & 2, W/SYNCHRONIZED TRANSMISSION, W/8 X 8, 16 X 8
07N01 SHIFTER 1 & 2, W/SYNCHRONIZED TRANSMISSION, W/8 X 8, 16 X 8, L/CAB - EXCEPT 3930H
07N02 SHIFTER 1 & 2, W/SYNCHRONIZED TRANSMISSION, W/8 X 8, 16 X 8, W/CAB - 3430, 3930, 3930H, 4130, 4630
07P01 SHIFTER 3 & 4, HIGH & LOW, W/SYNCHRONIZED TRANSMISSION, W/8 X 8, L/CAB - EXCEPT 3930H
07P02 SHIFTER 3 & 4, HIGH & LOW, W/SYNCHRONIZED TRANSMISSION, W/8 X 8, 16 X 8, W/CAB - 3430,3930,3930H,4130,4630
07Q01 SHIFTER FRONT & REAR, W/SYNCHRONIZED TRANSMISSION, W/8 X 8, L/CAB - EXCEPT 3930H
07Q02 SHIFTER FRONT & REAR, W/SYNCHRONIZED TRANSMISSION, W/8 X 8, W/CAB - 3230,3430,3930,3930H,4130,4630
07Q03 SHIFTER FRONT & REAR, W/SYNCHRONIZED TRANSMISSION, W/16 X 8, L/CAB - EXCEPT 3930H
07Q04 SHIFTER FRONT & REAR, W/SYNCHRONIZED TRANSMISSION, W/16 X 8, W/CAB - 3430,3930,3930H,4130,4630
07R01 SHIFT LEVERS, W/SYNCHRONIZED TRANSMISSION, W/8 X 8, 16 X 8, L/CAB - EXCEPT 3930H
07R02 SHIFT LEVERS, W/SYNCHRONIZED TRANSMISSION, W/8 X 8, 16 X 8, W/CAB - 3430,3930,3930H,4130,4630
07T01 TRANSMISSION ASSEMBLY, CASE & SHIFT FORKS, W/NON-SYNCHRONIZED TRANSMISSION, 8 SPEED, W/8 X 2
07T02 GEARS & RELATED PARTS, W/NON-SYNCHRONIZED TRANSMISSION, 8-SPEED, W/8 X 2
07U01 PTO COVER, 2-SPEED SHIFTABLE, W/8 X 8, 16 X 8 (NH-E)
07U02 PTO COVER ASSEMBLY
07U03 IPTO COVER & RELATED PARTS, W/8 X 2
07U04 PTO SHIFT CONTROL
07U05 IPTO CLUTCH & RELATED PARTS
07U06 PTO CLUTCH VALVES
07U07 PTO, 2-SPEED SHIFTABLE, W/2WD
07U08 IPTO CONTROL LEVER & RELATED PARTS, W/CAB - 3430, 3930, 3930H, 4130, 4630
07U10 IPTO HANDLE ASSEMBLY & RELATED PARTS
07U11 PTO GUARD, HINGED
07U12 PTO GUARD, DETACHABLE
07V01 OIL COOLERS, HYDRAULIC & TRANSMISSION
07W01 CLUTCH ASSEMBLY, W/CAB, W/13" CLUTCH - 3430, 3930, 3930H, 4130, 4630
07W02 CLUTCH ASSEMBLY, L/CAB, W/13" CLUTCH - 3230, 3430, 3930, 4130, 4630
07X01 MAIN SHIFT LEVERS, W/SYNCHRONIZED TRANSMISSION, W/16 X 8, W/CAB - 3430, 3930, 4130, 4630
07X02 SHUTTLE SHIFT CONTROL, W/SYNCHRONIZED TRANSMISSION, L/CAB - EXCEPT 3930H
07X03 SHUTTLE SHIFT CONTROL, W/SYNCHRONIZED TRANSMISSION, W/CAB - 3430, 3930, 3930H, 4130, 4630
07X04 SHIFT CONTROL, W/CAB, W/8 X 8; W/SYNCHRONIZED TRANSMISSION, W/16 X 8, W/DUAL POWER
07X05 SHIFTER ASSEMBLY, REVERSE - 3430, 3930, 3930H, 4130, 4630, 4630-O
07Y01 REDUCTION GEARBOX ASSEMBLY, W/CREEPER, W/NON-SYNCHRONIZED TRANSMISSION, W/8 X 2, D.I.A.
08A01 RADIATOR & RELATED PARTS
08B01 WATER PUMP & RELATED PARTS
08C01 OIL COOLER & RELATED PARTS FOR HORIZONTAL EXHAUST- 4130; W/HEADLAND PISTONS - 4630
08C01[A] OIL COOLER & RELATED PARTS FOR VERTICAL EXHAUST - 4130; W/HEADLAND PISTONS - 4630
08D01 WATER FILTER, L/CAB, EXCEPT 3930H
08D02 WATER FILTER, W/CAB, 3430, 3930, 3930H, 4130 & 4630
09A01 FUEL SYSTEM, NON-EMISSIONIZED (3/90-12/97)
09A02 FUEL SYSTEM, EMISSIONIZED (1/98)
09B01 FUEL TANK & RELATED PARTS
09C01 FUEL TANK & RELATED PARTS, AUXILIARY
09D01 FUEL INJECTION PUMP, DPA ROTARY, UPPER HALF
09D02 FUEL INJECTION PUMP, DPA ROTARY, LOWER HALF
09E01 FUEL SEDIMENTER & FILTER ASSEMBLY
09E02 FUEL FILTER ASSEMBLY, EMISSIONIZED (1-98/)
09F01 FUEL INJECTOR ASSEMBLY
09G01 TUBE & CLAMP ASSEMBLY, FUEL INJECTION
09H01 DIESEL COLD START

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

4630 3 CYL AG TRACTOR ALL PURPOSE (3/90-7/99)


03A05 FRONT AXLE ASSEMBLY (6-94/) - EXCEPT 3230

Ref	Part Number	Qty	Description
1	5169930	1	Axle Assy., Low Clearance, Start Year: 06/01/1994
1	5169997	1	Axle Assy., High Clearance, Includes: Ref. 1A thru 28 & 36, 37, No Longer Serviced - NH-E, Start Year: 06/01/1994
1A	5166089	1	Axle, Center, Start Year: 06/01/1994
2	5166094	2	End, Axle, High Profile, Start Year: 06/01/1994
2	5166105	2	End, Axle, Low Profile, Start Year: 06/01/1994
3	5189894	1	Cylinder Assy., Steering, Start Year: 06/01/1994
4	5166080	1	Arm, Steering, L.H., Start Year: 06/01/1994
5	5166081	1	Arm, Steering, R.H., Start Year: 06/01/1994
6	15862131	2	Bolt, M14 x 1.5 x 80, Start Year: 06/01/1994
7	10517174	2	Washer, Lock, M14, Start Year: 06/01/1994
8	12164021	2	Nut, M14, Start Year: 06/01/1994
9	5168833	4	Pin, Start Year: 06/01/1994
10	11191779	4	Washer, M20, Start Year: 06/01/1994
11	16980931	4	Nut, EBM, M20 x 1.5, Start Year: 06/01/1994
12	5168896	1	Tube, Steering, RH, Start Year: 06/01/1994
13	5168898	1	Tube, Steering, LH, Start Year: 06/01/1994
14	5166075	1	Tie Rod Assy., Start Year: 06/01/1994
15	12575921	3	Nut, Self-Locking, M16 x 1.5, Start Year: 06/01/1994
16	5100730	1	Washer, Start Year: 06/01/1994
17	5166099	1	Spindle, RH, High Profile, Start Year: 06/01/1994
17	5166109	1	Spindle, RH, Low Profile, NHNA Only, Start Year: 06/01/1994
18	5166101	1	Spindle, LH, High Profile, Start Year: 06/01/1994
18	5166111	1	Spindle, LH, Low Profile, NHNA Only, Start Year: 06/01/1994
19	10839510	4	Dowel, Start Year: 06/01/1994
20	5144475	2	Washer, Thrust, Start Year: 06/01/1994
21	561953	2	Ring, Start Year: 06/01/1994
22	566125	2	Cup, Start Year: 06/01/1994
23	5166087	1	Pin, Start Year: 06/01/1994
24	5166084	1	Bushing, Start Year: 06/01/1994
25	5168900	1	Washer, M18, Start Year: 06/01/1994
26	12576014	1	Nut, Self-Locking, M18 x 1.5, Start Year: 06/01/1994
27	11191974	1	Washer, Lock, Tapered, M22 x 42x5, Start Year: 06/01/1994
28	87414	1	Nipple, Lube, Straight, 1/4"-28, Start Year: 06/01/1994
29	82002582	1	Kit, Hydraulic Line Extension, Includes: Ref. 30 thru 35, NHNA Only, Start Year: 06/01/1994
30	82002579	1	Extension, Tube Assy., LH, Start Year: 06/01/1994
31	82002578	1	Extension, Tube Assy., RH, Start Year: 06/01/1994
32	10902224	1	Screw, Cap, HH, CL 8.8, M6 x 1 x 16, Start Year: 06/01/1994
33	86517328	1	Washer, Lock, 6mm, Start Year: 06/01/1994
34	4999554	1	Clamp, Tube, Start Year: 06/01/1994
35	5138294	1	Clamp, Tube, Start Year: 06/01/1994

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

03G05 DRIVE SHAFT & SHIELD ASSEMBLY



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


4630 3 CYL AG TRACTOR ALL PURPOSE (3/90-7/99)


05B02 LIFT CONTROL & DRAFT CONTROL, L/CAB (3-90/3-94) - EXCEPT 3930H

Ref	Part Number	Qty	Description
1	D3NNN625A	1	Quadrant, Years: 03/01/1990-03/31/1994
2	D3NN516A	1	Plate, 3230,3430,3930,4130,4630,4630-O, Years: 03/01/1990-03/31/1994
2	83930487	1	Plate, 3930N,3930NO,4130N,4130NO,4630N,4630NO, No Longer Serviced - NH-E, Years: 03/01/1990-03/31/1994
3	56701S2	2	Screw, Cap, Flg Hd, Pilot Pt, G5, 1/4"-20 x 1/2", Years: 03/01/1990-03/31/1994
4	D3NNF982A	1	Support, 3230,3430,3930,4130,4630,4630-O, Years: 03/01/1990-03/31/1994
4A	E0NNF982AA	1	Support, 3930N,3930NO,4130N,4130NO,4630N,4630NO, Years: 03/01/1990-03/31/1994
5	9706729	2	Screw, Cap, HH, G5, 7/16"-14 x 1", Years: 03/01/1990-03/31/1994
6	81547	2	Washer, Lock, 7/16", Years: 03/01/1990-03/31/1994
7	88011	2	Screw, Cap, HH, G5, 3/8"-16 x 1-1/4", Years: 03/01/1990-03/31/1994
8	80680	2	Washer, Lock, 3/8", Years: 03/01/1990-03/31/1994
9	D3NNJ977A	AR	Spacer, Years: 03/01/1990-03/31/1994
10	E5NNB505AA11L	1	Handle Assy., Draft, 3230,3430,3930,4130,4630,4630-O, Years: 03/01/1990-03/31/1994
10A	E0NNB505AB11L	1	Handle Assy., Draft, 3930N,3930NO,4130N,4130NO4630N,4630NO, Years: 03/01/1990-03/31/1994
11	C5NN518B	2	Disc, Friction, Years: 03/01/1990-03/31/1994
11		2	Disc, Friction, NH-E Only, Years: 03/01/1990-03/31/1994
12	280474	1	Nut, Lock, Hex, 7/16"-20, Years: 03/01/1990-03/31/1994
13	E1ADDN522B	1	Washer, Spring, 7/16", Years: 03/01/1990-03/31/1994
14	C7NNA611A	1	Washer, Cupped, Years: 03/01/1990-03/31/1994
15	E5NND943AA11L	1	Handle Assy., Lift Position, 3230,3430,3930,4130,4630,4630-O, Years: 03/01/1990-03/31/1994
15A	E0NND943AB11L	1	Handle Assy., Lift Position, 3930N,4130N,4630N,3930NO,4130NO,4630NO, Years: 03/01/1990-03/31/1994
16	D4NN534A	1	Stop, Years: 03/01/1990-03/31/1994
17	D3NNA906A	1	Knob, Years: 03/01/1990-03/31/1994
18	34464S36	1	Nut, Tee, 1/4"-20, Years: 03/01/1990-03/31/1994
19	957E532	1	Gasket, Years: 03/01/1990-03/31/1994
20	E5NNL892BA	2	Knob, Years: 03/01/1990-03/31/1994

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com





PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com

05J07 ATTACHING PARTS, 3RD & 4TH DELUXE REMOTE, W/CAB - 3230, 3430, 3930, 3930H, 4130, 4630

Ref	Part Number	Qty	Description
42	F0NND972AA	1	Seal, Foam, 94mm x 154mm, Start Year: 03/01/1990
43	F0NN3N528AA	1	Cover, Cab Floor, Start Year: 03/01/1990
44	86511830	2	Screw, Pan Hd, CL 4.8, M6 x 1 x 20, Start Year: 03/01/1990
45	277634	4	O-Ring, 90 Duro, .799" ID x .103" Thk, Start Year: 03/01/1990
46	302210S36	5	Screw, Cap, HS, G8, 5/16"-18 x 1", Start Year: 03/01/1990
47	306457S36	1	Screw, Cap, HS, G8, 5/16"-18 x 4-1/2", Start Year: 03/01/1990
48	306421S36	1	Screw, Cap, HS, G8, 5/16"-18 x 3-1/2", Start Year: 03/01/1990
49	97326S35	2	Clamp, Start Year: 03/01/1990
50	E0NNJ853AB11B	1	Bracket, Start Year: 03/01/1990
51	304896S36	AR	Screw, Cap, HH, G5, 5/8"-11 x 2-1/2", Start Year: 03/01/1990
51	58725S36	AR	Screw, Cap, HH, G8, 5/8"-11 x 3", No Longer Serviced, Start Year: 03/01/1990
52	80680	3	Washer, Lock, 3/8", Start Year: 03/01/1990
53	88206	3	Screw, Cap, HH, G5, 3/8"-16 x 1", Start Year: 03/01/1990
54	E2NNJ908AA	2	Hose, Start Year: 03/01/1990
55	85700737	2	Clip, Start Year: 03/01/1990
56	87037S94	1	O-Ring, .750" ID x .103" Thk, Start Year: 03/01/1990
57	129979	1	O-Ring, .674" ID x .103" Thk, Start Year: 03/01/1990
58	E7NN4N308AA	1	Decal, Refer to Fig. 16B5, Start Year: 03/01/1990
59	F0NND948AA	1	Decal, Refer to Fig. 16B1, Start Year: 03/01/1990
60	82013395	1	Decal, Refer to Fig. 16B1, Start Year: 03/01/1990

PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

07G01 INPUT SHAFT & GEARS, W/SYNCHRONIZED TRANSMISSION, W/8 X 8



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

07Q04 SHIFTER FRONT & REAR, W/SYNCHRONIZED TRANSMISSION, W/16 X 8, W/CAB - 3430,3930,3930H,4130,4630

Ref	Part Number	Qty	Description
1	K3660629731	1	Rod, Shift, Start Year: 03/01/1990
2	K3660629741	1	Lever, Shift, Start Year: 03/01/1990
3	K0541100632	1	Pin, Spring, Start Year: 03/01/1990
4	K3660229201	1	Fork, Shift 1 & 2, Refer to ISO Field Service Program No. 520, Start Year: 03/01/1990
5	K3582029432	1	Pin, Fork Set, Start Year: 03/01/1990
6	K3660229221	1	Spring, Refer to ISO Field Service Program No. 520, Start Year: 03/01/1990
7	K0771500803	1	Ball, Refer to ISO Field Service Program No. 520, Start Year: 03/01/1990
8	K3660629761	1	Plunger, Start Year: 03/01/1990
9	K3660629771	1	Switch, Dual Power Lockout, Start Year: 03/01/1990
10	K0471100200	1	Gasket, Start Year: 03/01/1990
11	K3660629781	1	Shaft, Shift Lever, Start Year: 03/01/1990
12	SBA052100180	1	O-Ring, Start Year: 03/01/1990
13	K3660629791	1	Lever, Shift, Start Year: 03/01/1990
14	370024	1	Ring, Snap, Ext, M20, Start Year: 03/01/1990
15	K3660629811	1	Lever, Support, Start Year: 03/01/1990
16	K0112350816	1	Bolt, Start Year: 03/01/1990
17	82001723	2	Bushing, Start Year: 03/01/1990

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

4630 3 CYL AG TRACTOR ALL PURPOSE (3/90-7/99)


07U10 IPTO HANDLE ASSEMBLY & RELATED PARTS

Ref	Part Number	Qty	Description
1	E0NNL909EC11M	1	Handle Assy., PTO Control, Years: 03/01/1990-09/30/1995
1	82007171	1	Handle Assy., PTO Control, Start Year: 10/01/1995
1A	E2NNL909BB	1	Handle Assy., PTO Control, Start Year: 03/01/1990
2	E9NNC771BB	1	Knob, Start Year: 03/01/1990
3	82005029	1	Stop Assy., PTO, Refer to Service Journal 9-86, 2T & 2-90, 1T., Start Year: 03/01/1990
3	82007169	1	Stop Assy., PTO, Start Year: 10/01/1995
3A	E2NNC767AA	1	Stop Assy., PTO, Start Year: 03/01/1990
4	100037	1	Nut, Lock, Prevailing Torque, CL 8, M10 x 1.5, Start Year: 03/01/1990
5	80680	1	Washer, Lock, 3/8", Start Year: 03/01/1990
6	88374	1	Screw, Cap, HH, G5, 3/8"-24 x 1", Start Year: 03/01/1990

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

08C01 OIL COOLER & RELATED PARTS FOR HORIZONTAL EXHAUST- 4130; W/HEADLAND PISTONS - 4630



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


09G01 TUBE & CLAMP ASSEMBLY, FUEL INJECTION

Ref	Part Number	Qty	Description
1	E9NN9N868AA	1	Tube & Clamp Assy., Fuel Injection Pump, Includes: Ref. 2 thru 5, Order Components, Start Year: 03/01/1990
1	87801783	1	Tube & Clamp Assy., Fuel Injection Pump, Components Not Serviced Separately, Used W/ 3930 & 4630 Emissionised Engines from 1-98/, Start Year: 01/01/1998
2	E9NN9A555AA	1	Tube, #1 Cylinder, Start Year: 03/01/1990
3	E9NN9A556AA	1	Tube, #2 Cylinder, Start Year: 03/01/1990
4	E9NN9A557AA	1	Tube, #3 Cylinder, Start Year: 03/01/1990
5	E5NN9N653DA	1	Clip Assy., Start Year: 03/01/1990

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


11C01 REAR WIRING, W/CROWN FENDERS, NH-E, 3430, 3930, 4130 & 4630



PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com

11G01 STARTER MOTOR ASSEMBLY (3-90/3-92)




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


15F01 HEATER ASSEMBLY - 3430, 3930, 3930H, 4130, 4630



PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com

15K01 HEATER & RELATED PARTS, W/LOW PROFILE CAB, 3430, 3930, 4130 & 4630



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 25 of 631 pages

The full manual includes:

- All 631 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

New Holland 4630 Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual