NUMERICAL INDEX

Part number	Page	Item
I0-01558-3000	38	598
I0-01804-1300	22	30(A)
I0-03509-1100	21	119
I0-03559-3000	21	231(A)
I0-03566-3000	21	488(C)
I0-04420-2700	28-1	194(A)
I0-20800-6120	20	66(A)
I0-28050-6120	19	198(B)
	27	311
	34	150(A)
	36	467(A)
I0-28050-6160	6	401
	10	136
	12	124
	21	21
	29	782(B)
	38	465
	28-1	697
I0-28050-8100	27	29(A)
I0-28050-8120	14	139(A)
	22	280
	34	150(B)
I0-28050-8160	12	36(A)
	17	63(A)
	20	66(B)
	26	49
	34	150(B)
	28-1	472
I0-28050-8200	5	13
	12	36(B)
	16	295
	25	76(D)
	38	448
I0-28050-8300	26	29(A)
I0-28050-8350	12	36(C)
I0-28050-8450	12	36(D)
	26	29(B)
I0-28050-8600	5	263(A)
	12	36(E)
	17	36
I0-28050-8700	14	13(A)
	17	63(C)
	22	283(A)
I0-28050-8800	18	50
	28	2(A)
I0-28050-8900	25	76(B)
I0-28051-0160	34	150(C)
I0-28051-0200	34	150(D)
I0-28051-0300	13	20(A)
I0-28051-0450	13	20(B)
I0-28051-0600	13	20(C)
I0-28051-0700	13	20(D)
I0-28055-8110	14	13(B)
	25	76(E)
I0-28056-0130	29	16
I0-28061-0600	10	114(A)
I0-28161-2600	10	114(B)
I0-28650-6200	27	414(A)
I0-28650-6300	3	26
	14	809
I0-28650-6350	36	534
I0-28650-8200	20	96
	38	68
I0-28650-8250	6	211
	12	185
	23	426
	28	2(B)
I0-28650-8300	12	36(F)
	17	63(B)
I0-28650-8350	5	263(B)
	25	76(C)
I0-28650-8400	4	143
	36	580(A)
	37	580(A)
I0-28651-0300	12	211(A)
I0-28751-0250	5	15
I0-28751-2350	12	211(B)
	29	4
I0-41010-6160	12	81(A)
I0-41010-6200	14	32
	21	141
I0-41010-8180	27	585
I0-41010-8200	25	374
I0-41010-8250	28	15
I0-41010-8300	17	42
I0-41010-8350	17	154
I0-41010-8400	8	30
I0-41010-8500	28	16
I0-49140-8300	12	81(B)
I0-50640-8180	8	23
I0-58330-6100	4	155
I0-58330-6160	10	166
I0-58330-6500	14	731
I0-58330-8250	9	87(A)
I0-58330-8400	9	87(B)
I0-91110-5060	14	808
I0-91180-1060	21	460
	22	110
I0-91180-1080	28-1	747
I0-91180-1100	12	205
I0-91180-2060	3	2
	12	80(A)
	19	49
	19	160
I0-91180-2080	5	224
	8	29
	12	98
	12	621
	12	80(B)
	14	20
	17	40
	17	155
	20	82
	25	362
	27	131
	28	12
	28	681
	28-1	565
I0-91610-6080	28-1	779
I0-91610-7060	30	737
I0-91614-7080	20	88
I0-95234-8550	27	89(A)
I0-95235-0520	19	29(A)
I0-95235-8560	34	483(A)
I0-95690-2260	17	22
I1-09070-1201	10	200
I1-09600-0122	4	7(A)
I1-09604-0740	27	480
I1-09605-0500	7	15
I1-09623-5410	22	219
I1-09630-0830	22	175
I1-09630-0860	24	9
I1-09630-0900	8	3
I1-09639-0340	5	230
I1-09675-0810	21	138(A)
I1-09675-0880	21	138(B)
I1-09675-0951	24	69
I1-09700-1261	16	18(A)
I1-09700-6071	34	483(B)
I1-09700-8610	34	483(C)
I1-09700-8630	34	483(D)
I1-09701-0130	34	483(F)
I1-09701-0470	16	18(B)
I1-09701-1071	34	483(E)
I1-09709-1820	28-1	73(B)
I1-13240-2322	25	2
I1-47475-8680	16	97
I1-81118-0110	32	62
I1-81229-3820	32	21
I1-81229-4740	32	18
I1-81229-4780	32	88
I1-81229-4790	32	87
I1-81229-7230	32	3(A)
I1-81229-7330	32	43
I1-81229-7580	32	3(B)
I1-81229-7601	32	15
I1-82699-5880	14	685
I1-84132-0120	32	65
I5-09000-2270	12	211(C)
I5-09302-0030	28-1	756
I5-09500-0120	36	530
	37	530
I5-09500-0130	15	33
I5-09600-0130	7	21(C)
I5-09605-0050	18	112
I5-09623-0020	8	9
I5-09675-0181	27	338
I5-09707-0311	34	102(B)
I5-11129-0030	8	383
I5-11129-0060	6	70
	7	70
I5-11219-0080	4	7(B)
	6	23(B)
	7	23(B)
I5-11219-0110	4	7(C)
I5-11219-0150	6	23(C)
I5-11219-0170	7	21(A)
I5-11219-0180	7	21(B)
	7	23(D)
I5-15411-2231	23	315(A)
I5-87411-8440	37	641
I5-87816-8230	2	2
I5-87816-8240	2	2
I5-87816-8250	2	2
I5-87817-0650	1	1
I5-87817-0660	1	1
I5-87817-0670	1	1
I8-12146-8300	29	797
I8-94107-7930	5	267
	18	193
I8-94109-8900	21	408(B)
I8-94121-1130	16	90
I8-94123-6231	3	5
I8-94125-8621	5	268
	18	147
	21	118(A)
I8-94133-2075	3	4
I8-94142-1561	11	38
I8-94152-6130	7	448
I8-94152-9720	31	21

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

ENGINE GASKET KIT (1/2)


ENGINE GASKET KIT (1/2)

REF NO.	PARTS NO.	Description	Q'ty	I	R	Remarks
1	**15-87817-0650**	GASKET SET; ENG OVERHAUL (HEAD GASKET T=1.05)	1			
1	**15-87817-0660**	GASKET SET; ENG OVERHAUL (HEAD GASKET T=1.10)	1			
1	**15-87817-0670**	GASKET SET; ENG OVERHAUL (HEAD GASKET T=1.15)	1			

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

ENGINE GASKET KIT (1/2)



PREVIEW ONLY FIXTHIS.COM


Download full manual at youfixthis.com

略語表/Abbreviation List

略語 ABBREVIATIONS	語源 DEFINITION	略語 ABBREVIATIONS	語源 DEFINITION
A	AMPERE	KOYO	KOYO SEIKO CO.
ACCEL	ACCELRATOR	KW	KILOWATT
ACL	AIR CLEANER	L	LITER
ADJ	ADJUSTER	L1=	LENGTH(VERTICAL)
AL	ALUMINUM	L2=	LENGTH(SIDE)
A/R	AS REQUIRED	L=	LENGTH
ASM	ASSEMBLY	LH	LEFT HAND
AUTO	AUTOMATIC	LK	LOCK
B=	BREADTH	LVR	LEVER
BRG	BEARING	LWR	LOWER
BRK	BRAKE	MAN	MANUAL
BRKT	BRACKET	MANIF	MANIFOLD
CAC	CHARGE AIR COOLER	MTG	MOUNTING
C/BL	CYLINDER BLOCK	M/T	MANUAL TRANSMISSION
CLU	CLUTCH	MM	MILLIMETER
CMPR	COMPRESSOR	NACHI	FUJIKOSHI CO.
COMB	COMBINATION	NGK	NIHON TOKUSHU TOGYO CO.
COMPL	COMPLETE	NO.	NUMBER
CONN	CONNECTING	NOK	NOK CO.
CONT	CONTROL	NOS	NIHON OIL SEAL CO.
CVR	COVER	NPN	NO PART NUMBER
CYL	CYLINDER	NPR	NIPPON PISTON RING CO.
D=	DIAMETER	NSG	NIPPON SHEET GLASS CO.
DC	DIRECT CURRENT	NSS	NOT SERVICED SEPARATELY
DIAPH	DIAPHRAGM	NSK	NIHON SEIKO CO.
DIFF	DIFFERENTIAL	NTN	TOYO BEARING CO.
EGR	EXHAUST GAS RECIRCULATION	OD	OUTSIDE DIAMETER
ENG	ENGINE	OPT	OPTION
EXC	EXCEPT	OVSI	OVERSIZE
EXH	EXHAUST	PCV	POSITIVE CRANK CASE
E#	ENGINE NUMBER		VENTILATION
EXP	EXPORT	PL	PLAIN
FIG NO.	FIGURE NUMBER	PRE-CHAMBER	PRECOMBUSTION CHAMBER
FLEX	FLEXIBLE	PROP	PROPELLER
FRT	FRONT	P/S	POWER STEERING
FWD	FORWARD	PTO	POWER TAKE OFF
G	GRAM	QOS	QUICK ON START
GEN	GENERATOR	QTY	QUANTITY
GOV	GOVERNOR	QUAD	QUADRANT
GRD=	GRADE	RAD	RADIATOR
G/RATIO	GEAR RATIO	REG	REGULATOR
H=	HEIGH	RET	RETAINER
HD	HEAD	REV	REVERSE
HEX	HEXAGON	RH	RIGHT HAND
HSG	HOUSING	RR	REAR
ID=	INSIDE DIAMETER	RWD	REARWARD
IGN	IGNITION	SPD	SPEED
INCL	INCLUDING	SPR	SPRING
INJ	INJECTION	STD	STANDARD
INL	INLET	SW	SWITCH
ISC	IDLE SPEED CONTROL	SYN	SYNCHRONIZER
JBK	JIDOSHA BUHIN KOGYO CO.	T=	THICKNESS
KG	KILOGRAM	TAP	TAPPING
KM/H	KILOMETER PER HOUR	TC	TURBOCHARGER

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



⑦ 親 ・ 子の表示

部品の親（アセンブリ）と子（その構成部品）の関係を表現するもので、イラスト上でのみ表現されます。

（例１） ＫＥＹ ＮＯ．８４は８６／８８及びＮＳＳ（コンロット、キャップは単品非補給）を含むことを示しています。

（例２） ＫＥＹ ＮＯ．８／９は４２、及び＊印（単品非補給、キットの内容品）を含むことを示しています。

⑦ ASSEMBLIES, KITS, SETS AND THEIR COMPONENTS

Assemblies, Kits and/or Sets are shown within a frame/box. Also shown within the frame/box are any components included with the assembly, Kit or Set.

EXAMPLE: Key No.84 includes Key No.86/88 and the connecting Rod and Cap which are notsupplied individually.

EXAMPLE: Key No.8/9 includes Key No.42 and those items identified with an asterisk(*). Items identified with no key number may only be available in an assembly, Kit or Set.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


OIL PAN AND LEVEL GAUGE OIL PAN AND LEVEL GAUGE

REF NO.	PARTS NO.	Description	Q'ty	I	R	Remarks
1(A)	18-98038-7652	PAN ASM; OIL	1			
2	18-98084-4781	GAUGE; OIL LEVEL	1			
3	11-09630-0900	GASKET; DRAIN PLUG	1			
6	18-98144-2470	PLUG; OIL DRAIN	1			
8(B)	18-98210-8650	TUBE; GUIDE, OIL LEVEL GAUGE	1			
9	15-09623-0020	GASKET; GUIDE TUBE, OIL LEVEL GAUGE	2			
17	18-98253-0910	GASKET; OIL PAN	1			
23	10-50640-8180	BOLT; OIL PAN (M8X18 W/LK&PL WASHER)	24			
27	18-98014-8246	CRANKCASE	1			
29	10-91180-2080	NUT; CRANKCASE (M8 FLANGE)	1			
30	10-41010-8400	STUD; CRANKCASE (M8X40 L=52)	1			
383	15-11129-0030	CUP; SEALING (OD=15.6)	1			

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

WATER PIPING; ENGINE



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

REF NO.	PARTS NO.	Description	Q'ty	I	R	Remarks
73(A)	18-94315-4260	CLIP; VAC HOSE (ID=13.2 & 7.5)	2			
73(B)	11-09709-1820	CLIP; VAC HOSE (ID=11.8 & 7.5)	1			
73(C)	18-94169-0270	CLIP; VAC HOSE (ID=8.3 & 16.5)	1			
73(D)	18-97031-6740	CLIP; VAC HOSE (ID=7.3)	8			
82	18-98045-3850	JOINT; 3WAY	1			
194(A)	10-04420-2700	HOSE; VAC (ID=3.5 L=270)	1			
194(B)	18-98153-8150	HOSE; VAC	1			
194(C)	18-98187-0610	HOSE; VAC (ID=4 L=490)	1			
194(D)	18-98187-0620	HOSE; VAC (ID=4 L=200)	1			
472	10-28050-8160	BOLT; BRKT	2			
565	10-91180-2080	NUT; BRKT	1			
667	18-98044-5200	SENSOR; VAC	1			
697	10-28050-6160	BOLT; SENSOR	2			
738	18-98141-5760	BRACKET; SENSOR, VAC	1			
747	10-91180-1080	NUT; VAC REG VALVE	2			
752	18-98162-8830	VALVE; EVRV	1			
753	18-97381-5711	BRACKET; VALVE	1			
756	15-09302-0030	STUD; BRKT	1			
779	10-91610-6080	WASHER; VALVE	2			

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 8 of 91 pages

The full manual includes:

- All 91 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Isuzu 4JJ1XZSB03 Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual