ISUZU
GENUINE PARTS

# A-4JB1PAA10

# PARTS CATALOG

PREVIEW - YOUFIXTHIS.COM



Download full manual at youfixthis.com

## FIGURE NUMBER INDEX


FIG-NO. 0-05 ENGINE GASKET KIT ..... page 10-76
FIG-NO. 0-10 CYLINDER HEAD COVER ..... page 10-77
FIG-NO. 0-11 CYLINDER HEAD ..... page 10-78
FIG-NO. 0-12 CYLINDER BLOCK ..... page 10-79
FIG-NO. 0-13 OIL PAN AND LEVEL GAUGE ..... page 10-80
FIG-NO. 0-14 CAMSHAFT AND VALVE ..... page 10-82
FIG-NO. 0-15 CRANKSHAFT, PISTON AND FLYWHEEL ..... page 10-84
FIG-NO. 0-20 TIMING GEAR CASE AND FLYWHEEL HOUSING page 10-86
FIG-NO. 0-22 ENGINE MOUNTING ..... page 10-88
FIG-NO. 0-25 INLET MANIFOLD ..... page 10-89
FIG-NO. 0-27 EXHAUST MANIFOLD ..... page 10-90
FIG-NO. 0-28 VENTILATION SYSTEM ..... page 10-91
FIG-NO. 0-30 WATER PUMP AND CORROSION RESISTOR ..... page 10-92
FIG-NO. 0-31 THERMOSTAT AND HOUSING ..... page 10-93
FIG-NO. 0-32 WATER PIPING; ENGINE ..... page 10-94
FIG-NO. 0-33 FAN AND FAN BELT ..... page 10-95
FIG-NO. 0-35 ENGINE CONTROL VALVE AND LEVER ..... page 10-96
FIG-NO. 0-40 FUEL INJECTION SYSTEM ..... page 10-98
FIG-NO. 0-41 FUEL FILTER AND BRACKET ..... page 10-100
FIG-NO. 0-42 FUEL PUMP AND PIPE ..... page 10-102
FIG-NO. 0-50 OIL COOLER AND OIL FILTER ..... page 10-103
FIG-NO. 0-51 OIL PUMP AND OIL STRAINER ..... page 10-104
FIG-NO. 0-52 OIL AND VACUUM PIPING; ENGINE ..... page 10-105


## FIGURE NUMBER INDEX


FIG-NO. 0-60 ENGINE ELECTRICAL CONTROL PARTS ..... page 10-106
FIG-NO. 0-65 STARTER ..... page 10-108
FIG-NO. 0-66 GENERATOR ..... page 10-109
FIG-NO. 0-80 INJECTION PUMP ..... page 10-110
FIG-NO. 0-81 GOVERNOR; INJECTION PUMP ..... page 10-112
FIG-NO. 0-84 FEED PUMP; INJECTION PUMP ..... page 10-114
FIG-NO. 0-85 AUTO TIMER; INJECTION PUMP ..... page 10-115
FIG-NO. 0-86 MISCELLANEOUS PARTS; INJECTION PUMP ..... page 10-116
FIG-NO. 0-87 COUPLING; INJECTION PUMP ..... page 10-118
FIG-NO. 1-11 RADIATOR HOSE AND SUB TANK ..... page 10-119
FIG-NO. 1-41 FUEL PIPING; CHASSIS ..... page 10-120




PREVIEW - YOUFIXTHIS.COM



Download full manual at youfixthis.com

## 略語表/Abbreviation List

| 略語 ABBREVIATIONS | 語源 DEFINITION | 略語 ABBREVIATIONS | 語源 DEFINITION |
|---|---|---|---|
| A | AMPERE | JBK | JIDOSHA BUHIN KOGYO CO. |
| ABS | ABSORBER | KG | KILOGRAM |
| ACCEL | ACCELERATOR | KM/H | KILOMETER PER HOUR |
| ACL | AIR CLEANER | KOYO | KOYO SEIKO CO. |
| ADJ | ADJUSTER | KW | KILOWATT |
| AL | ALUMINUM | L | LITER OR LEFT HAND |
| A/R | AS REQUIRED | L1= | LENGTH(VERTICAL) |
| ASM | ASSEMBLY | L2= | LENGTH(SIDE) |
| A/T | AUTOMATIC TRANSMISSION | L= | LENGTH |
| AUTO | AUTOMATIC | LH | LEFT HAND |
| B= | BREADTH | LK | LOCK |
| BRG | BEARING | LVR | LEVER |
| BRK | BRAKE | LWR | LOWER |
| BRKT | BRACKET | MAN | MANUAL |
| CAC | CHARGE AIR COOLER | MANIF | MANIFOLD |
| C/BL | CYLINDER BLOCK | M/CYL | MASTER CYLINDER |
| CLU | CLUTCH | MITSUBA | MITSUBA DENKI SEISAKUSHO CO. |
| CMPR | COMPRESSOR | MTG | MOUNTING |
| COMB | COMBINATION | M/T | MANUAL TRANSMISSION |
| COMPL | COMPLETE | MM | MILLIMETER |
| CONN | CONNECTING | NACHI | FUJIKOSHI CO. |
| CONT | CONTROL | NGK | NIHON TOKUSHU TOGYO CO. |
| CVR | COVER | NL | NOT LISTED |
| CYL | CYLINDER | NO. | NUMBER |
| D= | DIAMETER | NOK | NOK CO. |
| DC | DIRECT CURRENT | NOS | NATIONAL OIL SEAL CO. |
| DIAPH | DIAPHRAGM | NPN | NOT PART NUMBER |
| DIFF | DIFFERENTIAL | NPR | NIPPON PISTON RING CO. |
| EGR | EXHAUST GAS RECIRCULATION | NSG | NIPPON SHEET GLASS CO. |
| ENG | ENGINE | NSS | NOT SERVICED SEPARATELY |
| EXC | EXCEPT | NSK | NIHON SEIKO CO. |
| EXH | EXHAUST | NTN | TOYO BEARING CO. |
| E# | ENGINE NUMBER | OD | OUTSIDE DIAMETER |
| EXP | EXPORT | OPT | OPTION |
| FIG NO. | FIGURE NUMBER | OVSI | OVERSIZE |
| FLEX | FLEXIBLE | PCV | POSITIVE CRANK CASE VENTILATION |
| FRT | FRONT | PL | PLAIN |
| FWD | FORWARD | PRE-CHAMBER | PRECOMBUSTION CHAMBER |
| G | GRAM | PROP | PROPELLER |
| GEN | GENERATOR | P/S | POWER STEERING |
| GOV | GOVERNOR | PTO | POWER TAKE OFF |
| GRD= | GRADE | QOS | QUICK ON START |
| G/R= | GEAR RATIO | QTY | QUANTITY |
| H= | HEIGHT | QUAD | QUADRANT |
| HD | HEAD | R | RIGHT HAND |
| HEX | HEXAGON | RAD | RADIATOR |
| HP | HORSE POWER | REG | REGULATOR |
| HSG | HOUSING | REINF | REINFORCEMENT |
| ID | INSIDE DIAMETER | RET | RETAINER |
| IGN | IGNITION | REV | REVERSE |
| INCL | INCLUDING | RH | RIGHT HAND |
| INJ | INJECTION | RR | REAR |
| INL | INLET | RWD | REARWARD |
| ISC | IDLE SPEED CONTROL | S.B. | SERVICED BY |
| | | SPD | SPEED |
| | | SPR | SPRING |
| | | STD | STANDARD |
| | | SW | SWITCH |
| | | SYN | SYNCHRONIZER |
| | | T= | THICKNESS |
| | | TAP | TAPPING |
| | | TC | TURBOCHARGER |
| | | TDC | TOP DEAD CENTER |
| | | TICS | TIMING INJECTION CONTROL SYSTEM |
| | | TEMP | TEMPERATURE |
| | | TRANS | TRANSMISSION |
| | | UNSI | UNDER SIZE |
| | | UPR | UPPER |
| | | V | VOLT |
| | | VAC | VACUUM |
| | | VLV | VALVE |
| | | W | WATT |
| | | W/ | WITH |
| | | WO/ | WITHOUT |
| | | Z | TEETH |
| | | ZN | ZINC |
| | | & | AND |
| | | " | INCH |
| | | # | NUMBER |
| | | 1ST | FIRST |
| | | 2ND | SECOND |
| | | 3RD | THIRD |
| | | 4TH | FOURTH |
| | | 5TH | FIFTH |
| | | 6TH | SIXTH |
| | | 7TH | SEVENTH |
| | | 8TH | EIGHTH |
| | | 9TH | NINTH |




PREVIEW - YOUFIXTHIS.COM




Download full manual at youfixthis.com

| 0-15 | CRANKSHAFT,PISTON AND FLYWHEEL |
|---|---|
| FIG-NO. | |




| CRANKSHAFT,PISTON AND FLYWHEEL | 0-15 |
|---|---|
| | FIG-NO. |





PREVIEW - YOUFIXTHIS.COM



Download full manual at youfixthis.com

| 0-05 | ENGINE GASKET KIT |
|---|---|
| FIG-NO. | |




| 0-05 | ENGINE GASKET KIT |
|---|---|
| FIG-NO. | |

| Key No. | Part number | Part name | ITC | Applied date | LR | Qty | Remarks |
|---|---|---|---|---|---|---|---|
| 1 | 587813-5580 | GASKET SET, ENG OVERHAUL | | 9807~ | | 1 | |
| 2 | 587811-3946 | GASKET SET, ENG HD OVERHAUL | | 9503~ | | 1 | |

97-01-76

PREVIEW YOUFIXTHIS.COM




Download full manual at youfixthis.com

| 部品番号 Part number | ページ Page | 符号 Item |
|---|---|---|
| 909150-6100 | 10-117 | 9 |
| 909160-5050 | 10-117 | 28 |
| 909160-5080 | 10-107 | 17 |
| | 10-95 | 19 |
| 909160-7080 | 10-87 | 82(B) |
| 909164-0100 | 10-83 | 94 |
| 909164-5100 | 10-117 | 8 |
| 909164-7080 | 10-95 | 175 |
| 909180-0190 | 10-83 | 56 |
| 909185-4040 | 10-112 | 25 |
| | 10-96 | 305 |
| 909185-4150 | 10-113 | 113 |
| 909202-3080 | 10-101 | 103(A) |
| 909571-3160 | 10-93 | 111 |
| 909571-4080 | 10-101 | 66 |
| 909571-4120 | 10-87 | 180 |
| 909571-4140 | 10-79 | 218 |
| 909571-4160 | 10-79 | 303 |
| 909572-0080 | 10-105 | 116 |
| 909572-0100 | 10-111 | 89 |
| 909572-0140 | 10-101 | 30 |
| | 10-102 | 239 |
| | 10-120 | 305 |
| 909606-5350 | 10-79 | 53 |
| 909630-0200 | 10-89 | 225 |
| 909661-0050 | 10-93 | 14(B) |
| 909662-0070 | 10-118 | 9 |
| 909715-0531 | 10-94 | 148 |
| 909814-0141 | 10-92 | 58 |
| 909878-5970 | 10-79 | 452 |
| 909902-2380 | 10-79 | 96 |
| 909906-3251 | 10-102 | 209 |
| 912626-0050 | 10-83 | 55 |
| 913113-20771 | 10-104 | 35(A) |
| 913140-1200 | 10-104 | 51(A) |
| 913143-0100 | 10-104 | 46 |
| 913639-0010 | 10-92 | 66 |
| 913642-0770 | 10-95 | 38 |
| 915419-0721 | 10-99 | 113(B) |
| 981215-1150 | 10-111 | 79 |
| 981215-1440 | 10-111 | 148 |
| 981221-2230 | 10-111 | 68 |
| 981222-2200 | 10-111 | 70 |
| 981225-0330 | 10-111 | 107 |
| | 10-111 | 162 |
| 981225-0470 | 10-111 | 49 |
| | 10-111 | 159 |
| 981225-0570 | 10-111 | 177 |
| 981225-0580 | 10-111 | 58 |
| 981235-0030 | 10-111 | 178 |
| 981235-0150 | 10-111 | 62 |
| 981235-0170 | 10-111 | 126 |
| 981235-0210 | 10-111 | 64 |
| 981235-0420 | 10-111 | 181 |
| 981235-0430 | 10-111 | 181 |
| 981235-0440 | 10-111 | 181 |
| 981235-0450 | 10-111 | 181 |
| 981315-0650 | 10-113 | 150(A) |
| 981321-2050 | 10-113 | 112 |
| 981322-2350 | 10-112 | 24 |
| 981325-0300 | 10-113 | 106 |
| 981325-0620 | 10-113 | 99 |
| 981325-0860 | 10-112 | 16 |
| 981325-0880 | 10-112 | 17 |
| 981325-1730 | 10-113 | 109 |
| 981325-2100 | 10-113 | 125 |
| 981325-4290 | 10-112 | 86 |
| 981325-4880 | 10-113 | 107 |
| 981325-5510 | 10-112 | 17 |
| 981325-5520 | 10-112 | 17 |
| 981325-5530 | 10-112 | 17 |
| 981351-2050 | 10-114 | 16 |
| 981351-3030 | 10-114 | 17 |
| 981351-4030 | 10-114 | 29 |
| 981351-4100 | 10-114 | 30 |
| 981351-6020 | 10-114 | 5 |
| 981351-7020 | 10-114 | 4 |
| 981355-0250 | 10-114 | 13 |
| 981355-0350 | 10-114 | 18 |
| 981391-9060 | 10-113 | 185 |
| 981391-9070 | 10-112 | 63 |
| 982235-0150 | 10-109 | 18 |
| 982530-0410 | 10-107 | 38 |
| 982931-5110 | 10-107 | 293 |
| 988410-5020 | 10-118 | 10 |
| 995821-2550 | 10-87 | 62 |
| 999202-3120 | 10-87 | 220 |
| 999202-3140 | 10-79 | 200 |
| 999202-3160 | 10-79 | 199 |
| 999202-3200 | 10-81 | 4 |

PREVIEW - YOUFIXTHIS.COM



Download full manual at youfixthis.com




| 0-33 FIG-NO. | FAN AND FAN BELT | | | | | | |
|---|---|---|---|---|---|---|---|
| Key No. | Part number | Part name | ITC | Applied date | LR | Qty | Remarks |
| 1(A) | 513660-3080 | FAN; COOLING | | 9503~ | | 1 | D=400-6-BLOW-PP |
| 19 | 909160-5080 | WASHER; PL, FAN DRIVE | | 9805~ | | 4 | |
| 36 | 894161-8410 | BELT; COOLING FAN | | 9701~ | | 1 | 1-PIECE, L=1051 |
| 38 | 913642-0770 | SPACER; FAN | | 9503~ | | 1 | |
| 71 | 028080-8200 | BOLT; ADJ PLATE | | 9805~ | | 1 | M8X20 FLANGE |
| 80(C) | 897184-2640 | PLATE; ADJ | | 9806~ | | 1 | |
| 96(A) | 050040-8350 | BOLT; GEN TO ADJ PLATE | | 9503~ | | 1 | M8X35 W/LK WASHER |
| 175 | 909164-7080 | WASHER; PL, ADJ PLATE | | 9503~ | | 1 | ID=8 OD=22 |

PREVIEW - YOUFIXTHIS.COM



Download full manual at youfixthis.com

# PREVIEW ONLY

You're viewing 7 of 59 pages

## The full manual includes:

- All 59 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

**GET FULL MANUAL NOW**

**Isuzu A-4JB1PAA10 Parts Catalog**

**Scan or click anywhere**
**youfixthis.com**

*Click anywhere on this page to get the full manual*