

FRONT CHASSIS GROUP



PREVIEW - YOUFIXTHIS.COM

1-B

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

(T/M TYPE NO. CT250D01 CT250D02)


(NOTE):SERIAL NUMBER INDICATES THE TRANSMISSION SERIAL NUMBER.



1-B

PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

REAR CHASSIS GROUP





PREVIEW - YOUFIXTHIS.COM

1-B

Download full manual at youfixthis.com

BRAKE LINE - REAR CHASSIS





1-A


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

FORWARD & 3RD CLUTCH

(T/M TYPE NO. CT250D01 CT250D02)


(NOTE):SERIAL NUMBER INDICATES THE TRANSMISSION SERIAL NUMBER.



1-C

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



3-A

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

CONTENTS I

• Before Use

• Chassis No. and Manufacturer's Serial No.

• CONTENTS II

• PARTS NAME INDEX

• 85Z5 <EXPORT SPEC.>

• CHASSIS AND ELECTRICAL SYSTEM Page

FRONT CHASSIS GROUP 1
LIFT ARM GROUP 3
PIN MOUNT 5
REAR CHASSIS GROUP 7
CENTER PIN GROUP 9
FUEL TANK GROUP 11
OIL TANK GROUP 13
FLOOR BOARD GROUP 17
SEAT STAND & CONTROL BOX MOUNT 19
CONTROL BOX COVER MOUNT 21
OPERATION STAND GROUP 25
DECK & FENDER GROUP 27
STEP & HANDRAIL GROUP 29
SCREEN BOARD MOUNT 31
ENGINE ROOM MOUNT 33
RADIATOR GUARD MOUNT 35
REAR GRILLE GROUP 37
WIND SHIELD GROUP<AIR BAFFLE GROUP> 39
COVER MOUNT 41
SEAT GROUP 43
SEAT 45
SUSPENSION 47
GREASE PIPING<FOR FRONT> 49
GREASE PIPING<FOR REAR> 51
GREASE GUN MOUNT 53
GAUGE GROUP 55
ELECTRICAL PARTS MOUNT 57

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PARTS NAME INDEX

	PART NAME	PAGE
A	ACCUMULATOR ASSY	158,234
	ADAPTER	96,114,130,160,162,164 ...
	ADAPTER,ELBOW	110,114,162,164,184,186 ...
	ADAPTER,ELBOW UNIO	96,114,148,154,214,219 ...
	ADAPTER,TEE	151,162,168,214,216,219 ...
	ADAPTER,TOOTH	255
	ADAPTER,UNION	96,219
	ADJUSTOR ASSY	48,130
	AIR CONDITIONER UN	304,318
	ANGLE	104,198
	ANTENNA	280
	ARM	188
	ARM ASSY	284
	ARM ASSY,LIFT	4
	ARM,WIPER	276,289,352
	ARMREST	23,46
	ASHTRAY	23
	ASSY, FLOOR BOARD	18
	AXLE ASSY,FRONT	136
	AXLE ASSY,REAR	138
B	BALL	239
	BAND	70,158
	BAND ASSY	112
	BAND,HOSE	76,88,102,104,106,110 ...
	BAND,HOSE-HIGH TOR	102,208
	BAR,ROUND	34,270,272,346,348
	BATTERY	68
	BEARING KIT	48,194
	BEARING,BALL	118,122,124,126,128,130 ...
	BEARING,NEEDLE	122,124,126,128
	BEARING,ROLLER	118,122,128,142,144
	BEARING,SPHERICAL	10
	BEARING,TAPER ROLL	10,118,136,138,142,144
	BEARING,THRUST	118,126,128
	BELT,SEAT	44
	BELT,V	314
	BIT,SIDE	248,252
	BLADE,WIPER	276,289,352
	BLOCK	15,88,102,164,210,212 ...
	BLOCK,PILLOW	90
	BLOWER ASSY	318,324,326
	BOARD ASSY,SCREEN	32
	BODY	15,62,334
	BOLT	8,10,15,18,34,38,60,62 ...
	BOLT ASSY	100
	BOLT SET	136,138,255
	BOLT(UNIFY)	114,180
	BOLT,EYE	132
	BOLT,FLANGED	2,6,8,10,12,15,18,20,23 ...
	BOLT,JOINT	15,88,110
	BOLT,SOCKET	15,116,118,120,124,136 ...
	BOLT,STUD	98,171
	BOLT,U	104,108,188,204,206,216
	BOLT,W/WASHER	44,326
	BOOT	23,70,171,188,239,242
	BOSS	2,4,198,248,250,252
	BOX	26,278,306
	BOX ASSY	8,20,306
	BOX,FUSE	60
	BRACKET	86,94,96,108,114,158 ...
	BRACKET,LAMP	62
	BRAKE ASSY	130
	BRAKE FLUID	262
	BREATHER ASSY	116
	BUCKET ASSY	248,250,252
	BULB	62,64,66,72,274,286,338 ...
	BUSHING	4,8,10,98,136,138,140 ...
	BUSHING,COLUMN	182
	BUSHING,ELASTIC	2,28,32,40,62,76,80,84 ...
B	BUZZER	60,74
C	CAB ASSY	343
	CAB ASSY,ROPS	264,267
	CABLE	76,80,84,280,328
	CABLE ASSY	70,76,80,84,202,282,328 ...
	CABLE ASSY,CONTROL	188
	CAGE,NEEDLE	136,138
	CAP	34,70,80,100,116,174 ...
	CAP ASSY	15,112
	CAP,ELASTIC	132,182
	CAP,TERMINAL	80,338
	CARRIER	340
	CARTRIDGE ASSY	114
	CASE	70,162,171,227,239,322
	CATCH	8,23,32,38,267,332,343
	CATCH ASSY	38,332
	CATCH,DOOR	34,36
	CATCH,MAGNET	306
	CHASSIS ASSY,FRONT	2
	CHASSIS ASSY,REAR	8
	CIGARLIGHTER	278
	CLAMP	108,320,322,324,334,336
	CLAMP,CABLE	239
	CLAMP,HOSE	70,76,80,84,198,202,204 ...
	CLEANER ASSY,AIR	106
	CLIP	106,188,270,272,276,280 ...
	CLUTCH ASSY	120,122,124,126,128,316
	COLLAR	100,171
	COLUMN ASSY	182
	COMPRESSOR ASSY	314,316
	CONDENSER	312,326
	CONNECTOR	80,84,328
	CONNECTOR ASSY	76,84
	CONTROLLER UNIT	60
	COOLER	100
	COOLER ASSY,OIL	100
	COOLER,AIR	96
	COOLER,OIL	96
	CORE ASSY	320,326
	COVER	12,15,23,26,28,32,36,42 ...
	COVER ASSY	2,15,34,38,46,120,136 ...
	COVER ASSY,ROD	196,246
	COVER,DRIVE	118
	COVER,PEDAL	171,188
	COVER,ROD	174,244
	COVER,SEAT	46
	CUP	270,272,346,348
	CUSHION	100
	CYLINDER	270,272,346,348
	CYLINDER ASSY,OIL	166,174,190,196,204,244 ...
D	DAMPER ASSY	48,299,322
	DECK	28
	DIFFERENTIAL ASSY	136,138,142,144
	DIODE	80,84,328
	DISC,FRICTION	122,124,126,128,136,138
	DISC,SEPARATION	122,124,126,128,136,138
	DOOR ASSY	267,270,272,320,322,324 ...
	DRIVE ASSY,METER	130
	DRUM,BRAKE	130
	DUCT	296,299,334,336
	DUCT ASSY	296,299,306
	DUCT,DEFROSTER	299
E	EDGE	248,250,252
	EDGE,SIDE	248,250,252
	EDGE,WEAR	255
	ELEMENT,FILTER	15,106,162,227
	ENGINE	86
	EVAPORATOR	320
	EXTENSION,AXLE HOU	136,138

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

FRONT LAMP MOUNT 61
REAR LAMP MOUNT 63
WORKING LAMP MOUNT 65
BATTERY MOUNT 67
RELAY & SWITCH MOUNT 69
INSTRUMENT PANEL MOUNT 71
HORN & BUZZER MOUNT 73
ELECTRICAL WIRING - FRONT CHASSIS 75
ELECTRICAL WIRING - REAR CHASSIS 77
ELECTRICAL WIRING - FLOOR BOARD 81

• POWER SYSTEM

POWER GROUP 85
DRAIN LINE 87
2ND PROPELLER SHAFT 89
3RD PROPELLER SHAFT 91
RADIATOR MOUNT 93
RADIATOR GROUP 95
FAN MOTOR 97
RADIATOR 99
WATER LINE 101
AIR COOLER LINE 103
AIR CLEANER GROUP 105
EXHAUST GROUP 107
FUEL LINE 109
SUB TANK GROUP 111


• TORQUE CONVERTER AND TRANSMISSION SYSTEM

TRANSMISSION HYDRAULIC LINE 113
TRANSMISSION 115
TORQUE CONVERTER 117
TRANSMISSION CASE GROUP 119
FORWARD & 3RD CLUTCH 121
4TH CLUTCH 123
REVERSE & 2ND CLUTCH 125
1ST CLUTCH 127
OUTPUT SHAFT GROUP 129

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


LIFT ARM GROUP



1-A

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



1-B

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

EXHAUST GROUP

SYM-BOL	PART NUMBER	PART NAME	UNIT Q,TY	SERIAL (A) - (B)	REMARKS N P D	(A) (B)	(C) (D)	REMARK
21A	44300-60990	MUFFLER	1	301 -				
22A	40902-29720	BRACKET	1	301 -				
23A	40902-33250	BRACKET	1	301 -				
24A	40902-27560	BRACKET	1	301 -				
25A	40902-20810	BRACKET	1	301 -				
26A	35750-24020	SLEEVE	4	301 -				
27A	50601-01310	GASKET	1	301 -				
28A	32920-20080	CLAMP	1	301 -				
29A	43962-20730	BOLT,U	1	301 -				
30A	88031-06101	NUT,SELF-LOCKING	6	301 -				
31A	38765-26460	PIPE,EXHAUST	1	301 -				
32A	38765-26070	PIPE,EXHAUST	1	301 -				
33A	35750-24030	SLEEVE	2	301 -				
34A	35750-20960	SLEEVE	6	301 -				
35A	41609-32030	PLATE	1	301 -				
36A	35750-23930	SLEEVE	1	301 -				
37A	61802-12025	BOLT,FLANGED	1	301 -				
38A	61033-10030	BOLT	6	301 -				
39A	61802-10020	BOLT,FLANGED	4	301 -				
40A	61802-08130	BOLT,FLANGED	2	301 -				
41A	61802-10100	BOLT,FLANGED	4	301 -				
42A	61802-08055	BOLT,FLANGED	1	301 -				
43A	61802-12055	BOLT,FLANGED	2	301 -				
44A	61802-10055	BOLT,FLANGED	6	301 -				
45A	61033-10020	BOLT	4	301 -				
46A	62401-81121	NUT	4	301 -				
47A	62710-18101	WASHER,PLANE	16	301 -				
48A	62701-40101	WASHER,PLANE	2	301 -				
61A	38706-21870	PIPE ASSY,FLARED	1	301 -				
62A	69100-21000	FLARED FITTING,ELB	1	301 -				
63A	72001-11000	HOLDER,PIPE	1	301 -				D=10
64A	62480-21101	NUT,FLANGED	1	301 -				

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PARKING BRAKE LINE

SYM-BOL	PART NUMBER	PART NAME	UNIT Q,TY	SERIAL (A) - (B)	REMARKS N P D	(A)	(B)	(C)	(D)	REMARK
21A	68055-30190	HOSE,HIGH PRESSURE	1	301 -						
22A	30230-28470	ADAPTER	1	301 -		Y01				
23A	72001-11800	HOLDER,PIPE	3	301 -						D=18
24A	62480-21081	NUT,FLANGED	3	301 -						
41A	65210-12014	RING,O	1	301 -		01				

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


LOADING HYDRAULIC LINE - REAR CHASSIS(FOR RETURN)

SYM-BOL	PART NUMBER	PART NAME	UNIT Q,TY	SERIAL (A) - (B)	REMARKS N P D	(A) (B)	(C) (D)	REMARK
21A	43113-39030	HOSE,HIGH PRESSURE	1	301 -				
22A	67040-38000	HOSE,HEAT RESISTIN	1 M	301 -				L=360
23A	67040-32000	HOSE,HEAT RESISTIN	1 M	301 -				L=200
24A	38775-39640	PIPE,OIL	1	301 -		Y01		
25A	38755-23310	PIPE,OIL	1	301 -				
26A	38534-60330	VALVE ASSY,CHECK	1	301 -				
27A	38755-34150	PIPE,OIL	1	301 -		Y01		
28A	69811-32210	FLANGE,SPLIT	8	301 -				
29A	65220-31027	RING,O	4	301 -				
30A	65220-31024	RING,O	1	301 -				
31A	69002-05700	BAND,HOSE	4	301 -				
32A	69002-05200	BAND,HOSE	4	301 -				
33A	68678-70164	HOSE,HIGH PRESSURE	1	301 -				
34A	41410-23580	BLOCK	1	301 -				
35A	41618-52060	PLATE	1	301 -				
36A	61802-10030	BOLT,FLANGED	4	301 -				
37A	61802-12030	BOLT,FLANGED	16	301 -				
38A	61802-10025	BOLT,FLANGED	2	301 -				
39A	62480-21101	NUT,FLANGED	2	301 -				
40A	61802-16030	BOLT,FLANGED	2	301 -				
41A	61802-10020	BOLT,FLANGED	4	301 -				
61A	65210-12044	RING,O	1	301 -		01		
63A	32923-20080	CLAMP,HOSE	2	301 -				
64A	38720-20970	PIPE	2	301 -				
65A	41600-42870	PLATE	2	301 -				
66A	61033-12130	BOLT	2	301 -				
67A	62710-18121	WASHER,PLANE	2	301 -				
68A	62480-21121	NUT,FLANGED	2	301 -				

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

(NOTE):SERIAL NUMBER INDICATES THE CAB SERIAL NUMBER.




1-A

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

AIR CONDITIONER UNIT MOUNT



1-A

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 18 of 426 pages

The full manual includes:

- All 426 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Kawasaki 85Z5 Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual