
Item	Part No.	Description	Book
ENGINE	01T001	CRANKCASE	100K0185
	01T002	OIL PAN	100K0185
	01T003	PISTON/CRANKSHAFT	100K0185
	01T004	MAIN BEARING CASE	100K0185
	01T005	FLYWHEEL	100K0185
	01T006	CYLINDER HEAD	100K0185
	01T007	VALVE/ROCKER ARM	100K0185
	01T008	NOZZLE HOLDER	100K0185
	01T009	NOZZLE HOLDER [COMPONENT PARTS]	100K0185
	01T010	CYLINDER HEAD COVER	100K0185
	01T011	INLET MANIFOLD	100K0185
	01T013	EXHAUST MANIFOLD	100K0185
	01T015	CAMSHAFT	100K0185
	01T016	GEAR CASE	100K0185
	01T017	WATER PUMP	100K0185
	01T018	TENSION PULLEY [CA]	100K0185
	01T019	WATER FLANGE	100K0185
	01T020	FUEL PUMP	100K0185
	01T021	INJECTION PUMP	100K0185
	01T022	INJECTION PUMP [COMPONENT PARTS]	100K0185
	01T023	ENGINE STOP LEVER	100K0185
	01T024	SPEED CONTROL PLATE	100K0185
	01T025	GOVERNOR	100K0185
	01T026	UPPER GASKET KIT	100K0185
	01T027	LOWER GASKET KIT	100K0185
ELECTRICAL SYSTEM	01T03501	DYNAMO [A] [AU] [NZ]	100K0185
	01T03502	ALTERNATOR [CA]	100K0185
	01T03601	DYNAMO [A] [AU] [NZ] [COMPONENT PARTS]	100K0185
	01T03602	ALTERNATOR [CA] [COMPONENT PARTS]	100K0185
CLUTCH	01T045	CLUTCH	100K0185
HYDRAULIC SYSTEM	01T096	HYDRAULIC GEAR PUMP	100K0185
	01T097	HYDRAULIC GEAR PUMP [COMPONENT PARTS]	100K0185
ENGINE	02T012	AIR CLEANER	100K0185
	02T01401	MUFFLER	100K0185
	02T01402	HORIZONTAL MUFFLER [OPTION]	100K0185
	02T028	ENGINE STOP ROD	100K0185
	02T029	ACCELERATOR LEVER	100K0185
FUEL SYSTEM	02T030	FUEL TANK	100K0185
	02T031	FUEL PIPE	100K0185
	02T032	FUEL FILTER [COMPONENT PARTS]	100K0185
COOLING WATER SYSTEM	02T03302	WATER PIPE	100K0185
	02T03402	RADIATOR	100K0185
ELECTRICAL SYSTEM	02T037	STARTER	100K0185
	02T038	STARTER [COMPONENT PARTS]	100K0185
	02T039	BATTERY	100K0185
	02T040	LIGHT	100K0185
	02T041	WORKING LIGHT [OPTION]	100K0185
	02T04201	PANEL/SWITCH [A] [AU] [NZ]	100K0185
	02T04202	PANEL/SWITCH [CA]	100K0185
	02T043	PANEL BOARD [COMPONENT PARTS]	100K0185
	02T04401	WIRE HARNESS [A] [AU] [NZ]	100K0185
	02T04402	WIRE HARNESS [CA]	100K0185
CLUTCH	02T046	CLUTCH ROD	100K0185
	02T047	CLUTCH PEDAL	100K0185
	02T048	CLUTCH HOUSING	100K0185
TRANSMISSION	02T049	TRANSMISSION CASE	100K0185
	02T050	TRANSMISSION CASE COVER	100K0185


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW ONLY
YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	15532-21110	PISTON	2			STD	0.365	0.803
010	15532-21910	PISTON	2			+0.5MM	0.365	0.803
020	15531-21123	PISTON	1			STD	0.35	0.77
020	15531-21922	PISTON	1			+0.5MM	0.37	0.814
030	15531-21050	ASSY PISTON RING	3			STD	0.046	0.1012
030	15531-21090	ASSY PISTON RING	3			+0.5MM	0.03	0.066
040	15261-21310	PIN PISTON	3				0.102	0.2244
050	15261-21330	CIRCLIP PISTON PIN	6				0.001	0.0022
060	15381-22010	ASSY CONNECTING ROD	3	<=755815			0	0
060	15694-22010	ASSY CONNECTING ROD	3	>=755816	↔		0.5	1.1
070	15261-21980	BUSH PISTON PIN	3				0.012	0.0264
080	15381-22140	BOLT CONNECTING ROD	6				0.02	0.044
090	15531-22310	METAL CRANKPIN	3	<=755815		STD SET	0	0
090	15694-22310	METAL CRANKPIN	3	>=755816	↔	STD SET	0.02	0.044
090	15694-22970	METAL CRANKPIN	3	<=755815		-0.2MM SET	0.025	0.055
090	15694-22970	METAL CRANKPIN	3	>=755816	↔	-0.2MM SET	0.025	0.055
090	15531-22980	METAL CRANKPIN	3	<=755815		-0.4MM SET	0	0
090	15694-22980	METAL CRANKPIN	3	>=755816	↔	-0.4MM SET	0.02	0.044
100	15752-23010	COMP.CRANKSHAFT	1				8	17.6
110	07715-00401	BALL	3				0.001	0.0022
120	09400-14247	SEAL OIL	1				0.004	0.0088
130	66621-14120	BEARING DRY	1				0.006	0.0132
140	19215-23280	SLEEVE CRANKSHAFT	1				0.05	0.11
150	15752-24110	GEAR CRANKSHAFT	1				0.046	0.1012
160	05712-00515	KEY FEATHER	1				0.003	0.0066
170	15752-23310	SLINGER OIL	1				0.002	0.0044
180	15752-23250	COLLAR CRANKSHAFT	1				0.043	0.0946
190	04811-05230	RING	1				0.001	0.0022
200	15261-23470	METAL CRANKSHAFT	1	<=755815		STD	0	0
200	15694-23470	METAL CRANKSHAFT	1	>=755816	↔	STD	0.035	0.077
200	15261-23910	METAL CRANKSHAFT	1	<=755815		-0.2MM	0	0
200	15694-23910	METAL CRANKSHAFT	1	>=755816	↔	-0.2MM	0.04	0.088
200	15261-23920	METAL CRANKSHAFT	1	<=755815		-0.4MM	0	0
200	15694-23920	METAL CRANKSHAFT	1	>=755816	↔	-0.4MM	0.045	0.099
210	15261-23480	METAL CRANKSHAFT	3	<=755815		STD SET	0	0
210	15694-23480	METAL CRANKSHAFT	3	>=755816	↔	STD SET	0.04	0.088
210	15261-23930	METAL CRANKSHAFT	3	<=755815		-0.2MM SET	0	0
210	15694-23930	METAL CRANKSHAFT	3	>=755816	↔	-0.2MM SET	0.05	0.11
210	15261-23940	METAL CRANKSHAFT	3	<=755815		-0.4MM SET	0	0
210	15694-23940	METAL CRANKSHAFT	3	>=755816	↔	-0.4MM SET	0.046	0.1012
220	15261-23530	METAL SIDE	2			STD	0.006	0.0132
220	15261-23950	METAL SIDE	2			+0.2MM	0.006	0.0132
220	15261-23960	METAL SIDE	2			+0.4MM	0.007	0.0154
230	15261-23540	METAL SIDE	2			STD	0.007	0.0154
230	15261-23970	METAL SIDE	2			+0.2MM	0.006	0.0132
230	15261-23980	METAL SIDE	2			+0.4MM	0.007	0.0154
240	07916-28270	KIT PISTON AND RING	2			STD	0.56	1.232
240	07916-26540	KIT PISTON AND RING	2			+0.5MM	0.42	0.924
250	07916-28280	KIT PISTON AND RING	1			STD	0.55	1.21
250	07616-26550	KIT PISTON AND RING	1			+0.5MM	0	0
260	07916-28090	KIT METAL ENGINE	1			STD	0.25	0.55

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Item	Part No.	Description	Book
TRANSMISSION	02T051	HST	100K0185
	02T05201	HST [COMPONENT PARTS]	100K0185
	02T05202	HST [COMPONENT PARTS]	100K0185
	02T053	PROPELLER SHAFT	100K0185
	02T054	2ND SHAFT	100K0185
	02T055	3RD SHAFT/5TH SHAFT	100K0185
	02T056	4TH SHAFT	100K0185
	02T057	FRONT WHEEL DRIVE SHAFT	100K0185
	02T058	REAR PTO	100K0185
	02T059	MID PTO	100K0185
	02T060	FRONT PTO [OPTION]	100K0185
SPEED CHANGE LEVER	02T061	NEUTRAL HOLDER	100K0185
	02T062	SPEED CONTROL PEDAL	100K0185
	02T063	SPEED CHANGE PLATE	100K0185
	02T064	SPEED SET LEVER	100K0185
	02T065	RANGE GEAR SHIFT LEVER	100K0185
	02T066	PTO GEAR SHIFT LEVER	100K0185
REAR AXLE/REAR WHEEL	02T067	REAR DIFFERENTIAL	100K0185
	02T068	DIFF. LOCK PEDAL	100K0185
	02T069	REAR AXLE	100K0185
	02T070	REAR AXLE CASE	100K0185
	02T07102	REAR WHEEL (8-16)	100K0185
	02T07103	REAR WHEEL (9.5-16)	100K0185
	02T07105	REAR WHEEL (31 X 13.5-15)	100K0185
	02T07106	REAR WHEEL (31 X 13.5-15 BAR) [A]	100K0185
BRAKE	02T072	BRAKE	100K0185
	02T073	BRAKE ROD	100K0185
	02T074	BRAKE PEDAL	100K0185
FRONT AXLE/FRONT WHEEL	02T07802	FRONT WHEEL HUB	100K0185
	02T07902	FRONT GEAR CASE	100K0185
	02T080	BEVEL GEAR CASE	100K0185
	02T08102	FRONT AXLE CASE [WITHOUT BI-SPEED TURN]	100K0185
	02T08103	FRONT AXLE CASE [WITH BI-SPEED TURN]	100K0185
	02T08202	FRONT DIFFERENTIAL [WITHOUT BI-SPEED TURN]	100K0185
	02T08203	FRONT DIFFERENTIAL [WITH BI-SPEED TURN]	100K0185
	02T083	BEVEL GEAR [WITH BI-SPEED TURN]	100K0185
	02T084	CLUTCH DISK [WITH BI-SPEED TURN]	100K0185
	02T085	FRONT DRIVE SHAFT	100K0185
	02T086	FRONT DRIVE LEVER	100K0185
	02T087	SHIFT FORK [WITH BI-SPEED TURN]	100K0185
	02T088	SHIFT LEVER [WITH BI-SPEED TURN]	100K0185
	02T089	BI-SPEED TURN ROD [WITH BI-SPEED TURN]	100K0185
	02T090	BI-SPEED TURN LEVER [WITH BI-SPEED TURN]	100K0185
	02T09101	FRONT WHEEL (6-12B)	100K0185
	02T09102	FRONT WHEEL (6-12)	100K0185
	02T09103	FRONT WHEEL (20.5 X 8.00-10)	100K0185
	02T092	FRONT AXEL FRAME	100K0185
	02T09302	KNUCKLE ARM [WITHOUT BI-SPEED TURN]	100K0185
	02T09303	KNUCKLE ARM [WITH BI-SPEED TURN]	100K0185
STEERING	02T09401	MANUAL STEERING	100K0185
	02T09402	POWER STEERING	100K0185
	02T09501	MANUAL STEERING [COMPONENT PARTS]	100K0185
	02T09502	POWER STEERING [COMPONENT PARTS]	100K0185
HYDRAULIC SYSTEM	02T098	HYDRAULIC PIPE (PS)	100K0185
	02T099	HYDRAULIC PIPE (FRONT)	100K0185
	02T100	HYDRAULIC PIPE (REAR)	100K0185

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


CYLINDER HEAD COVER

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	15656-14510	COVER CYL.HEAD	1	<=682801			0.8	1.76
010	15534-14510	COVER CYL.HEAD	1	>=682802	↔		0.6	1.32
020	15381-14520	GASKET HEAD COVER	1				0.005	0.011
030	15952-92330	NUT CAP	3				0.01	0.022
040	15951-96660	GASKET	3				0.001	0.0022
050	15221-33140	PLUG OIL FILLER	1	<=834110			0.038	0.0836
050	15852-33140	PLUG OIL FILLER	1	>=834111	↔		0.038	0.0836
060	04811-50300	RING	1				0.001	0.0022
070	15951-05140	PLATE B/THER ELEMENT	1				0.005	0.011
080	15521-05150	PLATE B/THER ELEMENT	1				0.01	0.022
090	15521-05670	ELEMENT BREATHER	1				0.01	0.022
100	15951-05370	OIL SHIELD BREATHER	1				0.005	0.011
110	03024-50510	SCREW WITH WASHER	2				0.002	0.0044
120	15521-05550	JOINT BREATHER PIPE	1				0.04	0.088
130	15261-05510	PIPE BREATHER	1				0.069	0.1518
140	15531-05580	CLAMP PIPE	1				0.019	0.0418

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	66416-43202	ASSY ROD RELEASE	1				0.26	0.572
020	66021-43220	STAY LH	1				0.013	0.0286
030	02014-50060	NUT	2				0.003	0.0066
040	04012-50060	WASHER PLAIN	1				0.001	0.0022
050	05511-51612	PIN SPLIT	1				0.001	0.0022
060	04013-50060	WASHER PLAIN	1				0	0
070	05511-51612	PIN SPLIT	1				0.001	0.0022
080	66416-43310	LEVER RELEASE	1				0.22	0.484
090	67156-43320	GRIP	1				0.026	0.0572
100	04011-50100	WASHER PLAIN	1				0.002	0.0044
110	05511-50320	PIN SPLIT	1				0.002	0.0044
120	67156-43354	ARM RELEASE	1				0.1	0.22
130	04013-50100	WASHER PLAIN	1				0	0
140	05511-50320	PIN SPLIT	1				0.002	0.0044
150	67156-43370	CAP LEVER	1				0.006	0.0132
160	67111-54920	BUSH	1				0.01	0.022
170	67156-43382	FULCRUM LEVER	1				0.026	0.0572
180	67156-43410	SHAFT RELEASE HOLDER	1				0.032	0.0704
190	05411-00425	PIN SPRING	1				0.001	0.0022
200	67156-43422	HOLDER RELEASE	1				0.04	0.088
210	04015-50080	WASHER PLAIN	2				0	0
220	66116-51530	SPRING PLATE	2				0.004	0.0088
230	02112-50080	NUT	1				0.003	0.0066
240	02114-50080	NUT	1				0.005	0.011
250	66417-43310	SPRING RETURN	1				0.01	0.022

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	37410-59110	ASSY SWITCH STARTER	1				0.32	0.704
020	37410-55150	KEY STARTER	2				0.025	0.055
025	66416-55170	WASHER	1	>=50541			0.001	0.0022
030	35110-32420	PLUG	1	<=65940			0.002	0.0044
030	66416-47170	LABEL COVER	1	>=65941	↔		0.001	0.0022
040	67156-55210	SWITCH COMBINATION	1				0.095	0.209
042	67156-55230	NUT RING	1				0.003	0.0066
043	67156-55240	LEVER FLASHER	1				0.004	0.0088
044	67156-55250	KNOB LIGHT	1				0.004	0.0088
050	19267-64600	COMP.REGULATOR	1	<=61807			0	0
050	19267-64602	ASSY REGULATOR	1	>=61808	←		0.188	0.4136
050	RP201-53710	ASSY REGULATOR	1	>=67419	↔		0.185	0.407
060	01053-50632	BOLT	2				0.005	0.011
070	04512-50060	WASHER SPRING	2				0	0
080	32430-33700	ASSY HAZARD UNIT	1				0.095	0.209
100	32430-94270	BRACKET HAZARD UNIT	1				0.015	0.033
110	32430-94280	HARNESS HAZARD UNIT	1				0.02	0.044
120	01053-50620	BOLT	1				0.006	0.0132
130	04013-50060	WASHER PLAIN	1				0	0
140	04512-50060	WASHER SPRING	1				0	0
150	31351-31410	TIMER	1	<=66405			0	0
150	T0070-31410	TIMER	1	>=66406	←		0.065	0.143
160	01023-50610	BOLT	2				0.005	0.011
170	66416-55810	ASSY SWITCH SAFETY	1				0.11	0.242
180	66416-55120	ASSY PANEL GAUGE	1	<=62006		REFER TO L.No.0C11-L0 FOR COMPONENTS.	0	0
180	66416-55122	ASSY PANEL GAUGE	1	>=62007	←	REFER TO L.No.0C11-L0 FOR COMPONENTS.	1.74	3.828
190	31351-18790	BOLT FLANGE	4				0.007	0.0154
200	31351-18860	WASHER	2	<=61783			0.002	0.0044
200	31351-18860	WASHER	4	>=61784			0.002	0.0044
210	66416-55310	CABLE HOUR METER	1				0.18	0.396


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
400	04810-00100	O RING	2				0.001	0.0022
405	05411-00325	PIN SPRING	2				0.001	0.0022
410	04811-00180	O RING	2				0.001	0.0022
415	04013-50060	WASHER PLAIN	2				0	0
420	66415-39550	GASKET	1				0.01	0.022
430	04810-00100	O RING	2				0.001	0.0022
440	66415-39740	BOLT HEX-SOC-HD	8				0.034	0.0748
450	66415-39560	WASHER SPRING	8				0.003	0.0066
460	01754-50835	BOLT FLANGE	1	>=64884			0.019	0.0418
470	04714-00080	GASKET	1	>=64884			0.001	0.0022
480	66363-39560	SEAL OIL	4				0.01	0.022
490	04611-00350	CIR CLIP INTERNAL	2				0.003	0.0066
500	66415-39520	PLUG	2				0.033	0.0726
510	04810-00140	O RING	2				0.001	0.0022
520	04714-00040	GASKET	2				0.001	0.0022
530	66415-39530	SCREW	2				0.005	0.011
540	15521-96030	PLUG	2				0.007	0.0154
550	66415-39540	COLLAR	1				0.025	0.055
560	04811-06530	O RING	1				0.001	0.0022
570	66415-39430	COLLAR	1				0.07	0.154
580	05012-00625	PIN STRAIGHT	2	<=64883			0.006	0.0132
580	05012-00620	PIN STRAIGHT	2	>=64884	≠		0.005	0.011
590	66415-83500	ASSY PUMP CHARGE	1	<=65940			0	0
590	66415-83503	ASSY PUMP CHARGE	1	>=65941	←		0.55	1.21
600	04811-06630	O RING	1				0.001	0.0022
610	04810-00120	RING	1				0.001	0.0022
620	66415-39640	COVER CHARGE PUMP	1				0.05	0.11
630	66363-39560	SEAL OIL	4				0.01	0.022
640	01123-50840	BOLT	3				0.018	0.0396
650	04612-00200	CIRCLIP EXTERNAL	1				0.001	0.0022
660	04611-00350	CIR CLIP INTERNAL	1				0.003	0.0066
670	66415-84900	KIT SEAL	1			OPTION	0.05	0.11

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	66415-17700	ASSY REAR WHEEL	1				0	0
020	66415-17710	ASSY REAR WHEEL	1				0	0
030	66416-17720	WHEEL	1				13.5	29.7
040	66415-17720	TIRE	1				0	0
050	34159-11850	VALVE TIRE	1				0.013	0.0286
060	32150-27740	CORE VALVE	1				0.003	0.0066
070	38240-11690	CAP VALVE	1				0.001	0.0022
080	66415-17730	LABEL TIRE LH	1				0	0
090	66415-17740	ASSY REAR WHEEL RH	1				0	0
100	66416-17720	WHEEL	1				13.5	29.7
110	66415-17720	TIRE	1				0	0
120	34159-11850	VALVE TIRE	1				0.013	0.0286
130	32150-27740	CORE VALVE	1				0.003	0.0066
140	38240-11690	CAP VALVE	1				0.001	0.0022
150	66415-17750	LABEL TIRE RH	1				0	0
160	66416-17300	ASSY HUB WHEEL	2	<=61807			0	0
160	66426-17300	ASSY HUB WHEEL	2	>=61808	←		0	0
160	66426-17303	ASSY HUB WHEEL	2	>=66406	↔		4.06	8.932
170	67401-17450	HUB WHEEL	2	<=66405			0	0
170	67401-17453	HUB WHEEL	2	>=66406	↔		2.78	6.116
180	66704-17313	BOLT	12				0.049	0.1078
190	02074-50140	NUT	12	<=61807			0.021	0.0462
190	35340-11390	NUT	12	>=61808	←		0.03	0.066
200	04512-50140	WASHER SPRING	12				0	0
210	04013-60140	WASHER PLAIN	12				0.01	0.022
220	67401-17460	SHOE	2	<=66405			0.256	0.5632
220	67401-17462	SHOE	2	>=66406	≠		0.22	0.484
230	67401-17470	SHOE	2	<=66405			0.476	1.0472
230	67401-17472	SHOE	2	>=66406	≠		0.21	0.462
235	01173-51604	BOLT	2	>=66406			0.195	0.429
240	02174-50160	NUT	2				0.022	0.0484
250	04512-50160	WASHER SPRING	2				0	0
260	63733-17270	PIN WHEEL TUBE	2				0.05	0.11
270	62131-17290	PIN	2				0.004	0.0088
280	66416-87400	KIT COTTER	2			SERVICE PARTS	0.62	1.364

PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	66416-56540	GEAR-SHAFT	1			22T	0.74	1.628
020	67156-76510	GEAR CLUTCH	1			17T	0.57	1.254
030	08824-04517	BEARING NEEDLE	1				0.03	0.066
040	67156-76340	COLLAR	1				0.001	0.0022
050	67156-76520	COLLAR	1				0.019	0.0418
060	67156-76530	COLLAR	1				0.015	0.033
070	67156-76540	BOSS CLUTCH	1				0.41	0.902
080	67156-76550	DISK CLUTCH	8				0.042	0.0924
090	67156-76560	PLATE FRICTION	8				0.054	0.1188
100	66416-56520	SHIFTER	1				0.56	1.232
110	67156-76580	BOSS SHIFTER SPLINE	1				0.146	0.3212
120	67156-76590	COLLAR	1				0.01	0.022
130	08823-54013	BEARING NEEDLE	1				0.022	0.0484
140	67156-76610	COLLAR	1				0.003	0.0066
150	67156-76620	SHAFT BI-SPEED TURN	1				0.38	0.836
160	67156-76690	BEARING NEEDLE	2				0.021	0.0462
170	67910-12330	COLLAR	2				0.006	0.0132
180	67156-76630	GEAR	1			20T	0.293	0.6446
190	66416-56550	GEAR	1			15T	0.23	0.506


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW.YOUFIXTHIS.COM

Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	67156-47500	ASSY LACE FRONT	1				0.1	0.22
020	67156-47510	LACE FRONT	1				0.124	0.2728
030	67156-47520	LACE FRONT LH	1				0.087	0.1914
040	67156-47530	LACE FRONT RH	1				0.088	0.1936
050	02014-50060	NUT	6				0.003	0.0066
060	04512-60060	WASHER SPRING	6				0.001	0.0022
070	66416-47550	LACE SIDE FRONT	2				0.184	0.4048
080	66416-47570	LACE SIDE REAR	2				0.05	0.11
090	02014-50060	NUT	12				0.003	0.0066
100	04512-50060	WASHER SPRING	12				0	0

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 18 of 304 pages

The full manual includes:

- All 304 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Kubota B1750HST-D Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual