Item	Part No.	Description	Book
ENGINE	01T001	CRANKCASE	100K0072
	01T002	OIL PAN	100K0072
	01T003	PISTON/CRANKSHAFT	100K0072
	01T004	MAIN BEARING CASE	100K0072
	01T005	FLYWHEEL	100K0072
	01T006	CYLINDER HEAD	100K0072
	01T007	VALVE/ROCKER ARM	100K0072
	01T008	NOZZLE HOLDER	100K0072
	01T009	NOZZLE HOLDER [COMPONENT PARTS]	100K0072
	01T010	CYLINDER HEAD COVER	100K0072
	01T011	INLET MANIFOLD	100K0072
	01T013	EXHAUST MANIFOLD	100K0072
	01T015	CAMSHAFT	100K0072
	01T016	GEAR CASE	100K0072
	01T017	WATER PUMP	100K0072
	01T018	WATER FLANGE/THERMOSTAT	100K0072
	01T019	FUEL CAMSHAFT	100K0072
	01T020	INJECTION PUMP	100K0072
	01T021	INJECTION PUMP [COMPONENT PARTS]	100K0072
	01T022	ENGINE STOP LEVER	100K0072
	01T023	SPEED CONTROL PLATE	100K0072
	01T024	GOVERNOR	100K0072
COOLING WATER SYSTEM	01T034	FAN	100K0072
ELECTRICAL SYSTEM	01T035	DYNAMO	100K0072
	01T036	DYNAMO [COMPONENT PARTS]	100K0072
CLUTCH	01T043	CLUTCH	100K0072
HYDRAULIC SYSTEM	01T087	HYDRAULIC GEAR PUMP	100K0072
	01T088	HYDRAULIC GEAR PUMP [COMPONENT PARTS]	100K0072
ENGINE	01T012	AIR CLEANER	100K0072
	01T014	MUFFLER	100K0072
	01T025	ENGINE STOP ROD	100K0072
	01T026	ACCELERATOR LEVER	100K0072
	01T027	RELEASE LEVER	100K0072
FUEL SYSTEM	01T028	FUEL TANK	100K0072
	01T029	FUEL PIPE 1	100K0072
	01T030	FUEL FILTER [COMPONENT PARTS]	100K0072
	01T031	FUEL PIPE 2	100K0072
COOLING WATER SYSTEM	01T032	WATER PIPE	100K0072
	01T033	RADIATOR	100K0072
ELECTRICAL SYSTEM	01T037	STARTER	100K0072
	01T038	STARTER [COMPONENT PARTS]	100K0072
	01T039	BATTERY	100K0072
	01T040	LIGHT	100K0072
	01T041	PANEL/SWITCH	100K0072
	01T042	WIRE HARNESS	100K0072
CLUTCH	01T044	CLUTCH ROD	100K0072
	01T045	CLUTCH PEDAL	100K0072
	01T046	CLUTCH HOUSING	100K0072
	01T047	TRANSMISSION CASE	100K0072
	01T048	TRANSMISSION CASE COVER	100K0072
	01T049	HST	100K0072
	01T050	HST [COMPONENT PARTS]	100K0072
	01T051	PROPELLER SHAFT	100K0072
	01T052	1ST SHAFT/2ND SHAFT	100K0072
TRANSMISSION	01T053	3RD SHAFT	100K0072
	01T054	4TH SHAFT	100K0072
	01T055	FRONT DRIVE SHAFT/6TH SHAFT	100K0072

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


CRANKCASE

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	15532-01010	COMP.CRANKCASE	1				26.5	58.3
020	15261-96170	PLUG	3				0.005	0.011
030	15261-96160	PLUG	1				0.02	0.044
040	15321-96260	CAP SEALING	5				0.014	0.0308
050	15221-03490	CAP SEALING	1				0.02	0.044
060	15261-96010	PLUG	6				0.002	0.0044
070	15521-96020	PLUG	3				0.003	0.0066
080	15521-96030	PLUG	1				0.007	0.0154
090	05012-00609	PIN STRAIGHT	2				0.003	0.0066
100	05012-00814	PIN STRAIGHT	2				0.006	0.0132
110	15221-33650	PIN PIPE	1				0.004	0.0088
120	15231-33960	PIN PIPE	2				0.001	0.0022
130	15531-02310	LINER CYLINDER	3				0.42	0.924
140	15221-33700	O RING	1				0.001	0.0022
150	15261-73910	COVER WATER	1				0.13	0.286
160	15261-73920	GASKET WATER COVER	1				0	0
170	01023-50618	BOLT	2				0.006	0.0132
180	15531-73170	JOINT DRAIN PIPE	1				0.145	0.319
190	15261-35010	ASSY PUMP OIL	1				0.32	0.704
200	15261-35150	GASKET OIL PUMP	1				0	0
210	15261-91022	BOLT	4				0.012	0.0264
220	15954-35662	GEAR OIL PUMP DRIVE	1				0.14	0.308
230	05712-00410	KEY FEATHER	1				0.001	0.0022
240	02771-50100	NUT FLANGE	1				0	0
250	15531-39010	SWITCH OIL	1				0.032	0.0704


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Item	Part No.	Description	Book
TRANSMISSION	01T056	7TH SHAFT	100K0072
	01T057	PTO SHAFT	100K0072
	01T058	NEUTRAL HOLDER	100K0072
	01T059	SPEED CONTROL PEDAL	100K0072
	01T060	SPEED CHANGE PLATE	100K0072
SPEED CHANGE LEVER	01T061	HI-LO GEAR SHIFT LEVER	100K0072
	01T062	HI-LO GEAR SHIFT FORK	100K0072
	01T063	FRONT WHEEL DRIVE LEVER/PTO LEVER	100K0072
	01T064	FRONT DRIVE FORK	100K0072
	01T065	PTO FORK SHAFT	100K0072
	01T066	REAR DIFFERENTIAL	100K0072
	01T067	DIFF.LOCK PEDAL	100K0072
REAR AXLE/REAR WHEEL	01T068	REAR AXLE	100K0072
	01T069	REAR AXLE CASE	100K0072
	01T070	REAR S.S. SURE GRIP TIRE (12.4-16)	100K0072
	01T071	REAR IND.SURE GRIP TIRE (12.4-16) (OPTION)	100K0072
BRAKE	01T072	BRAKE	100K0072
	01T073	BRAKE ROD	100K0072
	01T074	BRAKE PEDAL	100K0072
FRONT AXLE/FRONT WHEEL	01T075	BEVEL GEAR SHAFT	100K0072
	01T076	FRONT AXLE CASE	100K0072
	01T077	BEVEL GEAR CASE	100K0072
	01T078	FRONT AXLE ARM	100K0072
	01T079	FRONT DIFFERENTIAL	100K0072
	01T080	FRONT DRIVE SHAFT	100K0072
	01T081	FRONT SURE GRIP TIRE (23 X 8.50-12)	100K0072
	01T082	FRONT AXLE FRAME	100K0072
	01T083	MAIN FRAME	100K0072
	01T084	KNUCKLE ARM/TIE ROD	100K0072
STEERING	01T085	POWER STEERING	100K0072
	01T086	POWER STEERING [COMPONENT PARTS]	100K0072
HYDRAULIC SYSTEM	01T089	HYDRAULIC PIPE (PS)	100K0072
	01T090	HYDRAULIC GEAR PUMP (FRONT)	100K0072
	01T091	HYDRAULIC GEAR PUMP (FRONT) [COMPONENT PARTS]	100K0072
	01T092	HYDRAULIC PIPE (SUCTION)	100K0072
	01T093	HYDRAULIC PIPE (DELIVERY)	100K0072
	01T094	HYDRAULIC PIPE (RETURN)	100K0072
	01T095	HYDRAULIC BLOCK [COMPONENT PARTS]	100K0072
	01T096	HYDRAULIC PIPE (CHARGE)	100K0072
	01T097	LIFT ARM	100K0072
	01T098	HYD.CYLINDER CAP [COMPONENT PARTS]	100K0072
	01T099	CONTROL VALVE	100K0072
	01T100	CONTROL VALVE 1 [COMPORNENT PARTS]	100K0072
	01T101	CONTROL VALVE 2 [COMPORNENT PARTS]	100K0072
	01T102	CONTROL VALVE 3 [COMPORNENT PARTS]	100K0072
	01T103	TOP LINK	100K0072
	01T104	LOWER LINK / LIFT ROD	100K0072
	01T105	CHECK CHAIN	100K0072
	01T106	TOP LINK BRACKET	100K0072
HOOD(BONNET)/CHASSIS	01T107	HOOD (BONNET)	100K0072
	01T108	HOOD COVER REAR	100K0072
	01T109	FRONT GRILLE	100K0072
	01T110	FENDER	100K0072
	01T111	SEAT	100K0072
	01T112	SEAT TURN TABLE	100K0072
	01T113	SEAT BASE	100K0072

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	32701-51118	HOUSING FRAME CLUTCH	1				25	55
020	67800-51130	GASKET	1				0	0
022	32701-51120	PLATE CLUTCH HOUSING	1				0.95	2.09
024	01173-51025	BOLT	2				0.021	0.0462
026	04512-50100	WASHER SPRING	2				0	0
028	02118-50100	NUT	2				0.005	0.011
030	67111-51150	BOLT REAMER	4				0.04	0.088
040	04512-50140	WASHER SPRING	4				0	0
050	01123-51230	BOLT	6				0.04	0.088
060	01153-51225	BOLT	2				0.032	0.0704
070	04013-50120	WASHER PLAIN	2				0	0
080	04512-50120	WASHER SPRING	2				0	0
090	32701-51200	BOLT	2				0.03	0.066
095	01123-50845	BOLT	4				0.02	0.044
100	01518-50840	STUD	1				0.017	0.0374
110	99999-99999	BLANK	0				0	0
120	01123-50835	BOLT	8				0.02	0.044
130	04512-50100	WASHER SPRING	2				0	0
140	04512-50080	WASHER SPRING	1				0.001	0.0022
150	02114-50080	NUT	11				0.005	0.011
160	67111-51190	SEAL DUST	1				0.018	0.0396
170	34150-29390	CLAMP CORD	2				0.004	0.0088
180	06331-35016	PLUG	1				0.04	0.088
190	04717-01600	WASHER WITH RUBBER	1				0.003	0.0066
200	67800-51192	COVER TIMING HOLE	1				0.01	0.022
210	66301-51210	CAP	1				0.065	0.143
220	66301-51220	CAP	1				0.02	0.044
230	32701-51230	COVER	1				0.3	0.66
240	01123-50818	BOLT	4				0.012	0.0264
250	01123-50814	BOLT	2				0	0

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	32701-50010	ASSY TIRE	1			OBTAINED LOCALLY (RESERVED BY KTC)	0	0
020	32701-50110	ASSY TIRE LH	1			OBTAINED LOCALLY (RESERVED BY KTC)	0	0
030	70000-00899	WHEEL	1			OBTAINED LOCALLY (RESERVED BY KTC)	0	0
040	70000-00891	TIRE	1			OBTAINED LOCALLY (RESERVED BY KTC)	0	0
050	32701-50210	ASSY TIRE RH	1			OBTAINED LOCALLY (RESERVED BY KTC)	0	0
060	70000-00899	WHEEL	1			OBTAINED LOCALLY (RESERVED BY KTC)	0	0
070	70000-00891	TIRE	1			OBTAINED LOCALLY (RESERVED BY KTC)	0	0
080	01073-51635	BOLT	8				0.086	0.1892
090	01517-51632	STUD	4				0.076	0.1672
100	02076-50160	NUT	4				0.03	0.066
110	04512-50160	WASHER SPRING	12				0	0
120	04011-50160	WASHER PLAIN	12				0	0

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	66301-37710	PIPE CHARGE	1				0.33	0.726
020	32701-37730	PIPE CHARGE	1				0.05	0.11
030	66301-37810	COVER FILTER	1				0.27	0.594
040	66361-37950	FILTER OIL	1	<=50793			0	0
040	32701-37950	FILTER OIL	1	>=50794	←		0.7	1.54
050	66301-37910	PIPE SUCTION (C)	1				0.46	1.012
060	66301-37940	BOLT JOINT	1				0.08	0.176
070	04811-00220	RING	2				0.001	0.0022
080	66301-12170	PLUG	1				0.023	0.0506
090	04811-06100	RING	1				0.001	0.0022
100	66301-37922	PIPE SUCTION	1				0.48	1.056
110	66301-36220	HOSE	4				0.055	0.121
120	66204-36230	BAND PIPE	8				0.02	0.044
130	66301-37932	PIPE DELIVERY (C)	1				0.39	0.858
140	67850-37160	BOLT JOINT	4				0.09	0.198
150	04810-00200	RING	8				0.001	0.0022

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 12 of 251 pages

The full manual includes:

- All 251 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Kubota B20 Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual