
Item	Part No.	Description	Book
ENGINE	01T001	CRANKCASE	100K0200
	01T002	OIL PAN	100K0200
	01T003	PISTON/CRANKSHAFT	100K0200
	01T004	MAIN BEARING CASE	100K0200
	01T00502	FLYWHEEL	100K0200
	01T006	CYLINDER HEAD	100K0200
	01T007	VALVE/ROCKER ARM	100K0200
	01T008	NOZZLE HOLDER	100K0200
	01T009	NOZZLE HOLDER [COMPONENT PARTS]	100K0200
	01T010	CYLINDER HEAD COVER	100K0200
	01T011	INLET MANIFOLD	100K0200
	01T014	EXHAUST MANIFOLD	100K0200
	01T016	CAMSHAFT	100K0200
	01T017	GEAR CASE	100K0200
	01T018	WATER PUMP	100K0200
	01T019	WATER FLANGE/THERMOSTAT	100K0200
	01T020	FUEL CAMSHAFT	100K0200
	01T021	INJECTION PUMP	100K0200
	01T022	INJECTION PUMP [COMPONENT PARTS]	100K0200
	01T023	ENGINE STOP LEVER	100K0200
	01T024	SPEED CONTROL PLATE	100K0200
	01T025	GOVERNOR	100K0200
	01T026	UPPER GASKET KIT	100K0200
	01T027	LOWER GASKET KIT	100K0200
COOLING WATER SYSTEM	01T036	FAN	100K0200
ELECTRICAL SYSTEM	01T037	TENSION PULLEY [CA]	100K0200
	01T03801	DYNAMO [A][AU][NZ]	100K0200
	01T03802	ALTERNATOR [CA]	100K0200
	01T03901	DYNAMO [A][AU][NZ] [COMPONENT PARTS]	100K0200
	01T03902	ALTERNATOR [CA] [COMPONENT PARTS]	100K0200
CLUTCH	01T04802	CLUTCH	100K0200
HYDRAULIC SYSTEM	01T103	HYDRAULIC GEAR PUMP	100K0200
	01T104	HYDRAULIC GEAR PUMP [COMPONENT PARTS]	100K0200
ENGINE	02T012	AIR CLEANER	100K0200
	02T013	AIR CLEANER [COMPONENT PARTS]	100K0200
	02T015	MUFFLER	100K0200
	02T028	ENGINE STOP ROD	100K0200
FUEL SYSTEM	02T029	ACCELERATOR LEVER	100K0200
	02T030	FUEL TANK	100K0200
	02T031	FUEL PIPE 1	100K0200
	02T032	FUEL FILTER	100K0200
	02T033	FUEL PIPE 2	100K0200
COOLING WATER SYSTEM	02T034	WATER PIPE	100K0200
	02T035	RADIATOR	100K0200
ELECTRICAL SYSTEM	02T040	STARTER	100K0200
	02T041	STARTER [COMPONENT PARTS]	100K0200
	02T042	BATTERY	100K0200
	02T043	LIGHT	100K0200
	02T044	WORKING LIGHT [OPTION]	100K0200
	02T045	PANEL/SWITCH	100K0200
	02T046	PANEL BOARD [COMPONENT PARTS]	100K0200
	02T04701	WIRE HARNESS [A][AU][NZ]	100K0200
	02T04702	WIRE HARNESS [CA]	100K0200
CLUTCH	02T04902	CLUTCH ROD	100K0200
	02T050	CLUTCH PEDAL	100K0200
	02T05102	CLUTCH HOUSING	100K0200
TRANSMISSION	02T052	TRANSMISSION CASE	100K0200
	02T05302	TRANSMISSION CASE COVER	100K0200
	02T054	HST	100K0200
	02T055	HST [COMPONENT PARTS]	100K0200

PREVIEW YOUFIXTHIS.COM
Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


CRANKCASE

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	15657-01010	COMP.CRANKCASE	1				34	74.8
020	15261-96170	PLUG	3				0.005	0.011
030	15261-96160	PLUG	1				0.02	0.044
040	15321-96260	CAP SEALING	6				0.014	0.0308
050	15221-03490	CAP SEALING	1				0.02	0.044
060	15261-96010	PLUG	7				0.002	0.0044
070	15521-96020	PLUG	3				0.003	0.0066
080	15521-96030	PLUG	1				0.007	0.0154
090	05012-00609	PIN STRAIGHT	2				0.003	0.0066
100	05012-00814	PIN STRAIGHT	2				0.006	0.0132
110	15221-33650	PIN PIPE	1				0.004	0.0088
120	15231-33960	PIN PIPE	2				0.001	0.0022
130	15531-02310	LINER CYLINDER	4				0.42	0.924
140	15221-33700	O RING	1				0.001	0.0022
150	15261-73910	COVER WATER	1				0.13	0.286
160	15263-73920	GASKET WATER COVER	1				0.002	0.0044
170	01023-50618	BOLT	2				0.006	0.0132
180	15531-73170	JOINT DRAIN PIPE	1				0.145	0.319
190	15261-35010	ASSY PUMP OIL	1				0.32	0.704
200	15263-35150	GASKET OIL PUMP NA	1				0.001	0.0022
210	15261-91022	BOLT	4				0.012	0.0264
220	15954-35662	GEAR OIL PUMP DRIVE	1				0.14	0.308
230	05712-00410	KEY FEATHER	1				0.001	0.0022
240	02771-60100	NUT FLANGE	1				0.01	0.022
250	15531-39010	SWITCH OIL	1				0.032	0.0704


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Item	Part No.	Description	Book
TRANSMISSION	02T05602	PROPELLER SHAFT	100K0200
	02T05702	1ST SHAFT/2ND SHAFT	100K0200
	02T058	3RD SHAFT	100K0200
	02T059	4TH SHAFT	100K0200
	02T06002	FRONT DRIVE SHAFT/6TH SHAFT	100K0200
	02T06102	7TH SHAFT	100K0200
	02T06301	PTO SHAFT	100K0200
	02T06302	MID PTO	100K0200
	02T06303	FRONT PTO [OPTION]	100K0200
SPEED CHANGE LEVER	02T066	NEUTRAL HOLDER	100K0200
	02T067	SPEED CONTROL PEDAL	100K0200
	02T068	SPEED CHANGE PLATE	100K0200
	02T069	SHIFT SET LEVER	100K0200
	02T070	RANGE GEAR SHIFT LEVER	100K0200
	02T071	RANGE GEAR SHIFT FORK	100K0200
	02T07201	FRONT WHEEL DRIVE LEVER/PTO LEVER	100K0200
	02T07202	BI-SPEED TURN LEVER [WITH BI-SPEED TURN]	100K0200
	02T073	FRONT DRIVE FORK	100K0200
	02T074	PTO FORK SHAFT	100K0200
REAR AXLE/REAR WHEEL	02T075	REAR DIFFERENTIAL	100K0200
	02T07602	DIFF.LOCK PEDAL	100K0200
	02T077	REAR AXLE	100K0200
	02T078	REAR AXLE CASE	100K0200
	02T07901	REAR WHEEL (8.3-24)	100K0200
	02T07902	REAR WHEEL (12.4-16)	100K0200
	02T07903	REAR WHEEL (12.4-16)	100K0200
	02T07904	REAR WHEEL (13.6-16)	100K0200
	02T07905	REAR WHEEL (13.6-16)	100K0200
BRAKE	02T080	BRAKE	100K0200
	02T081	BRAKE ROD	100K0200
	02T082	BRAKE PEDAL	100K0200
	02T083	BRAKE INTERLOCKER	100K0200
FRONT AXLE/FRONT WHEEL	02T087	BEVEL GEAR SHAFT	100K0200
	02T088	FRONT AXLE CASE	100K0200
	02T089	BEVEL GEAR CASE	100K0200
	02T090	FRONT AXLE ARM	100K0200
	02T09101	FRONT DIFFERENTIAL [W/0 BI-SPEED TURN]	100K0200
	02T09102	FRONT DIFFERENTIAL [WITH BI-SPEED TURN]	100K0200
	02T092	CLUTCH DISK [WITH BI-SPEED TURN]	100K0200
	02T093	GEAR CASE [WITH BI-SPEED TURN]	100K0200
	02T094	BI-SPEED TURN CASE [WITH BI-SPEED TURN]	100K0200
	02T095	SHIFT LEVER [WITH BI-SPEED TURN]	100K0200
	02T096	FRONT DRIVE SHAFT	100K0200
	02T09701	FRONT WHEEL (6-12)	100K0200
	02T09702	FRONT WHEEL (A6-12)	100K0200
	02T09703	FRONT WHEEL (24 X 8.50-12)	100K0200
	02T098	FRONT AXEL FRAME	100K0200
	02T099	FRONT WEIGHT BRACKET [OPTION]	100K0200
STEERING	02T100	KUNCKLE ARM	100K0200
	02T10101	MANUAL STEERING	100K0200
	02T10102	POWER STEERING	100K0200
	02T10201	MANUAL STEERING [COMPONENT PARTS]	100K0200
	02T10202	POWER STEERING [COMPONENT PARTS]	100K0200
HYDRAULIC SYSTEM	02T105	HYDRAULIC PIPE (PS)	100K0200
	02T10602	HYDRAULIC PIPE (SUCTION)	100K0200
	02T10702	HYDRAULIC PIPE (DELIVERY/RETURN)	100K0200
	02T108	HYDRAULIC BLOCK [COMPONENT PARTS]	100K0200
	02T109	HYDRAULIC PIPE (CHARGE)	100K0200
	02T110	LIFT ARM	100K0200
	02T111	HYD.CYLINDER CAP	100K0200

PREVIEW YOUFIXTHIS.COM
Download full manual at youfixthis.com



15658-013-10

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	07916-29975	KIT GASKET LOWER	1				0.21	0.462
020	19087-01620	GASKET OIL PAN	1				0.001	0.0022
030	15263-73920	GASKET WATER COVER	1				0.002	0.0044
040	15263-35150	GASKET OIL PUMP NA	1				0.001	0.0022
050	15263-04360	GASKET BRG.CASE NA	1				0.005	0.011
060	15263-04820	GASKET BRG.CASE COV.	1				0.001	0.0022
070	15676-04130	GASKET GEAR CASE NA	1				0.01	0.022
080	15296-88130	GASKET H/METER UNIT	1				0.002	0.0044
090	15676-73430	GASKET WATER PUMP	1				0.005	0.011
100	15263-52140	GASKET FUEL PUMP NA	1				0.001	0.0022
110	15263-05130	GASKET BREATHER NA	1				0.001	0.0022
120	15263-57210	GASKET NA	1				0.001	0.0022
130	09400-14247	SEAL OIL	1				0.004	0.0088
140	19215-04460	SEAL OIL	1				0.03	0.066
150	15841-04140	SEAL OIL	1				0.012	0.0264
160	15471-57980	SEAL OIL	1				0.001	0.0022
170	04811-00140	O RING	1				0.001	0.0022
180	04811-05230	O RING	1				0.001	0.0022
190	04811-06130	O RING	3				0.001	0.0022
200	04810-00150	O RING	1				0.001	0.0022
210	04811-05140	O RING	2				0.001	0.0022
220	04811-00070	O RING	1				0.001	0.0022
230	04811-10750	O RING	1				0.001	0.0022
240	04811-10530	O RING	1				0.005	0.011
250	15109-33660	GASKET	1				0.001	0.0022
260	15021-33660	GASKET	2				0.001	0.0022
270	15601-96650	GASKET	2				0.001	0.0022
280	66905-51160	GASKET NA	1				0.002	0.0044

PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	67800-53410	PIPE MUFFLER	1				0.57	1.254
020	67800-53420	BAND PIPE	1				0.04	0.088
030	01153-50865	BOLT	1				0.025	0.055
040	04013-50080	WASHER PLAIN	2				0.003	0.0066
050	04512-60080	WASHER SPRING	1				0.002	0.0044
060	02114-50080	NUT	1				0.005	0.011
070	66361-54512	COMP.MUFFLER	1				4	8.8
080	15263-12370	GASKET MUFFLER	1				0.015	0.033
090	02156-50080	NUT	4				0.004	0.0088
100	04512-60080	WASHER SPRING	4				0.002	0.0044
110	66416-54520	COVER MUFFLER LH	1				0.02	0.044
120	66416-54530	COVER MUFFLER RH	1				0.025	0.055


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	67521-56210	CASE BEVEL GEAR	2				2.8	6.16
020	67521-56220	SHIM	4			0.5MM	0.01	0.022
020	67521-56230	SHIM	4			0.3MM	0.005	0.011
020	67521-56240	SHIM	4			0.2MM	0.004	0.0088
030	67521-56250	STUD	4				0.035	0.077
040	04512-50120	WASHER SPRING	4				0.003	0.0066
050	02176-50120	NUT	4				0.01	0.022
060	01133-51230	BOLT	10				0.04	0.088
070	67521-56260	SEAL DUST	2				0.002	0.0044
080	67121-56263	SUPPORT KNUCKLE ARM	2				0.4	0.88
090	76621-56270	GASKET	2				0.005	0.011
100	01123-50822	BOLT	8				0.012	0.0264

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


FRONT WHEEL (24 X 8.50-12)

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	66418-57500	ASSY FRONT WHEEL	1				32	70.4
020	66418-57510	ASSY FRONT WHEEL LH	1				16	35.2
030	67810-57530	TIRE	1				7.6	16.72
040	34159-11850	VALVE TIRE	1				0.013	0.0286
050	66418-57560	ASSY WHEEL	1	<=57497			8	17.6
050	32711-57420	WHEEL	1	>=57498	←		8	17.6
060	66418-57540	LABEL TIRE LH	1				0.002	0.0044
070	66418-57570	ASSY FRONT WHEEL RH	1				16	35.2
080	67810-57530	TIRE	1				7.6	16.72
090	34159-11850	VALVE TIRE	1				0.013	0.0286
100	66418-57560	ASSY WHEEL	1	<=57497			8	17.6
100	32711-57420	WHEEL	1	>=57498	←		8	17.6
110	66418-57550	LABEL TIRE RH	1				0.001	0.0022
120	66519-56564	BOLT STUD	12				0	0
130	04013-60120	WASHER PLAIN	12				0.01	0.022
140	04512-50120	WASHER SPRING	12				0.003	0.0066
150	02174-50120	NUT	12				0.01	0.022
160	66418-57520	WHEEL	1	<=57497			8	17.6
170	67800-57540	RIM	1	<=57497			3.88	8.536
180	67800-57550	RIM	1	<=57497			3.92	8.624
190	35260-11860	GASKET	1	<=57497			0.065	0.143
200	01173-51022	BOLT	8	<=57497			0.019	0.0418
210	04512-60100	WASHER SPRING	8	<=57497			0.002	0.0044
220	02118-50100	NUT	8	<=57497			0.005	0.011
230	66418-57520	WHEEL	1	<=57497			8	17.6
240	67800-57540	RIM	1	<=57497			3.88	8.536
250	67800-57550	RIM	1	<=57497			3.92	8.624
260	35260-11860	GASKET	1	<=57497			0.065	0.143
270	01173-51022	BOLT	8	<=57497			0.019	0.0418
280	04512-60100	WASHER SPRING	8	<=57497			0.002	0.0044
290	02118-50100	NUT	8	<=57497			0.005	0.011


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 18 of 310 pages

The full manual includes:

- All 310 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Kubota B2150HSD Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual