Instructions for Parts Books

The heading at the top of the page will be the same for the picture of the parts at it is for the page with the part numbers.

Definition of column headings on part number pages:

REF.No → The number refering to the part on the picture page of the parts book.

Part No. → The number assigned to this part at the time of printing the parts book.

Description → Discription of part.

Q'ty → Quanity of part used on that page.

S.No. → Serial number range of the equipment that this part will fit.
>= Your serial number should be greater than or equal to the number shown.
<= Your serial number should be lesser than or equal to the serial number shown.

I/C → Interchangeability of part shown.
←→ The part shown will work for the older and later serial number.
The part shown is not interchangable with the other serial number.
← new for old
→ old for new

Remarks → Notes about this particulart part. Sometimes this may say except [FR] or [CA]

Note about Country Codes:


The parts books we use in the United States of America may also contain information about a part that would be different in another country. It is important that you are aware of the country codes in some instances.

Symbol	Country
A	United States of America
CA	Canada
FR	France
GR	Greece
PO	Portugal
AU	Australia

If the remarks column says for example EXCEPT [FR] this part works in all countries except France.
That means it will work here in the USA.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



LABELS

ACCESSORIES


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Item	Part No.	Description	Book
ENGINE	010001	CRANK CASE	100A0078
	010002	OIL PAN	100A0078
	010003	CYLINDER HEAD	100A0078
	010004	GEAR CASE	100A0078
	010005	HEAD COVER	100A0078
	010100	MAIN BEARING CASE	100A0078
	010101	CAMSHAFT AND IDLE GEAR SHAFT	100A0078
	010102	PISTON AND CRANK SHAFT	100A0078
	010103	FLYWHEEL	100A0078
	010105	FUEL CAMSHAFT AND GOVERNOR SHAFT	100A0078
	010201	STOP SOLENOID	100A0078
	010202	INJECTION PUMP	100A0078
	010203	INJECTION PUMP [COMPONENT PARTS]	100A0078
	010204	GOVERNOR	100A0078
	010205	SPEED CONTROL PLATE	100A0078
	010206	NOZZLE HOLDER AND GLOW PLUG	100A0078
	010207	NOZZLE HOLDER [COMPONENT PARTS]	100A0078
	010500	WATER FLANGE AND THERMOSTAT	100A0078
	010501	WATER PUMP	100A0078
	010600	VALVE AND ROCKER ARM	100A0078
	010601	INLET MANIFOLD	100A0078
	010602	EXHAUST MANIFOLD	100A0078
	01090001	UPPER GASKET KIT	100A0078
	01090002	LOWER GASKET KIT	100A0078
ELECTRICAL SYSTEM	01A521	DYNAMO	100A0078
	01A523	DYNAMO [COMPONENT PARTS]	100A0078
CLUTCH	01C101	CLUTCH	100A0078
HYDRAULIC SYSTEM	01J120	HYDRAULIC PUMP	100A0078
	01J125	HYDRAULIC PUMP [COMPONENT PARTS]	100A0078
ENGINE	02060301	AIR CLEANER	100A0078
	02060302	AIR CLEANER	100A0078
	02060303	AIR CLEANER (DOUBLE) [OPTION]	100A0078
	020605	MUFFLER	100A0078
FUEL SYSTEM	02A001	ACCELERATOR LEVER	100A0078
	02A101	FUEL TANK	100A0078
	02A110	FUEL PIPE	100A0078
	02A11001	FUEL PIPE	100A0078
	02A130	FUEL FILTER [COMPONENT PARTS]	100A0078
COOLING WATER SYSTEM	02A401	FAN	100A0078
	02A410	WATER PIPE	100A0078
	02A420	RADIATOR	100A0078
ELECTRICAL SYSTEM	02A515	ALTERNATOR [CA]	100A0078
	02A520	ALTERNATOR [COMPONENT PARTS] [CA]	100A0078
	02A525	STARTER	100A0078
	02A530	STARTER [COMPONENT PARTS]	100A0078
	02A535	BATTERY	100A0078
	02B115	PANEL BOARD	100A0078
	02B120	PANEL BOARD [COMPONENT PARTS]	100A0078
	02B301	HEAD LIGHT	100A0078
	02B302	TAIL LIGHT/HAZARD LIGHT/WORKING LIGHT	100A0078
	02B50101	ELECTRICAL WIRING	100A0078
	02B50102	ELECTRICAL WIRING [CA]	100A0078
CLUTCH	02C110	CLUTCH ROD	100A0078
	02C301	CLUTCH PEDAL	100A0078
	02C401	CLUTCH HOUSING	100A0078
FRAME	02C415	FRAME	100A0078


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Item	Part No.	Description	Book
TRANSMISSION	02C420	TRANSMISSION CASE	100A0078
	02C425	DIFFERENTIAL GEAR CASE	100A0078
	02C427	REAR AXLE CASE	100A0078
	02D001	CLUTCH SHAFT/PROPELLER SHAFT	100A0078
	02D010	HST	100A0078
	02D015	HST [COMPONENT PARTS]	100A0078
	02D105	2ND SHAFT/3RD SHAFT/4TH SHAFT	100A0078
	02D135	5TH SHAFT/PTO SHAFT	100A0078
	02D137	MID PTO	100A0078
REAR AXLE	02D140	REAR DIFFERENTIAL	100A0078
	02D301	REAR AXLE	100A0078
BRAKE	02E001	BRAKE	100A0078
	02E015	PARKING BRAKE LEVER	100A0078
SPEED CHANGE LEVER	02F010	SPEED CHANGE LEVER	100A0078
	02F020	SPEED CONTROL PEDAL	100A0078
	02F030	SPEED SET LEVER	100A0078
	02F110	RANGE GEAR SHIFT LEVER	100A0078
	02F113	FRONT WHEEL DRIVE LEVER PLUG	100A0078
	02F125	PTO GEAR SHIFT LEVER	100A0078
	02F140	POSITION CONTROL LEVER	100A0078
	02F201	BRAKE PEDAL	100A0078
	02F205	DIFFERENTIAL LOCK PEDAL	100A0078
FRONT AXLE	02G101	FRONT AXLE FRAME	100A0078
	02G103	FRONT WHEEL HUB	100A0078
STEERING	02H001	DRAG LINK/TIE ROD	100A0078
	02H101	STEERING HANDLE	100A0078
	02H110	STEERING CONTROLLER	100A0078
	02H11501	STEERING CONTROLLER [COMPONENT PARTS]	100A0078
	02H11502	STEERING CONTROLLER [COMPONENT PARTS]	100A0078
HYDRAULIC SYSTEM	02J201	HYDRAULIC OIL LINE (SUCTION)	100A0078
	02J203	FLOW DIVIDER VALVE [COMPONENT PARTS]	100A0078
	02J215	HYDRAULIC OIL LINE (STEERING)	100A0078
	02J230	HYDRAULIC OIL LINE (T/M)	100A0078
	02J235	HYDRAULIC OIL LINE (HST)	100A0078
	02J240	HYDRAULIC OIL LINE (OIL COOLER)	100A0078
	02J301	HYDRAULIC CYLINDER CASE	100A0078
	02J405	CONTROL VALVE	100A0078
	02J41001	CONTROL VALVE [COMPONENT PARTS]	100A0078
	02J41002	CONTROL VALVE [COMPONENT PARTS]	100A0078
	02K101	LIFT ROD	100A0078
	02K115	LOWER LINK	100A0078
	02K120	TOP LINK	100A0078
HOOD(BONNET)/ROPS	02M101	FRONT GRILLE	100A0078
	02M105	HOOD (BONNET)	100A0078
	02M120	SIDE COVER	100A0078
	02M210	FENDER	100A0078
	02M211	EXTENSION FENDER	100A0078
	02M217	SEAT SUPPORT	100A0078
	02M220	SEAT	100A0078
	02M225	STEP	100A0078
	02M301	ROPS	100A0078
WHEEL	02R10102	FRONT WHEEL (6.50-10)	100A0078
	02R11003	REAR WHEEL (11.2-16)	100A0078
	02R11004	REAR WHEEL (33*12.5-15)	100A0078
	02R11005	REAR WHEEL (31*15.5-15)	100A0078
LABELS	02S101	LABEL	100A0078

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	6C050-11110	CASE TRANSMISSION	1				5.49	12.078
020	01555-51260	STUD	4				0.067	0.1474
030	6C040-11150	PIPE OIL GAUGE	1	<=30364			0.07	0.154
030	6A320-11150	PIPE OIL GAUGE	1	>=30365	↔		0.078	0.1716
040	6C040-11160	GAUGE OIL	1				0.01	0.022
050	04811-10070	O RING	1	<=30196			0.001	0.0022
050	04811-10070	O RING	2	>=30197			0.001	0.0022
060	04811-00120	O RING	2				0.001	0.0022
070	01123-60816	BOLT	1	<=30546			0.01	0.022
070	01125-60820	BOLT	1	>=30547	←		0.015	0.033
080	06311-55030	PLUG	1				0.05	0.11
090	04717-01700	WASHER WITH RUBBER	1				0.003	0.0066
100	6C040-11180	BRACKET	1				0.4	0.88
110	99999-99999	BLANK	0				0	0
120	01123-51030	BOLT	2				0.025	0.055
130	6C050-11140	PLUG	1				0.075	0.165
140	04811-00200	O RING	1				0.001	0.0022
150	01127-50816	BOLT	1				0.02	0.044
160	6C050-12110	HOLDER BEARING	1				0.23	0.506
170	6C050-12120	BOLT REAMER	3				0.036	0.0792
180	04512-60100	WASHER SPRING	3				0.002	0.0044
190	6C050-12412	COVER UPPER	1				0.76	1.672
200	01123-60816	BOLT	4	<=30518			0.01	0.022
200	01123-50820	BOLT	4	>=30519	↔		0.011	0.0242
210	13824-67580	CLAMP CORD	1				0.006	0.0132

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 12 of 255 pages

The full manual includes:

- All 255 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Kubota B2400HSE Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual