Instructions for Parts Books

The heading at the top of the page will be the same for the picture of the parts at it is for the page with the part numbers.

Definition of column headings on part number pages:

REF.No → The number refering to the part on the picture page of the parts book.

Part No. → The number assigned to this part at the time of printing the parts book.

Description → Discription of part.

Q'ty → Quanity of part used on that page.

S.No. → Serial number range of the equipment that this part will fit.
>= Your serial number should be greater than or equal to the number shown.
<= Your serial number should be lesser than or equal to the serial number shown.

I/C → Interchangeability of part shown.
←→ The part shown will work for the older and later serial number.
The part shown is not interchangable with the other serial number.
← new for old
→ old for new

Remarks → Notes about this particulart part. Sometimes this may say except [FR] or [CA]

Note about Country Codes:


The parts books we use in the United States of America may also contain information about a part that would be different in another country. It is important that you are aware of the country codes in some instances.

Symbol	Country
A	United States of America
CA	Canada
FR	France
GR	Greece
PO	Portugal
AU	Australia

If the remarks column says for example EXCEPT [FR] this part works in all countries except France.
That means it will work here in the USA.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



LABELS

OPTION


ACCESSORIES

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


Item	Part No.	Description	Book
ENGINE	010001	CRANKCASE	100K0564
	010002	OIL PAN	100K0564
	010003	CYLINDER HEAD	100K0564
	010004	GEAR CASE	100K0564
	010005	HEAD COVER	100K0564
	010006	OIL FILTER	100K0564
	010007	DIPSTICK AND GUIDE	100K0564
	010100	MAIN BEARING CASE	100K0564
	010101	CAMSHAFT AND IDLE GEAR SHAFT	100K0564
	010102	PISTON AND CRANKSHAFT	100K0564
	010103	FLYWHEEL	100K0564
	010104	CLUTCH	100K0564
	010105	FUEL CAMSHAFT AND GOVERNOR SHAFT	100K0564
	010200	ENGINE STOP LEVER	100K0564
	010202	INJECTION PUMP	100K0564
	010204	GOVERNOR	100K0564
	01020401	GOVERNOR	100K0564
	010205	SPEED CONTROL PLATE	100K0564
	010206	NOZZLE HOLDER AND GLOW PLUG	100K0564
	010207	NOZZLE HOLDER [COMPONENT PARTS]	100K0564
	010301	FUEL PUMP(MECHANICAL)	100K0564
	010400	DYNAMO AND PULLEY	100K0564
	010401	DYNAMO [COMPONENT PARTS]	100K0564
	010500	WATER FLANGE AND THERMOSTAT	100K0564
	010501	WATER PUMP	100K0564
	010600	VALVE AND ROCKER ARM	100K0564
	010601	INLET MANIFOLD	100K0564
	010602	EXHAUST MANIFOLD	100K0564
	010603	AIR CLEANER	100K0564
	010605	MUFFLER	100K0564
	010700	HYDRAULIC PUMP	100K0564
	010701	HYDRAULIC PUMP [COMPONENT PARTS]	100K0564
	010900	UPPER GASKET KIT	100K0564
	01090001	UPPER GASKET KIT	100K0564
	010901	LOWER GASKET KIT	100K0564
	010910	ALTERNATOR KIT	100K0564
	010911	ALTERNATOR [COMPONENT PARTS]	100K0564
	01A001	ACCELERATOR LEVER	100K0564
FUEL SYSTEM	01A101	FUEL TANK	100K0564
	01A110	FUEL PIPE	100K0564
	01A11001	FUEL PIPE	100K0564
	01A130	FUEL FILTER [COMPONENT PARTS]	100K0564
COOLING WATER SYSTEM	01A401	FAN	100K0564
	01A410	WATER PIPE	100K0564
	01A42001	RADIATOR [4WD] [EXCEPT[AU]]	100K0564
	01A430	RESERVE TANK	100K0564
ELECTRICAL SYSTEM	01A510	STOP SOLENOID	100K0564
	01A525	STARTER	100K0564
	01A530	STARTER [COMPONENT PARTS]	100K0564
	01A53501	BATTERY [EXCEPT[AU]]	100K0564
	01B101	SWITCH	100K0564
	01B10101	SWITCH	100K0564
	01B115	PANEL BOARD	100K0564
	01B120	PANEL BOARD [COMPONENT PARTS]	100K0564
	01B301	HEAD LIGHT	100K0564
	01B302	HAZARD LIGHT	100K0564
	01B304	TAIL LIGHT	100K0564
	01B501	ELECTRICAL WIRING	100K0564
	01B50101	ELECTRICAL WIRING	100K0564

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com




PREVIEW ONLY - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW FROM YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW FROM YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW YOUFIXTHIS.COM

Download full manual at youfixthis.com


Item	Part No.	Description	Book
CLUTCH	01C110	CLUTCH ROD	100K0564
	01C301	CLUTCH PEDAL	100K0564
	01C40101	CLUTCH HOUSING [4WD]	100K0564
FRAME	01C41301	FRONT FRAME [4WD]	100K0564
	01C415	CENTER FRAME	100K0564
TRANSMISSION/REAR AXLE	01C420	TRANSMISSION CASE	100K0564
	01C425	DIFFERENTIAL GEAR CASE	100K0564
	01C42701	REAR AXLE CASE [EXCEPT[BI-SPEED TURN TYPE]]	100K0564
	01D001	CLUTCH SHAFT	100K0564
	01D005	PROPELLER SHAFT	100K0564
	01D010	HST	100K0564
	01D015	HST [COMPONENT PARTS]	100K0564
	01D103	FRONT SHAFT	100K0564
	01D135	PTO SHAFT	100K0564
	01D137	MID PTO	100K0564
	01D140	REAR DIFFERENTIAL	100K0564
	01D143	FRONT WHEEL PROPELLER SHAFT [4WD]	100K0564
	01D149	2ND SHAFT	100K0564
	01D152	3RD SHAFT	100K0564
	01D155	4TH SHAFT	100K0564
	01D217	RANGE GEAR SHIFT FORK	100K0564
	01D220	PTO GEAR SHIFT FORK	100K0564
	01D225	DIFFERENTIAL LOCK SHIFT FORK	100K0564
	01D301	REAR AXLE	100K0564
SPEED CHANGE LEVER/BRAKE	01E001	BRAKE	100K0564
	01E005	BRAKE ROD 1	100K0564
	01E01501	PARKING BRAKE LEVER [EXCEPT[AU]]	100K0564
	01F030	SPEED SET LEVER	100K0564
	01F107	NEUTRAL HOLDER LINK	100K0564
	01F108	SPEED CONTROL PEDAL	100K0564
	01F110	RANGE GEAR SHIFT LEVER	100K0564
	01F11301	FRONT WHEEL DRIVE LEVER [4WD]	100K0564
	01F125	PTO GEAR SHIFT LEVER	100K0564
	01F143	HYDRAULIC CONTROL LEVER	100K0564
	01F201	BRAKE PEDAL	100K0564
	01F205	DIFFERENTIAL LOCK PEDAL	100K0564
FRONT AXLE	01G10501	FRONT AXLE CASE [4WD] [EXCEPT[BI-SPEED TURN TYPE]]	100K0564
	01G11501	FRONT DIFFERENTIAL[4WD][EXCEPT[BI-SPEED TURN TYPE]]	100K0564
	01G120	DIFFERENTIAL GEAR SHAFT [4WD]	100K0564
	01G123	BEVEL GEAR CASE [4WD]	100K0564
	01G12501	FRONT AXLE CASE [4WD] [EXCEPT[BI-SPEED TURN TYPE]]	100K0564
	01G130	FRONT AXLE [4WD]	100K0564
	01G13501	FRONT DRIVE SHAFT[4WD][EXCEPT[BI-SPEED TURN TYPE]]	100K0564
STEERING	01H00101	KNUCKLE ARM [4WD]	100K0564
	01H003	DRAG LINK	100K0564
	01H00501	TIE ROD [4WD]	100K0564
	01H101	STEERING HANDLE	100K0564
	01H105	STEERING POST	100K0564
HYDRAULIC SYSTEM	01J101	HYDRAULIC PUMP(PS)	100K0564
	01J105	HYDRAULIC PUMP(PS) [COMPONENT PARTS]	100K0564
	01J201	HYDRAULIC OIL LINE(SUCTION)	100K0564
	01J210	HYDRAULIC OIL LINE(DELIVERY)	100K0564
	01J215	HYDRAULIC OIL LINE(STEERING)	100K0564
	01J235	HYDRAULIC OIL LINE (HST)	100K0564
	01J240	HYDRAULIC OIL LINE (OIL COOLER)	100K0564

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	6C140-59210	ASSY STARTER	1				2.75	6.05
020	6C140-82610	ARMATURE	1				0.52	1.144
030	6C140-82620	ASSY SHAFT	1				0.53	1.166
040	99999-99999	BLANK	0				0	0
050	6C140-82640	GEAR.INTERNAL	1	<=50604			0.05	0.11
050	6C140-82810	GEAR.INTERNAL	1	>=50605	←		0	0
055	6C140-82820	GASKET	1	>=50605			0	0
060	6C040-82650	GEAR PLANETARY	3				0.016	0.0352
070	6C040-82660	CLUTCH OVER RUNNING	1				0.3	0.66
070	16853-63040	CLUTCH OVER RUNNING	1		↔		0.25	0.55
080	6C040-82670	STOPPER	1				0.004	0.0088
090	6C040-82680	GASKET	1	<=50604			0.003	0.0066
100	6C040-82690	BALL	1				0.001	0.0022
110	6C140-82700	ASSY YOKE	1				0.35	0.77
120	99999-99999	BLANK	0				0	0
130	6C140-82720	ASSY HOLDER BRUSH	1				0.07	0.154
140	99999-99999	BLANK	0				0	0
150	99999-99999	BLANK	0				0	0
160	6C140-82750	ASSY BRACKET REAR	1				0.14	0.308
170	6C040-82760	BUSH	1				0.005	0.011
180	6C040-82770	ASSY BRACKET FRONT	1				0.4	0.88
190	15852-63240	BUSH	1				0.006	0.0132
200	6C140-82780	BOLT	2				0.015	0.033
210	6C040-82790	LEVER FORK	1				0.022	0.0484
220	6C040-82800	ASSY SWITCH MAGNETIC	1				0.63	1.386
230	15852-93310	SCREW PAN-HEAD	1				0.02	0.044

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW OF YOUFIXTHIS.COM

Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	66611-17114	AXLE REAR	2				4.64	10.208
020	08101-06306	BEARING BALL	2				0.335	0.737
030	04612-00300	CIR CLIP EXTERNAL	2				0.003	0.0066
040	6C040-17130	GEAR	2			57T	2.55	5.61
050	6C040-17140	COLLAR	2				0.26	0.572
060	08101-06208	BEARING BALL	2				0.355	0.781
070	09500-00014	SEAL OIL	2				0.06	0.132

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	6A100-57300	ASSY SHAFT F.AXLE	2				1.5	3.3
020	6C040-57330	BOLT	12				0.035	0.077
030	6C040-57310	GEAR BEVEL	2			41T	2.79	6.138
040	08101-06206	BEARING BALL	2				0.196	0.4312
050	08101-06305	BEARING BALL	2				0.23	0.506
060	67156-56820	COLLAR SET	4				0.004	0.0088
070	37410-57340	SEAL OIL	2				0.045	0.099

PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	6C040-36410	PISTON HYD.	1				0.78	1.716
020	04811-00600	O RING	1				0.006	0.0132
030	67111-36720	RING BACK UP	1				0.005	0.011
040	6C040-36430	ROD HYD.PISTON	1				0.36	0.792
050	6C040-36470	SHAFT HYD.ARM	1				1.66	3.652
060	6C040-36550	O RING	2				0.003	0.0066
070	6C040-36510	ARM LIFT LH	1				1.88	4.136
080	6C040-36524	ARM LIFT RH	1				1.86	4.092
090	04612-00320	CIR CLIP EXTERNAL	2				0.004	0.0088
100	6C040-36450	ARM HYDRAULIC	1				0.99	2.178
110	05411-00640	PIN SPRING	1				0.006	0.0132
120	6C040-36750	STOPPER	1				0.222	0.4884

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 18 of 334 pages

The full manual includes:

- All 334 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Kubota B2410HSD Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual