Instructions for Parts Books

The heading at the top of the page will be the same for the picture of the parts at it is for the page with the part numbers.

Definition of column headings on part number pages:

REF.No → The number refering to the part on the picture page of the parts book.

Part No. → The number assigned to this part at the time of printing the parts book.

Description → Discription of part.

Q'ty → Quanity of part used on that page.

S.No. → Serial number range of the equipment that this part will fit.
>= Your serial number should be greater than or equal to the number shown.
<= Your serial number should be lesser than or equal to the serial number shown.

I/C → Interchangeability of part shown.
←→ The part shown will work for the older and later serial number.
The part shown is not interchangable with the other serial number.
← new for old
→ old for new

Remarks → Notes about this particulart part. Sometimes this may say except [FR] or [CA]

Note about Country Codes:


The parts books we use in the United States of America may also contain information about a part that would be different in another country. It is important that you are aware of the country codes in some instances.

Symbol	Country
A	United States of America
CA	Canada
FR	France
GR	Greece
PO	Portugal
AU	Australia

If the remarks column says for example EXCEPT [FR] this part works in all countries except France.
That means it will work here in the USA.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



LABELS


ACCESSORIES

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


Item	Part No.	Description	Book
ENGINE	01T001	CRANKCASE GROUP	100K0037
	01T002	CYLINDER HEAD GROUP	100K0037
	01T003	GEAR CASE GROUP	100K0037
	01T004	BEARING CASE GROUP	100K0037
	01T005	BREATHER GROUP	100K0037
	01T006	INLET MANIFOLD GROUP	100K0037
	01T007	VALVE ROCKER ARM GROUP	100K0037
	01T008	HEAD COVER GROUP	100K0037
	01T009	CAMSHAFT GROUP	100K0037
	01T010	PISTON CRANK SHAFT GROUP	100K0037
	01T011	FLYWHEEL GROUP	100K0037
	01T012	NOZZLE HOLDER GROUP	100K0037
	01T013	INJECTION PUMP GROUP	100K0037
	01T014	SPEED CONTROL PLATE GROUP	100K0037
	01T015	GOVERNOR GROUP	100K0037
	01T016	DYNAMO GROUP	100K0037
	01T017	CLUTCH GROUP	100K0037
	01T018	NAME PLATE GROUP	100K0037
	01T019	NOZZLE HOLDER GROUP	100K0037
	01T020	INJECTION PUMP GROUP	100K0037
	01T021	DYNAMO GROUP	100K0037
	01T022	STARTER GROUP	100K0037
	01T023	OIL PRESSURE PUMP GROUP	100K0037
TRANSMISSION	01T024	TRANSMISSION CASE GROUP	100K0037
	01T025	CASE COVER GROUP	100K0037
	01T026	AXLE CASE GROUP	100K0037
REAR AXLE/REAR WHEEL	01T02701	REAR WHEEL GROUP	100K0037
CLUTCH	01T028	CLUTCH ROD GROUP	100K0037
REAR AXLE/REAR WHEEL	01T029	1ST SHAFT 4TH SHAFT GROUP	100K0037
	01T030	2ND SHAFT REVERSE SHAFT GROUP	100K0037
	01T031	3RD 5TH PTO SHAFT GROUP	100K0037
	01T032	DIFFERENTIAL GROUP	100K0037
SPEED CHANGE LEVER	01T033	MAIN SPEED CHANGE GROUP	100K0037
	01T034	AUX.SPEED CHANGE GROUP	100K0037
FRONT AXLE/FRONT WHEEL	01T035	FRONT DRIVE GROUP	100K0037
BRAKE	01T036	BRAKE GROUP	100K0037
HYDRAULIC SYSTEM	01T037	OIL PRESSURE PIPE GROUP	100K0037
	01T038	CONTROL VALVE GROUP	100K0037
	01T039	OIL PRESSURE GROUP 1	100K0037
	01T040	OIL PRESSURE GROUP 2	100K0037
STEERING	01T041	STEERING GROUP	100K0037
BRAKE	01T042	BRAKE ROD GROUP	100K0037
ENGINE	01T043	ACCELERATOR PEDAL GROUP	100K0037
HOOD(BONNET)/CHASSIS	01T044	SEAT GROUP	100K0037
LABELS	01T045	NAME PLATE GROUP	100K0037
CLUTCH	01T046	CLUTCH HOUSING GROUP	100K0037
FRONT AXLE/FRONT WHEEL	01T047	FRONT WHEEL SUPPORT GROUP	100K0037
COOLING WATER SYSTEM	01T048	RADIATOR GROUP	100K0037
HOOD(BONNET)/CHASSIS	01T049	FENDER GROUP	100K0037
	01T050	BONNET GROUP	100K0037
ENGINE	01T051	MUFFLER GROUP	100K0037
FUEL SYSTEM	01T052	FUEL TANK GROUP	100K0037
ELECTRICAL SYSTEM	01T053	BATTERY GROUP	100K0037
	01T054	PANEL GROUP	100K0037
ENGINE	01T061	AIR CLEANER GROUP	100K0037
FUEL SYSTEM	01T062	FUEL FILTER GROUP	100K0037
FRONT AXLE/FRONT WHEEL	01T063	FRONT AXLE GROUP [B5100E]	100K0037
	01T064	FRONT WHEEL GROUP [B5100E-P B5100E-PT]	100K0037
HYDRAULIC SYSTEM	01T065	3-POINT LINKAGE GROUP [B5100D-P B5100E-P B5100E-PT]	100K0037

PREVIEW YOUFIXTHIS.COM
Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com



REF. No. 14 01555-51035
Change of material


PREVIEW ONLY - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



REF. No. 35 66711-4215-0




ℓ : 25→40mm

REF. No. 41 66706-4725-0

English → English and French.


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



REF. No. 35 01153-50828
36 04512-50060




Change of bolt with spring washer.

REF. No. 44 35217-1837-0

Change of sentence.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	66704-61200	ASSY TOOLS	1				1.8	3.96
002	15241-86610	WRENCH FILTER	1				0.133	0.2926
003	66494-62910	MANUAL INSTRUCTION	1	<=10295			0	0
003	66704-62915	MANUAL INSTRUCTION	1	>=10296			0	0
003	66701-62910	MANUAL INSTRUCTION	1				0.122	0.2684
004	66494-62920	PARTS LIST	1				0.23	0.506
005	54711-41830	SWITCH HORN	1			OPTIONAL PARTS FOR E-P	0.014	0.0308
006	66591-55300	ASSY HORN	1			OPTIONAL PARTS FOR E-P	0.15	0.33
007	01202-50612	BOLT	1			OPTIONAL PARTS FOR E-P	0.005	0.011
008	66494-81200	KIT HORN	1			REF.No.013 TO 019 KIT FOR E-PT CANADA	0.2	0.44
009	66591-55300	ASSY HORN	1			KIT FOR E-PT CANADA	0.15	0.33
010	32150-32240	SWITCH HORN	1			KIT FOR E-PT CANADA	0.013	0.0286
011	01202-50612	BOLT	2			KIT FOR E-PT CANADA	0.005	0.011
012	66494-81210	SERVICE MANUAL	1			KIT FOR E-PT CANADA	0.03	0.066
013	66704-82200	ASSY L/W WIRE HARN.	1				0.28	0.616
014	66704-81100	KIT MIRROR	1				0.307	0.6754
016	66704-86110	PIN LOWER LINK	1				1.19	2.618
017	66704-86200	ASSY GEAR	1			REF.No.018 019	0.74	1.628
018	66704-56950	GEAR SPUR 12	1				0.162	0.3564
019	66704-56960	GEAR SPUR 25	1				0.58	1.276
020	66704-83600	ASSY SPRING AND COL.	1			REF.No.021 022	0.025	0.055
021	66591-36350	SPRING	1				0.01	0.022
022	66591-36370	COLLAR	1				0.016	0.0352
023	66494-88500	KIT PTO FRONT	1			REF.No.024 TO 034	2.3	5.06
024	15263-74280	PULLEY FAN DRIVE	1				0.85	1.87
025	66704-88520	WASHER CRANKSHAFT	1				0.008	0.0176
026	66704-88530	FRANGE	1				0.4	0.88
027	01123-50825	BOLT	3				0.013	0.0286
028	04013-50080	WASHER PLAIN	3				0	0
029	66494-88540	SHAFT FRONT PTO	1				0.92	2.024
030	02118-50100	NUT	1				0.005	0.011
031	04512-50100	WASHER SPRING	1				0	0
032	66494-88550	SHIM 1	2				0.012	0.0264
033	66494-88560	SHIM 2	6				0.006	0.0132
034	66494-88570	MANUAL FIXING	1				0.005	0.011
035	66704-62930	INSTRUCTION MIS.OIL	1				0.001	0.0022
036	66704-85600	HOLDER FUSE	1				0.005	0.011

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Item	Part No.	Description	Book
ACCESSORIES	**01T066**	**ACCESSARY AND SERVICE PARTS GROUP**	**100K0037**

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 12 of 125 pages

The full manual includes:

- All 125 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Kubota B5100E-P, B5100E, B5100D-P, B5100E-PT Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual