Instructions for Parts Books

The heading at the top of the page will be the same for the picture of the parts at it is for the page with the part numbers.

Definition of column headings on part number pages:

REF.No → The number refering to the part on the picture page of the parts book.

Part No. → The number assigned to this part at the time of printing the parts book.

Description → Discription of part.

Q'ty → Quanity of part used on that page.

S.No. → Serial number range of the equipment that this part will fit.
>= Your serial number should be greater than or equal to the number shown.
<= Your serial number should be lesser than or equal to the serial number shown.

I/C → Interchangeability of part shown.
←→ The part shown will work for the older and later serial number.
The part shown is not interchangable with the other serial number.
← new for old
→ old for new

Remarks → Notes about this particulart part. Sometimes this may say except [FR] or [CA]

Note about Country Codes:


The parts books we use in the United States of America may also contain information about a part that would be different in another country. It is important that you are aware of the country codes in some instances.

Symbol	Country
A	United States of America
CA	Canada
FR	France
GR	Greece
PO	Portugal
AU	Australia

If the remarks column says for example EXCEPT [FR] this part works in all countries except France.
That means it will work here in the USA.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



LABELS

ACCESSORIES

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


CRANKCASE [D850-LA-H D950-LA-H]

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	15533-01010	COMP.CRANKCASE	1				26	57.2
020	06311-75015	PLUG EXPANSION	3				0.002	0.0044
030	06311-75040	PLUG EXPANSION	1				0.02	0.044
040	15321-96260	CAP SEALING	5				0.014	0.0308
050	15221-03490	CAP SEALING	1				0.02	0.044
060	15261-96010	PLUG	6				0.002	0.0044
070	15521-96020	PLUG	3				0.003	0.0066
080	15521-96030	PLUG	1				0.007	0.0154
090	05012-00609	PIN STRAIGHT	2				0.003	0.0066
100	05012-00814	PIN STRAIGHT	2				0.006	0.0132
110	15221-33650	PIN PIPE	1				0.004	0.0088
120	15231-33960	PIN PIPE	2				0.001	0.0022
130	15531-02310	LINER CYLINDER	3				0.42	0.924
140	15221-33700	O RING	1				0.001	0.0022
150	15261-73910	COVER WATER	1				0.13	0.286
160	15261-73920	GASKET WATER COVER	1				0	0
170	01023-50618	BOLT	2				0.006	0.0132
180	15531-73170	JOINT DRAIN PIPE	1				0.145	0.319
190	15261-35010	ASSY PUMP OIL	1				0.32	0.704
200	15261-35150	GASKET OIL PUMP	1				0	0
210	15261-91022	BOLT	4				0.012	0.0264
220	15954-35660	GEAR OIL PUMP DRIVE	1				0.14	0.308
230	05712-00410	KEY FEATHER	1				0.001	0.0022
240	02016-50100	NUT	1				0.009	0.0198
250	04211-50100	WASHER CLAW	1				0.002	0.0044
260	15521-39010	SWITCH OIL	1				0.048	0.1056


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW ONLY
YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Item	Part No.	Description	Book
CLUTCH	01T031	CLUTCH HOUSING	100K0070
HOOD(BONNET)/CHASSIS	01T032	FRONT AXLE FRAME	100K0070
COOLING WATER SYSTEM	01T033	RADIATOR	100K0070
HOOD(BONNET)/CHASSIS	01T034	FENDER	100K0070
	01T035	HOOD	100K0070
ELECTRICAL SYSTEM	01T036	BATTERY	100K0070
ENGINE	01T037	MUFFLER	100K0070
FUEL SYSTEM	01T038	FUEL TANK	100K0070
	01T039	FUEL FILTER	100K0070
ENGINE	01T040	AIR CLEANER	100K0070
	01T041	DECOMPRESS WIRE/ENGINE STOP WIRE	100K0070
ELECTRICAL SYSTEM	01T042	PANEL	100K0070
	01T043	PANEL SWITCH	100K0070
	01T044	LIGHT	100K0070
FRONT AXLE/FRONT WHEEL	01T055	FRONT AXLE ARM	100K0070
	01T056	BEVEL GEAR CASE	100K0070
	01T057	FRONT AXLE CASE	100K0070
	01T058	KNUCKLE ARM	100K0070
	01T059	FRONT DIFFERENTIAL	100K0070
	01T060	BEVEL GEAR	100K0070
	01T061	DRIVE SHAFT	100K0070
	01T06201	FRONT WHEEL (6-12)	100K0070
	01T06202	FRONT WHEEL (20.5-8.00 X 10)	100K0070
HYDRAULIC SYSTEM	01T063	3-POINT LINKAGE	100K0070
FUEL SYSTEM	01T064	FUEL FILTER	100K0070
HYDRAULIC SYSTEM	01T066	CONTROL VALVE	100K0070
ACCESSORIES	01T067	ACCESSORIES AND SERVICE PARTS	100K0070

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	67061-18610	SHAFT PTO FORK	1				0.2	0.44
020	67061-18620	FORK PTO SHIFT	1				0.18	0.396
030	62061-18260	SPRING STOPPER	1				0.002	0.0044
040	07715-01605	BALL	1				0.003	0.0066
050	05511-50322	PIN SPLIT	1				0.002	0.0044
060	66591-18220	ARM	1				0.12	0.264
070	04811-00160	O RING	1				0.001	0.0022
080	66591-18180	RETAINER FORK ROD	1				0.012	0.0264
090	01202-50614	BOLT	2				0.006	0.0132
100	66611-19310	ROD	1				0.129	0.2838

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 12 of 168 pages

The full manual includes:

- All 168 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Kubota B7200HSTD Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual