Instructions for Parts Books

The heading at the top of the page will be the same for the picture of the parts at it is for the page with the part numbers.

Definition of column headings on part number pages:

REF.No → The number refering to the part on the picture page of the parts book.

Part No. → The number assigned to this part at the time of printing the parts book.

Description → Discription of part.

Q'ty → Quanity of part used on that page.

S.No. → Serial number range of the equipment that this part will fit.
>= Your serial number should be greater than or equal to the number shown.
<= Your serial number should be lesser than or equal to the serial number shown.

I/C → Interchangeability of part shown.
←→ The part shown will work for the older and later serial number.
The part shown is not interchangable with the other serial number.
← new for old
→ old for new

Remarks → Notes about this particulart part. Sometimes this may say except [FR] or [CA]

Note about Country Codes:

The parts books we use in the United States of America may also contain information about a part that would be different in another country. It is important that you are aware of the country codes in some instances.

Symbol	Country
A	United States of America
CA	Canada
FR	France
GR	Greece
PO	Portugal
AU	Australia

If the remarks column says for example EXCEPT [FR] this part works in all countries except France.
That means it will work here in the USA.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Item	Part No.	Description	Book
ENGINE	021001	CRANKCASE	100K0704
	021002	OIL PAN	100K0704
	021003	CYLINDER HEAD	100K0704
	021004	GEAR CASE	100K0704
	021005	HEAD COVER	100K0704
	021006	OIL FILTER	100K0704
	021007	DIPSTICK AND GUIDE	100K0704
	021100	MAIN BEARING CASE	100K0704
	021101	CAMSHAFT AND IDLE GEAR SHAFT	100K0704
	021102	PISTON AND CRANKSHAFT	100K0704
	021103	FLYWHEEL	100K0704
	021104	CLUTCH	100K0704
	021105	FUEL CAMSHAFT AND GOVERNOR SHAFT	100K0704
	021200	ENGINE STOP LEVER	100K0704
	021201	STOP SOLENOID	100K0704
	021202	INJECTION PUMP	100K0704
	021203	INJECTION PUMP [COMPONENT PARTS]	100K0704
	021204	GOVERNOR	100K0704
	021205	SPEED CONTROL PLATE	100K0704
	021206	NOZZLE HOLDER AND GLOW PLUG	100K0704
	021207	NOZZLE HOLDER [COMPONENT PARTS]	100K0704
	021301	FUEL PUMP(MECHANICAL)	100K0704
	021400	DYNAMO AND PULLEY	100K0704
	021401	DYNAMO [COMPONENT PARTS]	100K0704
	021500	WATER FLANGE AND THERMOSTAT	100K0704
	021501	WATER PUMP	100K0704
	021600	VALVE AND ROCKER ARM	100K0704
	021601	INLET MANIFOLD	100K0704
	021602	EXHAUST MANIFOLD	100K0704
	021700	HYDRAULIC PUMP	100K0704
	021701	HYDRAULIC PUMP [COMPONENT PARTS]	100K0704
	021900	UPPER GASKET KIT	100K0704
	021901	LOWER GASKET KIT	100K0704
	031603	AIR CLEANER	100K0704
	031605	MUFFLER	100K0704
	031910	ALTERNATOR KIT	100K0704
	031911	ALTERNATOR [COMPONENT PARTS]	100K0704
	03A00103	ACCELERATOR LEVER [HST TYPE]	100K0704
FUEL SYSTEM	03A10102	FUEL TANK	100K0704
	03A11002	FUEL PIPE	100K0704
	03A11003	FUEL PIPE	100K0704
	03A130	FUEL FILTER [COMPONENT PARTS]	100K0704
COOLING WATER SYSTEM	03A40102	FAN	100K0704
	03A41002	WATER PIPE	100K0704
	03A42003	RADIATOR [EXCEPT[AU]]	100K0704
	03A42004	RADIATOR [AU]	100K0704
	03A43003	RESERVE TANK	100K0704
ELECTRICAL SYSTEM	03A51002	STOP SOLENOID	100K0704
	03A52502	STARTER	100K0704
	03A53002	STARTER [COMPONENT PARTS]	100K0704
	03A53503	BATTERY [EXCEPT[AU]]	100K0704
	03A53504	BATTERY [AU]	100K0704
	03B10103	SWITCH [HST TYPE]	100K0704
	03B11502	PANEL BOARD	100K0704
	03B12002	PANEL BOARD [COMPONENT PARTS]	100K0704
	03B301	HEAD LIGHT	100K0704
	03B302	HAZARD LIGHT [OLD TYPE]	100K0704
	03B304	TAIL LIGHT	100K0704
	03B50103	ELECTRICAL WIRING [HST TYPE]	100K0704
CLUTCH	03C11002	CLUTCH ROD	100K0704

PREVIEW YOUFIXTHIS.COM
Download full manual at youfixthis.com


CRANKCASE

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	16612-01013	COMP.CRANKCASE	1	<=YK0004			0	0
010	16612-01014	COMP.CRANKCASE	1	>=YL0001	←		32	70.4
010	16612-01015	COMP.CRANKCASE	1	>=1G0001	←		0	0
020	15451-96270	CAP SEALING	4				0.012	0.0264
030	15221-03490	CAP SEALING	1				0.02	0.044
040	15261-96010	PLUG	3				0.002	0.0044
050	16683-96020	PLUG	1				0.47	1.034
060	16241-96010	PLUG	3				0.007	0.0154
070	15521-96020	PLUG	2				0.003	0.0066
080	17391-96160	PLUG EXPANSION	3				0.003	0.0066
090	16271-96160	PLUG EXPANSION	1				0.025	0.055
100	16225-94510	PIN STRAIGHT	2				0.001	0.0022
110	16221-94530	PIN STRAIGHT	2				0.006	0.0132
120	16221-94520	PIN STRAIGHT	2				0.005	0.011
130	15231-33960	PIN PIPE	2				0.001	0.0022
140	16241-33650	PIN PIPE	1				0.002	0.0044
150	16241-96262	PLUG FUEL CAMSHAFT	1				0.007	0.0154
160	16261-56280	PIN START SPRING	1				0.004	0.0088
170	16282-96010	PLUG	1				0.09	0.198
180	16271-55350	BUSH GOVERNOR GEAR	1				0.06	0.132
190	15221-33610	PLUG	1				0.009	0.0198
200	15021-33660	GASKET	1				0.001	0.0022
210	15221-33700	O RING	1				0.001	0.0022
220	15321-73340	PIPE WATER RETURN	1				0.016	0.0352


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Item	Part No.	Description	Book
CLUTCH	03C301	CLUTCH PEDAL	100K0704
	03C40102	CLUTCH HOUSING	100K0704
FRAME	03C41302	FRONT FRAME	100K0704
	03C41503	CENTER FRAME [HST TYPE]	100K0704
TRANSMISSION/REAR AXLE	03C42003	TRANSMISSION CASE [HST TYPE]	100K0704
	03C425	DIFFERENTIAL GEAR CASE	100K0704
	03C427	REAR AXLE CASE	100K0704
	03D00102	CLUTCH SHAFT	100K0704
	03D00501	PROPELLER SHAFT [HST TYPE]	100K0704
	03D010	HST [HST TYPE]	100K0704
	03D015	HST [COMPONENT PARTS] [HST TYPE]	100K0704
	03D10303	FRONT SHAFT [HST TYPE]	100K0704
	03D13501	PTO SHAFT [HST TYPE]	100K0704
	03D13701	MID PTO [HST TYPE]	100K0704
	03D140	REAR DIFFERENTIAL	100K0704
	03D14301	FRONT WHEEL PROPELLER SHAFT [HST TYPE]	100K0704
	03D14901	2ND SHAFT [HST TYPE]	100K0704
	03D15201	3RD SHAFT [HST TYPE]	100K0704
	03D15501	4TH SHAFT [HST TYPE]	100K0704
	03D21701	RANGE GEAR SHIFT FORK [HST TYPE]	100K0704
	03D22001	PTO GEAR SHIFT FORK [HST TYPE]	100K0704
	03D225	DIFFERENTIAL LOCK SHIFT FORK	100K0704
	03D301	REAR AXLE	100K0704
SPEED CHANGE LEVER/BRAKE	03E00101	BRAKE [HST TYPE]	100K0704
	03E00501	BRAKE ROD 1 [HST TYPE]	100K0704
	03E01501	PARKING BRAKE LEVER [HST TYPE] [EXCEPT[AU]]	100K0704
	03E01502	PARKING BRAKE LEVER [HST TYPE] [AU]	100K0704
	03F030	SPEED SET LEVER [HST TYPE]	100K0704
	03F107	NEUTRAL HOLDER LINK [HST TYPE]	100K0704
	03F108	SPEED CONTROL PEDAL [HST TYPE]	100K0704
	03F110	RANGE GEAR SHIFT LEVER [HST TYPE]	100K0704
	03F113	FRONT WHEEL DRIVE LEVER	100K0704
	03F125	PTO GEAR SHIFT LEVER	100K0704
	03F143	HYDRAULIC CONTROL LEVER	100K0704
	03F201	BRAKE PEDAL	100K0704
	03F20501	DIFFERENTIAL LOCK PEDAL [HST TYPE]	100K0704
FRONT AXLE	03G105	FRONT AXLE CASE	100K0704
	03G115	FRONT DIFFERENTIAL	100K0704
	03G120	DIFFERENTIAL GEAR SHAFT	100K0704
	03G123	BEVEL GEAR CASE	100K0704
	03G125	FRONT AXLE CASE	100K0704
	03G130	FRONT AXLE	100K0704
	03G13501	FRONT DRIVE SHAFT [HST TYPE]	100K0704
STEERING	03H001	KNUCKLE ARM	100K0704
	03H003	DRAG LINK	100K0704
	03H005	TIE ROD	100K0704
	03H10102	STEERING HANDLE	100K0704
	03H10502	UNIVERSAL JOINT	100K0704
HYDRAULIC SYSTEM	03J101	HYDRAULIC PUMP(PS)	100K0704
	03J105	HYDRAULIC PUMP(PS) [COMPONENT PARTS]	100K0704
	03J20102	HYDRAULIC OIL LINE(SUCTION)	100K0704
	03J21002	HYDRAULIC OIL LINE(DELIVERY)	100K0704
	03J215	HYDRAULIC OIL LINE(STEERING)	100K0704
	03J235	HYDRAULIC OIL LINE (HST) [HST TYPE]	100K0704
	03J24002	HYDRAULIC OIL LINE (OIL COOLER) [HST TYPE]	100K0704
	03J24502	HYDRAULIC OIL LINE (F/M) [HST TYPE]	100K0704
	03J301	HYDRAULIC CYLINDER	100K0704
	03J310	HYDRAULIC PISTON/LIFT ARM	100K0704
	03J330	FEED BACK LEVER	100K0704
	03J405	CONTROL VALVE	100K0704

PREVIEW YOUFIXTHIS.COM
Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	16271-95690	JOINT EYE	1				0.046	0.1012
020	16032-51010	ASSY PUMP INJECTION	1			REFER TO L.No.D12-L FOR COMPONENTS.	1	2.2
030	16006-52092	SHIM INJECTION PUMP	1			0.20mm	0.004	0.0088
030	16006-52112	SHIM INJECTION PUMP	1			0.25mm	0.004	0.0088
030	16006-52122	SHIM INJECTION PUMP	1			0.30mm	0.006	0.0132
040	01311-10620	BOLT HEX-SOC-HD	2				0.012	0.0264
050	15841-91500	STUD	2				0.04	0.088
060	15841-92320	NUT	2				0.01	0.022
070	04512-60060	WASHER SPRING	4				0.001	0.0022

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

UPPER GASKET KIT

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	07916-27787	KIT GASKET UPPER	1				0	0
020	04814-50300	O RING	2				0.001	0.0022
030	15221-33700	O RING	1				0.001	0.0022
040	15601-96650	GASKET	1				0.001	0.0022
050	16221-73270	GASKET THERMOSTAT	1				0.003	0.0066
060	15841-53622	GASKET	3				0.002	0.0044
070	15951-96660	GASKET	3				0.001	0.0022
080	1C010-13150	SEAL VALVE STEM	6				0.002	0.0044
090	16231-03310	GASKET CYLINDER HEAD	1				0.07	0.154
100	16261-11822	GASKET IN-MANIFOLD	1				0.01	0.022
110	16261-12350	GASKET EX-MANIFOLD	1				0.019	0.0418
120	16261-14520	GASKET HEAD COVER	1				0.01	0.022
130	15263-12370	GASKET MUFFLER NA	1				0.015	0.033
135	15313-12370	GASKET NA	1			OUT OF USE	0.008	0.0176
140	16264-72920	GASKET WATER FLANGE	1				0.001	0.0022
150	16261-96710	GASKET	1			OUT OF USE	0.002	0.0044
160	19077-53650	SEAL HEAT	3				0.005	0.011

PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	6A320-58810	ASSY TANK RESERVE	1	<=62292			0.28	0.616
010	6A320-58812	ASSY TANK RESERVE	1	>=62293	←		0.28	0.616
020	6A320-58820	ASSY CAP	1				0.08	0.176
030	37410-88640	CAP	1				0.01	0.022
040	6A320-58830	TUBE	1				0.007	0.0154
050	6A320-58840	TUBE	1				0.05	0.11
060	37410-88680	CLIP	2				0.003	0.0066
070	04811-00380	O RING	1				0.003	0.0066
080	53581-64150	BAND CORD	1				0.002	0.0044

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW YOUFIXTHIS.COM


Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	6C050-14410	GEAR-SHAFT	1			14T	0.635	1.397
020	08101-06205	BEARING BALL	1				0.14	0.308
030	61361-14280	BEARING BALL	1				0.09	0.198
040	6C050-14450	GEAR	1			18T	0.28	0.616
050	6C050-14520	COUPLING	1				0.099	0.2178


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	6C140-88100	ASSY ROPS	1				0	0
020	75599-04655	HEX.BOLT	3				0	0
030	75599-04660	HEX.BOLT	1				0	0
040	75599-33016	WASHER SPRING	4				0.08	0.176
050	75599-32016	WASHER PLAIN	4				0.009	0.0198
060	75599-31066	HEX.NUT	4				0	0
070	75599-04320	HEX.BOLT	2				0.02	0.044
080	75599-33013	WASHER SPRING	2				0	0
090	6C140-88450	MANUAL INSTRUCTION	1				0	0
100	01123-51235	BOLT	10				0.041	0.0902
110	6C040-72210	COVER ROPS	2				0.066	0.1452
120	6A100-51380	CUSHION	2				0.003	0.0066
130	6C040-51342	BOLT	2				0.017	0.0374

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 18 of 341 pages

The full manual includes:

- All 341 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Kubota B7500HSD Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual