

Item	Part No.	Description	Book
ENGINE	010001	CRANKCASE	100K0780
	010002	OIL PAN	100K0780
	010003	CYLINDER HEAD	100K0780
	010004	GEAR CASE	100K0780
	010005	HEAD COVER	100K0780
	010006	OIL FILTER	100K0780
	010007	DIPSTICK AND GUIDE	100K0780
	010100	MAIN BEARING CASE	100K0780
	010101	CAMSHAFT AND IDLE GEAR SHAFT	100K0780
	010102	PISTON AND CRANKSHAFT	100K0780
	010103	FLYWHEEL	100K0780
	010105	FUEL CAMSHAFT AND GOVERNOR SHAFT	100K0780
	010200	IDLE APPARATUS	100K0780
	010202	INJECTION PUMP	100K0780
	010204	GOVERNOR	100K0780
	01020401	GOVERNOR	100K0780
	010205	SPEED CONTROL PLATE	100K0780
	010206	NOZZLE HOLDER AND GLOW PLUG	100K0780
	010207	NOZZLE HOLDER [COMPONENT PARTS]	100K0780
	010301	FUEL PUMP(MECHANICAL)	100K0780
	010500	WATER FLANGE AND THERMOSTAT	100K0780
	010501	WATER PUMP	100K0780
	010600	VALVE AND ROCKER ARM	100K0780
	010601	INLET MANIFOLD	100K0780
	010602	EXHAUST MANIFOLD	100K0780
	020603	AIR CLEANER	100K0780
	020605	MUFFLER	100K0780
	010900	UPPER GASKET KIT [OPTION]	100K0780
	010901	LOWER GASKET KIT [OPTION]	100K0780
	02A00102	ACCELERATOR LEVER	100K0780
FUEL SYSTEM	02A101	FUEL TANK	100K0780
	02A110	FUEL PIPE	100K0780
	02A130	FUEL FILTER [COMPONENT PARTS]	100K0780
COOLING WATER SYSTEM	02A401	FAN	100K0780
	02A410	WATER PIPE	100K0780
	02A42001	RADIATOR [A] [CA]	100K0780
	02A42002	RADIATOR [EXCEPT [A] [CA]]	100K0780
	02A430	RESERVE TANK	100K0780
ELECTRICAL SYSTEM	02A51001	STOP SOLENOID	100K0780
	01A521	DYNAMO	100K0780
	01A523	DYNAMO [COMPONENT PARTS]	100K0780
	02A525	STARTER	100K0780
	02A530	STARTER [COMPONENT PARTS]	100K0780
	02A535	BATTERY	100K0780
	02B10102	SWITCH	100K0780
	02B11501	PANEL BOARD	100K0780
	02B120	PANEL BOARD [COMPONENT PARTS]	100K0780
	02B301	HEAD RIGHT	100K0780
	02B302	HAZARD LIGHT	100K0780
	02B30401	TAIL LIGHT	100K0780
	02B310	WINKER LAMP	100K0780
	02B50102	ELECTRICAL WIRING	100K0780
	02B50103	ELECTRICAL WIRING [A] [CA]	100K0780
	02B50104	ELECTRICAL WIRING [AU] [NZ]	100K0780

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com




PREVIEW YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Item	Part No.	Description	Book
CLUTCH	01C101	CLUTCH	100K0780
	02C110	CLUTCH ROD	100K0780
	02C301	CLUTCH PEDAL	100K0780
	02C401	CLUTCH HOUSING	100K0780
	02C41502	CENTER FRAME	100K0780
TRANSMISSION	02C42002	TRANSMISSION CASE	100K0780
	02C425	DIFFERENTIAL GEAR CASE	100K0780
	02C427	REAR AXLE CASE	100K0780
	02D001	CLUTCH SHAFT	100K0780
	02D00502	PROPELLER SHAFT	100K0780
	02D010	HST	100K0780
	02D01501	HST [COMPONENT PARTS]	100K0780
	02D01502	HST [COMPONENT PARTS]	100K0780
	02D01503	HST [COMPONENT PARTS]	100K0780
	02D10302	FRONT SHAFT	100K0780
	02D13502	PTO SHAFT	100K0780
	02D13702	MID PTO	100K0780
	02D140	REAR DIFFERENTIAL	100K0780
	02D14302	FRONT WHEEL PROPELLER SHAFT	100K0780
	02D14902	2ND SHAFT	100K0780
	02D15202	3RD SHAFT	100K0780
	02D15502	4TH SHAFT	100K0780
SPEED CHANGE	02D21702	RANGE GEAR SHIFT FORK	100K0780
	02D22002	PTO GEAR SHIFT FORK	100K0780
	02D225	DIFFERENTIAL LOCK SHIFT FORK	100K0780
REAR AXLE	02D30101	REAR AXLE	100K0780
BRAKE	02E00102	BRAKE	100K0780
	02E00502	BRAKE ROD	100K0780
	02E01503	PARKING BRAKE LEVER [EXCEPT [AU] [NZ]]	100K0780
	02E01504	PARKING BRAKE LEVER [AU] [NZ]	100K0780
SPEED CHANGE	02F030	SPEED SET LEVER	100K0780
	02F107	NEUTRAL HOLDER LINK	100K0780
	02F108	SPEED CONTROL PEDAL	100K0780
	02F11001	RANGE GEAR SHIFT LEVER	100K0780
	02F113	FRONT WHEEL DRIVE LEVER	100K0780
	02F12501	PTO GEAR SHIFT LEVER	100K0780
PUMP/MOTOR SYSTEM	02F14301	HYDRAULIC CONTROL LEVER	100K0780
BRAKE	02F20101	BRAKE PEDAL	100K0780
REAR AXLE	02F20502	DIFFERENTIAL LOCK PEDAL	100K0780
FRONT AXLE	02G10102	FRONT AXLE FRAME	100K0780
	02G10501	FRONT AXLE CASE	100K0780
	02G11501	FRONT DIFFERENTIAL	100K0780
	02G120	DIFFERENTIAL GEAR SHAFT	100K0780
	02G123	BEVEL GEAR CASE	100K0780
	02G125	FRONT AXLE CASE	100K0780
	02G130	FRONT AXLE	100K0780
	02G13502	FRONT DRIVE SHAFT	100K0780
STEERING	02H00101	KNUCKLE ARM	100K0780
	02H003	DRAG LINK	100K0780
	02H00501	TIE ROD	100K0780
	02H101	STEERING HANDLE	100K0780
	02H105	STEERING POST	100K0780
	02J101	HYDRAULIC PUMP(PS)	100K0780
	02J105	HYDRAULIC PUMP(PS) [COMPONENT PARTS]	100K0780
PUMP/MOTOR SYSTEM	01J120	HYDRAULIC PUMP	100K0780
	01J125	HYDRAULIC PUMP [COMPONENT PARTS]	100K0780


PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	16271-95690	JOINT EYE	1				0.046	0.1012
020	16032-51010	ASSY PUMP INJECTION	1				1	2.2
030	16006-52092	SHIM INJECTION PUMP	1			0.20mm	0.004	0.0088
030	16006-52112	SHIM INJECTION PUMP	1			0.25mm	0.004	0.0088
030	16006-52122	SHIM INJECTION PUMP	1			0.30mm	0.006	0.0132
040	01311-10620	BOLT HEX-SOC-HD	2				0.012	0.0264
050	15841-91500	STUD	2				0.02	0.044
060	15841-92320	NUT	2				0.01	0.022
070	04512-60060	WASHER SPRING	4				0.001	0.0022
080	16271-51320	SCREW FOLLOW	1				0.031	0.0682
090	15841-96650	GASKET	2				0.001	0.0022
100	16030-96010	PLUG	1				0.008	0.0176
110	15861-96650	GASKET	1				0.001	0.0022

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	6C120-51220	BRACKET BATTERY	1				2.6	5.72
020	01135-51030	BOLT	2				0.03	0.066
030	6C090-51260	NET	1				0.26	0.572
040	76650-42520	TRIM DUSTPROOF	1				0.03	0.066
050	76611-56920	TRIM DUSTPROOF PLATE	2				0.025	0.055
060	99999-99999	ASSY BATTERY	1			55B24L	0	0
070	6C040-55590	LABEL BATTERY	1			ENGLISH	0.001	0.0022
080	34150-33220	CUSHION	2				0.015	0.033
090	6C090-55530	CORD BATTERY(+)	1				0.22	0.484
096	55311-41260	BAND CORD	1				0.007	0.0154
100	6C040-55540	CORD BATTERY(-)	1				0.11	0.242
105	53581-64150	BAND CORD	1				0.002	0.0044
110	6C090-55550	RETAINER BATTERY	1				0.005	0.011
120	6C040-55560	BOLT HOOK	1				0.038	0.0836
130	04015-60060	WASHER PLAIN	1				0.005	0.011
140	02810-50060	NUT WING	1				0.009	0.0198
150	6C040-55580	CUSHION	1				0.002	0.0044

PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	6C090-14310	SHAFT	1				0.35	0.77
020	08101-06204	BEARING BALL	1				0.102	0.2244
030	08101-06304	BEARING BALL	1				0.146	0.3212
040	6C090-14320	GEAR	1			17-13T	0.44	0.968
050	6C050-14520	COUPLING	1				0.099	0.2178

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	6C070-41320	POST STEERING	1				1.57	3.454
020	6C040-41510	BUSH	1				0.035	0.077
030	6C040-41390	COLLAR	2				0.007	0.0154
040	6C040-41523	COVER BEARING	2				0.007	0.0154
050	08121-06002	BEARING BALL	1				0.03	0.066
060	04611-00420	CIR CLIP INTERNAL	1				0.006	0.0132
070	6C070-41340	SHAFT STEERING	1				0.5	1.1
080	04612-00150	CIR CLIP EXTERNAL	1				0.001	0.0022
090	6C042-41330	JOINT UNIVERSAL	1				0.27	0.594
100	04612-00160	CIR CLIP EXTERNAL	1				0.001	0.0022
110	04013-60160	WASHER PLAIN	1				0.01	0.022
120	01123-50820	BOLT	4				0.011	0.0242


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	6C042-50110	ASSY WHEEL	1				27	59.4
020	6C042-50120	ASSY WHEEL LH	1				13.5	29.7
030	37500-57920	WHEEL	1				5.8	12.76
040	67521-57330	TIRE	1				7.4	16.28
050	93016-01120	TUBE	1				0.7	1.54
060	32150-27740	CORE VALVE	1				0.003	0.0066
070	38240-11690	CAP VALVE	1				0.001	0.0022
080	6C042-50130	ASSY WHEEL RH	1				13.5	29.7
090	37500-57920	WHEEL	1				5.8	12.76
100	67521-57330	TIRE	1				7.4	16.28
110	93016-01120	TUBE	1				0.7	1.54
120	32150-27740	CORE VALVE	1				0.003	0.0066
130	38240-11690	CAP VALVE	1				0.001	0.0022
140	04013-60120	WASHER PLAIN	12				0.01	0.022
150	04512-60120	WASHER SPRING	12				0.005	0.011
160	02176-50120	NUT	12				0.01	0.022

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 17 of 348 pages

The full manual includes:

- All 348 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Kubota B7510HSD Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual