Instructions for Parts Books

The heading at the top of the page will be the same for the picture of the parts at it is for the page with the part numbers.

Definition of column headings on part number pages:

REF.No → The number refering to the part on the picture page of the parts book.

Part No. → The number assigned to this part at the time of printing the parts book.

Description → Discription of part.

Q'ty → Quanity of part used on that page.

S.No. → Serial number range of the equipment that this part will fit.
>= Your serial number should be greater than or equal to the number shown.
<= Your serial number should be lesser than or equal to the serial number shown.

I/C → Interchangeability of part shown.
←→ The part shown will work for the older and later serial number.
The part shown is not interchangable with the other serial number.
← new for old
→ old for new

Remarks → Notes about this particulart part. Sometimes this may say except [FR] or [CA]

Note about Country Codes:


The parts books we use in the United States of America may also contain information about a part that would be different in another country. It is important that you are aware of the country codes in some instances.

Symbol	Country
A	United States of America
CA	Canada
FR	France
GR	Greece
PO	Portugal
AU	Australia

If the remarks column says for example EXCEPT [FR] this part works in all countries except France.
That means it will work here in the USA.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



LABELS

ACCESSORIES


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Item	Part No.	Description	Book
ENGINE	01T001	CRANKCASE	100K0092
	01T002	OIL PAN	100K0092
	01T003	CYLINDER HEAD	100K0092
	01T004	GEAR CASE	100K0092
	01T005	MAIN BEARING CASE	100K0092
	01T006	CYLINDER HEAD COVER	100K0092
	01T007	INLET MANIFOLD	100K0092
	01T008	VALVE/ROCKER ARM	100K0092
	01T009	CAMSHAFT	100K0092
	01T010	ENGINE STOP LEVER	100K0092
	01T011	GEAR PUMP	100K0092
	01T012	CRANKSHAFT/PISTON	100K0092
	01T013	FLYWHEEL	100K0092
	01T014	NOZZLE HOLDER	100K0092
	01T015	SPEED CONTROL PLATE	100K0092
	01T016	GOVERNOR	100K0092
	01T017	WATER FLANGE	100K0092
	01T018	FUEL CAMSHAFT	100K0092
	01T019	WATER PUMP	100K0092
	01T082	GEAR PUMP [SECTION PARTS]	100K0092
	01T083	NOZZLE HOLDER [SECTION PARTS]	100K0092
	01T084	INJECTION PUMP [SECTION PARTS]	100K0092
	01T085	STARTER [SECTION PARTS]	100K0092
	01T086	DYNAMO [A] [SECTION PARTS]	100K0092
TRANSMISSION	01T020	TRANSMISSION CASE AND DIFFERENTIAL CASE	100K0092
	01T021	MID P.T.O	100K0092
	01T022	COVER	100K0092
REAR AXLE/REAR WHEEL	01T023	AXLE CASE	100K0092
CLUTCH	01T024	CLUTCH	100K0092
TRANSMISSION	01T025	1ST SHAFT AND 2ND SHAFT	100K0092
	01T026	3RD SHAFT	100K0092
	01T027	4TH SHAFT	100K0092
	01T028	FRONT DRIVE SHAFT AND 6TH SHAFT	100K0092
	01T029	7TH SHAFT AND PTO SHAFT	100K0092
REAR AXLE/REAR WHEEL	01T030	REAR DIFFERENTIAL	100K0092
	01T031	REAR AXLE,AND REAR WHEEL (8.3-24) [B8200HST-EP] [A]	100K0092
	01T03101	REAR AXLE,AND REAR WHEEL (12.4-16)	100K0092
	01T03102	REAR WHEEL (13.6-16) [B8200HST-EPT, B8200HST-DPT]	100K0092
SPEED CHANGE LEVER	01T032	SPEED CHANGE FORK	100K0092
	01T033	FRONT DRIVE FORK	100K0092
	01T034	ROTARY SPEED CHANGE FORK	100K0092
BRAKE	01T035	BRAKE	100K0092
HYDRAULIC SYSTEM	01T036	HITCH	100K0092
	01T037	HYDROSTATIC TRANSMISSION	100K0092
	01T038	CASE COVER AND LIFT ARM	100K0092
	01T039	CONTROL VALVE	100K0092
	01T040	HYDRAULIC PIPING	100K0092
	01T041	HYDRAULIC BLOCK	100K0092
STEERING	01T042	STEERING	100K0092
SPEED CHANGE LEVER	01T043	SPEED CHANGE LEVER 1	100K0092
	01T044	SPEED CHANGE LEVER 2	100K0092
	01T045	SPEED CHANGE 1	100K0092
	01T046	SPEED CHANGE 2	100K0092
CLUTCH	01T047	CLUTCH PEDAL AND BRAKE PEDAL	100K0092
REAR AXLE/REAR WHEEL	01T048	DIFF.LOCK PEDAL	100K0092


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW ONLY - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW OF YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 12 of 189 pages

The full manual includes:

- All 189 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Kubota B8200HST-DP Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual