Instructions for Parts Books

The heading at the top of the page will be the same for the picture of the parts at it is for the page with the part numbers.

Definition of column headings on part number pages:

REF.No → The number refering to the part on the picture page of the parts book.

Part No. → The number assigned to this part at the time of printing the parts book.

Description → Discription of part.

Q'ty → Quanity of part used on that page.

S.No. → Serial number range of the equipment that this part will fit.
>= Your serial number should be greater than or equal to the number shown.
<= Your serial number should be lesser than or equal to the serial number shown.

I/C → Interchangeability of part shown.
←→ The part shown will work for the older and later serial number.
The part shown is not interchangable with the other serial number.
← new for old
→ old for new

Remarks → Notes about this particulart part. Sometimes this may say except [FR] or [CA]

Note about Country Codes:

The parts books we use in the United States of America may also contain information about a part that would be different in another country. It is important that you are aware of the country codes in some instances.

Symbol	Country
A	United States of America
CA	Canada
FR	France
GR	Greece
PO	Portugal
AU	Australia

If the remarks column says for example EXCEPT [FR] this part works in all countries except France.
That means it will work here in the USA.


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Item	Part No.	Description	Book
ENGINE	010001	CRANKCASE	100K0727
	010002	OIL PAN	100K0727
	010003	CYLINDER HEAD	100K0727
	010004	GEAR CASE	100K0727
	010005	HEAD COVER	100K0727
	010006	OIL FILTER	100K0727
	010007	DIPSTICK AND GUIDE	100K0727
	010008	OIL PUMP	100K0727
	010100	MAIN BEARING CASE	100K0727
	010101	CAMSHAFT AND IDLE GEAR SHAFT	100K0727
	010102	PISTON AND CRANKSHAFT	100K0727
	010103	FLYWHEEL	100K0727
	010105	FUEL CAMSHAFT AND GOVERNOR SHAFT	100K0727
	010200	IDLE APPARATUS	100K0727
	010202	INJECTION PUMP	100K0727
	010204	GOVERNOR	100K0727
	010205	SPEED CONTROL PLATE	100K0727
	010206	NOZZLE HOLDER AND GLOW PLUG	100K0727
	010305	COVER	100K0727
	010406	OIL SWITCH/THERMOMETER	100K0727
	010500	WATER FLANGE AND THERMOSTAT	100K0727
	010501	WATER PUMP	100K0727
	010600	VALVE AND ROCKER ARM	100K0727
	010601	INLET MANIFOLD	100K0727
	010602	EXHAUST MANIFOLD	100K0727
	010900	UPPER GASKET KIT [OPTION]	100K0727
	010901	LOWER GASKET KIT [OPTION]	100K0727
	010908	PISTON KIT [OPTION]	100K0727
COOLING WATER SYSTEM	01A401	FAN	100K0727
ELECTRICAL SYSTEM	01A521	DYNAMO	100K0727
	01A523	DYNAMO [COMPONENT PARTS]	100K0727
	01A525	STARTER	100K0727
	01A530	STARTER [COMPONENT PARTS]	100K0727
HYDRAULIC SYSTEM	01J120	HYDRAULIC PUMP	100K0727
	01J125	HYDRAULIC PUMP [COMPONENT PARTS]	100K0727
ENGINE	010603	AIR CLEANER	100K0727
	010605	MUFFLER	100K0727
	01A001	ACCELERATOR LEVER	100K0727
FUEL SYSTEM	01A101	FUEL TANK	100K0727
	01A110	FUEL PIPE	100K0727
COOLING WATER SYSTEM	01A410	WATER PIPE	100K0727
	01A420	RADIATOR	100K0727
ELECTRICAL SYSTEM	01A510	STOP SOLENOID	100K0727
	01A535	BATTERY	100K0727
	01B115	PANEL BOARD	100K0727
	01B215	SWITCH/SENSOR	100K0727
	01B301	HEAD RIGHT	100K0727
	01B303	HAZARD LIGHT/TAIL LIGHT	100K0727
	01B310	WINKER LAMP	100K0727

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


Kubota **CRANKCASE**

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	1G460-01010	COMP.CRANKCASE	1				18	39.6
020	16851-96260	CAP SEALING	3				0.005	0.011
030	16851-96270	CAP SEALING	2				0.005	0.011
040	06311-85025	CAP SEALING	1				0.01	0.022
050	15451-96270	CAP SEALING	2				0.012	0.0264
060	15261-96010	PLUG	4				0.002	0.0044
070	15521-96020	PLUG	3				0.003	0.0066
080	15521-96030	PLUG	1				0.007	0.0154
090	15261-96160	PLUG EXPANSION	1				0.02	0.044
100	05012-00508	PIN STRAIGHT	2				0.001	0.0022
110	05012-00814	PIN STRAIGHT	2				0.006	0.0132
120	15221-33650	PIN PIPE	1				0.004	0.0088
130	15231-33960	PIN PIPE	2				0.001	0.0022
140	17331-59190	PIN PIPE	2				0.02	0.044
150	16851-16212	COVER FUEL CAMSHAFT	1				0.03	0.066
160	15221-33700	O RING	1				0.001	0.0022
170	06311-55020	PLUG	1				0.031	0.0682
180	04714-00200	GASKET	1				0.002	0.0044


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW ONLY YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW YOUFIXTHIS.COM

Download full manual at youfixthis.com

Item	Part No.	Description	Book
ELECTRICAL SYSTEM	01B501	ELECTRICAL WIRING	100K0727
FRONT AXLE	01C413	FRONT FRAME	100K0727
	01C419	ENGINE SUPPORT	100K0727
TRANSMISSION	01C420	TRANSMISSION CASE	100K0727
REAR AXLE	01C427	REAR AXLE CASE	100K0727
TRANSMISSION	01D001	CLUTCH SHAFT/OUTPUT SHAFT	100K0727
	01D005	PROPELLER SHAFT	100K0727
	01D010	HST	100K0727
	01D015	HST [COMPONENT PARTS]	100K0727
	01D107	RANGE GEAR SHAFT	100K0727
	01D135	PTO SHAFT	100K0727
	01D137	MID PTO	100K0727
	01D140	REAR DIFFERENTIAL	100K0727
	01D141	FWD IDLE SHAFT	100K0727
	01D142	GP IDLE SHAFT	100K0727
	01D143	FRONT WHEEL PROPELLER SHAFT	100K0727
SPEED CHANGE LEVER	01D217	RANGE GEAR SHIFT FORK	100K0727
	01D220	PTO GEAR SHIFT FORK	100K0727
	01D222	PTO GEAR SHIFT ARM	100K0727
	01D225	DIFFERENTIAL LOCK SHIFT FORK	100K0727
REAR AXLE	01D301	REAR AXLE	100K0727
BRAKE	01E001	BRAKE	100K0727
SPEED CHANGE LEVER	01F107	NEUTRAL HOLDER LINK	100K0727
	01F108	SPEED CONTROL PEDAL	100K0727
	01F110	RANGE GEAR SHIFT LEVER	100K0727
	01F113	FRONT WHEEL DRIVE LEVER	100K0727
	01F122	PTO SELECT LEVER	100K0727
	01F125	PTO GEAR SHIFT LEVER	100K0727
	01F143	HYDRAULIC CONTROL LEVER	100K0727
BRAKE	01F201	BRAKE PEDAL	100K0727
REAR AXLE	01F205	DIFFERENTIAL LOCK PEDAL	100K0727
FRONT AXLE	01G105	FRONT AXLE CASE	100K0727
	01G115	FRONT DIFFERENTIAL	100K0727
	01G120	DIFFERENTIAL GEAR SHAFT	100K0727
	01G125	FRONT AXLE CASE	100K0727
	01G130	FRONT AXLE	100K0727
STEERING	01H101	STEERING HANDLE	100K0727
	01H110	STEERING CONTROLLER	100K0727
	01H120	STEERING LINKAGE	100K0727
	01H122	STEERING CYLINDER [COMPONENT PARTS]	100K0727
HYDRAULIC SYSTEM	01J201	HYDRAULIC OIL LINE(SUCTION)	100K0727
	01J210	HYDRAULIC OIL LINE(DELIVERY)	100K0727
	01J215	HYDRAULIC OIL LINE(STEERING)	100K0727
	01J301	HYDRAULIC CYLINDER	100K0727
	01J310	HYDRAULIC PISTON/LIFT ARM	100K0727
	01J405	CONTROL VALVE	100K0727
	01J410	CONTROL VALVE [COMPONENT PARTS]	100K0727

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	K2561-45510	PEDAL DIFF.LOCK	1				0	0
020	K2561-45540	COVER DIFF.LOCK PDL	1				0	0
030	K2561-45520	SPRING DIFF.LOCK PDL	1				0	0
040	K2561-45530	ROD DIFF.LOCK	1				0	0
050	K1211-91120	RUE RING COTTER	2				0.001	0.0022

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 12 of 250 pages

The full manual includes:

- All 250 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Kubota BX1500D Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual