
Item	Part No.	Description	Book
ENGINE	021001	CRANKCASE	100K0782
	021002	OIL PAN	100K0782
	021003	CYLINDER HEAD	100K0782
	021004	GEAR CASE	100K0782
	021005	HEAD COVER	100K0782
	021006	OIL FILTER	100K0782
	021007	DIPSTICK AND GUIDE	100K0782
	021008	OIL PUMP	100K0782
	021100	MAIN BEARING CASE	100K0782
	021101	CAMSHAFT AND IDLE GEAR SHAFT	100K0782
	021102	PISTON AND CRANKSHAFT	100K0782
	021103	FLYWHEEL	100K0782
	021105	FUEL CAMSHAFT AND GOVERNOR SHAFT	100K0782
	021200	IDLE APPARATUS	100K0782
	021201	STOP SOLENOID	100K0782
	021202	INJECTION PUMP	100K0782
	021204	GOVERNOR	100K0782
	021205	SPEED CONTROL PLATE	100K0782
	021206	NOZZLE HOLDER AND GLOW PLUG	100K0782
	021207	NOZZLE HOLDER [COMPONENT PARTS]	100K0782
	021305	COVER	100K0782
	021400	DYNAMO AND PULLEY	100K0782
	021401	DYNAMO [COMPONENT PARTS]	100K0782
	021404	STARTER	100K0782
	021405	STARTER [COMPONENT PARTS]	100K0782
	021406	OIL SWITCH/THERMOMETER AND PLUG	100K0782
	021500	WATER FLANGE AND THERMOSTAT	100K0782
	021501	WATER PUMP	100K0782
	021504	FAN	100K0782
	021600	VALVE AND ROCKER ARM	100K0782
	021601	INLET MANIFOLD	100K0782
	021602	EXHAUST MANIFOLD	100K0782
	021700	HYDRAULIC PUMP	100K0782
	021701	HYDRAULIC PUMP [COMPONENT PARTS]	100K0782
	021900	UPPER GASKET KIT [OPTION]	100K0782
	021901	LOWER GASKET KIT [OPTION]	100K0782
	021908	PISTON KIT [OPTION]	100K0782
	031603	AIR CLEANER	100K0782
	031605	MUFFLER	100K0782
	03A00102	ACCELERATOR LEVER	100K0782
FUEL SYSTEM	03A101	FUEL TANK	100K0782
	03A11002	FUEL PIPE	100K0782
COOLING WATER SYSTEM	03A41002	WATER PIPE	100K0782
	03A42002	RADIATOR	100K0782
ELECTRICAL SYSTEM	03A53502	BATTERY	100K0782
	03B115	PANEL BOARD	100K0782

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


Kubota **CRANKCASE**

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	1G470-01013	COMP.CRANKCASE	1				0	0
020	16851-96260	CAP SEALING	3				0.005	0.011
030	16851-96270	CAP SEALING	3				0.005	0.011
040	06311-85025	CAP SEALING	2				0.01	0.022
050	15451-96270	CAP SEALING	2				0.012	0.0264
060	15261-96010	PLUG	5				0.002	0.0044
070	15521-96020	PLUG	3				0.003	0.0066
080	15521-96030	PLUG	1				0.007	0.0154
090	15261-96160	PLUG EXPANSION	1				0.02	0.044
100	05012-00508	PIN STRAIGHT	2				0.001	0.0022
110	05012-00814	PIN STRAIGHT	2				0.006	0.0132
120	15221-33650	PIN PIPE	1				0.004	0.0088
130	15231-33960	PIN PIPE	2				0.001	0.0022
140	17331-59190	PIN PIPE	2				0.02	0.044
150	16851-16212	COVER FUEL CAMSHAFT	1				0.03	0.066
160	15221-33700	O RING	1				0.001	0.0022
170	06311-55020	PLUG	1				0.031	0.0682
180	04724-00130	GASKET	1				0.003	0.0066


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Item	Part No.	Description	Book
ELECTRICAL SYSTEM	03B215	SWITCH/SENSOR	100K0782
	03B301	HEAD RIGHT	100K0782
	03B303	HAZARD LIGHT/TAIL LIGHT	100K0782
	03B310	WINKER LAMP	100K0782
	03B501	ELECTRICAL WIRING	100K0782
TRANSMISSION	03C420	TRANSMISSION CASE	100K0782
	03C427	REAR AXLE CASE	100K0782
	03D001	CLUTCH SHAFT/OUTPUT SHAFT	100K0782
	03D005	PROPELLER SHAFT	100K0782
	03D010	HST	100K0782
	03D015	HST [COMPONENT PARTS]	100K0782
	03D107	RANGE GEAR SHAFT	100K0782
	03D135	PTO SHAFT	100K0782
	03D137	MID PTO	100K0782
	03D140	REAR DIFFERENTIAL	100K0782
	03D141	FWD IDLE SHAFT	100K0782
	03D142	GP IDLE SHAFT	100K0782
	03D143	FRONT WHEEL PROPELLER SHAFT	100K0782
SPEED CHANGE LEVER	03D217	RANGE GEAR SHIFT FORK	100K0782
	03D220	PTO GEAR SHIFT FORK	100K0782
	03D222	PTO GEAR SHIFT ARM	100K0782
	03D225	DIFFERENTIAL LOCK SHIFT FORK	100K0782
REAR AXLE	03D301	REAR AXLE	100K0782
BRAKE	03E001	BRAKE	100K0782
SPEED CHANGE LEVER	03F104	CRUISE CONTROL LEVER	100K0782
	03F107	NEUTRAL HOLDER LINK	100K0782
	03F108	SPEED CONTROL PEDAL	100K0782
	03F110	RANGE GEAR SHIFT LEVER	100K0782
	03F113	FRONT WHEEL DRIVE LEVER	100K0782
	03F122	PTO SELECT LEVER	100K0782
	03F125	PTO GEAR SHIFT LEVER	100K0782
PUMP	03F143	HYDRAULIC CONTROL LEVER	100K0782
BRAKE	03F201	BRAKE PEDAL	100K0782
REAR AXLE	03F205	DIFFERENTIAL LOCK PEDAL	100K0782
FRONT AXLE	03G10102	FRONT AXLE FRAME	100K0782
	03G110	FRONT DIFFERENTIAL CASE	100K0782
	03G115	FRONT DIFFERENTIAL	100K0782
	03G120	DIFFERENTIAL GEAR SHAFT	100K0782
	03G125	FRONT AXLE CASE	100K0782
	03G130	FRONT AXLE	100K0782
STEERING	03H101	STEERING HANDLE	100K0782
	03H110	STEERING CONTROLLER	100K0782
	03H120	STEERING LINKAGE	100K0782
	03H122	STEERING CYLINDER [COMPONENT PARTS]	100K0782
PUMP	03J201	HYDRAULIC OIL LINE(SUCTION)	100K0782
	03J210	HYDRAULIC OIL LINE(DELIVERY)	100K0782
	03J215	HYDRAULIC OIL LINE(STEERING)	100K0782
	03J301	HYDRAULIC CYLINDER	100K0782

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	K2561-15712	SHAFT GEAR	1			11T	0.5	1.1
020	08711-30205	BEARING TAPER-ROLLER	2				0.148	0.3256
030	6C040-56620	COLLAR	2			4.5mm	0.01	0.022
030	37410-58120	COLLAR	2			4.0mm	0.01	0.022
030	37410-58130	COLLAR	2			4.1mm	0.01	0.022
030	37410-58140	COLLAR	2			4.2mm	0.01	0.022
030	6C040-56630	COLLAR	2			3.9mm	0.009	0.0198
030	37410-58150	COLLAR	2			3.8mm	0.01	0.022
030	37410-58160	COLLAR	2			3.4mm	0.01	0.022
030	37410-56660	COLLAR	2			4.6mm	0.011	0.0242
030	37410-58170	COLLAR	2			3.6mm	0.01	0.022
030	37410-56680	COLLAR	2			4.4mm	0.015	0.033
040	37410-56690	COLLAR	1				0.04	0.088
050	37410-56710	NUT	1				0.03	0.066
060	04611-00520	CIR CLIP INTERNAL	1				0.009	0.0198
070	59700-45520	SEAL OIL	1				0.023	0.0506
080	K2561-15910	GEAR BEVEL	1			20T	0.37	0.814
090	K2561-16010	ASSY DIFF. FRONT	1				1.29	2.838
100	K2561-16020	CASE DIFF.FRONT	1				0.94	2.068
110	K2561-16120	SHAFT DIFF.PINION	1				0.045	0.099
120	05411-00440	PIN SPRING	1				0.002	0.0044
130	K2561-16130	GEAR BEVEL	2			10T	0.05	0.11
140	K2561-16050	SHIM	2			3.5mm	0.006	0.0132
140	K2561-16060	SHIM	2			3.3mm	0.005	0.011
140	K2561-16070	SHIM	2			3.7mm	0.006	0.0132
140	K2561-16080	SHIM	2			3.9mm	0.006	0.0132
150	K2561-16140	GEAR BEVEL	2			14T	0.11	0.242
160	37410-56930	SHIM	2			1.0mm	0.005	0.011
160	37410-56920	SHIM	2			0.8mm	0.005	0.011
160	37410-56940	SHIM	2			1.2mm	0.01	0.022
170	08101-06010	BEARING BALL	2				0.262	0.5764
180	66611-15150	SHIM DIFF.SIDE	1				0.002	0.0044

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 12 of 261 pages

The full manual includes:

- All 261 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Kubota BX2230D Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual