Instructions for Parts Books

The heading at the top of the page will be the same for the picture of the parts at it is for the page with the part numbers.

Definition of column headings on part number pages:

REF.No → The number refering to the part on the picture page of the parts book.

Part No. → The number assigned to this part at the time of printing the parts book.

Description → Discription of part.

Q'ty → Quanity of part used on that page.

S.No. → Serial number range of the equipment that this part will fit.
>= Your serial number should be greater than or equal to the number shown.
<= Your serial number should be lesser than or equal to the serial number shown.

I/C → Interchangeability of part shown.
←→ The part shown will work for the older and later serial number.
The part shown is not interchangable with the other serial number.
← new for old
→ old for new

Remarks → Notes about this particulart part. Sometimes this may say except [FR] or [CA]

Note about Country Codes:

The parts books we use in the United States of America may also contain information about a part that would be different in another country. It is important that you are aware of the country codes in some instances.


Symbol	Country
A	United States of America
CA	Canada
FR	France
GR	Greece
PO	Portugal
AU	Australia

If the remarks column says for example EXCEPT [FR] this part works in all countries except France.
That means it will work here in the USA.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

FREQUENTLY USED ITEMS



TOP LINK/TOP LINK BRACKET/PTO PROTECTOR

LABELS

ACCESSORIES AND SERVICE PARTS

OPTION

PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	1G470-01017	COMP.CRANKCASE	1				23	50.6
020	16851-96260	CAP SEALING	3				0.005	0.011
030	16851-96270	CAP SEALING	3				0.005	0.011
040	06311-85025	CAP SEALING	2				0.01	0.022
050	15451-96270	CAP SEALING	2				0.001	0.0022
060	15261-96010	PLUG	5				0.002	0.0044
070	15521-96020	PLUG	3				0.003	0.0066
080	15521-96030	PLUG	1				0.007	0.0154
090	15261-96160	PLUG EXPANSION	1				0.02	0.044
100	05012-00508	PIN STRAIGHT	2				0.001	0.0022
110	05012-00814	PIN STRAIGHT	2				0.006	0.0132
120	15221-33650	PIN PIPE	1				0.004	0.0088
130	15231-33960	PIN PIPE	2				0.001	0.0022
140	17331-59190	PIN PIPE	2				0.02	0.044
150	16851-16212	COVER FUEL CAMSHAFT	1				0.03	0.066
160	99999-99999	BLANK	0				0	0
170	06311-55020	PLUG	1				0.031	0.0682
180	04724-00130	GASKET	1				0.003	0.0066


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW FROM YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW ONLY
YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW YOUFIXTHIS.COM

Download full manual at youfixthis.com

Item	Part No.	Description	Book
ELECTRICAL SYSTEM	03B303	HAZARD LIGHT/TAIL LIGHT	100K0929
	03B50103	ELECTRICAL WIRING	100K0929
FRONT AXLE	03C41302	FRONT FRAME	100K0929
	03C41702	SUB FRAME	100K0929
	03C41902	ENGINE SUPPORT	100K0929
TRANSMISSION	03C420	TRANSMISSION CASE	100K0929
	03C427	REAR AXLE CASE	100K0929
	03D001	CLUTCH SHAFT/OUTPUT SHAFT	100K0929
	03D005	PROPELLER SHAFT	100K0929
	03D011	HST 1	100K0929
	03D012	HST 2	100K0929
	03D013	HST 3	100K0929
	03D014	HST 4	100K0929
	03D108	RANGE GEAR SHAFT	100K0929
	03D135	PTO SHAFT	100K0929
	03D137	MID PTO	100K0929
	03D140	REAR DIFFERENTIAL	100K0929
	03D141	FWD IDLE SHAFT	100K0929
	03D142	GP IDLE SHAFT	100K0929
	03D14302	FRONT WHEEL PROPELLER SHAFT	100K0929
SPEED CHANGE	03D217	RANGE GEAR SHIFT FORK	100K0929
	03D220	PTO GEAR SHIFT FORK	100K0929
	03D222	PTO GEAR SHIFT ARM	100K0929
	03D225	DIFFERENTIAL LOCK SHIFT FORK	100K0929
REAR AXLE	03D301	REAR AXLE	100K0929
BRAKE	03E001	BRAKE	100K0929
SPEED CHANGE	03F104	CRUISE CONTROL LEVER	100K0929
	03F10802	SPEED CONTROL PEDAL	100K0929
	03F110	RANGE GEAR SHIFT LEVER	100K0929
	03F113	FRONT WHEEL DRIVE LEVER	100K0929
	03F122	PTO SELECT LEVER	100K0929
	03F125	PTO GEAR SHIFT LEVER	100K0929
PUMP/MOTOR SYSTEM	03F143	HYDRAULIC CONTROL LEVER	100K0929
BRAKE	03F201	BRAKE PEDAL	100K0929
REAR AXLE	03F205	DIFFERENTIAL LOCK PEDAL	100K0929
FRONT AXLE	03G11002	FRONT DIFFERENTIAL CASE	100K0929
	03G11502	FRONT DIFFERENTIAL	100K0929
	03G12002	DIFFERENTIAL GEAR SHAFT	100K0929
	03G12502	FRONT AXLE CASE	100K0929
	03G13002	FRONT AXLE	100K0929
STEERING	03H101	STEERING HANDLE	100K0929
	03H110	STEERING CONTROLLER	100K0929
	03H12002	STEERING LINKAGE	100K0929
	03H122	STEERING CYLINDER [COMPONENT PARTS]	100K0929
PUMP/MOTOR SYSTEM	03J120	HYDRAULIC PUMP	100K0929
	03J125	HYDRAULIC PUMP [COMPONENT PARTS]	100K0929
	03J21002	HYDRAULIC OIL LINE(DELIVERY)	100K0929

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	K2581-13010	ROD FORK	1				0.125	0.275
020	K2581-13020	FORK RANGE SHIFT	1				0.14	0.308
030	62061-18260	SPRING STOPPER	1				0.002	0.0044
040	07715-01605	BALL	1				0.003	0.0066
050	K2581-13030	ARM RANGE SHIFT	1				0.18	0.396
060	04817-00160	O RING	2				0.001	0.0022
070	K2581-42980	ARM LEVER	1				0.12	0.264
080	05411-00836	PIN SPRING	1				0.008	0.0176

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 12 of 281 pages

The full manual includes:

- All 281 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Kubota BX24D Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual