




見出 REF NO.	部品番号 PARTS NO.	部品名	Description	クランクケース CRANKCASE		備考
				数量 Q'ty	互換性 I	
10	1E051-0101-5 (A=E/--5K1589)	クランクケース, ユニ	COMP. CRANKCASE	1		
10	1E051-0101-6 (A=E/5L0179--)	クランクケース, ユニ	COMP. CRANKCASE	1	N	
20	16851-9626-0	ワシカタ プラ	CAP, SEALING	3		
30	16851-9627-0	ワシカタ プラ	CAP, SEALING	5		
40	15451-9627-0	ワシカタ プラ	CAP, SEALING	2		
50	15261-9601-0	プラグ (M87-ハ)	PLUG	5		
60	15521-9602-0	プラグ (R1/8)	PLUG	3		
70	15521-9603-0	プラグ (R1/4)	PLUG	1		
80	15261-9616-0	ヘルチプラグ	PLUG, EXPANSION	1		
90	05012-00508	ペイコ ピン	PIN, STRAIGHT	2		
100	05012-00814	ペイコ ピン	PIN, STRAIGHT	2		
110	15221-3365-0	パイプ ピン	PIN, PIPE	1		
120	15231-3396-0	パイプ ピン	PIN, PIPE	2		
130	17331-5919-0	パイプ ピン	PIN, PIPE	2		
140	16851-1621-2	カバー (フューエルカムシャフト)	COVER, FUEL CAMSHAFT	1		
150	15221-3370-0 (A=E/--5F3683)	O リング	O RING	1		
160	15847-7313-0 (A=E/--5D3552)	ドレーンパイプ ツキテ	JOINT, DRAIN PIPE	1		
160	06312-10020 (A=E/5E0001--)	プラグ	PLUG	1	S	






1G386-029-10








1G386-045-10

NUMERICAL INDEX



Part number	Page	Item	Part number	Page	Item	Part number	Page	Item	Part number	Page	Item	Part number	Page	Item
01023-50610	35	110	02114-50800	26	030	05712-00515	11	130	14601-1312-0	35	020	15501-7247-0	34	090
01023-50612	2	020	02156-50080	24	070		13	050	14601-1324-0	35	030	15511-6376-0	27	140
	10	080	02751-50060	4	250	05712-00518	10	060	14601-1333-0	35	040	15511-9666-0	27	200
	13	140		32	040	06311-55010	32	100	14601-1336-0	35	050	15521-4313-0	21	070
	38	090	02751-50080	38	100	06312-10020	1	160	14601-1424-0	35	210	15521-4315-0	21	080
01023-50614	10	140	02756-50060	37	050	06331-35010	42	080	14601-1431-0	35	180	15521-4352-2	21	020
01023-50616	24	100	02761-50040	18	170	06331-45016	2	030	14971-4275-0	42	110	15521-4354-2	21	040
	29	060	02783-50100	8	060	07012-11012	42	030	15021-3366-0	14	050	15521-4355-2	21	050
01023-50618	4	130	03024-50510	5	130	07012-11214	42	040	15126-1109-0	38	050	15521-4367-2	21	030
	4	320	03024-50520	18	140	07012-11317	42	050	15221-0175-0	3	010	15521-9602-0	1	060
	17	030	03054-50308	21	140	07013-01922	42	020	15221-1172-0	39	030	15521-9603-0	1	070
	23	030	04013-60080	12	070	07115-56143	42	060		39	050	15531-3901-0	28	010
	36	040		24	060	07715-00401	10	040	15221-3365-0	1	110	15531-7241-0	34	015
01023-50620	9	070	04512-60050	20	100	07715-00801	13	080	15221-3370-0	1	150	15531-7242-2	34	040
01023-50622	9	080	04512-60060	16	080	07715-03207	11	100	15221-8821-0	4	240	15531-7243-2	34	050
	30	080	04512-60080	24	080	07715-03211	4	110	15231-3396-0	1	120	15533-2516-2	12	020
01023-50635	20	120		26	040	07715-03217	13	100	15231-4328-3	21	150	15601-9665-0	14	090
01023-50638	30	090	04612-00170	13	120	08153-06203	13	030	15241-3229-0	4	080		17	050
01023-50645	36	050	04717-01000	42	090	09318-88125	5	090	15261-0337-0	3	070		18	040
01023-50660	4	160	04724-00100	32	110	09318-89033	32	080	15261-1172-0	39	040	15694-2393-0	11	160
01023-50680	4	180	04724-00160	2	040	09318-89039	32	090	15261-2133-0	11	040	15694-2394-0	11	160
01023-60650	4	140	04811-10290	21	060	09661-40320	42	100		44	040	15694-6599-0	41	040
	4	310	04811-50650	21	090	11173-6313-0	27	220	15261-2353-0	11	170	15831-4325-0	21	120
	29	070	04814-00150	4	070	11420-1315-0	35	070	15261-2354-0	11	180	15841-0454-0	9	020
01023-60670	4	170	04814-00160	2	060	11460-6307-0	27	030	15261-2395-0	11	170		9	100
01053-50618	17	040	04814-06130	4	200	11460-6308-0	27	020	15261-2396-0	11	170		9	120
01123-50822	12	040	04814-10070	17	140	11460-6311-0	27	070	15261-2397-0	11	180	15841-0456-2	9	130
01123-50825	26	020	04814-10160	17	080	11460-6312-0	27	190	15261-2398-0	11	180	15841-0480-0	9	140
	29	130	04814-16220	11	210	11460-6327-0	27	080	15261-5547-0	13	090	15841-0480-3	9	140
01123-60814	2	070	04814-50300	4	280	11460-6332-0	27	180	15261-6641-0	20	090	15841-0481-5	9	040
	12	060		5	070	11460-6339-0	27	120	15261-9202-0	14	030	15841-0482-2	9	060
01123-60816	3	020	04814-50600	4	060	11460-6350-0	27	050	15261-9601-0	1	050	15841-1354-0	3	090
01153-50885	24	050	04816-00160	21	130	11460-6353-0	27	040		3	080	15841-1356-0	3	100
01311-10620	16	050	04817-00060	21	160	11460-9331-0	27	160	15261-9616-0	1	080	15841-1403-0	35	190
01513-50618	37	040	05012-00508	1	090	11470-6338-0	27	110	15263-1237-0	37	070	15841-1423-0	35	200
01513-50822	37	060	05012-00814	1	100	11982-7246-0	34	010	15321-7301-4	29	100	15841-1627-0	10	070
01754-50612	15	020	05411-00314	17	130	13963-9201-0	27	210	15321-9626-0	3	060	15841-1632-0	13	130
01754-50620	33	040	05411-00318	20	080	14182-9203-0	25	270	15377-8601-0	42	010	15841-2325-0	11	190
01754-50640	35	130	05411-00420	35	170	14601-0345-0	3	110	15451-9627-0	1	040	15841-2411-0	11	120
01759-50616	37	030	05712-00408	8	050	14601-1311-0	35	010	15481-7305-0	30	040	15841-3566-0	8	040

Engine for TB014 KUBOTA D782-E2B-BHTU-1
CRANKCASE



1G386-049-10

旧 部品



1G386-804-10

PREVIEW ONLY

You're viewing 8 of 94 pages

The full manual includes:

- All 94 pages, complete
 - Searchable PDF (find any keyword)
 - No watermarks
 - Instant download
 - Print-ready quality
-

GET FULL MANUAL NOW

Kubota D782-E2B-BHTU-1 Parts Catalog



Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual