Instructions for Parts Books

The heading at the top of the page will be the same for the picture of the parts at it is for the page with the part numbers.

Definition of column headings on part number pages:

REF.No → The number refering to the part on the picture page of the parts book.

Part No. → The number assigned to this part at the time of printing the parts book.

Description → Discription of part.

Q'ty → Quanity of part used on that page.

S.No. → Serial number range of the equipment that this part will fit.
>= Your serial number should be greater than or equal to the number shown.
<= Your serial number should be lesser than or equal to the serial number shown.

I/C → Interchangeability of part shown.
←→ The part shown will work for the older and later serial number.
The part shown is not interchangable with the other serial number.
← new for old
→ old for new

Remarks → Notes about this particulart part. Sometimes this may say except [FR] or [CA]

Note about Country Codes:

The parts books we use in the United States of America may also contain information about a part that would be different in another country. It is important that you are aware of the country codes in some instances.

Symbol	Country
A	United States of America
CA	Canada
FR	France
GR	Greece
PO	Portugal
AU	Australia

If the remarks column says for example EXCEPT [FR] this part works in all countries except France.
That means it will work here in the USA.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Item	Part No.	Description	Book
ENGINE	01E01	CRANKCASE	100K0077
	01E02	OIL PAN	100K0077
	01E03	CYLINDER HEAD	100K0077
	01E04	GEAR CASE	100K0077
	01E05	MAIN BEARING CASE	100K0077
	01E06	CYLINDER HEAD COVER	100K0077
	01E07	MANIFOLD	100K0077
	01E08	VALVE/ROCKER ARM	100K0077
	01E09	CAMSHAFT	100K0077
	01E10	PISTON/CRANKSHAFT	100K0077
	01E11	FLYWHEEL	100K0077
	01E12	NOZZLE HOLDER	100K0077
	01E13	INJECTION PUMP	100K0077
	01E14	IDLING APPARATUS	100K0077
	01E15	GOVERNOR	100K0077
	01E16	SPEED CONTROL PLATE	100K0077
	01E17	DYNAMO	100K0077
	01E18	WATER FLANGE	100K0077
	01E19	WATER PUMP	100K0077
	01E39	NOZZLE HOLDER (SECTION PARTS)	100K0077
	01E40	INJECTION PUMP (SECTION PARTS)	100K0077
	01E41	DYNAMO (SECTION PARTS)	100K0077
HYDRAULIC SYSTEM	01I09	HYDRAULIC OUTLET (OPTION)	100K0077
	01I10	AUX CONTROL VALVE (OPTION)	100K0077
	01I11	3-POINT LINKAGE (OPTION)	100K0077
MOWER LINK/DRIVE BELT	01I12	REAR PTO (OPTION)	100K0077
HYDRAULIC SYSTEM	01I13	HYDRAULIC LIFT (OPTION)	100K0077
TRANSMISSION	01T01	TRANSMISSION CASE	100K0077
	01T02	PROPELLER SHAFT	100K0077
	01T03	4TH SHAFT	100K0077
	01T04	5TH SHAFT	100K0077
	01T05	DIFFERENTIAL	100K0077
REAR AXLE/REAR WHEEL	01T06	REAR AXLE	100K0077
BRAKE	01T0701	BRAKE	100K0077
	01T0702	BRAKE	100K0077
TRANSMISSION	01T08	PTO SHAFT	100K0077
	01T09	TENSION PULLEY	100K0077
	01T10	PTO LEVER	100K0077
	01T11	H.S.T.	100K0077
HYDRAULIC SYSTEM	01T12	HYDRAULIC PIPE	100K0077
STEERING	01T15	STEERING	100K0077
BRAKE	01T16	BRAKE PEDAL	100K0077
SPEED CHANGE	01T17	ACCEL.LEVER	100K0077
	01T18	SPEED CHANGE LEVER	100K0077
	01T19	ENGINE STOP WIRE	100K0077
MOWER LINK/DRIVE BELT	01T2001	LIFT LEVER	100K0077
	01T21	LIFT LINK	100K0077
BONNET/HOOD/CHASSIS	01T2201	SEAT	100K0077
	01T2202	SEAT	100K0077
LABELS	01T23	LABEL	100K0077
BONNET/HOOD/CHASSIS	01T24	FRAME	100K0077
	01T25	FENDER	100K0077
COOLING WATER SYSTEM	01T26	RADIATOR	100K0077
FUEL SYSTEM	01T27	FUEL TANK	100K0077
BONNET/HOOD/CHASSIS	01T28	PANEL COVER	100K0077
	01T29	RADIATOR NET	100K0077

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


CRANKCASE

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	15852-01010	CRANKCASE	1	<=9789			0	0
010	15852-01013	COMP.CRANKCASE	1	>=9790	←		0	0
010	15852-01016	COMP.CRANKCASE	1	>=109828	←		16.3	35.86
020	15451-96300	CAP SEALING	3	<=124705			0.002	0.0044
020	06311-85014	CAP SEALING	3	>=124706	≠		0.003	0.0066
020	16851-96260	CAP SEALING	3	>=132501	↔		0.005	0.011
030	15451-96260	CAP SEALING	3	<=124705			0.007	0.0154
030	06311-85020	CAP SEALING	3	>=124706	≠		0.002	0.0044
030	16851-96270	CAP SEALING	3	>=132501	↔		0.005	0.011
040	15451-96270	CAP SEALING	2				0.012	0.0264
050	15261-96010	PLUG	4				0.002	0.0044
060	15521-96020	PLUG	3				0.003	0.0066
070	15521-96030	PLUG	1				0.007	0.0154
080	06311-75040	PLUG	1	<=70639			0.02	0.044
080	15261-96160	PLUG	1	>=70640	←		0.02	0.044
090	05012-00508	PIN STRAIGHT	2				0.001	0.0022
100	05012-00814	PIN STRAIGHT	2				0.006	0.0132
110	15221-33650	PIN PIPE	1				0.004	0.0088
120	15231-33960	PIN PIPE	2				0.001	0.0022
130	15841-96010	PLUG	1	<=112012			0.015	0.033
140	15221-33700	O RING	1				0.001	0.0022
150	15841-73020	ASSY COCK DRAIN	1				0.03	0.066
160	15841-35010	ASSY PUMP OIL	1	<=121837			0	0
160	16851-35010	ASSY PUMP OIL	1	>=121838	←		0.24	0.528
170	15841-35150	GASKET OIL PUMP	1	<=121837			0	0
170	16851-35150	GASKET OIL PUMP	1	>=121838	≠		0	0
180	15841-91050	BOLT	3				0.01	0.022
190	15841-35660	GEAR OIL PUMP DRIVE	1				0.113	0.2486
200	05712-00408	KEY FEATHER	1				0.001	0.0022
210	02016-50100	NUT	1	<=150379			0.009	0.0198
210	02783-50100	NUT FLANGE	1	>=150380	↔		0.01	0.022
220	04211-50100	WASHER CLAW	1	<=155086			0.002	0.0044
230	15841-39010	SWITCH OIL	1				0.03	0.066
240	17331-59190	PIN PIPE	2				0.02	0.044


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW ONLY YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com



REF.No.010 65021-5111-5




REF.No.120 37150-3446-0




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com

Item	Part No.	Description	Book
BONNET/HOOD/CHASSIS	01T30	HOOD	100K0077
ELECTRICAL SYSTEM	01T31	ELECTRICAL SYSTEM	100K0077
	01T32	BATTERY	100K0077
FRONT AXLE/FRONT WHEEL	01T33	FRONT AXLE	100K0077
ENGINE	01T34	MUFFLER	100K0077
	01T35	AIR CLEANER	100K0077
FUEL SYSTEM	01T36	FUEL PUMP	100K0077
	01T37	FUEL FILTER	100K0077
	01T38	FUEL PIPE	100K0077
ELECTRICAL SYSTEM	01T39	STARTER	100K0077
FUEL SYSTEM	01T42	FUEL FILTER (SECTION PARTS)	100K0077
ELECTRICAL SYSTEM	01T43	STARTER (SECTION PARTS)	100K0077
BONNET/HOOD/CHASSIS	01T45	SEAT SUSPENTION KIT (OPTION)	100K0077
ELECTRICAL SYSTEM	01T46	COMBI.METER KIT (OPTION)	100K0077
ENGINE	01T47	EXHUST PIPE KIT (OPTION)	100K0077
ACCESSORIES	01T48	ACCESSORIES AND SERVICE PARTS	100K0077

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

S. No.;
- G4200H; 31478~····EXCEPT CANADA
- G4200H; 30310~····ONLY CANADA
- G5200H; 32925~····EXCEPT CANADA
- G5200H; 30253~····ONLY CANADA
- G6200H; 30001~



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 12 of 150 pages

The full manual includes:

- All 150 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Kubota G4200H Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual