Kubota

MINI EXCAVATOR

MODELES

KX101

s/n 55001-Up

SPARE PARTS CATALOG

07/2006

CE

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


KX101 S/N 55001-Up

Table of contents

Description	Index
CRANKCASE	0001
OIL PAN	0002
PISTON CRANKSHAFT	0003
MAIN BEARING CASE	0004
CAMSHAFT	0005
CYLINDER HEAD	0006
VALVE ROCKER ARM	0007
CYLINDER HEAD COVER	0008
GEAR CASE	0009
ENGINE STOP LEVER	0010
NOZZLE HOLDER GLOW PLUG	0011
NOZZLE HOLDER COMPONENT PARTS	0012
SPEED CONTROL PLATE	0013
GOVERNOR	0014
INJECTION PUMP CAMSHAFT 1	0015
INJECTION PUMP COMPONENT PARTS	0016
INJECTION PUMP CAMSHAFT 2	0017
WATER FLANGE	0018
WATER PUMP	0019
FLYWHEEL STARTER	0020
STARTER COMPONENT PARTS	0021
STARTER COMPONENT PARTS	0022
DYNAMO	0023
DYNAMO COMPONENT PARTS	0024
ENGINE BRACKET	0025
AIR CLEANER INLET MANIFOLD	0026
MUFFLER EXHAUST MANIFOLD	0027
ACCEL LEVER	0028
FUEL PIPING	0029
FUEL TANK	0030
RADIATOR	0031
WATER PIPE	0032
BATTERY	0033
REGULATOR HORN	0034
SWITCH METER	0035
ELECTRICAL WIRING	0036
PUMP HOUSING	0037
GEAR PUMP COMPONENT PARTS	0038
HYDRAULIC PUMP COMPONENT PART	0039
DRIVE MOTOR COMPONENT PARTS 1	0040
DRIVE MOTOR COMPONENT PARTS 2	0041
SWIVEL MOTOR COMPONENT PARTS	0042
ROTARY JOINT	0043
OIL TANK	0044
CONTROL VALVE 1	0045
CONTROL VALVE 1 COMPONENT PA	0046
SPOOL SECTION TRAVEL RH	0047
SPOOL SECTION BOOM	0048
SPOOL SECTION BUCKET	0049
SPOOL SECTION	0050
SPOOL SECTION TRAVEL SPEED 2ND	0051
SPOOL SECTION TRAVEL LH	0052
SPOOL SECTION BOOM	0053
SPOOL SECTION ARM	0054
SPOOL SECTION S P	0055
SPACER SECTION	0056
CONTROL VALVE 3	0057
CONTROL VALVE 3 COMPONENT PA	0058
SPOOL SECTION SWIVEL	0059


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	68658-81100	KIT TOOLS	1				1.18	2.596
020	32360-19300	SCREW DRIVER	1				0.07	0.154
030	07211-10150	PLIERS	1				0.16	0.352
040	07012-11012	SPANNER	1				0.041	0.0902
050	07012-11417	SPANNER	1				0.084	0.1848
060	68651-81110	SPANNER	1	55315			0.5	1.1
070	07013-01012	WIRENCH(SOCKET)	1				0.144	0.3168
080	07013-00022	WRENCH SOCKET	1				0.225	0.495
090	07014-00008	SPANNER	1				0.052	0.1144
100	07018-81922	SPANNER RING	1				0.312	0.6864
110	68061-81110	SQUEEZER GREASE	1				1.75	3.85
120	15241-86612	WRENCH FILTER	1				0.115	0.253
130	15527-86610	WRENCH FILTER	1				0.15	0.33
140	68311-81120	BAG TOOLS	1				0.05	0.11
150	68318-81332	MANUAL INSTRUCTION	1		←	KDG	0	0
150	68318-81342	MANUAL INSTRUCTION	1		←	KE KUK	0	0
160	68658-81392	LIST PARTS	1	55064	←		0	0
160	68658-81393	LIST PARTS	1	55065	←		0	0
160	68658-81394	LIST PARTS	1	55412	←		0	0
160	68658-81395	LIST PARTS	1	55476	←		0	0
160	68658-81396	LIST PARTS	1	55734	←		0.275	0.605
170	68773-53250	LINK FUSIBLE	1				0.01	0.022

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

SPOOL SECTION SWING	0060
SPOOL SECTION BLADE	0061
CHANGE VALVE	0062
CHANGE VALVE	0063
CONTROL LEVER FRAME	0064
CONTROL LEVER FRAME	0065
CONTROL LEVER BOX LH	0066
CONTROL LEVER LEVER LH	0067
PILOT VALVE COMPONENT PARTS	0068
CONTROL LEVER BOX RH	0069
CONTROL LEVER LEVER RH	0070
CONTROL LEVER TRAVEL LH	0071
CONTROL LEVER TRAVEL RH	0072
CONTROL TRAVEL PEDAL	0073
CONTROL LEVER SAFETY LOCK LEVE	0074
CONTROL PEDAL SWIVEL SWING CHA	0075
CONTROL PEDAL SWIVEL SWING CHA	0076
CONTROL LEVER BLADE	0077
CONTROL LEVER S P	0078
OIL PIPING THIRD LINE	0079
OIL PIPING SUCTION	0080
OIL PIPING DELIVERY	0081
OIL PIPING UNLOAD VALVE COMP	0082
OIL PIPING RETURN C V TANK	0083
OIL PIPING OIL COOLER	0084
OIL PIPING TRAVEL LH	0085
OIL PIPING TRAVEL RH	0086
OIL PIPING SWIVEL SWING	0087
OIL PIPING SWIVEL SWING	0088
OIL PIPING SWIVEL	0089
OIL PIPING SWING	0090
OIL PIPING LOCK	0091
OIL PIPING BOOM 1	0092
OIL PIPING BOOM 1	0093
OIL PIPING BOOM 2	0094
OIL PIPING ARM 1	0095
OIL PIPING ARM 1	0096
OIL PIPING ARM 2	0097
OIL PIPING BUCKET 1	0098
OIL PIPING BUCKET 2	0099
OIL PIPING BLADE	0100
OIL PIPING CONFLUENCE	0101
OIL PIPING CUSHION	0102
OIL PIPING S P	0103
OIL PIPING S P	0104
BOOM CYLINDER COMPONENT PARTS	0105
ARM CYLINDER COMPONENT PARTS	0106
BUCKET CYLINDER COMPONENT PAR	0107
BLADE CYLINDER COMPONENT PART	0108
SWING CYLINDER COMPONENT PART	0109
SWING BRACKET	0110
BOOM	0111
CYLINDER COVER BOOM	0112
ARM	0113
BUCKET LINK	0114
BUCKET	0115
BLADE	0116
TRUCK FRAME	0117
IDLER	0118
TRUCK ROLLER	0119
CRAWLER	0120
SWIVEL FRAME	0121
SWIVEL GEAR CASE	0122
SWIVEL GEAR	0123

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 12 of 299 pages

The full manual includes:

- All 299 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Kubota KX101 Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual