Item	Part No.	Description	Book
ENGINE	0101	CRANK CASE	100K0133
	0102	GEAR CASE [A]	100K0133
	0104	VALVE HEAD COVER ROCKER ARM	100K0133
	0105	CRANK SHAFT	100K0133
	0106	CAM SHAFT	100K0133
	0107	FUEL CAMSHAFT	100K0133
	0108	BREATHER INJECTION PUMP	100K0133
	0109	COOLING FAN RADIATOR [A]	100K0133
	0112	AIR CLEANER MUFFLER [A]	100K0133
	0133	STARTER	100K0133
	0134	FUEL INJECTION PUMP	100K0133
	0135	GENERATOR	100K0133
	0136	OIL FILTER	100K0133
	0137	NOZZLE	100K0133
FRONT AXLE AND FRONT WHEEL	0114	FRONT WHEEL	100K0133
	0115	FRONT AXLE	100K0133
CLUTCH	0116	CLUTCH HOUSING MISSION CASE	100K0133
	0117	CLUTCH PEDAL	100K0133
STEERING	0118	STEERING	100K0133
SPEED CHANGE LEVER	0119	HAND ACCEL	100K0133
BONNET(HOOD) AND CHASSIS AND CANOPY	0120	HOOD	100K0133
	0121	SEAT FENDER [A]	100K0133
TRANSMISSION	0123	TRANSMISSION GEAR	100K0133
	0124	DIFFERENTIAL [A]	100K0133
SPEED CHANGE LEVER	0126	SPEED CHANGE	100K0133
REAR AXLE AND REAR WHEEL	0127	REAR WHEEL SHAFT	100K0133
BRAKE	0128	BRAKE	100K0133
FUEL SYSTEM	0129	FUEL TANK	100K0133
HYDRAULIC SYSTEM	0130	HYDRAULIC	100K0133
	0131	HYDRAULIC	100K0133
DRAWBAR AND HITCH	0132	3-POINT LINKAGE	100K0133
ELECTRICAL SYSTEM	0138	ELECTRICAL	100K0133
ACCESSORIES	0139	ACCESSORIES AND SERVICE PARTS	100K0133

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

CRANK CASE

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	15222-01010	ASSY CRANK CASE	1				0	0
002	15103-94590	LABEL DRAIN	1				0.001	0.0022
003	15221-02314	LINER CYLINDER	2			HONE IINER AFTER INSERTING IN CRANKCASE	0	0
004	06311-75015	PLUG BELCH	3				0.002	0.0044
005	15221-03383	PLUG	3				0	0
006	15221-03392	PLUG	2				0	0
007	06311-75045	PLAG BELCH	1				0.026	0.0572
008	15221-33630	PLUG PIN	2				0.001	0.0022
009	15221-33640	PLUG	1				0.003	0.0066
010	05012-00408	PIN	2				0.001	0.0022
011	05012-00609	PIN	2				0.003	0.0066
012	05012-00612	PIN	2				0.003	0.0066
013	05012-01018	PIN	3				0.012	0.0264
014	15221-33650	PIN PIPE	1				0.004	0.0088
015	15221-72842	PIPE WATER 3	1				0	0
016	14412-73110	ASSY COCK DRAIN	1				0.09	0.198
017	15221-33610	PLUG	3				0.009	0.0198
018	15021-33660	GASKET	3				0.001	0.0022
019	15221-33752	PLAG	1				0	0
020	15109-33660	GASKET	1				0.001	0.0022
021	15221-04552	BOLT KNOCK	1				0	0
022	15021-33660	GASKET	1				0.001	0.0022
023	15221-33700	O-RING	1				0.001	0.0022
024	15221-36413	GAUGE OIL	1				0	0
025	04811-00050	O-RING	2				0.001	0.0022
026	15221-01613	COVER OIL	1				0	0
027	15221-01622	GASKET OIL COVER	1				0	0
028	01053-50816	BOLT	16				0.011	0.0242
029	04512-00080	WASHER LOCK	16				0	0
030	15221-33752	PLUG	1				0	0
031	15109-33660	GASKET	1				0.001	0.0022
032	34159-14183	ASSY HOUSING FLYWHEE	1				0	0
033	15103-94590	LABEL	1				0.001	0.0022
034	05012-01018	PIN	2				0.012	0.0264
035	31220-14172	COVER	1				0	0
036	01053-50812	BOLT	1				0.009	0.0198
037	04512-00080	WASHER LOCK	1				0	0
038	01073-51030	BOLT	11				0.028	0.0616
039	04512-00100	WASHER LOCK	11				0	0
040	15221-03024	ASSY HEAD CYLINDER	1				0	0
041	34150-18070	PLATE BAFFLE 2	1				0.045	0.099
042	15221-03373	PLUG	6	<=3439			0	0
042	15221-03373	PLUG	2	>=3440			0	0
043	15221-03493	PLUG	1				0	0
044	15131-01380	PLUG	2				0.001	0.0022
045	15221-13585	GUIDE INLET VALVE	2			REAM QUIDE AFTER INSERTING IN HEAD	0	0
046	15601-13560	GUIDE EXHAUST VALVE	2	>=10584			0	0
047	15221-01750	HOOK ENGINE	2				0.04	0.088

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	15221-74283	PULLEY FAN DRIVE	1				0	0
002	05712-00720	KEY FEATHER	1				0.008	0.0176
003	15221-23360	NUT CRANK SHAFT	1				0.11	0.242
004	15221-23380	WASHER CRANK SHAFT	1				0.02	0.044
005	15221-72060	ASSY RADIATOR	1	<=8663			5.6	12.32
005	15221-72063	ASSY RADIATOR	1	>=8664			0	0
006	99999-99999	BLANK	0				0	0
007	15021-72632	CAP RADIATOR	1				0	0
008	15221-72710	PIPE WATER OVERFLOW	1				0.05	0.11
009	15222-72200	ASSY NET RADIATOR	1				0.094	0.2068
010	01053-50612	BOLT	4				0.004	0.0088
011	04512-50060	WASHER LOCK	4				0	0
012	04013-50060	WASHER FLAT	3				0	0
013	14301-73114	ASSY COCK DRAIN	1				0	0
014	15021-72042	WHISTLE	1				0	0
015	15221-74112	FAN BLADE	1				0	0
016	01053-50610	BOLT	4				0.004	0.0088
017	15131-74234	WASHER FAN	2				0	0
018	15221-74142	SHAFT FAN	1				0	0
019	08143-06203	BEARING BALL	2				0.064	0.1408
020	05712-00515	KEY FEATHER	1				0.003	0.0066
021	04013-50120	WASHER FLAT	1				0	0
022	04512-50120	WASHER LOCK	1				0	0
023	02076-50120	NUT	1				0.015	0.033
024	04611-00400	CIR-CLIP INTERNAL	2				0.005	0.011
025	15221-74190	COLLAR FAN SHAFT	1				0.04	0.088
026	15221-74252	PULLEY FAN	1				0	0
027	15221-72530	BELT FAN	1	<=1015			0.086	0.1892
027	15221-72532	BELT FAN	1	>=1016			0	0
027	15221-72533	BELT FAN	1	>=8664			0	0
028	15221-72910	FLANGE WATER	1				0.28	0.616
029	15221-72920	GASKET WATER FLANGE	1				0	0
030	01053-50822	BOLT	4				0.013	0.0286
031	01513-00858	STUD	1	<=8663			0	0
031	01513-50860	STUD	1	>=8664			0.024	0.0528
032	01513-50822	STUD	1				0.01	0.022
033	02056-50080	NUT	2				0.005	0.011
034	04512-50080	WASHER LOCK	6				0.001	0.0022
035	04012-50080	WASHER FLAT	5				0.001	0.0022
036	15221-72850	PIPE WATER 1	1	<=8663			0.14	0.308
036	15221-72852	PIPE WATER 1	1	>=8664			0	0
037	15221-72940	PIPE WATER 4	1				0.136	0.2992
038	15108-72873	CLAMP	4				0	0
039	15221-64012	ASSY GENERATOR	1	<=8663		TO REFERENCE FIG.No.35	0	0
039	15321-64012	ASSY GENERATOR	1	>=8664		TO REFERENCE FIG.No.35	0	0
040	99999-99999	BLANK	0				0	0
041	01053-50830	BOLT	1	<=1015			0.015	0.033
041	15221-91010	BOLT	1	>=1016			0	0
042	01053-50835	BOLT	1				0.016	0.0352
043	04512-50080	WASHER LOCK	1				0.001	0.0022
044	04012-50080	WASHER FLAT	2				0.001	0.0022

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	34150-11115	ASSY KNUCKLE	2				0	0
002	08101-06204	BEARING	2				0.102	0.2244
003	08101-06205	BEARING	2				0.14	0.308
004	34150-11152	SEAL OIL	2				0	0
005	34150-11422	COLLAR	2				0	0
006	34150-11480	COVER DUST	2				0.055	0.121
007	02372-50200	NUT	2				0.024	0.0528
008	05511-50435	PIN SPLIT	2				0.004	0.0088
009	34150-11312	HUB FRONT WHEEL	2				0	0
010	32130-11350	CAP FRONT WHEEL	2				0.22	0.484
011	32130-11360	GASKET	2				0	0
012	01150-50814	BOLT	6				0.01	0.022
013	04512-50080	WASHER LOCK	6				0.001	0.0022
014	34159-11600	ASSY WHEEL FRONT	2			[A] L175F	9	19.8
014	99424-27200	ASSY WHEEL FRONT	2			[EXCEPT A] L175F	0	0
015	32150-11612	ASSY TIRE	2			[A]	0	0
016	32150-11620	TIRE	2			[A]	3.8	8.36
016	99424-27210	TIRE	2			[EXCEPT A]	0	0
017	32150-11630	TUBE	2			[A]	0.45	0.99
017	99424-27220	TUBE	2			[EXCEPT A]	0	0
018	34159-11710	LABEL	2				0.001	0.0022
019	34159-11850	VALVE	2				0.013	0.0286
020	32150-11644	WHEEL	2				0	0
021	01173-51225	BOLT	8				0.033	0.0726
022	04512-50120	WASHER LOCK	8				0	0
023	34159-11214	ARM KNUCKLE LH	1				0	0
024	34150-11225	ARM KNUCKLE RH	1				0	0
025	04811-50250	O RING	2				0.001	0.0022
026	01114-51050	BOLT	2	<=14023			0	0
026	01173-51055	BOLT	2	>=14024			0.036	0.0792
027	02173-50100	NUT	2	<=14023			0	0
027	02118-50100	NUT	2	>=14024			0.005	0.011
028	04512-50100	WASHER LOCK	2				0	0
029	05712-00722	KEY	2				0.009	0.0198
030	34150-11252	BEARING	2				0	0
031	34150-11280	SEAL OIL	2				0.048	0.1056
032	34159-12202	ASSY RINK DRAG	1				0	0
033	99999-99999	BLANK	0			ORDER BY REF.No.039	0	0
034	34150-12840	NIPPLE GREASE	2				0.003	0.0066
035	34150-12603	ASSY END TIE ROD RH	1				0	0
036	34150-12703	ASSY END TIE ROD LH	1				0	0
037	02172-50140	NUT	1				0.01	0.022
038	34150-12282	NUT	1				0	0
039	34150-12832	NUT	2				0	0
040	05511-12520	PIN SPLIT	2				0	0
041	34159-12400	ASSY ROD TIE	1				1.6	3.52
042	34159-12412	ROD TIE	1				0	0
043	34150-12840	NIPPLE GREASE	2				0.003	0.0066
044	34150-12603	ASSY END TIE ROD RH	1				0	0
045	34150-12703	ASSY END TIE ROD LH	1				0	0
046	02172-50140	NUT	1				0.01	0.022
047	34150-12282	NUT	1				0	0
048	34150-12832	NUT	2				0	0
049	05511-12520	PIN SPLIT	2				0	0
050	34150-11440	SPACER	2	>=11200			0.004	0.0088

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	15221-51010	ASSY PUMP FUEL INJEC	1				1.5	3.3
002	15221-51220	HOLDER DELIVERY VALV	2				0	0
003	15221-51230	SPRING DELIVERY VALV	2				0.002	0.0044
004	15221-51240	GASKET DELIVERY VALV	2				0.001	0.0022
005	15221-51030	VALVE DELIVERY	2				0.012	0.0264
006	15221-51050	ELEMENT PUMP	2				0.053	0.1166
007	15221-51350	SCREW	1				0.008	0.0176
008	15221-96660	GASKET	1				0.002	0.0044
009	15221-51320	SCREW	1				0.032	0.0704
010	15221-96650	GASKET	2				0.001	0.0022
011	15221-51250	PIN TAPPET GUIDE	2				0.001	0.0022
012	15221-51430	PIN CRANK	1				0.001	0.0022
013	15221-91010	BOLT	1	<=2509		Z750-A	0	0
013	15221-91030	BOLT	1	>=2510		Z750-A	0	0
014	15221-51390	PLATE ADJUSTING	1				0	0
015	15221-51060	RACK CONTROL	1				0	0
016	99999-99999	BLANK	0			ORDER BY REF.No.001	0	0
017	15221-51380	SLEEVE CONTROL	2				0	0
018	15221-51270	SEAT SPRING UPPER	2				0.004	0.0088
019	15221-51280	SPRING PLUNGER	2				0.015	0.033
020	15221-51290	SEAT SPRING LOWER	2				0.01	0.022
021	15221-51490	SHIM	2				0.002	0.0044
022	15221-51070	ASSY TAPPET	2				0.039	0.0858

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	34150-37113	CYLINDER HYDRAULIC	1	<=10303			0	0
001	34150-37114	CYLINDER HYDRAULIC	1	>=10304			0	0
002	34150-37123	GASKET	1				0	0
003	34150-37450	BUSHING	1				0.104	0.2288
004	34150-37460	BUSHING	1				0.062	0.1364
005	34150-37510	BUSHING	2				0.07	0.154
006	01173-11040	BOLT	3	<=10303			0	0
006	34150-37530	BOLT	3	>=10304			0.047	0.1034
007	01173-51070	BOLT	1				0.044	0.0968
008	34150-37520	STUD	2	<=10303			0.04	0.088
008	34150-37523	STUD	2	>=10304			0	0
009	02118-50100	NUT	2				0.005	0.011
010	04512-10100	WASHER LOCK	8	<=10303			0	0
010	04512-50100	WASHER LOCK	6	>=10304			0	0
011	34150-37202	ASSY COVER CYLINDER	1				0	0
012	99999-99999	BLANK	0			ORDER BY REF.No.011	0	0
013	34150-37224	SHAFT HYDRAULIC ADJU	1				0	0
014	04810-00100	O RING	1				0.001	0.0022
015	34150-37232	GLIP LEVER	1				0	0
016	05411-10418	PIN SPRING	1				0	0
017	34150-37252	COLLAR ADJUSTING	1				0	0
018	04611-10180	CIR-CRIP INTERNAL	1				0	0
019	04611-10160	CIR-CRIP INTERNAL	1	<=10303			0	0
019	34150-37260	CIR-CRIP INTERNAL	1	>=10304			0.001	0.0022
020	04012-50080	WASHER FLAT	1				0.001	0.0022
021	34150-27590	PLUG	1				0.04	0.088
022	04714-00300	GASKET	1				0.002	0.0044
023	04811-50750	O RING	1				0.002	0.0044
025	04811-00120	O RING	1	<=15033			0.001	0.0022
025	04810-00140	O RING	1	>=15034			0.001	0.0022
026	01173-51038	BOLT	5				0.028	0.0616
027	04512-50100	WASHER LOCK	5				0	0
028	34150-37134	LINER CYLINDER	1				0	0
029	34150-37312	PISTON HYDRAULIC	1				0	0
030	04811-00550	O RING	1				0.006	0.0132
031	32200-37380	RING	1				0.003	0.0066
032	34150-37320	ROD HYDRAULIC	1				0.48	1.056
033	34150-37340	PIN SET	1				0.18	0.396
034	01150-51018	BOLT	1				0	0
035	04512-50100	WASHER LOCK	1				0	0
036	34150-37433	SHAFT OIL PRESSURE A	1				0	0
037	34150-37443	ARM HYDRAULIC	1				0	0
038	34150-37480	COLLAR	1				0.005	0.011
039	34150-37490	COLLAR	1				0.002	0.0044
040	04811-06400	O RING	1				0.001	0.0022
041	04811-50450	O RING	1				0.002	0.0044
042	34150-37613	ARM LIFT	2	<=18023			0	0
042	34150-37617	ARM LIFT	2	>=18024			0	0
043	01173-51070	BOLT	2	<=18023			0.044	0.0968
043	01173-51075	BOLT	2	>=18024			0.047	0.1034
044	02118-50100	NUT	2				0.005	0.011
045	04512-50100	WASHER LOCK	2				0	0
046	99261-22582	PIN LIFT ROD	2				0	0
047	02174-50160	NUT	2				0.022	0.0484
048	04512-50160	WASHER LOCK	2				0	0

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	15221-63014	ASSY STARTER	1				0	0
002	15221-63030	DRIVE END FRAME	1				1.4	3.08
003	15221-96160	PLUG BELCH	1				0	0
004	15221-63240	BUSH	1				0	0
005	15221-91370	BOLT SET	1				0.01	0.022
006	15221-91020	BOLT	2				0.01	0.022
007	15221-63050	LEVER DRIVE	1				0.044	0.0968
008	15221-63020	CLUTCH MAGNET	1				0	0
009	15221-63040	CLUTCH	1				0.342	0.7524
010	15221-63070	ARMATURE	1				1.8	3.96
011	15221-94820	PIN SNAP	1				0.001	0.0022
012	15221-63230	COLLAR	1				0	0
013	15221-63080	YOKE	1				1.7	3.74
014	15221-91380	BOLT SET	4				0.008	0.0176
015	15221-96680	GASKET	1				0.002	0.0044
016	15221-63090	COIL FIELD	1				0	0
017	15221-63370	BRUSH	2				0.006	0.0132
018	15221-63360	BRUSH	2				0.006	0.0132
019	15221-63380	HOLDER BRUSH	1				0.13	0.286
020	15221-63390	SPRING BRUSH	1				0.003	0.0066
021	15221-63320	BOLT THROUGH	2				0.017	0.0374
022	15221-63200	END FRAME	1				0.254	0.5588
023	15221-63250	BUSH	1				0.006	0.0132
024	15221-96670	GASKET	1				0.001	0.0022
025	15221-63490	SPRING RETURN	1				0.004	0.0088
026	15221-94030	WASHER	1				0.003	0.0066
027	15221-63510	CAP END FRAME	1				0.01	0.022

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Instructions for Parts Books

The heading at the top of the page will be the same for the picture of the parts at it is for the page with the part numbers.

Definition of column headings on part number pages:

REF.No → The number refering to the part on the picture page of the parts book.

Part No. → The number assigned to this part at the time of printing the parts book.

Description → Discription of part.

Q'ty → Quanity of part used on that page.

S.No. → Serial number range of the equipment that this part will fit.
>= Your serial number should be greater than or equal to the number shown.
<= Your serial number should be lesser than or equal to the serial number shown.

I/C → Interchangeability of part shown.
←→ The part shown will work for the older and later serial number.
The part shown is not interchangable with the other serial number.
← new for old
→ old for new

Remarks → Notes about this particulart part. Sometimes this may say except [FR] or [CA]

Note about Country Codes:

The parts books we use in the United States of America may also contain information about a part that would be different in another country. It is important that you are aware of the country codes in some instances.

Symbol	Country
A	United States of America
CA	Canada
FR	France
GR	Greece
PO	Portugal
AU	Australia

If the remarks column says for example EXCEPT [FR] this part works in all countries except France.
That means it will work here in the USA.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 8 of 83 pages

The full manual includes:

- All 83 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Kubota L175 Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual