Instructions for Parts Books

The heading at the top of the page will be the same for the picture of the parts at it is for the page with the part numbers.

Definition of column headings on part number pages:

REF.No → The number refering to the part on the picture page of the parts book.

Part No. → The number assigned to this part at the time of printing the parts book.

Description → Discription of part.

Q'ty → Quanity of part used on that page.

S.No. → Serial number range of the equipment that this part will fit.
>= Your serial number should be greater than or equal to the number shown.
<= Your serial number should be lesser than or equal to the serial number shown.

I/C → Interchangeability of part shown.
←→ The part shown will work for the older and later serial number.
The part shown is not interchangable with the other serial number.
← new for old
→ old for new

Remarks → Notes about this particulart part. Sometimes this may say except [FR] or [CA]

Note about Country Codes:

The parts books we use in the United States of America may also contain information about a part that would be different in another country. It is important that you are aware of the country codes in some instances.

Symbol	Country
A	United States of America
CA	Canada
FR	France
GR	Greece
PO	Portugal
AU	Australia

If the remarks column says for example EXCEPT [FR] this part works in all countries except France.
That means it will work here in the USA.


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Item	Part No.	Description	Book
ENGINE	01T001	CRANKCASE	100K0383
	01T002	OIL PAN	100K0383
	01T003	PISTON AND CRANKSHAFT	100K0383
	01T004	MAIN BEARING CASE	100K0383
	01T005	FLYWHEEL	100K0383
	01T006	CYLINDER HEAD	100K0383
	01T007	VALVE AND ROCKER ARM	100K0383
	01T008	NOZZLE HOLDER AND GLOW PLUG	100K0383
	01T009	NOZZLE HOLDER [COMPONENT PARETS]	100K0383
	01T010	CYLINDER HEAD COVER	100K0383
	01T011	INLET MANIFOLD	100K0383
	01T016	CAMSHAFT	100K0383
	01T017	GEAR CASE	100K0383
	01T018	WATER PUMP	100K0383
	01T019	WATER FLANGE AND THERMOSTAT	100K0383
	01T020	INJECTION PUMP AND FUEL CAMSHAFT	100K0383
	01T021	INJECTION PUMP [COMPONENT PARTS]	100K0383
	01T022	SPEED CONTROL PLATE	100K0383
	01T023	GOVERNOR	100K0383
	01T024	UPPER GASKET KIT	100K0383
	01T025	LOWER GASKET KIT	100K0383
	02T012	AIR CLEANER	100K0383
	02T013	AIR CLEANER [COMPONENT PARTS]	100K0383
	02T014	EXHAUST MANIFOLD	100K0383
	02T01501	MUFFLER	100K0383
	02T01502	UNDER MUFFLER [OLD TYPE] [OPTION]	100K0383
	02T01503	UNDER MUFFLER [NEW TYPE] [OPTION]	100K0383
	02T026	HAND ACCELERATOR LEVER	100K0383
FUEL SYSTEM	02T02702	FUEL TANK	100K0383
	02T028	FUEL FILTER AND FUEL PIPE	100K0383
COOLING WATER SYSTEM	02T029	WATER PIPE	100K0383
	02T030	RADIATOR	100K0383
	02T031	SHUTTER	100K0383
ELECTRICAL SYSTEM	02T032	DYNAMO AND FAN	100K0383
	02T033	DYNAMO [COMPONENT PARTS]	100K0383
	02T034	STARTER	100K0383
	02T035	STARTER [COMPONENT PARTS]	100K0383
	02T036	BATTERY	100K0383
	02T037	SWITCH	100K0383
	02T03801	LIGHT [OIL TYPE]	100K0383
	02T03802	LIGHT [NEW TYPE]	100K0383
	02T03902	REGULATOR AND METER	100K0383
	02T04003	ELECTRICAL WIRING [OLD TYPE]	100K0383


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com



32310-026-10


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

CRANKCASE

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	16411-01010	COMP.CRANKCASE	1				48.5	106.7
020	15521-96020	PLUG	5				0.003	0.0066
030	15521-96030	PLUG	2				0.007	0.0154
040	06311-75018	PLUG	3	<=13748			0.004	0.0088
040	17391-96160	PLUG	3	>=13749	←		0.003	0.0066
050	06311-75045	PLUG	1				0.026	0.0572
060	15221-03380	CAP SEALING	5				0.017	0.0374
070	15221-03390	CAP SEALING	2				0.03	0.066
080	05012-00408	PIN STRAIGHT	2				0.001	0.0022
090	05012-00609	PIN STRAIGHT	2				0.003	0.0066
100	05012-00612	PIN STRAIGHT	2				0.003	0.0066
110	05012-01018	PIN STRAIGHT	1				0.012	0.0264
120	15221-33650	PIN PIPE	1				0.004	0.0088
130	15221-02310	LINER CYLINDER	3				0.58	1.276
140	15221-33610	PLUG	1				0.009	0.0198
150	15021-33660	GASKET	1				0.001	0.0022
160	15221-33700	O RING	1				0.001	0.0022
170	15321-35010	ASSY PUMP OIL	1	<=12063			0.525	1.155
170	17331-35010	ASSY PUMP OIL	1	>=12064	↔		0	0
180	15296-35150	GASKET OIL PUMP	1				0.001	0.0022
190	01053-50648	BOLT	4				0.01	0.022
200	04512-60060	WASHER SPRING	4				0.001	0.0022
210	19202-35660	GEAR OIL PUMP DRIVE	1				0.23	0.506
220	05712-00410	KEY FEATHER	1				0.001	0.0022
230	15221-35682	NUT FLANGE	1				0.014	0.0308
240	15531-39010	SWITCH OIL	1				0.032	0.0704
250	06312-10020	PLUG	1				0.015	0.033


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Item	Part No.	Description	Book
ELECTRICAL SYSTEM	02T04004	ELECTRICAL WIRING [NEW TYPE]	100K0383
CLUTCH	02T041	CLUTCH	100K0383
	02T042	CLUTCH LEVER	100K0383
	02T043	CLUTCH PEDAL	100K0383
	02T044	CLUTCH HOUSING	100K0383
TRANSMISSION	02T045	TRANSMISSION CASE	100K0383
	02T046	MAIN SHAFT	100K0383
	02T047	COUNTERSHAFT	100K0383
	02T04802	PTO COUNTERSHAFT	100K0383
	02T049	REVERSE SHAFT	100K0383
SPEED CHANGE LEVER	02T050	MAIN GEAR SHIFT LEVER	100K0383
	02T051	PTO GEAR SHIFT LEVER	100K0383
	02T052	MAIN GEAR SHIFT FORK	100K0383
	02T053	PTO GEAR SHIFT FORK	100K0383
	02T054	PTO GEAR SHIFT FORK AND LEVER	100K0383
REAR AXLE AND REAR WHEEL	02T055	SPIRAL BEVEL PINION	100K0383
	02T056	REAR DIFFERENTIAL	100K0383
	02T057	DIFFERENTIAL LOCK PEDAL	100K0383
	02T058	REAR AXLE	100K0383
	02T05901	REAR WHEEL (9.5-24)	100K0383
	02T05902	REAR WHEEL (11.2-24)	100K0383
	02T05903	REAR WHEEL (13.6-16)	100K0383
	02T05904	REAR WHEEL (13.6-16)	100K0383
	02T05905	REAR WHEEL (355/80-D20)	100K0383
BRAKE	02T06002	BRAKE	100K0383
	02T061	BRAKE PEDAL	100K0383
	02T062	PARKING BRAKE LEVER	100K0383
FRONT AXLE AND FRONT WHEEL AND CHASSIS	02T067	FRONT AXLE	100K0383
	02T068	FRONT AXLE CASE	100K0383
	02T069	DIFFERENTIAL GEAR SHAFT	100K0383
	02T070	FRONT DIFFERENTIAL CASE	100K0383
	02T071	FRONT DIFFERENTIAL	100K0383
	02T072	PROPELLER SHAFT	100K0383
	02T073	FRONT WHEEL DRIVE CASE	100K0383
	02T074	FRONT WHEEL DRIVE LEVER	100K0383
	02T07501	FRONT WHEEL (6-14)	100K0383
	02T07502	FRONT WHEEL (7-16)	100K0383
	02T07503	FRONT WHEEL (24X8.50-14)	100K0383
	02T076	FRONT AXLE FRAME	100K0383
STEERING	02T07901	STEERING LINKAGE (DRAG LINK)(MS)	100K0383
	02T07902	STEERING LINKAGE (DRAG LINK)(PS)	100K0383
	02T080	STEERING LINKAGE (TIE ROD)	100K0383
	02T08101	MANUAL STEERING AND HANDLE (MS)	100K0383
	02T08102	POWER STEERING AND HANDLE	100K0383
	02T08201	MANUAL STEERING [COMPONENT PARTS]	100K0383
	02T08202	POWER STEERING [COMPONENT PARTS]	100K0383

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW YOUFIXTHIS.COM

Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	32400-45610	ASSY LINK DRAG(PS)	1			POWER STRG.	3.07	6.754
020	35270-12650	COVER DUST	2			POWER STRG.	0.01	0.022
030	35270-12660	CLIP	2			POWER STRG.	0.005	0.011
040	35270-12670	NUT	2			POWER STRG.	0.014	0.0308
050	05511-50328	PIN SPLIT	2			POWER STRG.	0.002	0.0044
060	32400-45460	END DRAG LINK	1			POWER STRG.	1.86	4.092
070	37800-43890	BUSH	1			POWER STRG.	0.035	0.077
080	04811-00260	O RING	1			POWER STRG.	0.001	0.0022
090	01133-51025	BOLT	4			POWER STRG.	0.023	0.0506

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 12 of 275 pages

The full manual includes:

- All 275 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Kubota L2350DT Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual