
Item	Part No.	Description	Book
ENGINE	01001	CRANKCASE	100K0129
	01002	CYLINDER HEAD	100K0129
	01003	GEAR CASE	100K0129
	01004	BEARING CASE	100K0129
	01005	BREATHER	100K0129
	01006	AIR CLEANER	100K0129
	0100701	MUFFLER [L245DT]	100K0129
	0100702	MUFFLER [L245]	100K0129
	01008	VALVE,ROCKER ARM	100K0129
	01009	HEAD COVER	100K0129
	01010	CAMSHAFT	100K0129
	01011	PISTON CRANKSHAFT	100K0129
	01012	FLYWHEEL	100K0129
	01013	NOZZLE HOLDER	100K0129
	01014	FUEL CAMSHAFT	100K0129
	01015	SPEED CONTROL PLATE	100K0129
	01016	GOVERNOR	100K0129
	01017	DYNAMO	100K0129
	01018	RADIATOR	100K0129
	01019	WATER PUMP	100K0129
	01020	NAME PLATE	100K0129
	01063	OIL FILTER 2 [SECTION PARTS]	100K0129
	01064	STARTER	100K0129
	01065	NOZZLE HOLDER	100K0129
	01066	INJECTION PUMP	100K0129
	01067	DYNAMO	100K0129
ELECTRICAL SYSTEM	01024	BATTERY	100K0129
CLUTCH	01025	CLUTCH HOUSING	100K0129
	01026	CLUTCH	100K0129
	01027	CLUTCH PEDAL	100K0129
STEERING	01028	STEERING	100K0129
SPEED CHANGE LEVER	01029	HAND ACCEL	100K0129
BONNET(HOOD) AND CHASSIS AND CANOPY	01030	BONNET	100K0129
ELECTRICAL SYSTEM	01031	MIRROR LAMP	100K0129
BONNET(HOOD) AND CHASSIS AND CANOPY	01032	SEAT	100K0129
TRANSMISSION	01033	TRANSMISSION CASE	100K0129
	01034	GEAR DRIVE SYSTEM 1	100K0129
	01035	GEAR DRIVE SYSTEM 2	100K0129
	01036	GEAR DRIVE SYSTEM 3	100K0129
SPEED CHANGE LEVER	01037	SPEED CHANGE SYSTEM 1	100K0129
	01038	SPEED CHANGE SYSTEM 2	100K0129
	01039	CHANGE LAVER	100K0129
REAR AXLE AND REAR WHEEL	01040	DIFFERENTIAL SYSTEM 1	100K0129
	01041	DIFFERENTIAL SYSTEM 2	100K0129
	01042	REAR AXLE	100K0129
	01043	AXLE CASE	100K0129
BRAKE	01044	BRAKE	100K0129
	01045	BRAKE PEDAL	100K0129
BONNET(HOOD) AND CHASSIS AND CANOPY	0104602	FENDER [U.S.A]	100K0129
ELECTRICAL SYSTEM	01047	ELECTICAL 1	100K0129
	01048	ELECTICAL 2	100K0129
	01049	ELECTICAL 3	100K0129
FUEL SYSTEM	01050	FUEL TANK	100K0129
	01051	FUEL FILTER	100K0129
HYDRAULIC SYSTEM	01052	OIL PRESSURE 1	100K0129
	01053	OIL PRESSURE 2	100K0129
	01054	O/P CYLINDER	100K0129


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW YOUFIXTHIS.COM

Download full manual at youfixthis.com




REF. No. ⑥ 34150 – 1631 – 0
⑩ 34150 – 1651 – 0
⑬ 35110 – 1654 – 0



Discontinuance.


REF. No. ⑰ 61011 – 1814 – 0



Discontinuance.


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW ONLY YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Item	Part No.	Description	Book
HYDRAULIC SYSTEM	01055	O/P LIFT ARM SYSTEM	100K0129
FRONT AXLE AND FRONT WHEEL	01056	FRONT WHEEL [L245DT]	100K0129
	01057	FRONT WHEEL DRIVE [L245DT]	100K0129
	01058	DIFF GEAR CASE [L245DT]	100K0129
	01059	FRONT AXLE SUPPORT [L245DT]	100K0129
	01060	DRIVE CASE [L245DT]	100K0129
	01061	PROPEELLER SHAFT [L245DT]	100K0129
	01062	FRONT AXLE BRACKET	100K0129
HYDRAULIC SYSTEM	01068	OIL PRESSURE PUMP	100K0129
	01069	CONTROL VALVE	100K0129
	01070	RELIEF VALVE	100K0129
STEERING	01072	DRAG LINK [INTEGRAL POWER STEERING] [L245DT]	100K0129
	01073	POWER STEERING [INTEGRAL POWER STEERING]	100K0129
	01074	FLOW PRIORITY VALVE [INTEGRAL POWER STEERING]	100K0129
	01075	FUEL TANK [INTEGRAL POWER STEERING]	100K0129
	01076	OIL PRESSURE [INTEGRAL POWER STEERING]	100K0129
	01077	STEERING JOINT [INTEGRAL POWER STEERING]	100K0129
DRAWBAR AND HITCH	01078	3-POINT LINKAGE [3P]	100K0129
ACCESSORIES	01079	ACCESSORIES AND SERVICE PARTS	100K0129

PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	99999-99999	BLANK	0				0	0
002	15601-51220	HOLDER,DELIVERY VALV	3				0.055	0.121
003	15221-51230	SPRING,DELIVERY VALV	3				0.002	0.0044
004	15221-51240	GASKET,DELIVERY VALV	3				0.001	0.0022
005	15221-51030	VALVE,DELIVERY	3				0.012	0.0264
006	15221-51050	ELEMENT,PUMP	3				0.053	0.1166
007	15221-51350	SCREW	1				0.008	0.0176
008	15221-96660	GASKET	1				0.002	0.0044
009	15221-51320	SCREW	1				0.032	0.0704
010	15221-96650	GASKET	2				0.001	0.0022
011	15221-51250	PIN,TAPPET GUIDE	3				0.001	0.0022
012	15321-51430	PIN,CRANK	1				0.001	0.0022
013	15221-91030	BOLT	2				0	0
014	15221-51390	PLATE,ADJUSTING	2				0	0
015	15321-51060	PACK,CONTROL	1				0.038	0.0836
016	99999-99999	BLANK	0			ORDER BY REF.No.001 ON FIG.No.014	0	0
017	15221-51380	SLEEVE,CONTROL	3				0	0
018	15221-51270	SEAT,SPRING UPPER	2				0.004	0.0088
019	15221-51280	SPRING,PLUNGER	3				0.015	0.033
020	15221-51290	SEAT,SPRING LOWER	3				0.01	0.022
021	15221-51490	SHIM	3				0.002	0.0044
022	15221-51070	ASSY TAPPET	3				0.039	0.0858

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 12 of 160 pages

The full manual includes:

- All 160 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Kubota L245DT Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual