


LABELS

ACCESSORIES


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Item	Part No.	Description	Book
ENGINE	01T001	CRANKCASE	100K0339
	01T002	OIL PAN	100K0339
	01T003	PISTON AND CRANKSHAFT	100K0339
	01T004	MAIN BEARING CASE	100K0339
	01T00501	FLYWHEEL(DC)	100K0339
	01T00502	FLYWHEEL(SC)	100K0339
	01T006	CYLINDER HEAD	100K0339
	01T007	VALVE AND ROCKER ARM	100K0339
	01T008	NOZZLE AND GLOW PLUG	100K0339
	01T009	CYLINDER HEAD COVER	100K0339
	01T010	INLET MANIFOLD	100K0339
	01T015	CAMSHAFT	100K0339
	01T016	GEAR CASE	100K0339
	01T017	WATER PUMP	100K0339
	01T018	WATER FLANGE	100K0339
	01T019	FUEL CAMSHAFT	100K0339
	01T020	INJECTION PUMP	100K0339
	01T021	INJECTION PUMP [COMPONENT PARTS]	100K0339
	01T022	ENGINE STOP LEVER	100K0339
	01T023	SPEED CONTROL PLATE 1	100K0339
	01T024	SPEED CONTROL PLATE 2	100K0339
	01T025	GOVERNOR	100K0339
	01T01101	AIR CLEANER	100K0339
	01T01102	DOUBLE AIR CLEANER [OPTION]	100K0339
	01T012	PRE-CLEANER [OPTION]	100K0339
	01T013	EXHAUST MANIFOLD	100K0339
	01T01401	MUFFLER	100K0339
	01T01402	UNDER MUFFLER [OPTION]	100K0339
	01T02601	STOP ROD EXCEPT [GR]	100K0339
	01T027	ACCELERATOR LEVER	100K0339
	01T028	ACCELERATOR LINKAGE	100K0339
FUEL SYSTEM	01T029	FUEL TANK	100K0339
	01T030	FUEL FILTER	100K0339
	01T031	FUEL FILTER [COMPONENT PARTS]	100K0339
COOLING WATER SYSTEM	01T032	FAN	100K0339
	01T033	WATER PIPE	100K0339
	01T034	RADIATOR	100K0339
	01T035	SHUTTER	100K0339
ELECTRICAL SYSTEM	01T03601	DYNAMO EXCEPT [CA]	100K0339
	01T03701	DYNAMO [COMPONENT PARTS]	100K0339
	01T038	STARTER	100K0339
	01T03901	STARTER [COMPONENT PARTS]	100K0339
	01T03902	STARTER [COMPONENT PARTS]	100K0339
	01T040	BATTERY	100K0339
	01T04101	SWITCH AND REGULATOR EXCEPT [FR][GR][PO]	100K0339
	01T04201	PANEL [WITH EASY CHECKER] EXCEPT [FR][GR][PO][AU]	100K0339
	01T04202	PANEL [WITHOUT EASY CHECKER] [A][FR][GR][PO][AU]	100K0339
	01T04301	LIGHT EXCEPT [FR]	100K0339
	01T04601	ELECTRICAL WIRING [WITH EASY CHECKER] [A]	100K0339
	01T04602	ELECTRICAL WIRING [WITHOUT EASY CHECKER] [A][AU]	100K0339
CLUTCH	01T04701	CLUTCH(DC)	100K0339
	01T04702	CLUTCH(SC)	100K0339

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


CRANKCASE

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	17325-01010	COMP.CRANKCASE	1				30	66
020	15521-96020	PLUG	5				0.003	0.0066
030	15521-96030	PLUG	2				0.007	0.0154
040	06311-75018	PLUG	3				0.004	0.0088
050	06311-75045	PLUG	1				0.026	0.0572
060	15221-03380	CAP SEALING	5				0.017	0.0374
070	15221-03390	CAP SEALING	2				0.03	0.066
080	05012-00408	PIN STRAIGHT	2				0.001	0.0022
090	05012-00609	PIN STRAIGHT	2				0.003	0.0066
100	05012-00612	PIN STRAIGHT	2				0.003	0.0066
110	05012-01018	PIN STRAIGHT	1				0.012	0.0264
120	15221-33650	PIN PIPE	1				0.004	0.0088
130	15321-73340	PIPE WATER RETURN	1				0.016	0.0352
140	15521-02310	LINER CYLINDER	3				0.66	1.452
150	15221-33610	PLUG	1				0.009	0.0198
160	15021-33660	GASKET	1				0.001	0.0022
170	15221-33700	O RING	1				0.001	0.0022
180	17331-35010	ASSY PUMP OIL	1				0	0
190	15221-35150	GASKET OIL PUMP	1				0	0
200	01053-50648	BOLT	4				0.01	0.022
210	04512-50060	WASHER SPRING	4				0.001	0.0022
220	19202-35660	GEAR OIL PUMP DRIVE	1				0.23	0.506
230	05712-00410	KEY FEATHER	1				0.001	0.0022
240	15221-35680	NUT	1	<=19773			0	0
240	15221-35682	NUT FLANGE	1	>=19774	←		0.014	0.0308
250	15531-39010	SWITCH OIL	1				0.032	0.0704
260	15221-35670	WASHER	1	<=19773			0.005	0.011


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com






PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Item	Part No.	Description	Book
HYDRAULIC SYSTEM	01T09801	HYDRAULIC PUMP(MS)	100K0339
	01T09802	HYDRAULIC PUMP(PS)	100K0339
	01T09901	HYDRAULIC PUMP(MS) [COMPONENT PARTS]	100K0339
	01T09902	HYDRAULIC PUMP(PS) [COMPONENT PARTS]	100K0339
	01T100	HYDRAULIC OIL FILTER	100K0339
	01T101	HYDRAULIC OIL LINE	100K0339
	01T102	HYDRAULIC OIL LINE(PS)	100K0339
	01T103	HYDRAULIC BLOCK	100K0339
	01T104	CONTROL VALVE	100K0339
	01T10501	CONTROL VALVE [COMPONENT PARTS]	100K0339
	01T10502	CONTROL VALVE [COMPONENT PARTS]	100K0339
	01T106	DRAFT CONTROL VALVE [OPTION]	100K0339
	01T107	DRAFT CONTROL VALVE [COMPONENT PARTS]	100K0339
	01T108	CYLINDER FRONT COVER	100K0339
	01T109	HYDRAULIC CYLINDER	100K0339
	01T110	LIFT ARM	100K0339
	01T111	POSITION LEVER	100K0339
	01T112	FEED BACK LEVER	100K0339
	01T113	AUX.CONTROL VALVE 1 [OPTION]	100K0339
	01T114	AUX.CONTROL VALVE 2 [OPTION]	100K0339
	01T115	AUX.CONTROL VALVE [COMPONENT PARTS]	100K0339
	01T116	3-POINT LINKAGE 1	100K0339
	01T117	3-POINT LINKAGE 2	100K0339
	01T118	TOP LINKAGE BRACKET [OPTION]	100K0339
DRAWBAR	01T11901	DRAWBAR EXCEPT [FR][GR][PO]	100K0339
	01T11903	SWINGING DRAWBAR [OPITON]	100K0339
HOOD(BONNET) AND CHASSIS	01T12001	FRONT GRILLE [OLD TYPE]	100K0339
	01T12002	FRONT GRILLE [NEW TYPE]	100K0339
	01T12101	LIGHT GRILLE EXCEPT [FR]	100K0339
	01T12201	FRONT GRILLE SUPPORT [OLD TYPE]	100K0339
	01T12202	FRONT GRILLE SUPPORT [NEW TYPE]	100K0339
	01T123	HOOD(BONNET)	100K0339
	01T12401	SIDE COVER [OLD TYPE]	100K0339
	01T12402	SIDE COVER [NEW TYPE]	100K0339
	01T125	REAR HOOD(BONNET)	100K0339
	01T12601	MAIN AND PTO CHANGE COVER [OLD TYPE]	100K0339
	01T12602	MAIN AND PTO CHANGE COVER [NEW TYPE]	100K0339
	01T127	FENDER	100K0339
	01T12801	FLOOR SEAT [OLD TYPE]	100K0339
	01T12802	FLOOR SEAT [NEW TYPE]	100K0339
	01T12901	SEAT EXCEPT [FR]	100K0339
	01T130	FOOT COVER	100K0339
	01T13101	STEP [OLD TYPE]	100K0339
	01T13102	STEP [NEW TYPE]	100K0339
	01T132	ROPS [A]	100K0339
LABELS	01T13301	LABEL 1 EXCEPT [FR]	100K0339
	01T13401	LABEL 2 EXCEPT [FR]	100K0339
ACCESSORIES	01T135	ACCESSORIES AND SERVICE PARTS	100K0339

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


ACCELERATOR LINKAGE

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	31341-17610	ROD ACCEL.	1				0.14	0.308
020	34150-17390	JOINT ROD	1				0.025	0.055
030	02012-50060	NUT	2				0.002	0.0044
040	04012-50060	WASHER PLAIN	2				0.001	0.0022
050	05511-50218	PIN SPLIT	2				0.001	0.0022
060	31351-17624	LINK ACCEL.	1				0.11	0.242
070	31351-17630	SUPPORT ACCEL.LINK	1				0.2	0.44
080	01774-51220	BOLT FLANGE	2				0.03	0.066
090	04011-50120	WASHER PLAIN	1				0.005	0.011
100	05511-50320	PIN SPLIT	1				0.002	0.0044
110	31351-17650	ROD ACCELERATOR	1				0.06	0.132
120	04012-50060	WASHER PLAIN	2				0.001	0.0022
130	05511-50218	PIN SPLIT	2				0.001	0.0022

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	32420-21910	SHAFT GEAR	1			13T	0.885	1.947
020	37150-21551	CIR-CLIP EXTERNAL	1				0.005	0.011
030	35260-23270	BOSS SPLINE	1				0.3	0.66
040	35260-23299	SHIFTER	1				0.325	0.715
050	35260-23280	CLIP	1				0	0
060	08151-06305	BEARING BALL	1				0.233	0.5126
070	34150-21942	RETAINER BEARING	1				0.035	0.077
080	01123-50820	BOLT	1				0.011	0.0242
090	32430-21920	GEAR	1	<=56277		28T EXCEPT [FR][GR][PO]	0	0
090	32430-21922	GEAR	1	>=56278	←	28T EXCEPT [FR][GR][PO]	0.585	1.287
090	32425-21920	GEAR	1			25T [FR][GR][PO]	0.91	2.002
100	32430-21980	COLLAR	1	<=57176		EXCEPT [FR][GR][PO]	0	0
100	32430-21990	COLLAR	1	>=57177	↔	EXCEPT [FR][GR][PO]	0.1	0.22
100	32425-21980	COLLAR	1			[FR][GR][PO]	0.085	0.187
110	08101-06305	BEARING BALL	1				0.23	0.506
120	37150-21551	CIR-CLIP EXTERNAL	1				0.005	0.011
130	32420-22510	COUNTERSHAFT	1				1.12	2.464
140	37150-21551	CIR-CLIP EXTERNAL	1			WITHOUT CREEP	0.005	0.011
150	08151-06205	BEARING BALL	1				0.131	0.2882
160	35260-23300	RETAINER BEARING	2				0.02	0.044
170	01123-50816	BOLT	2				0.011	0.0242
180	31361-22520	GEAR	1			24T	0.63	1.386
190	31361-22530	BEARING ROLLER	1				0.27	0.594
200	38430-21762	COLLAR THRUST	1				0.035	0.077
210	31361-22540	RING INNER	1				0.115	0.253
220	35260-23240	WASHER	2				0.01	0.022
230	08823-23920	BEARING NEEDLE	2				0.03	0.066
240	31361-22550	GEAR	1			23T	0.62	1.364
250	35260-23260	BOSS SPLINE	1				0.17	0.374
260	35260-23250	NUT	1	<=52641			0	0
260	35260-23252	NUT	1	>=52642	↔		0.04	0.088
270	32430-21980	COLLAR	1	<=57176			0	0
270	32430-21990	COLLAR	1	>=57177	↔		0.1	0.22
280	31351-21820	GEAR	1	<=52085		42T WITH CREEP	0.7	1.54
280	31351-21822	GEAR	1	>=52086	≠	42T WITH CREEP	0.735	1.617
290	31351-94050	ASSY GEAR CREEP	1			WITH CREEP	1.47	3.234

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	32430-43110	CASE FRONT AXLE	1	<=56302			0	0
010	32430-43113	CASE FRONT AXLE	1	>=56303	≠		19.5	42.9
020	04717-02000	WASHER WITH RUBBER	1	<=53171			0.004	0.0088
020	04811-00180	O RING	1	>=53172	≠		0.001	0.0022
030	31353-43120	GAUGE OIL	1	<=52251			0	0
030	31353-43122	GAUGE OIL	1	>=52252	↔		0.015	0.033
040	31353-43220	COLLAR SEAL	1				0.035	0.077
050	04811-10250	O RING	1				0.001	0.0022
060	09500-32528	SEAL OIL	1				0.017	0.0374
070	31353-43240	ROLLER TAPER	2				0.23	0.506
080	31353-43140	SHIM	1			0.4MM	0.003	0.0066
080	31353-43150	SHIM	1			0.6MM	0.001	0.0022
080	31353-43160	SHIM	1			0.8MM	0.01	0.022
080	31353-43170	SHIM	1			1.0MM	0.006	0.0132
080	31353-43180	SHIM	1			1.2MM	0.003	0.0066
090	31220-22340	NUT	1	<=52641			0.033	0.0726
090	35260-23252	NUT	1	>=52642			0.04	0.088
100	31353-43260	ASSY CASE PINION BRG	1				5	11
110	01173-51040	BOLT	4				0.028	0.0616
120	04512-50100	WASHER SPRING	4				0.003	0.0066
130	31353-43250	O RING	1				0.005	0.011
140	01517-51022	STUD	2				0	0
150	02176-50100	NUT	2				0.005	0.011
160	04512-50100	WASHER SPRING	2				0.003	0.0066
170	01133-51025	BOLT	8				0.023	0.0506
180	06331-35012	PLUG	1				0.022	0.0484
190	04717-01200	WASHER WITH RUBBER	1				0.002	0.0044

PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	31351-37310	PISTON HYD.	1				1.375	3.025
020	04811-00750	O RING	1				0.008	0.0176
030	34350-37330	RING BACK UP	1				0.004	0.0088
040	31351-37320	ROD HYD.	1				0.605	1.331
050	31351-37330	GUIDE HYD.ROD	1				0.003	0.0066
060	05411-00645	PIN SPRING	1	<=51248			0.006	0.0132
060	05411-00656	PIN SPRING	1	>=51249	←		0.006	0.0132
070	31351-37430	SHAFT HYD.ARM	1				3.2	7.04
080	31351-37440	ARM HYDRAULIC	1				0	0
090	32240-37450	BUSH	1				0	0
100	32240-37460	BUSH	1				0	0
110	34150-37480	COLLAR	1				0.005	0.011
120	37300-37490	COLLAR	1				0.01	0.022
130	04811-50450	O RING	1				0.002	0.0044
140	04811-50500	O RING	1				0.001	0.0022
150	38240-37613	ARM LIFT	2				2.1	4.62
160	04612-00450	CIR-CLIP EXTERNAL	1				0.007	0.0154
170	32240-37695	PIN LIFT ROD	2	<=55756			0.2	0.44
170	30442-37690	PIN LIFT ROD	2	>=55757	≠		0.205	0.451
180	04512-50160	WASHER SPRING	2				0	0
190	02174-50160	NUT	2				0.022	0.0484
200	34150-37640	PIN SET	2				0.06	0.132
210	04011-50180	WASHER PLAIN	2	>=55757			0.012	0.0264

PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com




030 31351-1862-0



040 31351-1874-0
050 04512-50050
060 02054-50050



070 31351-1861-0



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 17 of 317 pages

The full manual includes:

- All 317 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Kubota L2550DT Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual