Instructions for Parts Books

The heading at the top of the page will be the same for the picture of the parts at it is for the page with the part numbers.

Definition of column headings on part number pages:

REF.No → The number refering to the part on the picture page of the parts book.

Part No. → The number assigned to this part at the time of printing the parts book.

Description → Discription of part.

Q'ty → Quanity of part used on that page.

S.No. → Serial number range of the equipment that this part will fit.
>= Your serial number should be greater than or equal to the number shown.
<= Your serial number should be lesser than or equal to the serial number shown.

I/C → Interchangeability of part shown.
←→ The part shown will work for the older and later serial number.
The part shown is not interchangable with the other serial number.
← new for old
→ old for new

Remarks → Notes about this particulart part. Sometimes this may say except [FR] or [CA]

Note about Country Codes:


The parts books we use in the United States of America may also contain information about a part that would be different in another country. It is important that you are aware of the country codes in some instances.

Symbol	Country
A	United States of America
CA	Canada
FR	France
GR	Greece
PO	Portugal
AU	Australia

If the remarks column says for example EXCEPT [FR] this part works in all countries except France.
That means it will work here in the USA.

PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com




LABELS
ACCESSORIES AND SERVICE PARTS

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



010 15301-0101-0
020 34150-2758-0
080 15221-3363-0
320 15221-3375-0
330 15109-3366-0
340 15521-3361-0




320 15521-3362-0



ℓ : 9→12.5mm

320 15521-9601-0



320 15521-9601-0
260 15221-3568-0
350 15221-3567-0
Discontinuance




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


Item	Part No.	Description	Book
ENGINE	01T001	CRANKCASE	100K0125
	01T002	OIL PAN	100K0125
	01T003	PISTON AND CRANKSHAFT	100K0125
	01T004	MAIN BEARING CASE	100K0125
	01T005	FLY WHEEL	100K0125
	01T006	CYLINDER HEAD	100K0125
	01T007	VALVE AND ROCKER ARM	100K0125
	01T008	NOZZLE HOLDER AND GLOW PLUG	100K0125
	01T009	NOZZLE HOLDER [COMPONENT PARTS]	100K0125
	01T010	CYLINDER HEAD COVER	100K0125
	01T011	BREATHER	100K0125
	01T012	INLET MANIFOLD	100K0125
	01T01301	AIR CLEANER	100K0125
	01T01302	AIR CLEANER (DOUBLE)	100K0125
	01T014	EXHAUST MANIFOLD	100K0125
	01T01501	MUFFLER	100K0125
	01T01502	UNDER MUFFLER	100K0125
	01T016	CAMSHAFT	100K0125
	01T017	GEAR CASE	100K0125
	01T018	OIL FILTER [COMPONENT PARTS]	100K0125
	01T019	WATER PUMP	100K0125
	01T020	WATER FLANGE	100K0125
	01T021	INJECTION PUMP AND FUEL CAMSHAFT	100K0125
	01T022	INJECTION PUMP [COMPONENT PARTS]	100K0125
	01T023	SPEED CONTROL PLATE	100K0125
	01T024	GOVERNOR	100K0125
COOLING WATER SYSTEM	01T028	RADIATOR	100K0125
ELECTRICAL SYSTEM	01T029	DYNAMO AND FRONT PTO(OPTION)	100K0125
	01T030	DYNAMO [COMPONENT PARTS]	100K0125
ENGINE	01T025	HAND ACCELERATOR	100K0125
FUEL SYSTEM	01T026	FUEL TANK	100K0125
	01T027	FUEL FILTER	100K0125
ELECTRICAL SYSTEM	01T031	STARTER	100K0125
	01T03201	STARTER [COMPLNENT PARTS]	100K0125
	01T03202	STARTER [COMPONENT PARTS]	100K0125
	01T033	BATTERY	100K0125
	01T034	PANEL 1	100K0125
	01T035	PANEL 2	100K0125
	01T036	PANEL 3	100K0125
	01T03701	LIGHT [EXCEPT EUROPE]	100K0125
	01T039	WORK LIGHT	100K0125
CLUTCH	01T041	CLUTCH	100K0125
	01T042	CLUTCH LEVER	100K0125
	01T043	CLUTCH PEDAL	100K0125
	01T044	CLUTCH HOUSING	100K0125
TRANSMISSION	01T045	TRANSMISSION CASE	100K0125
	01T046	MAIN SHAFT	100K0125
	01T047	COUNTER SHAFT	100K0125
	01T048	PTO COUNTER SHAFT	100K0125
	01T049	REVERSE SHAFT	100K0125
SPEED CHANGE LEVER	01T050	MAIN GEAR SHIFT LEVER AND PTO GEAR SHIFT LEVER	100K0125
	01T051	MAIN SHIFT FORK	100K0125
	01T052	HI-LO GEAR SHIFT LEVER	100K0125
	01T053	CREEP GEAR SHIFT LEVER	100K0125
	01T054	PTO SHIFT FORK	100K0125
REAR AXLE AND REAR WHEEL	01T055	SPIRAL BEVEL GEAR	100K0125
	01T056	DIFFERENTIAL SYSTEM 1	100K0125
	01T057	DIFFERENTIAL SYSTEM 2	100K0125
			100K0125

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com




PREVIEW ONLY YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW ONLY
YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW ONLY YOUFIXTHIS.COM

Download full manual at youfixthis.com

Item	Part No.	Description	Book
REAR AXLE AND REAR WHEEL	01T059	REAR AXLE	100K0125
	01T060	AXLE CASE	100K0125
	01T06101	REAR WHEEL(12.4-24)	100K0125
BRAKE	01T062	BRAKE	100K0125
	01T063	BRAKE PEDAL	100K0125
	01T064	PARKING BRAKE LEVER	100K0125
FRONT AXLE AND FRONT WHEEL	01T068	FRONT AXLE BRACKET	100K0125
	01T071	DIFF.GEAR SHAFT	100K0125
	01T072	DIFF.GEAR CASE	100K0125
	01T073	FRONT AXLE SUPPORT	100K0125
	01T074	PROPELLER SHAFT	100K0125
	01T075	DRIVE CASE	100K0125
	01T076	FRONT WHEEL(7-16)	100K0125
	01T077	DRAG LINKAGE	100K0125
	01T078	TIE ROD	100K0125
STEERING	01T079	MANUAL STEERING	100K0125
	01T080	MANUAL STEERING [COMPONENT PARTS]	100K0125
HYDRAULIC SYSTEM	01T081	HYDRAULIC PUMP	100K0125
	01T08201	HYDRAULIC PUMP [COMPONENT PARTS]	100K0125
	01T08202	HYDRAULIC PUMP [COMPONENT PARTS]	100K0125
	01T083	HYDRAULIC OIL LINE	100K0125
	01T084	HYDRAULIC OIL FILTER	100K0125
	01T085	CONTROL VALVE	100K0125
	01T086	CONTROL VALVE [COMPONENT PARTS]	100K0125
	01T087	RELIEF VALVE	100K0125
	01T088	RELIEF VALVE [COMPONENT PARTS]	100K0125
	01T089	DRAFT CONTROL VALVE	100K0125
	01T090	DRAFT CONTROL VALVE [COMPONENT PARTS]	100K0125
	01T091	HYDRAULIC CYLINDER	100K0125
	01T092	LIFT ARM	100K0125
	01T093	3-POINT LINKAGE	100K0125
	01T094	TOP LINKAGE BRACKET	100K0125
DRAWBAR	01T095	DRAWBAR AND HITCH	100K0125
	01T096	PTO SHAFT PROTECTOR	100K0125
HOOD(BONNET) AND CHASSIS	01T097	HOOD (BONNET)	100K0125
	01T098	REARVIEW MIRROR	100K0125
	01T099	UPPER FRAME	100K0125
	01T10001	FENDER	100K0125
	01T10002	FENDR	100K0125
	01T101	TOOLS CASE	100K0125
	01T10201	SEAT	100K0125
	01T10202	SEAT [OPTION]	100K0125
	01T103	S.M.V.EMBLEM BRACKET	100K0125
	01T104	STEP	100K0125
LABELS	01T105	LABEL 1	100K0125
	01T106	LABEL 2	100K0125
ACCESSORIES AND SERVICE PARTS	01T107	ACCESSORIES AND SERVICE PARTS	100K0125

PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	15221-56020	COMP.LEVER GOVERNOR	1				0.06	0.132
020	15221-56050	ASSY LEVER FORK	1				0.385	0.847
030	15221-56040	COMP.LEVER FORK	1				0.144	0.3168
040	15221-56130	LEVER FORK	1				0.065	0.143
050	15221-56150	SHAFT FORK LEVER	1				0.1	0.22
060	15021-56240	BOLT LEVER SHAFT	1				0.005	0.011
070	04512-50060	WASHER SPRING	2				0	0
080	15221-56230	HOLDER FORK LEVER	1				0.1	0.22
090	15221-66410	BOLT	1				0.005	0.011
100	15221-91060	BOLT	2	<=3550			0.155	0.341
100	01123-50832	BOLT	2	>=3551	↔		0.016	0.0352
110	01053-50628	BOLT	1	<=3550			0.008	0.0176
110	01023-50628	BOLT	1	>=3551	↔		0.015	0.033
120	04012-50080	WASHER PLAIN	2				0.001	0.0022
130	04012-50060	WASHER PLAIN	1				0.001	0.0022
140	15221-56480	SPRING START	1				0.008	0.0176
150	15321-56410	SPRING GOVERNOR	1				0.01	0.022
160	04512-50080	WASHER SPRING	2	<=3550			0	0
170	04512-50060	WASHER SPRING	1	<=3550			0	0

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	35110-76100	ASSY PUMP HYDRAULIC	1				1.9	4.18
020	04810-50550	O RING	1				0.002	0.0044
030	38180-76172	SQUARE RING	4				0.002	0.0044
040	04810-00050	O RING	1				0.001	0.0022
050	01156-51030	BOLT	4				0.02	0.044
060	04011-50100	WASHER PLAIN	4				0.002	0.0044
070	31381-76190	SEAL OIL	1				0.007	0.0154
080	04611-00280	CIR-CLIP INTERNAL	1				0.002	0.0044

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 12 of 219 pages

The full manual includes:

- All 219 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Kubota L295DT Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual