Instructions for Parts Books

The heading at the top of the page will be the same for the picture of the parts at it is for the page with the part numbers.

Definition of column headings on part number pages:

REF.No → The number refering to the part on the picture page of the parts book.

Part No. → The number assigned to this part at the time of printing the parts book.

Description → Discription of part.

Q'ty → Quanity of part used on that page.

S.No. → Serial number range of the equipment that this part will fit.
>= Your serial number should be greater than or equal to the number shown.
<= Your serial number should be lesser than or equal to the serial number shown.

I/C → Interchangeability of part shown.
←→ The part shown will work for the older and later serial number.
The part shown is not interchangable with the other serial number.
← new for old
→ old for new

Remarks → Notes about this particulart part. Sometimes this may say except [FR] or [CA]

Note about Country Codes:


The parts books we use in the United States of America may also contain information about a part that would be different in another country. It is important that you are aware of the country codes in some instances.

Symbol	Country
A	United States of America
CA	Canada
FR	France
GR	Greece
PO	Portugal
AU	Australia

If the remarks column says for example EXCEPT [FR] this part works in all countries except France.
That means it will work here in the USA.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW ONLY FIXTHIS.COM

LABELS

OPTION

ACCESSORIES

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


CRANKCASE

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	1G726-01010	COMP.CRANKCASE	1	<=3Q1566			48.5	106.7
010	1G726-01012	COMP.CRANKCASE	1	>=3S0001	≠		48.5	106.7
020	15521-96020	PLUG	5				0.003	0.0066
030	15521-96030	PLUG	2				0.007	0.0154
040	17391-96160	PLUG EXPANSION	3				0.003	0.0066
050	06311-75045	PLUG EXPANSION	1	<=3G0964			0.026	0.0572
050	16271-96160	PLUG EXPANSION	1	>=3J0001	←		0.025	0.055
060	15221-03380	CAP SEALING	5				0.017	0.0374
070	15221-03390	CAP SEALING	2				0.03	0.066
080	05012-00408	PIN STRAIGHT	2				0.001	0.0022
090	05012-00609	PIN STRAIGHT	3				0.003	0.0066
100	05012-00612	PIN STRAIGHT	2				0.003	0.0066
110	05012-01018	PIN STRAIGHT	1				0.012	0.0264
120	15221-33650	PIN PIPE	1				0.004	0.0088
130	15321-73340	PIPE WATER RETURN	1				0.016	0.0352
140	15221-33610	PLUG	1				0.009	0.0198
140	15469-33610	PLUG	1		↔		0.008	0.0176
150	15021-33660	GASKET	1				0.001	0.0022
160	16427-33140	PLUG OIL FILLER	1				0.025	0.055
170	1A021-33110	FLANGE OIL FILLER	1				0.07	0.154
180	1A021-51660	GASKET PUMP COVER	1				0.003	0.0066
190	01023-50618	BOLT	1				0.006	0.0132
200	15471-35012	ASSY PUMP OIL	1				0.55	1.21
210	1A021-35150	GASKET OIL PUMP	1				0.001	0.0022
220	01023-60650	BOLT	4				0.015	0.033
230	19202-35660	GEAR OIL PUMP DRIVE	1				0.23	0.506
240	05712-00410	KEY FEATHER	1				0.001	0.0022
250	15221-35682	NUT FLANGE	1				0.014	0.0308
260	1A021-57483	BRACKET ACCEL.CABLE	1				0.125	0.275
270	01023-50622	BOLT	3				0.005	0.011


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW YOUFIXTHIS.COM


Download full manual at youfixthis.com

ACCESSORIES AND SERVICE PARTS
ACCESSOIRES ET PIECES DE SERVICE
SONTIGES ZUBEHOER UND SERVICE-TEILE

TITLE-001-10

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Item	Part No.	Description	Book
CLUTCH/TRANSMISSION/REAR AXLE	01C20101	CLUTCH LEVER [EXCEPT HST TYPE]	100K0721
	01C20102	CLUTCH LEVER [HST TYPE]	100K0721
	01C30101	CLUTCH PEDAL [EXCEPT HST TYPE]	100K0721
	01C30102	CLUTCH PEDAL [HST TYPE] [ROPS TYPE]	100K0721
	01C40102	CLUTCH HOUSING [MANUAL T/M TYPE]	100K0721
	01C40103	CLUTCH HOUSING [GST TYPE]	100K0721
	01C40104	CLUTCH HOUSING [HST TYPE]	100K0721
	01C40301	HST (PISTON/PLUG) [COMPONENT PARTS] [HST TYPE]	100K0721
	01C40302	HST (REGULATOR/PIPE) [COMPONENT PARTS] [HST TYPE]	100K0721
	01C40303	HST (ROTARY) [COMPONENT PARTS] [HST TYPE]	100K0721
	01C405	GST VALVE [GST TYPE]	100K0721
	01C406	GST VALVE [COMPONENT PARTS] [GST TYPE]	100K0721
	01C41001	MID CASE [MANUAL T/M TYPE]	100K0721
	01C41003	MID CASE [GST TYPE]	100K0721
	01C41005	MID CASE [HST TYPE]	100K0721
	01C42002	TRANSMISSION CASE [MANUAL T/M TYPE]	100K0721
	01C42003	TRANSMISSION CASE [GST TYPE]	100K0721
	01C42004	TRANSMISSION CASE [HST TYPE]	100K0721
	01D101	MAIN SHAFT [EXCEPT HST TYPE]	100K0721
	01D103	INPUT SHAFT [HST TYPE]	100K0721
	01D10501	COUNTERSHAFT [MANUAL T/M TYPE]	100K0721
	01D10502	COUNTERSHAFT [GST TYPE]	100K0721
	01D10504	COUNTERSHAFT [HST TYPE]	100K0721
	01D11001	HYDRAULIC CLUTCH [GST TYPE]	100K0721
	01D11501	SHUTTLE SHAFT [MANUAL T/M TYPE]	100K0721
	01D11502	SHUTTLE SHAFT [GST TYPE]	100K0721
	01D11601	REVERSE SHAFT [MANUAL T/M TYPE]	100K0721
	01D11603	REVERSE SHAFT [GST TYPE]	100K0721
	01D11701	RANGE GEAR SHAFT [MANUAL T/M TYPE]	100K0721
	01D11702	RANGE GEAR SHAFT [GST TYPE]	100K0721
	01D11703	RANGE GEAR SHAFT [HST TYPE]	100K0721
	01D12501	SPIRAL BEVEL PINION [EXCEPT HST TYPE]	100K0721
	01D12502	SPIRAL BEVEL PINION [HST TYPE]	100K0721
	01D127	REAR DIFFERENTIAL	100K0721
	01D13001	PTO COUNTERSHAFT [EXCEPT HST TYPE]	100K0721
	01D13002	PTO COUNTERSHAFT [HST TYPE]	100K0721
	01D13201	PTO CLUTCH [EXCEPT HST TYPE]	100K0721
	01D13202	PTO CLUTCH [HST TYPE]	100K0721
	01D133	PTO CLUTCH [COMPONENT PARTS]	100K0721
	01D13501	PTO SHAFT	100K0721
	01D20101	MAIN GEAR SHIFT FORK [MANUAL T/M TYPE]	100K0721
	01D20102	MAIN GEAR SHIFT FORK [GST TYPE]	100K0721
	01D20501	SHUTTLE SHIFT FORK [MANUAL T/M TYPE]	100K0721
	01D20502	SHUTTLE SHIFT FORK [GST TYPE]	100K0721
	01D21701	RANGE GEAR SHIFT FORK [MANUAL T/M TYPE]	100K0721
	01D21702	RANGE GEAR SHIFT FORK [GST TYPE]	100K0721
	01D21703	RANGE GEAR SHIFT FORK [HST TYPE]	100K0721
	01D22501	DIFFERENTIAL LOCK SHIFT FORK [EXCEPT HST TYPE]	100K0721
	01D22502	DIFFERENTIAL LOCK SHIFT FORK [HST TYPE] [ROPS TYPE]	100K0721
SPEED CHANGE LEVER/BRAKE	01E10101	MAIN GEAR SHIFT LEVER [MANUAL T/M TYPE]	100K0721
	01E10102	MAIN GEAR SHIFT LEVER [GST TYPE]	100K0721
	01E105	SHUTTLE SHIFT LEVER [EXCEPT HST TYPE]	100K0721
	01E106	CRUISE CONTROL LEVER [HST TYPE]	100K0721

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com


↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	16467-42502	ASSY PIPE OVER FLOW	1				0.045	0.099
020	17331-42500	ASSY PIPE OVER FLOW	1				0.02	0.044
030	14971-42750	CLIP PIPE	1				0.001	0.0022
040	10244-42320	CLIP PIPE	1				0.001	0.0022
050	16082-53900	KIT HOLDER NOZZLE	3				0.145	0.319
060	15841-53622	GASKET	3				0.002	0.0044
070	19077-53650	SEAL HEAT	3				0.005	0.011
080	19077-53714	PIPE INJECTION	1				0.14	0.308
090	19077-53723	PIPE INJECTION	1				0.14	0.308
100	19077-53733	PIPE INJECTION	1				0.12	0.264
110	15841-53850	CLAMP PIPE	2				0.01	0.022
120	15841-53860	CLAMP PIPE	2				0.009	0.0198
130	03024-50520	SCREW WITH WASHER	2				0.004	0.0088
140	16415-65510	GLOW PLUG	3	<=2Y2172			0.03	0.066
140	19077-65510	GLOW PLUG	3	>=3A0001	←		0.03	0.066
150	16415-65560	CORD GLOW PLUG	1				0.015	0.033
150	1G742-65560	CORD GLOW PLUG	1		↔		0	0
160	02761-50040	NUT FLANGE	3				0.002	0.0044
170	15241-67580	CLAMP CORD	1				0.004	0.0088

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

OLD PARTS




PREVIEW - YOUFIXTHIS.COM

TD052-800-10

Download full manual at youfixthis.com

OLD PARTS



TD030-810-10

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	T1060-22200	COUNTERSHAFT	1	<=43513			0	0
010	T1060-22203	COUNTERSHAFT	1	>=43514	←		1.27	2.794
020	34070-22260	BEARING BALL	1				0.235	0.517
030	04611-00250	CIR CLIP INTERNAL	1				0.001	0.0022
040	TD050-22210	COMP.GEAR	1			24T	0.92	2.024
050	T1060-22310	BEARING NEEDLE	1				0.025	0.055
060	TD060-22170	ASSY SHIFTER	2				0.61	1.342
065	T1063-22250	COUPLING	2				0.35	0.77
070	TD050-22260	SHIFTER	2				0.25	0.55
080	32430-21440	KEY SYNCHRONIZER	6				0.004	0.0088
090	T0120-21780	SPRING	4				0.003	0.0066
100	34076-62260	RING SYNCHRONIZER	4				0.05	0.11
110	T1060-22280	CIR CLIP EXTERNAL	2				0.003	0.0066
120	TD050-22220	COMP.GEAR	1			29T	1.04	2.288
130	T1060-22320	BEARING NEEDLE	2				0.024	0.0528
140	TD050-22230	COMP.GEAR	1			34T	1.39	3.058
150	TD050-22240	COMP.GEAR	1			37T	2.1	4.62
160	T1060-22330	BEARING NEEDLE	2			SET	0.016	0.0352
170	35890-41290	BEARING BALL	1				0.233	0.5126
180	37150-21682	COUPLING	1				0.24	0.528

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	T1150-24400	FORK SHIFT	1				0.16	0.352
020	TD050-24410	ROD FORK	1				0.255	0.561
030	05411-00625	PIN SPRING	1				0.004	0.0088
040	T1060-24180	SPRING	1				0.003	0.0066
050	07715-01605	BALL	1				0.003	0.0066
060	T1060-24420	ARM RANGE SHIFT	1				0.205	0.451
070	04816-00200	O RING	2				0.003	0.0066
080	34070-24350	STOPPER	1				0.02	0.044
090	01754-50812	BOLT FLANGE	1				0.01	0.022

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


OLD PARTS



PREVIEW - YOUFIXTHIS.COM

TD030-873-10


Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


OLD PARTS



PREVIEW - YOUFIXTHIS.COM


TD052-809-10

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 24 of 581 pages

The full manual includes:

- All 581 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Kubota L3130DT, L3130GST, L3130HST Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual