Instructions for Parts Books

The heading at the top of the page will be the same for the picture of the parts at it is for the page with the part numbers.

Definition of column headings on part number pages:

REF.No → The number refering to the part on the picture page of the parts book.

Part No. → The number assigned to this part at the time of printing the parts book.

Description → Discription of part.

Q'ty → Quanity of part used on that page.

S.No. → Serial number range of the equipment that this part will fit.
>= Your serial number should be greater than or equal to the number shown.
<= Your serial number should be lesser than or equal to the serial number shown.

I/C → Interchangeability of part shown.
←→ The part shown will work for the older and later serial number.
The part shown is not interchangable with the other serial number.
← new for old
→ old for new

Remarks → Notes about this particulart part. Sometimes this may say except [FR] or [CA]

Note about Country Codes:


The parts books we use in the United States of America may also contain information about a part that would be different in another country. It is important that you are aware of the country codes in some instances.

Symbol	Country
A	United States of America
CA	Canada
FR	France
GR	Greece
PO	Portugal
AU	Australia

If the remarks column says for example EXCEPT [FR] this part works in all countries except France.
That means it will work here in the USA.


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




3-POINT LINKAGE/DRAWBAR/HITCH
LABELS
ACCESSORIES AND SERVICE PARTS
OPTION

PREVIEW ONLY FIXTHIS.COM
Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW BY YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Kubota **CRANKCASE**

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	1G799-01010	COMP.CRANKCASE	1				54.5	119.9
020	15521-96020	PLUG	6				0.003	0.0066
030	15521-96030	PLUG	2				0.007	0.0154
040	17391-96160	PLUG EXPANSION	3				0.003	0.0066
050	16271-96160	PLUG EXPANSION	1				0.025	0.055
060	15221-03380	CAP SEALING	6				0.017	0.0374
070	15221-03390	CAP SEALING	2				0.03	0.066
080	05012-00408	PIN STRAIGHT	2				0.001	0.0022
090	05012-00609	PIN STRAIGHT	3				0.003	0.0066
100	05012-00612	PIN STRAIGHT	2				0.003	0.0066
110	05012-01018	PIN STRAIGHT	1				0.012	0.0264
120	15221-33650	PIN PIPE	1				0.004	0.0088
130	06312-10020	PLUG	1				0.016	0.0352
140	15469-33610	PLUG	1				0.008	0.0176
150	15021-33660	GASKET	1				0.001	0.0022
160	99999-99999	BLANK	0				0	0
170	15471-35013	ASSY PUMP OIL	1				0	0
180	1A021-35150	GASKET OIL PUMP	1				0.001	0.0022
190	01053-50650	BOLT	4				0.011	0.0242
200	04512-60060	WASHER SPRING	4				0.001	0.0022
210	19202-35660	GEAR OIL PUMP DRIVE	1				0.23	0.506
220	05712-00410	KEY FEATHER	1				0.001	0.0022
230	15221-35682	NUT FLANGE	1				0.014	0.0308
240	16427-33142	PLUG OIL FILLER	1				0.025	0.055
250	1A021-33110	FLANGE OIL FILLER	1				0.07	0.154
260	1A021-51660	GASKET PUMP COVER	1				0.003	0.0066
270	01023-50618	BOLT	2				0.006	0.0132
280	1A053-57482	BRACKET ACCEL.CABLE	1				0.077	0.1694
290	01023-50622	BOLT	2				0.005	0.011

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Item	Part No.	Description	Book
CLUTCH/TRANSMISSION	01C410	MID CASE	100K0825
	01C42002	TRANSMISSION CASE	100K0825
	01D101	MAIN SHAFT	100K0825
	01D105	COUNTERSHAFT	100K0825
	01D117	RANGE GEAR SHAFT	100K0825
	01D12502	SPIRAL BEVEL PINION	100K0825
	01D127	REAR DIFFERENTIAL	100K0825
	01D130	PTO COUNTERSHAFT	100K0825
	01D132	PTO CLUTCH	100K0825
	01D133	PTO CLUTCH [COMPONENT PARTS]	100K0825
	01D13502	PTO SHAFT	100K0825
SPEED CHANGE SHIFT FORK /SHIFT LEVER	01D201	MAIN GEAR SHIFT FORK	100K0825
	01D217	RANGE GEAR SHIFT FORK	100K0825
	01D225	DIFFERENTIAL LOCK SHIFT FORK	100K0825
	01E101	MAIN GEAR SHIFT LEVER	100K0825
	01E110	RANGE GEAR SHIFT LEVER	100K0825
	01E112	RANGE GEAR SHIFT ROD	100K0825
	01E126	PTO CLUTCH CONTROL LEVER	100K0825
	01E127	PTO CLUTCH VALVE [COMPONENT PARTS]	100K0825
	01E140	FRONT WHEEL DRIVE LEVER	100K0825
REAR AXLE/BRAKE	01E151	REAR AXLE LH	100K0825
	01E152	REAR AXLE RH	100K0825
	01E161	BRAKE LH	100K0825
	01E162	BRAKE RH	100K0825
	01E165	BRAKE ROD 1 (BRAKE PEDAL)	100K0825
	01E170	BRAKE ROD 2 (BRAKE CAM)	100K0825
	01E201	BRAKE PEDAL	100K0825
FRONT AXLE/CHASSIS	01F10502	FRONT AXLE FRAME	100K0825
	01F120	PROPELLER SHAFT	100K0825
	01F122	FRONT WHEEL DRIVE SHAFT	100K0825
	01F125	FRONT DIFFERENTIAL CASE	100K0825
	01F127	BEVEL GEAR (FRONT)	100K0825
	01F130	DIFFERENTIAL (FRONT)	100K0825
	01F141	FRONT AXLE CASE LH	100K0825
	01F142	FRONT AXLE CASE RH	100K0825
	01F145	DIFFERENTIAL GEAR SHAFT	100K0825
	01F150	FRONT AXLE	100K0825
STEERING	01G101	STEERING HANDLE	100K0825
	01G110	STEERING CONTROLLER	100K0825
	01G11701	STEERING SUPPORT [OLD TYPE]	100K0825
	01G11702	STEERING SUPPORT [NEW TYPE]	100K0825
	01G18002	STEERING CYLINDER	100K0825
	01G18502	STEERING CYLINDER [COMPONENT PARTS]	100K0825
HYDRAULIC SYSTEM	01H120	HYDRAULIC PUMP	100K0825
	01H125	HYDRAULIC PUMP [COMPONENT PARTS]	100K0825
	01H145	REGULATOR VALVE	100K0825
	01H205	HYDRAULIC OIL LINE(INLET)	100K0825
	01H210	HYDRAULIC OIL LINE(DELIVERY)	100K0825
	01H21502	HYDRAULIC OIL LINE (PS)	100K0825
	01H230	PTO HYDRAULIC OIL LINE	100K0825

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

SPEED CONTROL PLATE

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
005	1A021-54350	ASSY BOLT ADJUSTMENT	1				0.015	0.033
010	1A021-54120	BOLT ADJUSTING	1				0.009	0.0198
020	15601-92012	NUT	1				0.006	0.0132
030	15601-96650	GASKET	2				0.001	0.0022
040	15841-14620	NUT	1				0.01	0.022
050	99999-99999	PIPE LOCK	1				0	0
060	1A053-57000	ASSY PLATE CONTROL	1				0.21	0.462
070	1A021-56020	COMP.LEVER GOVERNOR	1				0.046	0.1012
080	1A053-57150	LEVER SPEED CONTROL	1				0.051	0.1122
090	15471-57980	SEAL OIL	1				0.001	0.0022
100	05411-00420	PIN SPRING	1				0.001	0.0022
110	1A021-57920	SPRING RETURN	1				0.01	0.022
120	1A021-57210	GASKET PLATE	1				0.001	0.0022
130	01023-50620	BOLT	2				0.006	0.0132
140	15221-88210	STUD	2				0.005	0.011
150	02751-50060	NUT FLANGE	2				0.005	0.011

PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	15521-43015	ASSY FILTER FUEL	1				0.59	1.298
020	15521-43114	ASSY BODY	1				0.235	0.517
030	15521-43522	HANDLE FILTER	1				0.04	0.088
040	15521-43672	GASKET	1				0.001	0.0022
050	15521-43552	RETAINER HANDLE	1				0.01	0.022
060	15521-43542	PLATE THRUST	1				0.001	0.0022
070	04811-10290	O RING	1				0.001	0.0022
080	03054-50308	SCREW PAN-HEAD	2				0.005	0.011
090	15521-43150	RING RETAINER	1				0.14	0.308
100	15521-43100	ASSY CUP FILTER	1				0.05	0.11
105	15521-43130	CUP FILTER	1				0.1	0.22
110	16873-88430	LABEL FUEL	1				0.001	0.0022
120	15521-43160	ELEMENT FILTER	1				0.07	0.154
130	04811-50650	O RING	1				0.002	0.0044
140	15521-43930	SPRING	1				0.004	0.0088
150	04816-00160	O RING	1				0.003	0.0066

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	TA040-23500	GEAR-SHAFT I-PTO	1			12T	1.48	3.256
020	TD060-69002	ASSY CLUTCH I-PTO	1				3.7	8.14
030	TA040-69150	DISK BRAKE	1				0.41	0.902
040	TA040-69160	BEARING NEEDLE	1				0.029	0.0638
050	31501-72403	RING SEAL	2				0.005	0.011
060	08101-06207	BEARING BALL	1				0.282	0.6204
070	69331-24330	COLLAR DISTANCE	1				0.012	0.0264
080	36740-41150	CIR CLIP EXTERNAL	1				0.01	0.022
090	36540-41130	BEARING BALL	1				0.34	0.748


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	YW125-00102	ASSY VALVE SAFETY	1				0.4	0.88
020	04817-00160	O RING	1				0.001	0.0022
030	04816-06280	O RING	1				0.002	0.0044
040	YT133-00160	RING BACK UP	1				0.001	0.0022
050	31351-37210	COVER CYL.FRONT	1				0.315	0.693
060	04817-00220	O RING	1				0.001	0.0022
070	04817-06250	O RING	1				0.001	0.0022
080	38240-37250	COLLAR ADJUSTING	1				0.01	0.022
090	04611-00160	CIR CLIP INTERNAL	1				0.001	0.0022
100	T0070-34510	SHAFT	1				0.04	0.088
110	T0070-34570	PIPE	1				0.025	0.055
120	05411-00414	PIN SPRING	1				0.001	0.0022
130	05511-50425	PIN SPLIT	1				0.003	0.0066
140	04817-00100	O RING	2				0.001	0.0022
150	T0070-34560	GRIP	1				0.011	0.0242
160	34150-37260	CIR CLIP INTERNAL	1				0.001	0.0022
170	04012-50080	WASHER PLAIN	2				0.001	0.0022
180	30812-37360	SPRING	1				0.005	0.011
190	01123-50825	BOLT	2				0.013	0.0286
200	31351-39604	ASSY VALVE CONTROL	1				1.9	4.18
210	TA040-36400	BOLT	3				0.02	0.044
220	04817-00120	O RING	2				0.001	0.0022

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	TD060-27730	TIRE	1			ALR6807R	0	0
020	TC230-27630	ASSY WHEEL	1			ALR6807R	0	0
030	TC050-00880	RIM	1			ALR6807R	0	0
040	TC230-27660	DISK	1			ALR6807R	0	0
050	TC050-00970	BOLT	6			ALR6807R	0.16	0.352
060	TC050-00980	WASHER PLAIN	6			ALR6807R	0.02	0.044
070	TC050-00990	NUT	6			ALR6807R	0	0
080	99999-99999	LABEL TIRE RH	1			ALR6807R	0	0
090	TD060-27730	TIRE	1			ALR6807L	0	0
100	TC230-27630	ASSY WHEEL	1			ALR6807L	0	0
110	TC050-00880	RIM	1			ALR6807L	0	0
120	TC230-27660	DISK	1			ALR6807L	0	0
130	TC050-00970	BOLT	6			ALR6807L	0.16	0.352
140	TC050-00980	WASHER PLAIN	6			ALR6807L	0.02	0.044
150	TC050-00990	NUT	6			ALR6807L	0	0
160	99999-99999	LABEL TIRE LH	1			ALR6807L	0	0
170	01517-51635	STUD	8				0.078	0.1716
180	02076-50160	NUT	12				0.03	0.066
190	04512-60160	WASHER SPRING	12				0.01	0.022
200	01517-51635	STUD	4				0.078	0.1716

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 18 of 315 pages

The full manual includes:

- All 315 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Kubota L4400DT Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual