Instructions for Parts Books

The heading at the top of the page will be the same for the picture of the parts at it is for the page with the part numbers.

Definition of column headings on part number pages:

REF.No → The number refering to the part on the picture page of the parts book.

Part No. → The number assigned to this part at the time of printing the parts book.

Description → Discription of part.

Q'ty → Quanity of part used on that page.

S.No. → Serial number range of the equipment that this part will fit.
>= Your serial number should be greater than or equal to the number shown.
<= Your serial number should be lesser than or equal to the serial number shown.

I/C → Interchangeability of part shown.
←→ The part shown will work for the older and later serial number.
The part shown is not interchangable with the other serial number.
← new for old
→ old for new

Remarks → Notes about this particulart part. Sometimes this may say except [FR] or [CA]

Note about Country Codes:


The parts books we use in the United States of America may also contain information about a part that would be different in another country. It is important that you are aware of the country codes in some instances.

Symbol	Country
A	United States of America
CA	Canada
FR	France
GR	Greece
PO	Portugal
AU	Australia

If the remarks column says for example EXCEPT [FR] this part works in all countries except France.
That means it will work here in the USA.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




LABELS
ACCESSORIES
OPTION

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


Item	Part No.	Description	Book
ENGINE	010001	CRANKCASE	100K0559
	010002	OIL PAN	100K0559
	010003	CYLINDER HEAD	100K0559
	010004	GEAR CASE	100K0559
	010005	HEAD COVER	100K0559
	010100	MAIN BEARING CASE	100K0559
	010101	CAMSHAFT AND IDLE GEAR SHAFT	100K0559
	010102	PISTON AND CRANKSHAFT	100K0559
	01010302	FLYWHEEL [HST TYPE]	100K0559
	010105	FUEL CAMSHAFT	100K0559
	010200	ENGINE STOP LEVER	100K0559
	010202	INJECTION PUMP	100K0559
	010203	INJECTION PUMP [COMPONENT PARTS]	100K0559
	010204	GOVERNOR	100K0559
	010205	SPEED CONTROL PLATE	100K0559
	010206	NOZZLE HOLDER AND GLOW PLUG	100K0559
	010207	NOZZLE HOLDER [COMPONENT PARTS]	100K0559
	01050001	WATER FLANGE AND THERMOSTAT [ROPS TYPE]	100K0559
	010501	WATER PUMP	100K0559
	010600	VALVE AND ROCKER ARM	100K0559
	01060101	INLET MANIFOLD [ROPS TYPE]	100K0559
	010901	UPPER GASKET KIT	100K0559
	010902	LOWER GASKET KIT	100K0559
	010603	EXHAUST MANIFOLD/MUFFLER	100K0559
	01060401	AIR CLEANER [ROPS TYPE]	100K0559
	01A002	STOP SOLENOID/ENGINE STOP WIRE	100K0559
	01A01002	ACCELERATOR LEVER [HST TYPE] [ROPS TYPE]	100K0559
	01A03002	ACCELERATOR ROD [HST TYPE]	100K0559
FUEL SYSTEM	01A10101	FUEL TANK [ROPS TYPE]	100K0559
	01A110	FUEL PIPE AND FUEL FILTER	100K0559
	01A130	FUEL FILTER [COMPONENT PARTS]	100K0559
COOLING WATER SYSTEM	01A401	FAN	100K0559
	01A41001	WATER PIPE [ROPS TYPE]	100K0559
	01A420	RADIATOR	100K0559
	01A43001	RESERVE TANK [ROPS TYPE]	100K0559
ELECTRICAL SYSTEM	01A51501	ALTERNATOR [ROPS TYPE]	100K0559
	01A52001	ALTERNATOR [COMPONENT PARTS] [ROPS TYPE]	100K0559
	01A525	STARTER	100K0559
	01A530	STARTER [COMPONENT PARTS]	100K0559
	01A53501	BATTERY [ROPS TYPE]	100K0559
	01B10202	SWITCH 1 [HST TYPE] [ROPS TYPE]	100K0559
	01B10302	SWITCH 2 [HST TYPE] [ROPS TYPE]	100K0559
	01B115	PANEL BOARD	100K0559
	01B120	PANEL BOARD [COMPONENT PARTS]	100K0559
	01B30401	LIGHT 1 [ROPS TYPE] [OLD TYPE]	100K0559
	01B30402	LIGHT 1 [ROPS TYPE] [NEW TYPE]	100K0559
	01B50102	ELECTRICAL WIRING [HST TYPE] [ROPS TYPE]	100K0559
CLUTCH/TRANSMISSION/REAR AXLE	01C101	CLUTCH	100K0559
	01C201	CLUTCH LEVER	100K0559
	01C30102	CLUTCH PEDAL [HST TYPE] [ROPS TYPE]	100K0559
	01C40102	CLUTCH HOUSING [HST TYPE]	100K0559
	01C41002	MID CASE [HST TYPE]	100K0559
	01C415	HST [COMPONENT PARTS] [HST TYPE]	100K0559
	01C42002	TRANSMISSION CASE [HST TYPE]	100K0559
	01D10102	MAIN SHAFT [HST TYPE]	100K0559
	01D103	INPUT SHAFT [HST TYPE]	100K0559
	01D107	OUTPUT SHAFT [HST TYPE]	100K0559
	01D12503	SPIRAL BEVEL PINION [HST TYPE]	100K0559

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com




PREVIEW YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW OF YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Item	Part No.	Description	Book
CLUTCH/TRANSMISSION/REAR AXLE	01D127	REAR DIFFERENTIAL	100K0559
	01D13202	PTO CLUTCH [HST TYPE]	100K0559
	01D13502	PTO SHAFT [HST TYPE]	100K0559
	01D217	RANGE GEAR SHIFT FORK [HST TYPE]	100K0559
	01D22502	DIFFERENTIAL LOCK SHIFT FORK [HST TYPE][ROPS TYPE]	100K0559
	01D30101	REAR AXLE [ROPS TYPE]	100K0559
SPEED CHANGE LEVER/BRAKE	01D401	BRAKE	100K0559
	01D40502	BRAKE ROD 1 [HST TYPE] [ROPS TYPE]	100K0559
	01D41002	BRAKE ROD 2 [HST TYPE]	100K0559
	01E106	CRUISE CONTROL LEVER [HST TYPE]	100K0559
	01E107	CRUISE CONTROL CABLE [HST TYPE]	100K0559
	01E108	NEUTRAL HOLDER LINK [HST TYPE]	100K0559
	01E10901	SPEED CONTROL PEDAL [HST TYPE] [ROPS TYPE]	100K0559
	01E11001	RANGE GEAR SHIFT LEVER [HST TYPE] [ROPS TYPE]	100K0559
	01E112	RANGE GEAR SHIFT ROD [HST TYPE]	100K0559
	01E125	PTO GEAR SHIFT LEVER [HST TYPE]	100K0559
	01E140	FRONT WHEEL DRIVE LEVER	100K0559
	01E20102	BRAKE PEDAL [HST TYPE] [ROPS TYPE]	100K0559
FRONT AXLE/CHASSIS	01F105	FRONT AXLE FRAME	100K0559
	01F120	PROPELLER SHAFT	100K0559
	01F122	FRONT WHEEL DRIVE SHAFT	100K0559
	01F125	FRONT DIFFERENTIAL CASE	100K0559
	01F127	BEVEL GEAR (FRONT)	100K0559
	01F130	DIFFERENTIAL(FRONT)	100K0559
	01F140	FRONT AXLE CASE	100K0559
	01F145	DIFFERENTIAL GEAR SHAFT	100K0559
	01F150	FRONT AXLE	100K0559
STEERING	01G10102	STEERING HANDLE [HST TYPE] [ROPS TYPE]	100K0559
	01G110	STEERING CONTROLLER	100K0559
	01H110	STEERING CYLINDER	100K0559
	01H115	STEERING CYLINDER [COMPONENT PARTS]	100K0559
HYDRAULIC SYSTEM	01H12002	HYDRAULIC PUMP [HST TYPE]	100K0559
	01H12502	HYDRAULIC PUMP [COMPONENT PARTS] [HST TYPE]	100K0559
	01H20502	HYDRAULIC OIL LINE(INLET) [HST TYPE]	100K0559
	01H21002	HYDRAULIC OIL LINE(DELIVERY) [HST TYPE]	100K0559
	01H21502	HYDRAULIC OIL LINE(PS) [HST TYPE]	100K0559
	01H23502	HYDRAULIC OUTLET BLOCK [HST TYPE]	100K0559
	01H240	HYDRAULIC PIPE [HST TYPE]	100K0559
	01H245	OIL COOLER [HST TYPE]	100K0559
	01H301	HYDRAULIC CYLINDER	100K0559
	01H320	LIFT ARM	100K0559
	01H330	FEED BACK LEVER	100K0559
	01H405	CONTROL VALVE	100K0559
	01H410	CONTROL VALVE [COMPONENT PARTS] [OLD TYPE]	100K0559
	01H41001	CONTROL VALVE [COMPONENT PARTS] [NEW TYPE]	100K0559
	01H44001	POSITION CONTROL LEVER [ROPS TYPE]	100K0559
	01J105	TOP LINK	100K0559
	01J110	3-POINT LINKAGE 1(LOWER LINK) [OLD TYPE]	100K0559
	01J11001	3-POINT LINKAGE 1 (LOWER LINK) [NEW TYPE]	100K0559
	01J115	3-POINT LINKAGE 2(LIFT ROD)	100K0559
HITCH/DRAWBAR	01K105	DRAWBAR	100K0559
	01K12501	PTO PROTECTOR [ROPS TYPE]	100K0559
HOOD(BONNET)/ROPS/CAB	01L101	FRONT GRILLE	100K0559

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com

040 16661-7351-0



040

PREVIEW - YOUFIXTHIS.COM

1A012-801-10

Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	TA040-74020	STAY ALTERNATOR	1				0.09	0.198
020	17371-74280	PULLEY FAN DRIVE	1				0.98	2.156
030	05712-00720	KEY FEATHER	1				0.008	0.0176
040	34070-75602	ASSY ALTERNATOR	1	<=72630			0	0
050	01173-51000	BOLT	1				0.06	0.132
060	02116-50100	NUT	1				0.004	0.0088
070	04512-60100	WASHER SPRING	1				0.002	0.0044
080	04011-50100	WASHER PLAIN	1				0.002	0.0044
090	01153-60830	BOLT	1				0.025	0.055
100	04015-60080	WASHER PLAIN	1				0.01	0.022
110	04512-60080	WASHER SPRING	1				0.002	0.0044
120	02056-50060	NUT	1	<=73371			0.002	0.0044
120	12264-92020	NUT	1	>=73372	←		0.05	0.11
130	04512-60060	WASHER SPRING	1	<=73371			0.001	0.0022

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	TA240-51400	GEAR-SHAFT PTO	1			24T	1.52	3.344
020	08101-06207	BEARING BALL	1				0.282	0.6204
030	37410-14320	BEARING BALL	1				0.145	0.319
040	09500-35529	SEAL OIL	1				0.017	0.0374
050	TA240-51410	GEAR PTO	1			19T	0.28	0.616
060	TA240-51420	GEAR-SHAFT PTO	1			20T	1.545	3.399
070	37410-14320	BEARING BALL	1				0.145	0.319
080	TA220-51432	GEAR PTO	1			20T	0.355	0.781
090	37410-14320	BEARING BALL	1				0.145	0.319

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	TA040-15180	LEVER SHIFT	1				0.405	0.891
020	04811-00200	O RING	1				0.001	0.0022
020	04816-00200	O RING	1		←		0.003	0.0066
030	34070-24350	STOPPER	1				0.02	0.044
040	01754-50812	BOLT FLANGE	1				0.01	0.022
050	TA140-15470	LEVER 4WD CHANGE	1	<=73000			0.505	1.111
050	TA140-15473	LEVER 4WD CHANGE	1	>=73001	←		0.505	1.111
060	TA140-15490	LEVER 4WD CHANGE	1				0.086	0.1892
070	05411-00630	PIN SPRING	1				0.004	0.0088
080	TA040-15480	GRIP LEVER	1				0.053	0.1166
090	02116-50100	NUT	1				0.004	0.0088

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

190 TA250-5646-0



TA150-803-10

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


FRONT GRILLE SUPPORT [HST TYPE] [ROPS TYPE]
[EXCEPTE TYPE CABINE]

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	TA240-40016	SUPPORT FRONT	1	<=70404			0	0
010	TA240-40017	SUPPORT FRONT	1	>=70405	←		0	0
020	01123-50820	BOLT	2	<=72515			0.011	0.0242
020	01754-50820	BOLT FLANGE	2	>=72516	←		0.015	0.033
030	04012-50080	WASHER PLAIN	1	<=72515			0.001	0.0022
040	TA040-40024	SHUTTER	1				0.25	0.55
050	TA040-40033	SPRING	2				0.005	0.011
060	TA040-14213	SUPPORT	1				1.3	2.86
070	01123-50820	BOLT	4				0.011	0.0242

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 18 of 342 pages

The full manual includes:

- All 342 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Kubota L4610DT-HST Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual