
RC40-G
RC44-G
RC48-G

3. SPINDLE AND BLADE




Ref.No.	Code No.
	RC40-G
4	70712−3411−3
5	01130−51020
17	70713−3433−1
	RC44-G
4	70712−3411−3
5	01130−51020
17	70712−3433−2
	RC48-G
4	76500−3411−2
5	01170−51222
17	76500−3433−1
21	04512−50120

Ref.No.	Code No.
1	70712−9903−2
2	04612−00250
3	05712−00728
4	
5	
6	08101−06205
7	04611−00520
8	70722−3412−1
9	09500−35528
10	03410−50606
11	70722−3413−2
12	66616−3436−1
13	66616−3439−1
14	70712−3415−2
15	04612−00220
16	70722−3432−1
17	
18	70722−3435−1
19	70722−3437−3
20	70722−3439−2
21	

RC40-G
RC44-G
RC48-G

4. SPINDLE AND BLADE



Ref.No.	Code No.
	RC40-G
1	70712−3451−1
2	04013−50100
3	01130−51022
4	70713−3453−3
16	———
17	70713−3433−1
18	70713−3435−1
19	04512−50180
20	70713−3436−2
21	———
	RC44-G
1	70712−3451−1
2	04013−50100
3	01130−51022
4	70712−3453−2
16	70721−3457−2
17	70712−3433−2
18	70712−3435−2
19	04512−50140
20	01173−51428
21	———
	RC48-G
1	76500−3451−1
2	04013−50120
3	01170−51225
4	70713−3453−3
16	———
17	76500−3433−1
18	70713−3435−1
19	04512−50180
20	70713−3436−2

Ref.No.	Code No.
1	
2	
3	
4	
5	08101−06205
6	70722−3412−1
7	04611−00520
8	70712−3455−1
9	09500−35528
10	06613−10675
11	70725−3357−2
12	05712−00722
13	04512−50160
14	70721−3456−2
15	02172−50160
16	
17	
18	
19	
20	
21	


21	04512−50120

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

RC40-G
RC44-G
RC48-G


1. JOINT



Ref.No.	Code No.
1	70712－3201－3
2	70720－3111－7
3	70720－3112－3
4	70712－3114－2
5	70720－3117－6
6	70720－3211－1
7	70720－3121－2
8	70720－3118－2
9	70720－3212－1
10	70720－3120－2
11	02356－50080
12	04512－50080
13	05122－50845
14	05511－50218
15	04012－50080
16	70712－3235－2
17	01811－50812
18	04512－50080
19	04013－50080
20	70713－3236－1

RC40-G
RC44-G
RC48-G

2. GEAR BOX



Ref.No.	Code No.
	RC40-G
10	70713－3333－1
16	70713－3353－1
	RC44-G
10	70712－3333－1
16	70712－3353－1
	RC48-G
10	76500－3333－1
16	76500－3353－1


Ref.No.	Code No.
1	70712－3311－2
2	01170－51014
3	04717－01000
4	70722－3313－2
5	70722－3315－2
6	01173－51222
7	01173－51228
8	04512－50120
9	70712－3331－1
10	
11	70720－3335－2
11	70720－3336－2
12	08101－06205
13	04611－00520
14	09502－55210
15	70712－3351－2
16	
17	70712－3355－1
18	04611－00650
19	04612－00220
20	08101－06205
21	04611－00520
22	09502－55210
23	70712－3357－1
23	70712－3359－1
24	04811－10800
25	70712－3361－1
26	01123－50814

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

RC44-G


6. DECK AND DEFLECTOR



Ref.No.	Code No.
1	70712−4116−4
2	70712−4113−1
3	70712−4118−1
4	70722−4122−2
5	70712−4124−1
6	70722−4126−1
7	70712−4115−1
8	70712−4120−1
9	70722−4122−2
10	70712−4128−1
11	66204−5116−1
12	01120−50818
13	04013−50080
14	70712−4117−1
15	36200−9816−2
16	70720−4715−3
17	70712−4114−1
18	70712−4716−2
19	70712−4119−1
20	01170−51016
21	04512−50100
22	02118−50100
23	70712−4711−2
24	70721−4713−1
25	01170−51020
26	04512−50100
27	02118−50100
28	01170−51028
29	70722−4712−2
30	70712−4714−1
31	70712−3457−1

RC48-G

6. DECK AND DEFLECTOR



Ref.No.	Code No.
1	76500−4116−4
2	76500−4113−2
3	76500−4118−2
4	70722−4122−2
5	76500−4124−2
6	70722−4126−1
7	76500−4115−2
8	76500−4120−2
9	70722−4122−2
10	76500−4128−2
11	66204−5116−1
12	01120−50818
13	04013−50080
14	76500−4117−1
15	36200−9816−2
16	70720−4715−3
17	70712−4114−1
18	70712−4716−2
19	70712−4119−1
20	01170−51016
21	04512−50100
22	02118−50100
23	76500−4711−1
24	70721−4713−1
25	01170−51020
26	04512−50100
27	02185−50100
28	01170−51028
29	70722−4712−2
30	70712−4714−1
31	70713−3457−1

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 3 of 8 pages

The full manual includes:

- All 8 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Kubota RC40-G, RC44-G, RC48-G Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual