
ENGINE

60 6860

A-05
01

A0501

ENGINE ASSEMBLY - A4.236 ENGINE



1	3553131M91 ●		N.L.A. (1) "LD31202"PK	1	ENGINE


ENGINE

60 6860

A-05
02

A0502

SHORT ENGINE - A4.236 ENGINE




1	LD39336			1	SHORT ENGINE
2		!	1	22	BOLT
2		!	1	1	GASKET
2		!	1	1	LINER
2		!	1 A	1	SEAL
2		!	1	4	WASHER
2		!	1	1	HOUSING
2		!	1	4	HOUSING

! THIS IS A COMPONENT OF AN ASSEMBLY


A COMPLETE WITH PLUGS

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



1	3303000M96	●	1424135M93 (1) 3540479M91 (1)	1	CLUTCH
			(X) 0.1.2.8		
2	3311538M92	!	1 A (X) 0.1.2.8	1	DISC
3	3311959M1	!	1 A	1	BASE PLATE
4	1427880M91	!	1 A (X) 0.2.4.8	1	KIT
4	3106322M91	!	1 A (X) 0.0.1.2	1	KIT
5	3105290M91	!	4	3	LEVER
		⇒	REF.4		
6		!	5	3	STRUT
		⇒	REF.5		
7	1424130M1	!	4	3	REGISTER
8	392363X1	●	392310X1 (3)	3	NUT
		!	4		
9		!	4	3	PIN
		⇒	REF.5		
10		!	4	3	SPRING
		⇒	REF.N.4		
11		!	4	3	PIN
		⇒	REF.N.4		
13	391401X1	!	4 (X) 0.3.6.9	3	LINCH PIN
14	1424135M93	!	1 D (X) 0.0.1.2	1	DISC
15	3311960M1	!	1 D (X) 0.0.1.2	1	BASE PLATE




16	3106323M91	!	1 D	1	KIT
17		!	16	3	LEVER
		⇒	REF.16		
18		!	16	3	STRUT
		⇒	REF. 16		
19	3105294M1	!	16 (X) 0.3.6.9	3	BUSH
20		!	16	3	NUT
		⇒	REF.N.16		
21		!	16	3	PIN
		⇒	REF.N.16		
22	391401X1	!	16	3	LINCH PIN
23		!	16	3	SPRING
		⇒	REF.N.16		
24		!	16	3	PIN
		⇒	REF.N.16		
25	1440273X1	!	16	3	WASHER
26	391401X1	!	16	3	LINCH PIN
27	3310800M1	!	1 (X) 0.0.1.2	1	SPRING
28	1440961X1	!	1	3	DOWEL
29	1424122M1	!	1	1	BOX
30	973013M1			6	BOLT
31	1825511M1	●	3653185M91 (1)	1	FLYWHEEL
32	339599X1		(X) 0.1.2.4	1	BEARING
33			D	6	WASHER

!	THIS IS A COMPONENT OF AN ASSEMBLY
⇒	NOT SERVICED, ORDER
A	FOR TRANSMISSION
D	SUPPLIED BY PERKINS (SEE ENGINE SECTION)
D	FOR P.T.O.
(X)	QTY PER TRACTORS SOLD (AA.BBB.CCC.DDD) (AA) FOR 1,(BBB) 2-10 (CCC) 11-25 (DDD) 26-50

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



1		◇	U-47 01 1 AV014074	1 SEAT
2	339169X1	●	394367X1 (2)	2 NUT
3	3532486M95	● ◀	N.L.S. (1) A	1 FENDER
3	3532487M95	● ▶	N.L.S. (1) A	1 FENDER
5	1423841M1	●	1423841M2 (2) B G	2 PLATE
6	392462X1	◆▶	250MM. B	8 SCREW
7	395547X1			4 PLATE
8	1442739X1			6 NUT
9	3532879M96	● ◀	1440314X1 (1) 3019406X1 (2) 339401X1 (2) 3552534M92 (2) 3555280M93 (1)	1 FLOOR
10	3532880M97	● ▶	1440314X1 (2) 3019406X1 (2) 339401X1 (2) 3552507M92 (1) 3555282M93 (1) O	1 FLOOR
10	3535915M96	● ▶	1440314X1 (1) 3019406X1 (2) 339401X1 (2) 3552507M92 (2) 3555281M93 (1) N.L.S. (1) A N	1 FLOOR


FENDERS FOOTSTEPS AND PLATFORM

S-22
01

S2201

FENDERS AND PLATFORM


60 6860



11	339401X1			4 SCREW
12	339761X1			4 SCREW
13	391039X1			4 WASHER
14	3531661M1	●	3531661M2 (4)	4 DAMPER
15	339374X1			4 LOCK WASHER
16	1440086X1			4 NUT
17	1696186M91			1 TOOL BOX
18	3015039X1			2 SCREW
19	390734X1			2 WASHER
20	1440314X1			2 LOCK WASHER
21	3009693X1	●	339402X1 (2)	2 NUT
22	339374X1			2 LOCK WASHER
23	339123X1			2 SCREW
24	390972X1			2 WASHER
25	1423975M2		B	2 SHIM
26	3532893M4	●	3650497M2 (1)	1 PLATE
29	3307887M1	◀	125MM.	1 EXTENSION
29	3307888M1	▶	125MM.	1 EXTENSION
29	3307889M1	◀	30MM. C	1 EXTENSION
29	3307890M1	▶	30MM. C	1 EXTENSION
30	3308186M1		C	2 SUPPORT
31	3532633M2	◀		1 GUARD
31	3532634M2	▶		1 GUARD
32	339563X1			34 SCREW
32	339563X1		C	32 SCREW
33	390995X1		C	32 NUT
33	390995X1			34 NUT
34	1443775X1		C	32 WASHER
34	1443775X1			34 WASHER

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



1		⟲	P-42 03 1	1 PUMP
2	979599M1			1 RING
3		!	1	1 KEY
4		!	1	1 NUT
5		!	1	1 WASHER
6	1424121M94			1 KIT
7	974443M1	!	6	1 GASKET
8	390871X1	!	6	4 SCREW
9	392879X1	!	6	4 WASHER
10	3302108M1	!	6	1 SUPPORT
11	3302869M1	◐	3308788M1 (1)	1 GASKET
		!	6	
12	3302106M2	!	6	1 SHAFT
13	1440360X1	!	6	1 TONGUE
14	1440488X1	!	6	2 BEARING
15	339199X1	!	6	1 RING
15	339199X1			2 RING
16	982209M2	!	6	1 GEAR
		▲	14	
17	390735X1	!	6	1 WASHER
18	392843X1	!	6	1 NUT
19	2232151	!	6	2 SCREW
21	3307127M1			1 BODY
22	3307250M91			1 CARTRIDGE
			(X) 1.20.40.80	
23	3019920X1			1 O RING
24	1825223M91			1 COVER
25	3015061X1			1 O RING
26	1434782M1			2 STUD
27	339374X1			2 LOCK WASHER
28	1440086X1			2 NUT
29	339666X1			4 SCREW
30	390971X1			4 WASHER
31	1825227M1			1 FLANGE


HYDRAULICS AND LINKAGE

P-42
01

60 6860

P4201

HYDRAULIC EQUIPMENT - LIFT PIPINGS - UP TO SERIAL NUMBER P06076.




32	3019922X1			1 O RING
33	395579X1			4 SCREW
34	3532876M91			1 PIPE
35	1004637M1			1 RING
			(X) 0.5.10.20	
36	1441757X1			2 SCREW
37	1440314X1			2 LOCK WASHER
38	3307152M1			1 SLEEVE
39	394301X1			2 CLAMP
40		⟲	G-40 11 5 A	1 PIPE
40	3308634M91			1 PIPE
41	3019915X1			1 O RING
42	339096X1			4 SCREW
43	339375X1			4 LOCK WASHER
44	3307643M1	◐	1444744X1 (1) 3000145X1 (1) 3550949M2 (1)	1 FLANGE
			E	
45	762026M1		E	1 O RING
46	339761X1		E	2 SCREW
47	391136X1		E	2 SCREW
48	3308719M1			4 STIRRUP
49	339096X1			2 SCREW
50	1440085X1			2 NUT
51	3304523M93			1 UNION
52	851134M1			1 RING
53	339374X1		E	4 LOCK WASHER
54	3302107M2	!	6	1 GEAR
			(X) 0.2.3.4	
56	0748505	!	6	1 SCREW
57	1424590M1	!	6	1 SPACER
58	3302109M1	!	6	1 SPACER
59	391431X1	◐	1442962X1 (1)	1 LINCH PIN
		!	6	

PREVIEW YOUFIXTHIS.COM


Download full manual at youfixthis.com

ENGINE	A-05 03	CYLINDER BLOCK - - A4.236 ENGINE
60 6860	A0503	



1	ZZ50226			1	KIT
2	3135X031	!	1 A (X) 0.4.8.16	4	LINER
2	3135X032		B (X) 0.4.4.8	1	LINER
3	0650710	!	1	6	PLUG
4	32418122	!	1	4	PLUG
5	33142111		RTS CODE 511300 TIME 5,00	10	SLEEVE
6	32166329		RTS CODE 511300 TIME 5,00	10	SCREW
7	31134165	!	1	1	BUSH
8	0650710	!	1	2	PLUG
9	2485A204	!	1	1	PLUG
10	32416119	!	1	1	PLUG
11	32168212	●○	0650582 (1) ! 1	1	PLUG
12	3311R003	●○	2415D108 (1) ! 1	1	WASHER
13	0650588	!	1	2	PLUG
14	32417134		RTS CODE 510900 TIME 0,50	1	PLUG
15	3681E034		(X) 0.1.2.4	1	GASKET
16	4142V066			1	FLANGE
17	2418F475	!	16 (X) 0.1.2.4	1	SEAL
18	3681T012	●○	3681T018 (1)	1	GASKET
19	0746211			12	SCREW
20	390972X1			12	WASHER
21	0350009			2	DOWEL
22	2172530			2	SCREW
23	33112111			2	WASHER
24	0650594			1	PLUG
25	32416118			4	PLUG

ENGINE	A-05 03	CYLINDER BLOCK - - A4.236 ENGINE
60 6860	A0503	



26	32161114	2	PLUG
27	0650588	1	PLUG
28	32452113	1	PIN
29	32114143	1	PLUG

! THIS IS A COMPONENT OF AN ASSEMBLY


A PRESS FIT

B SLIP FIT

(X) QTY PER TRACTORS SOLD (AA.BBB.CCC.DDD) (AA) FOR 1,(BBB) 2-10 (CCC) 11-25 (DDD) 26-50

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



1	3300000M99		(X) 0.1.2.8	1	CLUTCH
2	3311396M1	!	1	1	BOX
3	3311538M92	!	1 A (X) 0.1.2.8	1	DISC
4	3300645M2	!	1 S11017	1	SUPPORT
4	3311923M1	!	1 S11018 (X) 0.0.1.2	1	PLATE
5	3311921M91	!	1 A (X) 0.1.2.8	1	KIT
6		!	5 REF.N.5	3	LEVER
7		!	5 REF.5	6	BUSH
8		!	5 REF.N.5	3	STEM
9	3300657M1	!	5	3	REGISTER
10	1441303X1	!	5	3	NUT
11	3300642M1	!	5	3	PIN
12	3300643M1	!	5 (X) 0.3.6.9	3	SPRING
13	3300644M1	!	5 (X) 0.3.6.9	3	PIN
14	1440389X1	●	1441726X1 (3) ! 5	3	DOWEL
15	1424135M93	!	1 D (X) 0.0.1.2	1	DISC
16	3311922M1	!	1	1	PLATE
17	3311920M91	!	1 D (X) 0.1.2.8	1	KIT


TRANSMISSION

E-04
02

E0402

CLUTCH - DUAL CLUTCH "O.M.G." - 11"

60 6860



18		!	17 REF.N.17	3	LEVER
19		!	17 REF.17	6	BUSH
20	3300649M1	!	17	3	STRUT
21	3300652M1	!	17	3	NUT
22	3300642M1	!	17	3	PIN
23	3300666M1	!	17	3	SPRING
24	3300644M1	!	17	3	PIN
25	1440389X1	●	1441726X1 (3) ! 17	3	DOWEL
26	3310981M2	!	1 (X) 0.1.2.8	1	SPRING
27	1440961X1	!	1 (X) 0.1.2.4	1	DOWEL
28	973013M1			6	BOLT
29	1825511M1	●	3653185M91 (1)	1	FLYWHEEL
30	339599X1			1	BEARING
31			(X) 0.1.2.4 D	6	WASHER

!	THIS IS A COMPONENT OF AN ASSEMBLY
➡	FROM SERIAL OR ENGINE NUMBER
⬅	UP TO SERIAL OR ENGINE NUMBER
➡	NOT SERVICED, ORDER
A	FOR TRANSMISSION
D	SUPPLIED BY PERKINS (SEE ENGINE SECTION)
D	FOR P.T.O.
(X)	QTY PER TRACTORS SOLD (AA.BBB.CCC.DDD) (AA) FOR 1,(BBB) 2-10 (CCC) 11-25 (DDD) 26-50

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


FENDERS FOOTSTEPS AND PLATFORM

S-22
01

60 6860

S2201

FENDERS AND PLATFORM



35	1440312X1			34	LOCK WASHER
35	1440312X1		C	32	LOCK WASHER
36	390469X1		C	16	LOCK WASHER
37	3304836M 1		C	2	RETAINER
38	3308502M 1		E	24	PLUG
39	3304833M 2	¢		1	DECAL
		@	AR114011		
40	3304833M 2	!	3	1	DECAL
		¢			
		@	AR114011		
41	3532065M 1	!	3	1	DECAL
		¢			
		@	AR114011		
42	3306263M 1	!	3	1	DECAL
		@	▼		
			AR114011		
42	3306263M 1	!	3	1	DECAL
		@	◀		
			AR114011		
43	3537793M 1			2	PLUG
44	3537794M 1			2	PLUG
46	1425837M 1			2	HANDLE
47	390972X1			4	WASHER
48	339123X1			4	SCREW
54	3309460M 1		M	1	PLUG
55	3533749M 2			2	PAD
56	3300178M 93	▶		1	PAD
57	392483X1			2	NUT


FENDERS FOOTSTEPS AND PLATFORM

S-22
02

60 6860

S2202


FENDERS - FRONT



1	390913X1	I		1	SCREW
		I	▼		
1	392241X1	I		1	SCREW
		I	◀		
2	3304590M 92	I		1	FRAME
		I	◀		
			A		
			A		
2	3304591M 92	I		1	FRAME
		I	▼		
			A		
			A		
2	3304600M 92	I		1	FRAME
		I	◀		
			A		
			A		
			G		
2	3304601M 92	I		1	FRAME
		I	▼		
			A		
			A		
			G		
2	3530502M 91	I		1	FRAME
		I	◀		
			C		
2	3530503M 91	I		1	FRAME
		I	▼		
			C		
3	339169X1	O	394367X1 (8)	8	NUT
		I			
4	339374X1	I		8	LOCK WASHER
5	390018X1	I		8	BOLT
6	3304607M 2	I		2	GUARD
			A		
			C		
			G		

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



1		⇔ P-42 04 1	1	PUMP
1		⇔ P-42 07 1 A	1	PUMP
1		⇔ P-42 05 1	1	PUMP
1		⇔ P-42 06 1 A	1	PUMP
2	1695001M2	(X) 0.2.3.4	1	GEAR
3	3308788M1		999	LOCTITE
4		D	1	SCREW
5		D	2	SCREW
6	3538871M91		1	PIPE
7	371468X1		1	O RING
8	390796X1		3	SCREW
9	339374X1		3	LOCK WASHER
11	3532598M91	(X) 1.20.40.80	1	BODY
12	3530223M92	(X) 1.2.4.10	1	CARTRIDGE
13	1007242M1		1	RING
14	3532630M1		1	COVER
15	1440086X1		3	NUT
16	339374X1		3	LOCK WASHER
17	3533143M1		1	STIRRUP
18	1442692X1		2	SCREW
19	339375X1		2	LOCK WASHER
20	3530225M92	(X) 0.1.2.4	1	SWITCH,IND
21	3535578M91		1	PIPE
22	1004637M1	(X) 0.5.10.20	1	RING


HYDRAULICS AND LINKAGE

P-42
02

HYDRAULIC EQUIPMENT - LIFT PIPINGS - FROM SERIAL NO P06077.

60 6860


P4202



23	1441757X1		2	SCREW
24	1440314X1		2	LOCK WASHER
25	3307152M1		2	SLEEVE
26	394301X1		4	CLAMP
27	3533078M91	◐ 3650529M91 (1)	1	PIPE
28	3300496M1	◐ 3300496M2 (1)	1	FLANGE
29	391980X1		3	SCREW
30	339375X1		3	LOCK WASHER
31	3019915X1		1	O RING
32	3545837M91	B	1	PIPE
33	3304523M93		1	UNION
34	851134M1	! 33	1	RING
35	3533138M91		1	SUPPORT
36	3533140M1		3	NAMEPLATE
37	339761X1		2	SCREW
38	339169X1	◐ 394367X1 (2)	2	NUT
39		! 1	1	TONGUE
40		! 1	1	WASHER
41		! 1	1	NUT
44	3307643M1	◐ 1444744X1 (1) 3000145X1 (1) 3550949M2 (1) E	1	FLANGE
44	3550949M1	◐ 3550949M2 (1) C23001 E	1	FLANGE
45	1441514X1	E	2	O RING
46	339761X1	E	2	SCREW
47	391136X1	E	2	SCREW
48	339374X1	E	4	LOCK WASHER

PREVIEW. YOUFIXTHIS.COM

Download full manual at youfixthis.com



1	ZZ90081			1	SHAFT
2		!	(X) 0.0.0.1 1 REF.1	1	SHAFT
3	81558	!	1 A	1	KIT
3	81558A	⧗ ▲	(X) 0.1.2.3 (-)0.25MM (-)0.010 A	999	BEARING
3	81558B	⧗ ▲	(-)0.50MM (-)0.020 A	999	BEARING
3	81558C	⧗ ▲	(-)0.75MM (-)0.030 A	999	BEARING
4	85042	!	1 A	1	KIT
4	85042A	⧗ ▲	(X) 0.0.1.2 (-)0.25MM (-)0.010 A	999	KIT
4	85042B	⧗ ▲	(-)0.50MM (-)0.020 A	999	KIT
4	85042C	⧗ ▲	(-)0.75MM (-)0.030 A	999	KIT
5	31137312		RTS CODE 540900 TIME 5,50	999	RING
5	31137551		RTS CODE 540900 TIME 5,50	2	WASHER
6	31137322		RTS CODE 540900 TIME 5,50	999	RING
6	31137561		RTS CODE 540900 TIME 5,50	2	WASHER
7	3242T001		D	1	RING
8	32186139		D	3	SCREW


ENGINE

A-05
04

A0504

60 6860


CRANKSHAFT, PISTONS AND CONNECTING RODS - - A4.236 ENGINE



9	ZZ90009			4	CONROD
10		!	(X) 0.0.4.8 9 REF.9	1	CONROD
11		!	9 REF.9	1	SUPPORT
12	31134123	!	9	1	THIMBLE
13	32762145	!	(X) 0.4.8.16 9	1	SCREW
14	33221328	!	(X) 0.4.8.16 9	1	NUT
15	U5LP0035		(X) 0.4.8.16 C	4	PISTON
15	U5LU0025		(X) 0.4.8.16 B	4	PISTON
16		!	(X) 0.4.8.16 15 REF.15	1	PISTON
17		!	15 REF.15	1	PIN
18	0170002	!	15	1	RING
19	0170002	!	15	1	RING
20	41158041			4	KIT
21	31171681	⚙	(X) 0.4.8.16 28	1	GEAR
22	0500012		(X) 0.1.2.4	1	KEY
23	31148798			1	PULLEY
24	33125416		E	1	WASHER
25	3552228M1	⚙	115	1	CROWNWHEEL
26	33117127			6	WASHER

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



1	3538627M93	◐	N.L.S. (1)	1	CLUTCH
2	3541349M91	!	1 D (X) 0.1.2.8	1	KIT
3	1440690X1	!	2	3	DOWEL
4	339303X1	!	2	3	DOWEL
5		!	2 REF.N.2	3	DOWEL
6		!	2 REF.N.2	3	PIN
7		!	2 REF.N.2	3	SPRING
8	3311502M91	!	2 D	1	KIT
9	3541349M91	!	1 A (X) 0.1.2.8	1	KIT
10	3541349M91	!	9	3	KIT
11		!	10 REF.N.10	3	BUSH
12	1441303X1	!	1 D	3	NUT
13	1440690X1	!	9	3	DOWEL
14	339303X1	!	9	3	DOWEL
15		!	9 REF.N.9	3	PIN
16	1441730X1	!	9	3	DOWEL
17		!	9 REF.N.9	3	SPRING
18		!	9 REF.N.9	3	LEVER
19	3311504M1	!	1	3	SCREW
20	3311942M91	!	1 A (X) 0.1.4.8	1	DISC


TRANSMISSION

E-04
03

E0403

60 6860

CLUTCH - DUAL CLUTCH "VALEO" - 12" - UP TO SERIAL NUMBER "A31058"




21	3541348M91	!	1 D	1	KIT
22	3541348M91	!	1	1	KIT
23	3002168X1	!	21	3	DOWEL
24		!	21 REF.N.21	3	PLATE
25	3311943M91	!	1 D (X) 0.1.1.8	1	DISC
26		!	1 REF.N.8 D	12	LOCK WASHER
27		!	1 REF.N.8 D	12	SCREW
28	3311949M91	◐	3541348M91 (1)	1	BASE PLATE
		!	1 A (X) 0.1.2.4		
29		!	28	3	PLATE
30	3311496M91	!	1	1	COVER
31		!	30 REF.N.30	12	BUSH

!	THIS IS A COMPONENT OF AN ASSEMBLY
◐	NOT SERVICED, ORDER
A	FOR TRANSMISSION
D	INCLUDED ON REPAIR KIT 3311502M91
D	FOR P.T.O.
(X)	QTY PER TRACTORS SOLD (AA.BBB.CCC.DDD) (AA) FOR 1,(BBB) 2-10 (CCC) 11-25 (DDD) 26-50

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



6	3304608M2	A A	2	FENDER
6	3547033M1	A	2	FENDER
7	339761X1		2	SCREW
8	339374X1		2	LOCK WASHER
11	3305982M2	355MM. A G	2	FENDER
11	3307291M1	310MM. B	2	FENDER
11	3307293M1	355MM. I	2	FENDER
12	3309370M91	B I	1	FRAME
12	3309377M91	B I	1	FRAME
12	3531151M91	A B	1	FRAME
12	3531152M91	A B	1	FRAME


FENDERS FOOTSTEPS AND PLATFORM

S-22
02

S2202

FENDERS - FRONT

60 6860



13	3536397M91	3536397M93 (1) 3536398M93 (1) A B B I	1	SUPPORT

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


HYDRAULICS AND LINKAGE

60 6860

P-42 03

P4203

HYDRAULIC PUMP - - UP TO SERIAL NUMBER P06076.



1	3539857M91	◁▷	P-42 01 1		1	PUMP
2		!	1		1	KIT
		▰	REF.N.1			
3	1493899M91	●	3539858M91	(999)	999	KIT
		!	1			
4	1429567M1	!	1		1	COVER
5	390796X1	!	1		16	SCREW
6	1429568M1	!	1		1	BASE
7	3302051M1	!	1		8	BUSH
8	1493867M91	●	3540159M91	(999)	999	KIT
		!	1			
9	1429586M1	!	8		1	SEAL
10	339361X1	!	1		1	RING
11	1440360X1	!	1		1	TONGUE
12	1442576X1	!	1		1	NUT
13	3302053M1	!	1		1	WASHER
14	979599M1	!	1		1	RING

! THIS IS A COMPONENT OF AN ASSEMBLY

◁▷ SEE PAGE - REFERENCE NUMBER

▰ NOT SERVICED, ORDER


HYDRAULICS AND LINKAGE

60 6860

P-42 04

P4204

HYDRAULIC PUMP - - FROM SERIAL NO P06077.



1	3533911M91	◁▷	P-42 02 1		1	PUMP
		◁	3534941M91			
			(X) 0.1.2.4			
2	3311521M91	●	N.L.A.	(1)	1	THIMBLE
3	3311524M91	●	N.L.S.	(1)	1	KIT
4		▰	REF.N.1		1	COVER
5	1442647X1				4	SCREW
6		▰	REF.N.1		1	COVER
7	3311523M1				4	DOWEL
8	3311522M91				1	KIT
			(X) 0.2.4.8			
9		!	8		1	RING
		▰	REF.N.8			
10	1441597X1	●	339361X1	(1)	1	RING
11	1440360X1				1	TONGUE
12	1442576X1				1	NUT
13	3302053M1				1	WASHER
14		▰	REF.N.1		1	BODY
15	3015039X1				4	SCREW
16	394869X1	!	8		2	RING

! THIS IS A COMPONENT OF AN ASSEMBLY

◁▷ SEE PAGE - REFERENCE NUMBER

◁ ALTERNATIVE

▰ NOT SERVICED, ORDER

QTY PER TRACTORS SOLD (AA.BBB.CCC.DDD) (AA) FOR 1,(BBB) 2-10 (CCC) 11-25 (DDD) 26-50

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 12 of 161 pages

The full manual includes:

- All 161 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Massey Ferguson 60 6860 Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual