





**50 8550**




| | | | | |
|---|---|---|---|---|
| 1 | 1427445M1 | ●<br>➡ | 3426523M2 (1)<br>3426654M2 (4)<br>3426831M91 (1)<br>3427163M1 (1)<br>2251753 | 1 HOUSING |
| 1 | 3302342M1 | ●<br>➡<br>➡ | 3426523M2 (1)<br>3426654M2 (4)<br>3426831M91 (1)<br>3427163M1 (1)<br>2251754<br>16795<br>A | 1 HOUSING |
| 1 | 3426121M2 | ●<br>➡<br>➡ | 3426523M2 (4)<br>3426654M2 (1)<br>3426831M91 (1)<br>16796<br>20888<br>A | 1 HOUSING |
| 1 | 3426235M2 | ●<br>➡ | 3426654M2 (1)<br>20889<br>A | 1 HOUSING |
| 2 | 392735X1 | | | 3 PLUG |
| 3 | 1823603M91 | | | 1 BREATHER |
| 4 | 1824239M92 | | | 1 BEARER |
| 5 | 1823570M2 | ! | 4 | 1 BUSH |
| 6 | 1823569M1 | | | 2 BUSH |
| 7 | 339608X1 | | | 1 GEAR |
| 8 | 1823571M1 | | | 1 RING |
| 9 | 1823542M1 | | | 1 PIN |
| 10 | 1440049X1 | | | 4 STUD |
| 11 | 1440316X1 | | | 4 WASHER |
| 12 | 1440223X1 | ● | 392416X1 (4) | 4 NUT BSF |
| 13 | 1424997M93 | | | 1 SUPPORT |




Download full manual at youfixthis.com
PREVIEW - YOUFIXTHIS.COM

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

**ACCESSORIES AND APPLICATION MISCELLANEOUS**

**50 8550**




**ROCKER ARM**

| | | | | | |
|---|---|---|---|---|---|
| 1 | ZZ90030 | | | 1 | AXLE |
| 2 | ZZ90032 | ! | 1 | 1 | SHAFT |
| 3 | 0650507 | ! | 2 | 2 | PLUG |
| 4 | 33117415 | ● | 33117434 (2) | 2 | WASHER |
| | | ! | 1 | | |
| 5 | 0170151 | ! | 1 | 2 | CIRCLIP |
| 6 | 37521331 | ● | 3818X901 (4) | 4 | SUPPORT |
| | | ! | 1 | | |
| 7 | 37371271 | ● | 4115R306 (4) | 4 | ROCKERARM |
| | | ! | 1 | | |
| | | ◄ | | | |
| 8 | 37371281 | ● | 4115R305 (4) | 4 | ROCKERARM |
| | | ! | 1 | | |
| | | ► | | | |
| 9 | 31744123 | ! | 1 | 2 | SPRING |
| 10 | 31743108 | ! | 1 | 2 | SPRING |
| 11 | 35511111 | ● | 2233022 (1) | 1 | PIPE |
| | | ! | 3775E012 (1) | | |
| | | | 1 | | |
| 12 | 33811113 | ● | 376525X1 (1) | 1 | SEAL |
| | | ! | 1 | | |
| 13 | 0726504 | ! | 1 | 1 | SETSCREW |
| 14 | 0720579 | ● | 32114145 (8) | 8 | SCREW |
| | | ! | 1 | | |
| 15 | 0576052 | ! | 1 | 8 | NUT |
| 16 | 31434163 | ● | 3142U031 (8) | 8 | TAPPET |
| 17 | 31434307 | | | 8 | ROD |
| 18 | 33117426 | ● | 3311K015 (2) | 2 | SHIM |
| | | ! | 1 | | |
| 19 | 0096634 | | | 4 | SCREW |
| 20 | 0920006 | | | 4 | WASHER |

! THIS IS A COMPONENT OF AN ASSEMBLY

◄ LEFT HAND

► RIGHT HAND



| | | | | |
|---|---|---|---|---|
| 1 | 3301722M91 | ●D<br>➡ | 3302790M91 (1)<br>3302791M91 (1)<br>3302792M91 (1)<br>3302793M91 (1)<br>3302794M92 (1)<br>3302795M91 (1)<br>N.L.A. (3)<br>1250597/2252615 | 1 FRAME |
| 1 | 3304208M91 | ●D<br>➡ | N.L.A. (1)<br>1250598/2252616 | 1 FRAME |
| 2 | 3301726M1 | | | 1 GASKET |
| 3 | 1426995M1 | | | 4 EYELET |
| 4 | 1427768M1 | | | 4 WASHER |
| 5 | 3301571M1 | | | 14 GUARD |
| 6 | 339124X1 | | | 20 SCREW |
| 7 | 3301745M1 | ●D | 391039X1 (18) | 18 WASHER |
| 8 | 390972X1 | | | 16 WASHER |
| 9 | 3301742M1 | | | 20 WASHER |
| 10 | 3301764M91 | | | 1 SUPPORT |
| 11 | 3301754M91 | ◀ | | 1 BEARER |
| 11 | 3301756M91 | ●D<br>▶ | N.L.A. (1) | 1 SUPPORT |
| 12 | 1441134X1 | | | 16 SCREW |
| 13 | 1440314X1 | | | 16 WASHER |
| 14 | 390734X1 | | | 16 WASHER |
| 15 | 3301801M91 | ➡ | 398<br>C | 1 SUPPORT |
| 15 | 3303065M92 | ●D<br>➡ | N.L.A. (1)<br>399<br>C | 1 SUPPORT |
| 16 | 1441134X1 | | | 8 SCREW |
| 17 | 1440314X1 | | | 8 WASHER |
| 18 | 1427089M1 | | | 2 PLUG |



PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com

PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com

## ACCESSORIES AND APPLICATION MISCELLANEOUS



## DISTRIBUTOR

**50 8550**





| | | | | | |
|---|---|---|---|---|---|
| 1 | 3303090M92 | ● | 3306467M97 (1) | 1 | VALVE |
| 2 | 1427247M91 | ! | 1 | 1 | PISTON |
| 3 | 1825248M1 | ! | 1 | 1 | SPRING |
| 4 | 1441267X1 | ! | 1 | 1 | SCREW |
| 5 | 3301057M91 | ● | 3304561M92 (1) | 1 | VALVE |
| | | ! | 1 | | |
| 6 | | ! | 5 | 1 | BUSH |
| | | ⇨ | 3301057M91 | | |
| 7 | | ! | 5 | 1 | VALVE |
| | | ⇨ | 3301057M91 | | |
| 8 | 1825253M1 | ! | 5 | 1 | SPRING |
| 9 | 1825254M1 | ● | 1825254M2 (1) | 1 | SEAT |
| | | ! | 5 | | |
| 10 | 1441211X1 | ! | 5 | 2 | SEAL |
| 11 | 1441514X1 | ! | 1 | 1 | SEAL |
| 12 | 1442477X1 | ! | 1 | 1 | O RING |
| 13 | 3301059M1 | ! | 1 | 1 | NUT |
| 14 | 3300158M2 | ! | 1 | 1 | LEVER |
| 15 | 3006467X1 | ! | 1 | 1 | ROLL PIN |
| 16 | 1442012X1 | ● | 1440399X1 (1) | 1 | PIN |
| 17 | 1825257M1 | ● | N.L.A. (1) | 1 | COVER |
| | | ! | 1 | | |
| 18 | 1441127X1 | ● | 3019926X1 (1) | 1 | O RING |
| | | ! | 1 | | |
| 19 | 391148X1 | ! | 1 | 4 | SCREW |
| 20 | 1825258M1 | ! | 1 | 1 | VALVE |
| 21 | 1825259M1 | ! | 1 | 1 | SPRING |
| 22 | 1825260M1 | ! | 1 | 1 | SEAT |
| 23 | 395593X1 | ! | 1 | 1 | PLUG |
| 24 | 395592X1 | ! | 1 | 1 | GASKET |
| 25 | 1825261M1 | ! | 1 | 1 | VALVE |
| 26 | 1825262M1 | ! | 1 | 1 | SPRING |

PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com






## FRONT FENDERS

| | | | | | |
|---|---|---|---|---|---|
| 1 | 1442190X1 | | D<br>F | 4 | NUT BSF |
| 2 | 3102005M1 | ●●<br>▶ | N.L.A. (1) | 1 | SUPPORT |
| | | | D<br>F | | |
| 2 | 3102006M1 | ●●<br>◀ | N.L.A. (1) | 1 | SUPPORT |
| | | | D<br>F | | |
| 3 | 339169X1 | ●● | 394367X1 (10)<br>D<br>F | 10 | NUT BSF |
| 4 | 339374X1 | | D<br>F | 10 | LOCK WASHER |
| 5 | 390018X1 | | D<br>F | 10 | BOLT |
| 6 | 1726060M1 | ●● | 3307291M1 (2)<br>D<br>F | 2 | FENDER |
| 7 | 3102007M1 | ●●<br>▶ | N.L.A. (1) | 1 | SUPPORT |
| | | | D<br>F | | |
| 7 | 3102008M1 | ●●<br>◀ | N.L.A. (1) | 1 | SUPPORT |
| | | | D<br>F | | |
| 8 | 3005455X1 | | D<br>F | 8 | SCREW |
| 9 | 1442285X1 | | D<br>F | 4 | SCREW |
| 10 | 1441473X1 | ●●<br>⇉<br>◀ | 3426884M1 (1)<br>1250629<br>G | 1 | SCREW |



## REAR AXLE-HOUSING




| | | | | | |
|---|---|---|---|---|---|
| 1 | 1423590M2 | | C | 2 | SUPPORT |
| 1 | 3304648M1 | ► | | 1 | AXLE HOUSING |
| | | | A #H | | |
| | | | E #H | | |
| 1 | 3304649M1 | ◄ | | 1 | AXLE HOUSING |
| | | | A #G | | |
| | | | E #G | | |
| 2 | 1440695X1 | | | 4 | PIN |
| 3 | 1441256X1 | ●● | 3306228M1 (2) | 2 | SEAL |
| | | | C | | |
| 3 | 392190X1 | | E | 4 | SEAL |
| 4 | 392735X1 | | E | 4 | PLUG |
| 5 | 3000253X1 | | E | 16 | SCREW |
| 5 | 395091X1 | | C | 22 | SCREW |
| 6 | 1824723M3 | ▲ | 67 | 2 | GEAR |
| 7 | 1824724M1 | | | 2 | SPACER |
| 8 | 1824722M3 | | | 2 | HUB |
| 9 | 1434760M1 | | A | 12 | STUD |
| 9 | 975124M1 | | A | 12 | STUD |
| 10 | 392501X1 | | | 12 | NUT |
| 11 | 1440547X1 | | | 2 | BEARING BALL |
| 12 | 975127M1 | | | 2 | SEAL |
| 13 | 1440521X1 | | | 2 | CIRCLIP |
| 14 | 1440561X1 | | | 2 | BEARING BALL |
| 15 | 1824725M1 | | | 2 | SPACER |
| 16 | 1442355X1 | | | 2 | CIRCLIP |
| 17 | 1824727M1 | | | 2 | COVER |
| 18 | 3308788M1 | | | 999 | LOCTITE |
| 19 | 339091X1 | | | 26 | SCREW |
| 20 | 3304650M1 | | E | 2 | O RING |
| 21 | 3304695M1 | | E | 4 | STUD |
| 22 | 339079X1 | | E | 4 | NUT |
| 23 | 3304296M1 | ●● | 3308788M1 (999) | 999 | GASKET |
| | | ◇ | 76 | | |




PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com



50 8550






| | | | | | |
|---|---|---|---|---|---|
| 1 | ZZ90009 | ● | M7BJ0015 | 4 | KIT |
| 2 | 32762116 | ● | 32762145 (8) | 8 | BOLT |
| 3 | 33221328 | | | 8 | NUT |
| 4 | 31134123 | | | 4 | BUSH |
| 5 | 89207 | ➡ | 248U839079J | 4 | KIT |
| 5 | U5LP0009 | ➡ | 248U839080J C | 4 | KIT |
| 5 | U5LU0005 | | B | 4 | KIT |
| 6 | 0170002 | ! | 5 | 8 | CIRCLIP |
| 7 | 41158022 | ➡ | 248U839080J | 4 | KIT |
| 7 | 41158038 | ● ➡ | 4181A009 (4) 248U839079J | 4 | KIT |
| 8 | U5BG0024 | ● | ZZ90081 (1) | 1 | KIT |
| 9 | 81558 | ! | 8 A | 1 | KIT |
| 9 | 81558A | ⧗ | -0,254MM. A | 999 | KIT |
| 9 | 81558B | ⧗ | -0,508MM. A | 999 | KIT |
| 9 | 81558C | ⧗ | -0,762MM. A | 999 | KIT |
| 10 | 85042 | ! | 8 A | 1 | KIT |
| 10 | 85042A | ⧗ | -0,254MM. A | 999 | KIT |
| 10 | 85042B | ⧗ | -0,508MM. A | 999 | KIT |
| 10 | 85042C | ⧗ | -0,762MM. A | 999 | KIT |
| 11 | 31137312 | ⧗ | +0,178MM. | 999 | WASHER |
| 11 | 31137551 | ! | 8 | 2 | WASHER |
| 12 | 31137322 | ⧗ | +0,178MM. | 999 | WASHER |

Download full manual at youfixthis.com


PREVIEW - YOUFIXTHIS.COM

PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com

## ACCESSORIES AND APPLICATION MISCELLANEOUS

**50 8550**



## CAB




| | | | | |
|---|---|---|---|---|
| | | | A | |
| 1 | 3301758M92 | ● | N.L.A. (1) | 1 COVER |
| 2 | 3301762M1 | ● | N.L.A. (1) | 1 OVERLAY |
| 3 | 392403X1 | ● | 3015126X1 (4) | 4 SCREW |
| 4 | 1427000M1 | | | 4 WASHER |
| 5 | 3301763M91 | ● | N.L.A. (1) | 1 GUARD |
| 6 | 3301019M1 | | | 2 HANDLE |
| 7 | 1442705X1 | | | 4 BOLT |
| 8 | 3300993M1 | | C | 2 CLIP |
| 8 | 3300993M1 | | B | 4 CLIP |
| 9 | 339124X1 | | B | 4 SCREW |
| 9 | 339124X1 | | B | 8 SCREW |
| 10 | 390972X1 | | | 8 WASHER |
| 11 | 3301745M1 | ● | 391039X1 (8) | 8 WASHER |
| 12 | 339169X1 | ● | 394367X1 (8) | 8 NUT BSF |
| 13 | 3301571M1 | | | 8 GUARD |
| 14 | 3301727M91 | ● | N.L.A. (1) | 1 COVER |
| 15 | 3301731M1 | | | 1 GASKET |
| 16 | 3301768M1 | | | 1 GASKET |
| 17 | 3301736M91 | ◄ | | 2 HINGE |
| 17 | 3301739M91 | ● ► | 3301739M92 (2) | 2 HINGE |
| 19 | 3301741M1 | | | 4 WASHER |
| 20 | 339124X1 | | | 8 SCREW |
| 21 | 3301742M1 | | | 8 WASHER |
| 22 | 3301617M91 | ● | 3310461M91 (2) B | 2 DAMPER |
| 999 | GLASS | | | |



## STEERING CONTROL VALVE


**50 8550**





| | | | | | |
|---|---|---|---|---|---|
| 2 | 1426418M92 | | | 1 | NON RETURN |
| 3 | 1809696M91 | | | 1 | DISTRIBUTOR |
| 5 | | ! | 3 | 1 | BODY |
| | | ⇨ | 1809696M91 | | |
| 6 | 1887719M1 | ! | 3 B | 1 | SEAL |
| 7 | 1806314M1 | ! | 3 B | 1 | SEAL |
| 8 | 1887718M1 | ! | 3 B | 1 | SEAL |
| 9 | 1887717M1 | ! | 3 B | 1 | SEAL |
| 10 | 1806311M1 | ! | 3 | 1 | BALL |
| 11 | 1806313M1 | ! | 3 | 1 | SEAL |
| 12 | 1887721M1 | ! | 3 | 1 | BEARING |
| 13 | 1887720M1 | ! | 3 | 1 | WASHER |
| 14 | 1887722M1 | ! | 3 | 1 | WASHER |
| 15 | | ! | 5 | 1 | VALVE |
| | | ⇨ | 1809696M91 | | |
| 16 | | ! | 5 | 1 | VALVE |
| | | ⇨ | 1809696M91 | | |
| 17 | 1806303M1 | ! | 3 | 1 | BUSH |
| 18 | 1806305M1 | ●○ | 1894415M1 (6) | 6 | SPRING |
| | | ! | 3 | | |
| 19 | 1806416M1 | ! | 3 | 1 | SHAFT |
| 20 | 1806310M1 | ! | 3 | 1 | PIN |
| 21 | 1806319M1 | ! | 3 | 1 | PLATE |
| 22 | 1806315M1 | ! | 3 B | 1 | SEAL |
| 23 | 1887733M91 | ●○ | 1887733M1 (1) | 1 | ROTOR |
| | | ! | 3 | | |
| 24 | 1887732M1 | ! | 3 | 1 | BUSH |
| 25 | 1806315M1 | ! | 3 B | 1 | SEAL |



Download full manual at youfixthis.com
PREVIEW - YOUFIXTHIS.COM




## FENDERS AND PLATFORM





| | | | | | |
|---|---|---|---|---|---|
| 1 | 1427550M93 | ● | N.L.A. (1) | 1 | FENDER |
| | | ◀ | | | |
| 2 | 1427553M93 | ● | N.L.A. (1) | 1 | FENDER |
| | | ▶ | | | |
| 3 | 3300221M1 | ◀ | | 1 | SHIELD |
| 3 | 3300386M1 | ▶ | | 1 | SHIELD |
| 4 | 391074X1 | | | 12 | SCREW |
| 5 | 391130X1 | ● | 339375X1 (12) | 12 | WASHER |
| 6 | 1427556M91 | ● | N.L.A. (1) | 1 | SUPPORT |
| | | ➡ | 1250475/2250797 | | |
| 6 | 3302005M94 | ➡ | 1250476/2250798 | 1 | SUPPORT |
| 7 | 339124X1 | | | 2 | SCREW |
| 8 | 1440313X1 | ● | 339374X1 (2) | 2 | WASHER |
| 9 | 390972X1 | | | 2 | WASHER |
| 10 | 339401X1 | | | 10 | SCREW |
| 11 | 390734X1 | | | 10 | WASHER |
| 12 | 1440314X1 | | | 10 | WASHER |
| 13 | 392293X1 | ● | 339402X1 (10) | 10 | NUT |
| 14 | 1427564M1 | | | 1 | PLATE |
| 15 | 339124X1 | | | 7 | SCREW |
| 16 | 1440313X1 | ● | 339374X1 (7) | 7 | WASHER |
| 17 | 390972X1 | | | 7 | WASHER |
| 18 | 1425837M1 | | | 2 | HANDLE |
| 19 | 390972X1 | | | 4 | WASHER |
| 20 | 339124X1 | | | 4 | SCREW |
| 21 | 1427588M92 | ● | N.L.A. (1) | 1 | PLATFORM |
| 22 | 339124X1 | | | 12 | SCREW |
| 23 | 1440313X1 | ● | 339374X1 (12) | 12 | WASHER |



Download full manual at youfixthis.com
PREVIEW - YOUFIXTHIS.COM



## CYLINDER BLOCK




| | | | | | |
|---|---|---|---|---|---|
| 1 | ZZ50076 | ➡| | | 1 | KIT |
| 1 | ZZ50116 | |➡ | | 1 | KIT |
| 2 | 33142111 | ! | 1 | | 10 | THIMBLE |
| 3 | 32166329 | ! | 1 | | 10 | BOLT |
| 4 | 31358346 | ! | 1 | | 4 | LINER |
| | | ➡| | U08336N A | | |
| 4 | 31358352 | ➡| | U08336N B | 999 | LINER |
| 4 | 3135X033 | ! | 1 | | 4 | LINER |
| | | |➡ | U08337N A | | |
| 4 | 3135X034 | |➡ | U08337N B | 999 | LINER |
| 5 | 0650618 | ●● | 32418117 (4) | | 4 | PLUG |
| | | ! | 1 | | | |
| 6 | 0650563 | ! | 1 | | 6 | PLUG |
| 7 | 0650563 | ! | 1 | | 2 | PLUG |
| 8 | 0650577 | ●● | 32416118 (4) | | 4 | PLUG |
| 9 | 0650588 | | | | 2 | PLUG |
| 11 | 32417134 | | | | 1 | PLUG |
| 12 | 2485A204 | ! | 1 | | 1 | PLUG |
| 13 | 32416105 | ●● | 32416119 (1) | | 1 | PLUG |
| 14 | 0650582 | | | | 1 | PLUG |
| 15 | 0920130 | | | | 1 | WASHER |
| 16 | 0650588 | | | | 1 | PLUG |
| 17 | 0650594 | |➡ | | 1 | PLUG |
| 17 | 2431131 | ➡| | | 1 | PLUG |
| 18 | 1423895M91 | ●● | 1877721M92 (1) | | 1 | SWITCH |
| | | ➡| | 1250754/2253781 | | |
| 18 | 1877721M92 | |➡ | 1250755/2553782 | 1 | PRESSURE S |
| 19 | 31134132 | ●● | 31134165 (1) | | 1 | BUSH |



PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

**ACCESSORIES AND APPLICATION MISCELLANEOUS**

**50 8550**

**SEAT**



| | | | | | |
|---|---|---|---|---|---|
| 1 | 3302385M91 | ●○ | 339124X1 (4)<br>3546859M91 (1)<br>3549755M91 (4)<br>390972X1 (1) | 1 | CUSHION |
| 2 | 3101653M1 | ! | 1 | 2 | PLUG |
| 3 | 3101494M1 | ! | 1 | 2 | BUSH |
| 4 | 3101989M1 | ! | 1 | 1 | FRAME |
| 5 | 3102293M1 | ! | 1 | 1 | GASKET |
| 6 | 3101659M1 | ! | 1 | 1 | BACK REST |
| 7 | 3101508M1 | ! | 1 | 1 | SPACER |
| 8 | 3101507M1 | ●○<br>! | N.L.A. (1)<br>1 | 1 | PLATE |
| 9 | 3101509M1 | ! | 1 | 4 | SPACER |
| 10 | 3101663M1 | ! | 1 | 4 | WASHER |
| 11 | 390972X1 | ! | 1 | 4 | WASHER |
| 12 | 339337X1 | ! | 1 | 4 | SCREW |
| 13 | 3101522M1 | ! | 1 | 2 | LOCK WASHER |
| 14 | 353559X1 | ! | 1 | 2 | SCREW |
| 15 | 3101656M1 | ! | 1 | 4 | SCREW |
| 16 | 3101510M1 | ! | 1 | 2 | PLATE |
| 17 | 3101657M1 | ●○<br>! | N.L.S. (1)<br>1 | 1 | FRAME |
| 18 | 3103619M1 | ! | 1 | 1 | GASKET |
| 19 | 3101658M1 | ! | 1 | 1 | CUSHION |
| 20 | 3101515M1 | ! | 1 | 1 | PLATE |
| 21 | 390881X1 | ! | 1 | 1 | NUT BSF |
| 22 | 390734X1 | ! | 1 | 1 | WASHER |
| 23 | 3101511M1 | ! | 1 | 1 | SPACER |
| 24 | 3101495M1 | ! | 1 | 1 | PIN |
| 25 | 1719928M1 | ! | 1 | 1 | GUIDE |
| 27 | 391025X1 | ! | 1 | 10 | LOCK WASHER |
| 28 | 339043X1 | ●○<br>! | 3008302X1 (4)<br>1 | 4 | SCREW |

PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com

## ACCESSORIES AND APPLICATION MISCELLANEOUS



**50 8550**

## AUXILIARY DISTRIBUTOR




| | | | | |
|---|---|---|---|---|
| 1 | 1426921M92 | | 1424273M91 (2)<br>1424317M2 (2)<br>1424666M91 (2)<br>A | 2 DISTRIBUTOR |
| 1 | 1426921M92 | | 1424273M91 (3)<br>1424317M2 (3)<br>1424666M91 (3)<br>B | 3 DISTRIBUTOR |
| 2 | | !<br>⇨<br>⇨ | 1<br>1426921M92<br>1426921M92<br>A<br>B | 3 BODY |
| 3 | 1426831M1 | !<br>! | N.L.A. (3)<br>1<br>B | 3 COVER |
| 3 | 1426831M1 | !<br>! | N.L.A. (2)<br>1<br>A | 2 COVER |
| 4 | | !<br>⇨ | 1<br>1426921M92<br>B | 3 PISTON |
| 4 | | !<br>⇨ | 1<br>1426921M92<br>A | 2 PISTON |
| 5 | 1426835M1 | !<br>! | N.L.A. (3)<br>1<br>B | 3 SEAT |
| 5 | 1426835M1 | !<br>! | N.L.A. (2)<br>1<br>A | 2 SEAT |
| 6 | 1426836M1 | !<br>! | N.L.A. (2)<br>1<br>A | 2 GASKET |

PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com

## ACCESSORIES AND APPLICATION MISCELLANEOUS



**50 8550**

## FENDERS AND PLATFORM BRACKETS





| | | | | | |
|---|---|---|---|---|---|
| 1 | 1427608M1 | ●● | 1427608M3 (2) | 2 | SUPPORT |
| 1 | 3302155M2 | | C | 2 | SUPPORT |
| 2 | 1427609M2 | ▲ | | 1 | PLATE |
| 3 | 1427610M2 | ▼ | | 1 | PLATE |
| 4 | 1440421X1 | ●● | 3019928X1 (8) | 8 | BOLT |
| 4 | 393542X1 | | C | 8 | SCREW |
| 5 | 391414X1 | | | 8 | WASHER |
| 6 | 1440202X1 | | | 8 | NUT BSF |
| 7 | 1425984M91 | | | 4 | DAMPER |
| 8 | 339081X1 | | | 8 | SCREW |
| 9 | 1440314X1 | | | 8 | WASHER |
| 10 | 392293X1 | ●● | 339402X1 (8) | 8 | NUT |
| 11 | 1426415M91 | | | 4 | SPACER |
| 12 | 1427601M93 | ●● ◄ | 3533168M91 (1) | 1 | SUPPORT |
| 12 | 1427602M93 | ●● ► | 3533169M91 (1) | 1 | SUPPORT |
| 13 | 3009847X1 | | B | 4 | BOLT |
| 13 | 390780X1 | | A | 4 | STUD |
| 14 | 391414X1 | | | 4 | WASHER |
| 15 | 339623X1 | | B | 4 | NUT BSF |
| 16 | 339275X1 | | | 8 | SCREW |
| 17 | 391414X1 | | | 8 | WASHER |

| | |
|---|---|
| A | UP TO SERIAL OR ENGINE NUMBER |
| B | FROM SERIAL OR ENGINE NUMBER |
| C | WITH HEAVY DUTY REDUCER |
| ▲ | TOP |
| ▼ | LOWER COMPONENT |
| ◄ | LEFT HAND |
| ► | RIGHT HAND |





## CYLINDER FOR HYDRAULIC LIFT




| | | | | |
|---|---|---|---|---|
| 21 | 395592X1 | | 2 | GASKET |
| 22 | 3303277M1 | | 1 | PLUG |
| 23 | 3304694M1 | A | 8 | SCREW |
| 23 | 395091X1 | | 14 | SCREW |

 SEE PAGE - REFERENCE NUMBER

A USED ONLY WITH WET BRAKES

◀ LEFT HAND

▶ RIGHT HAND




Download full manual at youfixthis.com
PREVIEW - YOUFIXTHIS.COM



50 8550

## LUBRICATING OIL FILTER





| | | | | | |
|---|---|---|---|---|---|
| 1 | 37764181 | | | 1 | FILTER HEAD |
| 2 | 2654403 | | | 1 | CARTRIDGE |
| 3 | 36862517 | ● | 36862206 (1) | 1 | UNIVERSAL |
| 4 | 2184454 | ● | 0746610 (2) | 2 | BOLT |
| | | ● | 0746610 | | |
| 5 | 33115118 | | | 2 | WASHER |
| 6 | 33286126 | ! | 1 | 1 | BOLT |

! THIS IS A COMPONENT OF AN ASSEMBLY

● REPAIRS AND REPLACES



PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com



| | | | | | |
|---|---|---|---|---|---|
| 24 | 3530074M91 | | ITEM 24A | 1 | GUARD |
| 25 | 1423682M3 | | | 1 | SLEEVE |
| 26 | 339469X1 | | | 1 | SEGMENT |
| 27 | 1423687M1 | ● | 1423687M3 (1) | 1 | LEVER |
| 28 | 3019914X1 | | | 1 | O RING |
| 29 | 974435M2 | | | 1 | SPRING |
| 30 | 974436M1 | ● | 974436M2 (1) | 1 | LEVER |
| 31 | 1423686M2 | | | 1 | SELECTOR |
| 32 | 339123X1 | | | 1 | SCREW |
| 33 | 3300074M92 | ● | 3304580M92 (1) B | 1 | LEVER |
| 33 | 3304580M91 | ● | 3304580M92 (1) C | 1 | LEVER |
| 34 | 339071X1 | | | 1 | PIN |
| 35 | 392321X1 | | | 1 | PIN |
| 36 | 390734X1 | | | 1 | WASHER |
| 37 | 3300077M91 | | | 1 | STEM |
| 38 | 3300078M1 | | | 1 | BUSH |
| 39 | 392293X1 | ● | 339402X1 (1) | 1 | NUT |
| 40 | 1425728M91 | | | 1 | KNOB |

➡ UP TO SERIAL OR ENGINE NUMBER

B UP TO SERIAL OR ENGINE NUMBER 1250707, 2 WHEEL DRIVE , UP TO SERIAL OR ENGINE NUMBER 2253170 25 KM/H, 4 WHEEL DRIVE , UP TO SERIAL OR ENGINE NUMBER 12500121, 2 WHEEL DRIVE , UP TO SERIAL OR ENGINE NUM

C FROM SERIAL OR ENGINE NUMBER 1250708, 2 WHEEL DRIVE , FROM SERIAL OR ENGINE NUMBER 2253171 25 KM/H, 4 WHEEL DRIVE , FROM SERIAL OR ENGINE NUMBER 12500122, 2 WHEEL DRIVE , FROM SERIAL OR ENGINE NUMBER

● NUMBER OF TEETH/SPLINES



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

# PREVIEW ONLY

You're viewing 17 of 313 pages

## The full manual includes:

- All 313 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

**GET FULL MANUAL NOW**

**Landini 50, 8550 Parts Catalog**

**Scan or click anywhere**
**youfixthis.com**

*Click anywhere on this page to get the full manual*