



	353527X1	●	0096236 (1) L. N7832, M. 0096236	1	SCREW
1	736340M91		L. 31215, M. 84636	1	CYLINDER B
2	731022M1		L. 27374, M. 0870001	10	RING
3	375722X1	●	32181441 (10) L. N7920, M. 0745105	10	SCREW
4	735865M1	●	0650563 (7) L. N7633, M. 0650563	7	PLUG
5	731354M1	●	0650710 (1) L. N7626, M. 0650710	1	PLUG
6	733067M1	●	0650588 (1) L. N8370, M. 0650588	1	PLUG
7	1434175M1		L. 28057, M. 31358322	4	BARREL
8	731356M1		L. N7624, M. 0650566	2	PLUG
9	1851764M1	●	31419 (1) L. 30142, M. 31419	1	COCK
10	346305X1		L. N7292, M. 0610904	1	DOWEL
11	731312M1		L. N6003, M. 0350015	2	DOWEL
12	731434M1	●	0350018 (2) L. N6004, M. 0350018	2	DOWEL
13	734308M1		L. N3675, M. 32524132	8	STUD
14	734266M1		L. N3674, M. 32524131	4	STUD
15	734309M1		L. N3661, M. 32524133	11	STUD
16	376506X1	●	33221327 (23) L. N7985, M. 33221315	23	NUT

Download full manual at youfixthis.com


PREVIEW - YOUFIXTHIS.COM

DISTRIBUTOR per sollevatore idraulico



	1821263M91		Z	999	VALVE
	977661M92		L. 26826	1	VALVE
	977671M91	●	N.L.A. (1) L. 26821	1	DISTRIBUTOR
	978710M91	●	N.L.A. (1) L. 23297	1	LIFT
1	978651M91		A 19 Y1 19 Y1 19	1	BODY
2	977663M92		L. 26827	1	VALVE
3	978692M1		L. 23156	1	SPRING
4	978693M1	●	N.L.A. (1) L. 23157	1	SEAT
5	977666M1	●	N.L.A. (1) L. 26816	1	PLATE
6	394913X1	●	N.L.A. (1) L. N8725	1	GASKET
7	391862X1	●	392097X1 (2) L. N654	2	BOLT
8	1440314X1		L. N3817	2	WASHER
9	977667M1	●	N.L.A. (1) L. 26815	1	CYLINDER
10	974464M1	●	N.L.A. (1) L. 34038	1	CYLINDER B
11	974465M1	●	N.L.A. (1) L. 34045	1	CONROD
12	1441132X1	●	3019914X1 (1) L. N4726	1	SEAL
13	977668M2	●	N.L.A. (1) L. 23115	1	RETAINER
14	393731X1		L. N8492	1	BOLT
15	977669M2		L. 26824	1	PLATE
16			A	1	VALVE
17	977672M1		L. 26822	1	BODY

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com




1440477X1	●	392758X1 (2) Z5	2	RING
1441990X1	●	N.L.A. (1) Z3	1	SHIM
1818256M2			1	SHIM
1818257M2			1	SHIM
1818258M2			1	SHIM
1818259M2			1	SHIM
1818260M2	●	1818261M2 (1)	1	SHIM
1818261M2			1	SHIM
1818262M2			1	SHIM
1818263M2			1	SHIM
1818264M2	●	N.L.A. (1)	1	SHIM
1818266M1			1	SHIM
1818267M1			1	SHIM
1818268M1			1	SHIM
1818269M1	●	N.L.A. (1)	1	SHIM
1818270M1			1	SHIM
1818271M1			1	SHIM
1818272M1			1	SHIM
1818273M1			1	SHIM
1818274M1			1	SHIM
1818275M1			1	CLIP
1818277M2	●	N.L.A. (1)	1	SUPPORT
1818278M2	●	N.L.A. (1)	1	CUP
1818279M2			1	CIRCLIP
1818280M2	●	N.L.A. (1)	1	FERRULE
1818281M2			1	FERRULE

Download full manual at youfixthis.com


PREVIEW - YOUFIXTHIS.COM

TRACK CARRIER




	1818442M91	●	N.L.A. (1)	1 SUPPORT
	975818M1	●	N.L.A. (1998) L. 26256/20	999 SUPPORT
	975819M1	●	N.L.A. (2997) L. 26256/30	999 CARRIAGE
	975829M1		L. 20629	999 SHIM
	978741M92		Z L. 26983	1 SHIM
	978742M92	●	N.L.A. (1) Z2 L. 26991	1 SHIM
	978743M92	●	N.L.A. (1) Z2 L. 26992	1 SUPPORT
1	1818441M91			1 CARRIAGE
2	1818363M1			4 BUSH
3	1818364M1			2 GASKET
4	1818800M1			2 PLATE
5	339124X1		L. N429	4 SCREW
6	393486X1	●	339608X1 (2) L. N6466	2 PLUG
6	973492M3	●	1821580M1 (2) ITEM 6A L. 25770	2 GREASER
7	974809M1		L. N4840	16 PLUG
8	1818365M1	●	N.L.A. (2)	2 WASHER
9	1440395X1	●	N.L.A. (2) L. N6100	2 DOWEL
10	976394M1		L. 20237	2 WASHER
11	975828M1	●	N.L.A. (999) L. 20628	999 SHIM
12	975814M2	●	N.L.A. (2) L. 26255	2 COVER

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com




HITCH

Cingolati Meccanici C6000




	1818893M91		L. 23865	1	BEARER
	1820897M91			1	HITCH
	1821261M91			1	HITCH
1	977042M91	●	N.L.A. (1) L. 26327	1	TOGGLE
2	977043M91		L. 26329	1	TOGGLE
3	977044M91		L. 26331	1	TENSIONER
4	974654M2		L. 34317	1	NUT
5	979392M91	●	N.L.A. (1) L. 23292	1	PIN
6	974631M93	●	1426056M91 (1) L. 34340	1	CLIP
7	1819500M91			2	BAR
8	1818885M91		L. 23863	1	SUPPORT
9	391375X1		L. N811	4	SCREW
10	1440315X1		L. N3818	4	WASHER
11	390419X1		L. N518	2	WASHER
11	391414X1		ITEM 11A L. 3820	2	BOLT
12	1434030M91	●	N.L.A. (2)	2	DRAGLINK
13	977051M91	●	N.L.A. (2) L. 26339	2	LINK
14	977052M91	●	N.L.A. (2) L. 26341	2	FORK
15	1818886M1	●	N.L.A. (2) L. 23862	2	HOUSING
16	392833X1		L. N1933	2	NUT
17	974642M1		L. 34361	2	PIN
18	974303M1		L. 34363	2	PIN
19	1817326M1	●	3307057M1 (2) L. 23850	2	PIN
20	1440280X1	●	N.L.A. (2) L. N3763	2	WASHER

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com



TRANSMISSION CASE



24	1819219M1	●	3308788M1 (1) ITEM 24A	1	GASKET
24	1820476M2	●	N.L.A. (1) B	1	CLUTCH
25	339053X1		L. N485	10	BOLT
26	339403X1		L. N487	2	SCREW
27	1440315X1		L. N3818	12	WASHER
28	1440035X1	●	974428M1 (4) L. N2905	4	STUD
29	1440089X1		L. N888	4	NUT BSF
30	973169M1		L. 20469	2	WASHER
31	973163M1	●	N.L.A. (2) L. 11134	2	BUSH
32	973164M1		Z1 L. 25056	1	POINTER
33	1400446X1		Z1 L. N4890	2	POINTER
34	973165M1	●	N.L.A. (1) L. 25057	1	PLATE
35	339124X1		L. N429	2	SCREW
36	1440313X1	●	339374X1 (2) L. N3816	2	WASHER
37	973166M1		L. 25106	1	COVER
38	339124X1		L. N429	4	SCREW
39	393988X1		L. N8327	1	PLUG
40	1441499X1	●	N.L.A. (1) L. N6267	1	RING
41	392003X1	●	392766X1 (1) L. N3	1	PLUG
42	1440784X1		L. N8925	1	GASKET
43	973820M1		L. N7270	4	CAP

A ◘

B ◘

Z1 ◘


Download full manual at youfixthis.com

PREVIEW - YOUFIXTHIS.COM


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Comando cambio velocità




42	1441737X1	●	1441738X1 (1) L. N70114	1	PIN
43	1441740X1	●	339248X1 (1) L. N70119	1	PIN




HAND BRAKE

Cingolati Meccanici C6000




63	976421M1	●	N.L.A. (1) L. 20423	1	LEVER
64	1818454M1		Z	1	LEVER
65	394799X1		L. N4819	2	SCREW
66	1440209X1	●	392310X1 (2) L. N920	2	NUT BSF
67	1818451M91		Z	1	TIE ROD
68	1440940X1		L. N60637	1	PIN
69	390739X1	●	390446X1 (2) L. N3926	2	PIN
70	977799M91	●	977799M92 (1) L. 25519	1	SUPPORT
71	339299X1		L. N477	2	SCREW
72	1440315X1		L. N3818	2	WASHER
73	1440088X1	●	1440200X1 (2) L. N886	2	NUT
Z		◘			
Z1		◘			

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com




JACK ASSEMBLY



21	974506M1	●	N.L.A. (1) ITEM 21A L. 34091	1 BUSH
22	1441128X1		L. N4722	2 SEAL
23	1441129X1		L. N4723	2 SEAL
24	1440816X1	●	N.L.A. (2) L. N8451	2 SCREW
25	375794X1	●	1444744X1 (2) L. N6262	2 WASHER
26	1441495X1		L. N2	1 PLUG
27	1440731X1		L. N8923	1 WASHER
28	977681M1	●	N.L.A. (1) L. 26848	1 CYLINDER
29	977682M1		L. 26849	1 UNIVERSAL
30	974508M1		L. 34114	1 PISTON
31	974509M1		L. N7076	1 GASKET
32	974510M1	●	N.L.A. (1) L. 34117	1 DISC
33	339065X1		L. N4558	1 BEARING BALL
34	977683M1	●	N.L.A. (1) L. 26897	1 ROD
35	974512M1		L. 34103	1 PIN
36	974513M1		L. 34104	1 PIN
37	339081X1		L. N453	1 SCREW
38	974514M1		L. 34105	1 SCREW
39	974515M1	●	N.L.A. (1) L. 34106	1 LEVER
40	977684M1		L. 26867	1 CAM
41	977685M1		L. 26864	1 CAM
42	977686M1		L. 26865	1 LEVER
43	977687M1		L. 26866	2 RING
44	1440532X1	●	N.L.A. (1) L. N4559	1 RING
45	974518M1	●	N.L.A. (2) L. 34109	2 WASHER

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com




22	732824M1		L. 31013, M. 33817114	4 SHIELD
23	734194M91		L. 31113, M. 35354234	1 PIPE
24	732899M91		L. 31114, M. 35354202	1 PIPE
25	732898M91		L. 31115, M. 35354203	1 PIPE
26	732897M91		L. 31116, M. 35354204	1 PIPE
27	733517M1		L. 31117, M. 36854104	1 CLIP
28	732913M1		L. 31118, M. 36474128	2 CLIP
29	732516M1		L. 31119, M. 36854103	1 CLIP
30	732914M1		L. 31120, M. 36516119	1 CLIP
31	733052M1		L. N3670, M. 0826017	3 STUD
32	376240X1		L. N7992, M. 0576301	3 NUT
33	733029M91		L. 31121, M. 35587323	1 PIPE
34	731567M1	●	0095315 (4) L. N6230, M. 0095315	4 BOLT
35	376518X1	●	0920107 (8) L. N8938, M. 0921176	8 WASHER
36	393993X1	●	N.L.A. (1) L. N8378	1 PLUG
37	1820784M1			1 PIPE
38	392697X1	●	3547988M1 (2) 3648425M1 (8) L. N9129	2 CLAMP
39	392460X1	●	3530490M91 (1) L. N6257	1 CLAMP

PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com

RADIATOR



35	892563M1	●	2415216 (1) Y1 19 Y1 19 Y1 19 2415209	1	RING
36	731805M1	●	31146582 (1) L. 30336, M. 31146582	1	PULLEY
37	353758X1	●	390735X1 (1) L. N3708, M. 0920007	1	WASHER
38	375724X1		L. N7975, M. 0576103	1	NUT
39	353554X1	●	0096441 (1) L. N7860, M. 0096441	1	BOLT UNF
40	1650486M1		L. N3825, M. 0920054	1	WASHER
41	731165M1		Y1 19 Y1 19 M. 0490690	1	GASKET
42	732646M1		L. 31012, M. 37556123	1	PLATE
43	353554X1	●	0096441 (1) L. N7860, M0096441	1	BOLT UNF
44	1650486M1		L. N3825, M. 0920054	1	WASHER
45	353546X1	●	0096436 (1) L. N7856, M. 0096436	1	SCREW
46	375726X1		L. N7940, M. 0746460	1	SCREW
47	375728X1	●	0920109 (2) L. N6277, M. 0920109	2	WASHER
48	975367M1		L. 31047	1	PULLEY

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com



14	1440444X1	●	1440445X1 (8) L. N8361	8	RIVET
15	973473M1	●	2740848M1 (4) L. 25753	4	PLATE
16	973474M1		L. 25754	999	PACKING
17	392076X1	●	N.L.A. (12) L. N476	12	SCREW
18	1440315X1		L. N3818	12	WASHER
19	973475M1	●	2740851M1 (4) 973474M1 (44) L. 25755	4	SKID
20	973479M1		L. 25756	999	SHIM
21	973481M1	●	2740849M1 (4) L. 25842	4	GUIDE
22	973482M1		L. 25758	999	SHIM
23	1441927X1		L. N8434	8	BOLT
24	1440314X1		L. N3817	8	WASHER
25	973483M1	●	N.L.A. (2) L. 25760	2	BEARER
26	391375X1		L. N811	8	SCREW
27	1440315X1		L. N3818	8	WASHER
28	973484M92	●	N.L.A. (1) L. 25761	1	CYLINDER
29	1441709X1	●	N.L.A. (2) L. N4733	2	GASKET
30	1440216X1	●	N.L.A. (2) L. N1142	2	NUT BSF
31	973486M1		L. 25766	2	WASHER
32	1818799M1	●	N.L.A. (2) L. 23798	2	PISTON
33	393322X1	●	3019922X1 (4) L. N4710	4	RING
34	393980X1		L. N8380	2	WASHER
35	393492X1		L. N6472	2	NIPPLE

Download full manual at youfixthis.com

PREVIEW - YOUFIXTHIS.COM

PREVIEW ONLY

You're viewing 12 of 135 pages

The full manual includes:

- All 135 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Landini C6000 Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual