



1	ZZ 90081		ZZ90081 (1) U5BG0024	1	KIT
2			REF.1 Y1	1	CRANKSHAFT
3	81558		A Y1	1	KIT
3	81558A		0.25MM 0.010" A Y1 Y1	999	KIT
3	81558B		0.50MM 0.020" A Y1 Y1	999	KIT
3	81558C		0.75MM 0.030" A Y1 Y1	999	KIT
4	85042		A Y1	1	KIT
4	85042A		0.25MM 0.010" A Y1 Y1	999	KIT
4	85042B		0.50MM 0.020" A Y1 Y1	999	KIT
4	85042C		0.75MM 0.030" A Y1 Y1	999	KIT

Download full manual at youfixthis.com

PREVIEW - YOUFIXTHIS.COM


"FRONT" PTO DRIVE SHAFT



1	1825498M1			1	SHAFT
2	1825483M1			1	SHAFT
3	1824898M2			1	SLEEVE
4	339469X1			1	SEGMENT
5	339436X1			1	BEARING BALL
6	1440559X1			1	BEARING
7	339469X1			3	SEGMENT
8	1825484M3	●	1825484M4 (1)	1	GEAR
		▲	24 Z		
8	3532048M2	●	3532048M3 (1)	1	GEAR
		▲	A		
9	1824899M1	●	3543737M3 (1)	1	SHAFT
10	831789M1			1	BEARING
11	1825485M3	▲	46 Z	1	GEAR
11	3532047M1		A	1	GEAR
12	1825001M3	▲	54	1	GEAR
13	3308788M1	➡	322A01441	999	LOCTITE
14	339436X1			1	BEARING BALL
15	392378X1			1	CIRCLIP
16	392771X1			1	NUT
17	1825005M3	●	1825005M4 (1)	1	COVER
18	3308788M1			999	LOCTITE
19	974743M1	●	3015155X1 (6)	6	STUD
20	1440200X1			6	NUT BSF
21	1825003M2	●	3019963X1 (1)	1	COVER
		➡	3543738M2 (1)		
			3543743M1 (1)		
			359104X1 (1)		
			390735X1 (2)		
			322A01441		


Download full manual at youfixthis.com

PREVIEW - YOUFIXTHIS.COM




Cingolati Meccanici C7830

4-AP38-012-A




1	3306467M93	●	3306467M97 (1)	1	DISTRIBUTOR
2	3306218M92	●	3306467M97 (1) Y1	1	HOUSING
3	1825248M1		Y1	1	SPRING
4	1441267X1		Y1	1	SCREW
5	3306227M93	●	3306227M94 (1) Y1	1	VALVE
6		▰	REF.N.5 Y1	1	SEAT
7		▰	REF.N.5 Y1	1	PISTON
8	1825253M1		Y1	1	SPRING
9	370552X1	●	3673221M1 (2) Y1	2	O RING
10	1000557M1		Y1	1	GASKET
11	1000578M1		Y1	1	O RING
12	365801X1	●	3673222M1 (1) Y1	1	RING
13	3306680M1	●	3306680M2 (1) Y1	1	NUT
14	3306229M1		Y1	1	PLUG
15	1425371M1	●	1425371M2 (1) Y1	1	SLIPPER
16	3019926X1		Y1	1	O RING
17	3531029M1	●	3531029M3 (1) Y1	1	COVER
18	371468X1		Y1	1	O RING
19	391148X1		Y1	4	SCREW
20	3306222M1		Y1	999	DIAPHRAGM
21	3308376M1		Y1	1	PLUG
22	3306235M2		Y1	1	VALVE
23	3306236M1		Y1	1	SPRING
24	3306468M2	●	3306468M3 (1) Y1	1	SEAT

Download full manual at youfixthis.com
PREVIEW - YOUFIXTHIS.COM



Cingolati Meccanici C7830

L-0569-37M-A




20	0096634		4	SCREW
21	0920006		4	WASHER
22	37188141		1	COVER
23	3681A026	3681A027 (1) 36811132	1	UNIVERSAL
24	2172513		4	SCREW
25	0920002		4	WASHER
26	0920052		4	WASHER
27	2487845		1	CAP
28		REF.27 Y1	1	CAP
29	24870002	Y1	1	UNIVERSAL
30	33872516		1	PIPE
31	21825195	0180063	1	CLIP
32	35731144		1	PIPE
33	0096215	U2267087	1	SCREW
33	2187333	U2267088	1	SCREW
34	0920003	390972X1 (1) A	1	WASHER
35	0920053	A	1	WASHER

- FROM SERIAL OR ENGINE NUMBER
- UP TO SERIAL OR ENGINE NUMBER
- REPAIRS AND REPLACES
- NOT SERVICED, ORDER
- A — FITTED UP TO ENGINE NUMBER U226708S
- ◄ — LEFT HAND
- ► — RIGHT HAND
- Y1 — NOTA PAGINA ANOMALA


Download full manual at youfixthis.com
PREVIEW - YOUFIXTHIS.COM

ALTERNATOR



1	3477851M91			1	ALTERNATOR
2		▰	REF.N.1	1	ALTERNATOR
3	339010X1			1	BOLT
4	390972X1			1	WASHER
5	390972X1			1	WASHER
6	1440313X1	●	339374X1 (1)	1	WASHER
7	339169X1	●	394367X1 (1)	1	NUT BSF
8	339337X1			1	SCREW
9	339056X1			1	WASHER
10	390048X1			1	WASHER
11	3600182M1			1	PULLEY
12	339168X1			1	BOLT
13	1440313X1	●	339374X1 (2)	2	WASHER
14	390972X1			1	WASHER
15	339169X1	●	394367X1 (1)	1	NUT BSF
16	3600184M1		Y1	1	FAN
17	3532010M1			1	TIGHTENER
18	1440313X1	●	339374X1 (1)	1	WASHER
19	0576002	●	353916X1 (1)	1	NUT
20	3531980M91	●	3531980M92 (1)	1	GUARD
21	1440313X1	●	339374X1 (1)	1	WASHER
22	3600176M91		Y1	1	ROTOR
23	3600177M91		Y1	1	STATOR
24	3600178M91		Y1	1	REGULATOR
25	3600179M91		Y1	1	DIODE
26	3600180M91		Y1	1	HOUSING

Download full manual at youfixthis.com
PREVIEW - YOUFIXTHIS.COM



1	3300096M93	◄		1	BODY
1	3300098M93	●○	3307395M91 (1)	1	BODY
		➡		322B00530	
		►			
1	3307395M91	➡	322B00531	1	HOUSING
		►			
2	1824769M1		Y1	4	BUSH
3	392735X1	➡	32200399	4	PLUG
3	392735X1	➡|	32200398	6	PLUG
4	3307905M92	●○	3307905M93 (2)	2	PLUG
		➡	32200399		
5	3300100M1			2	PINION
6	339441X1			4	KEY
7	392479X1	●○	3300945M1 (2)	2	BUSH
			3300946M1 (2)		
8	390613X1			4	CIRCLIP
9	339470X1			2	CIRCLIP
10	392485X1			2	BEARING
11	1440516X1			2	CIRCLIP
12	392759X1	●○	339820X1 (2)	2	CLIP
13	392775X1			2	RING
14	3300102M2			2	HUB
15	3019914X1		Y1	1	O RING
16	3300314M1			2	UNIVERSAL
17	339081X1			6	SCREW
18	3300105M2			2	GEAR
19	390504X1			4	BEARING
20	3003370X1			2	BEARING
21	1442355X1			2	CIRCLIP
22	3300106M1			2	SPACER
23	3300107M1	●○	N.L.A. (2)	2	SPACER


Download full manual at youfixthis.com

PREVIEW - YOUFIXTHIS.COM


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


4-4312-004-A



1	3305669M91	●	3305934M92 (1)	1 TANK
		→	3305940M92 (1)	
			322A00249	
1	3305940M92	⇒	322A00250	1 TANK
2	339402X1			4 NUT BSF
3	339376X1	●	1440314X1 (4)	4 LOCK WASHER
4	390734X1			4 WASHER
5	390839X1			1 WASHER
6	1441495X1			1 PLUG
7	3305320M91			1 CAP
8	1825221M91	●	3307127M1 (1)	1 FILTER
		→	3307250M91 (1)	
			3308199M1 (1)	
			322B00393	
8	3307127M1	⇒	322B00394	1 VALVE SEAT
9	1825222M91	●	3307250M91 (1)	1 HYDR.ELEMENT
		→	322B00393	
9	3307250M91	⇒	322B00394	1 ELEMENT
10	3015061X1			1 O RING
11	1825223M91			1 COVER
12	1434782M1			2 STUD
13	1440313X1	●	339374X1 (2)	2 WASHER
14	1440086X1			2 NUT BSF
15	3305517M1	●	3307251M1 (1)	1 HOSE
		→	322B00393	
15	3307251M1	⇒	322B00394	1 HOSE
16	339666X1			4 SCREW
17	390971X1			4 WASHER
18	3019922X1			1 O RING
19	3305454M92			1 SUPPORT
20	1440313X1	●	339374X1 (2)	2 WASHER



4-0799-007-A



1	3300372M93	●○	3305061M1 (1)	1 SHAFT
		➡		3306426M1 (1)
				3306427M1 (1)
				3306428M1 (1)
				3531782M2 (1)
				3531783M2 (1)
				3664485M1 (1)
				3664483M91 (1)
				32200401
1	3307915M92	●○	3664485M1 (1)	1 SHAFT
		➡		3664483M91 (1)
		➡		32200402
				322B01547
1	3532179M91	●○	979469M1 (2)	1 SHAFT
		➡		3664485M1 (1)
				3664484M1 (1)
				322B01548
2	979469M1			2 BUSH
3	3308393M1			1 SEAL
4	392184X1	➡	322B01548	1 SEAL
4	973454M1	➡	322B01547	1 SEAL
5	831789M1			1 BEARING
6	1440511X1			1 BEARING
7	392759X1	●○	339820X1 (3)	3 CLIP
		➡	322B01548	
7	392759X1	●○	339820X1 (2)	2 CLIP
		➡	322B01547	
8	1824663M1	▲	19	1 GEAR
9	1824664M1	➡	322B01547	2 SPACER
9	3531300M1	●○	3531300M3 (2)	2 SPACER
		➡	322B01548	
10	1440619X1			2 BEARING NE
11	3302093M1	➡	32200401	1 HUB
		▲	22	


Download full manual at youfixthis.com

PREVIEW - YOUFIXTHIS.COM



HYDRAULIC PUMP

4-AP32-032-A




1	1825212M91	●○	3539857M91 (1) ◇ 54/1	1	HIDRAULIC
2	1493872M91	●○	3539858M91 (999) Y1	999	PACKING
3	1493899M91	●○	3539858M91 (999) Y1	999	KIT
4	1429567M1		Y1	1	COVER
5	390796X1		Y1	16	SCREW
6	1429568M1		Y1	1	COVER
7	3302051M1		Y1	8	DOWEL
8	1493867M91	●○	3540159M91 (999) Y1	999	KIT SEAL
9	1429586M1		Y1	1	RING
10	339361X1		Y1	1	CIRCLIP
11	1440360X1	◇	54/2 Y1	1	KEY DOOR
12	1442576X1	◇	54/4 Y1	1	NUT BSF
13	3302053M1	◇	54/3 Y1	1	WASHER
14		◇	54/5	1	RING

◇ SEE PAGE - REFERENCE NUMBER

Y1 NOTA PAGINA ANOMALA


Download full manual at youfixthis.com

PREVIEW - YOUFIXTHIS.COM



Cingolati Meccanici C7830


L-0563-39M-A



5	31137312		0.19MM 0.0075" Y1 Y1	999 WASHER
5	31137551		Y1	2 WASHER
6	31137322		0.19MM 0.0075" Y1 Y1	999 WASHER
6	31137561		Y1	2 WASHER
7	3242T001			1 BEARING
8	32186139			3 SCREW
9	ZZ 90009		ZZ90009 (4)	4 KIT
10			REF.9 Y1	1 CONROD
11			REF.9 Y1	1 CAP
12	31134123		Y1	1 BUSH
13	32762144		32762145 (2) Y1	2 BOLT
14	33221328		Y1	2 NUT
15	U5LP0009		C	4 KIT
15	U5LU0005		B	4 KIT
16			REF.15 Y1	1 PISTON
17			REF.15 Y1	1 PIN
18	0170002		Y1	1 CIRCLIP
19	0170002		Y1	1 CIRCLIP
20	41158022			4 KIT
21	31171681		28	1 GEAR
22	0500012			1 KEY
23	31148797		31148798 (1)	1 PULLEY

Download full manual at youfixthis.com


PREVIEW - YOUFIXTHIS.COM



1		◇	80/16	2	LIGHT
2	3305194M91	●	3305194M92 (1)	1	KIT
3	1424252M1	●	N.L.A. (1) Y1	1	PROTECTOR
4	3599307M91	●	1877721M92 (1) B C	1	PRESSURE S
5	3536546M91	●	3539770M91 (1)	1	HORN
		⅄	1424311M91		
6	339228X1			1	SCREW
7	1440313X1	●	339374X1 (1)	1	WASHER
8	339169X1	●	394367X1 (1)	1	NUT BSF
9	3305720M92	●	3305720M94 (1)	1	SUPPORT
10	339337X1			1	SCREW
11	339169X1	●	394367X1 (1)	1	NUT BSF
12		◇	28/7	1	BATTERY
13	3305536M91	●	3539362M91 (1)	1	CABLE
14	3305535M91			1	CABLE
15	3300970M1			1	GROMMET
16	3533937M1			11	CLAMP
17	3300995M1			3	CLAMP
18		◇	29/24	1	CABLE
19	3305534M91			1	KIT
20	3305553M91			1	CABLE
21		◇	80/22	1	LIGHT
22		◇	80/5	2	LIGHT
23	1426711M92			1	SUPPORT
23	3305959M91		B	1	SUPPORT

Download full manual at youfixthis.com
PREVIEW - YOUFIXTHIS.COM

CLUTCH PEDAL AND LINKAGE



1			B	1	CLUTCH
2	339084X1			12	BOLT
3	1440313X1	●	339374X1 (12)	12	WASHER
5	1821699M3	●	1821699M4 (1)	1	CLAMP
6	1423471M92	●	1423471M93 (1)	1	CLAMP
7	1442381X1		Y1	1	BEARING
8	1821722M1		Y1	1	CHOCK
9	1423472M1	●	1423472M2 (1) Y1	1	DISC
10	1423473M91	●	1423473M94 (1)	1	BEARING
11	3305516M91			1	PIPE
12	339617X1			1	NUT BSF
13	1440317X1			1	WASHER
14	1441983X1			1	NIPPLE
15	3530489M2	➡	322B01548	1	SUPPORT
16	3305222M91			1	TIE ROD
17	3305619M1	●	N.L.A. (1) ➡ 322A00797	1	SUPPORT
17	3309148M1	●	N.L.S. (1) ➡ 322A00798 B	1	SUPPORT
18	339376X1	●	1440314X1 (2) ➡ 322B01548	2	LOCK WASHER
19	339401X1	➡	322B01548	2	SCREW
20	1824623M1	●	N.L.S. (1) ➡ 322A01730	1	CLEVIS
20	3534198M2	●	3534198M3 (1) ➡ 322A01731	1	YOKE
21	973144M1			2	PLUG
22	393361X1	➡	322A01731	1	SCREW

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 12 of 168 pages

The full manual includes:

- All 168 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Landini C7830 Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual