



Frutteti 530 F-L-V 6530F




1	ZZ90009	●	M7BJ0015	4	KIT
2	32762116	● !	32762145 (8) 1	8	BOLT
3	33221328	!	1	8	NUT
4	31134123	!	1	4	BUSH
5	68300		A	999	KIT
5	68300C	● ⧗	N.L.S. (1998) +0,762MM. A	999	KIT
5	68301		C	4	KIT
5	68301C	● ⧗	N.L.S. (999) +0,762MM. C	999	KIT
6	0170002	!	5	8	CIRCLIP
7	41158041			4	KIT
7	41158041C	⧗	+0,762MM. C	999	KIT
8		⛟	68609	1	CRANKSHAFT
9	81558	!	8 A	1	KIT
9	81558A	⧗	-0,254MM. A	999	KIT
9	81558B	⧗	-0,508MM. A	999	KIT
9	81558C	⧗	-0,762MM. A	999	KIT
10	85042	!	8 A	8	KIT
10	85042A	⧗	-0,254MM. A	999	KIT
10	85042B	⧗	-0,508MM. A	999	KIT
10	85042C	⧗	-0,762MM. A	999	KIT

Download full manual at youfixthis.com

PREVIEW - YOUFIXTHIS.COM




Frutteti 530 F-L-V 6530F



1	3426064M2	●○	1442524X1 (4) 3310930M91 (1) 339003X1 (1) 3426230M1 (2) 3426231M1 (2) 3426232M1 (1) 3426233M1 (1) 3426234M1 (4) 3426457M1 (2) 3426523M2 (4) 3426661M3 (4) 3426662M2 (2) 3426663M2 (4) 3426664M1 (4) 3426665M1 (4) 3426666M1 (4) 3426669M91 (2) 3429323M1 (2) C	1	AXLE
1	3426661M1	●○	3426661M3 (1) C	1	HOUSING
2	392735X1			3	PLUG
3	1823603M91			1	BREATHER
4	1824239M92			1	BEARER
5	1823570M2	!	4	1	BUSH
6	1823569M1			2	BUSH
7	339608X1			1	GREASER
8	1823571M1			1	SPACER
9	1823542M1			1	PIN
10	1440049X1			4	STUD
11	1440316X1			4	WASHER
12	1440223X1	●○	392416X1 (4)	4	NUT BSF
13	1424997M93			1	SUPPORT


Download full manual at youfixthis.com

PREVIEW - YOUFIXTHIS.COM




STEERING CYLINDER

Frutteti 530 F-L-V 6530F



1	3304039M2			1 SUPPORT
2	391414X1			2 WASHER
3	339275X1			2 SCREW
4	3314359M1			1 UNIVERSAL
5	1442597X1	●D !	339075X1 (1) 4	1 NUT
6	1442966X1	●D !	391423X1 (1) 4	1 PIN
7	1440236X1	●D	339617X1 (1)	1 NUT BSF
8	3314437M1	●D	3426660M1 (1)	1 UNIVERSAL
9	1442597X1	●D !	339075X1 (1) 8	1 NUT
10	1442966X1	●D !	391423X1 (1) 8	1 PIN
11	3102366M1	!	8	1 CLIP
12	390839X1			4 WASHER
13	393444X1			2 NUT
14	3304041M91			1 PIPE
15	3304045M91			1 PIPE
16	3401131M91	●D	3304040K91 (1) 3314359M1 (1) 3426660M1 (1)	1 RAM
17	1442082X1	!	16	1 SEAL
18	3187484M1	!	16	1 BUSH
19	1748237M1	!	16	1 BEARING
20	1748053M1	!	16	1 WIRE
21	1442710X1	!	16	1 SEAL
22	3404031M91	●D !	3304040K91 (1) 3314359M1 (1) 3426660M1 (1) 16	1 CYLINDER ROD


PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com



1	3302389M1	●	3302389M2 (1) C	1	TRANSM.HOU
1	3304646M3	●	N.L.A. (1) A 38 B 38	1	TRANSM.HOU
2	1423482M1			2	BUSH
3	1824657M3			1	GASKET
4	1440693X1			1	DOWEL
5	391198X1			11	BOLT
6	1440200X1			10	NUT BSF
7	1424374M1			2	PAD
8	391929X1			1	SCREW
9	392757X1			1	PLUG
10	1444745X1			1	RING
11	392798X1			1	PLUG
12	1444746X1			1	RING
13	979708M1			2	STUD
14	1440087X1	●	1440099X1 (2)	2	NUT BSF
15	974743M1	●	3015155X1 (6)	6	STUD
16	1440200X1			6	NUT BSF
17	3303304M2	●	3303304M3 (1)	1	COVER
18	3308788M1			999	LOCTITE
19	339761X1			13	SCREW
20	3303301M91	●	3533054M91 (1)	1	PLUG
21	1440704X1			1	GASKET
22	392735X1			2	PLUG
23	1423503M1			1	COVER
24	3303226M1		CC.250	999	LOCTITE
25	339401X1			6	SCREW


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




ALTERNATOR

Frutteti 530 F-L-V 6530F




1	2871A121	●	0096436 (1) 339010X1 (1) 339168X1 (1) 339374X1 (1) 3477851M91 (1) 3531989M92 (5) 3532010M1 (3) 390048X1 (1) 390972X1 (2) 394367X1 (1) A	1 ALTERNATOR
2	31141453			1 PULLEY
3	36155151			1 LEVER
4	0920054			1 WASHER
5	0096442	●	2185551 (1)	1 BOLT
6	2131467			1 SPACER
7	390972X1			2 WASHER
8	1440313X1	●	339374X1 (1)	1 WASHER
9	339008X1	●	339337X1 (1)	1 BOLT
10	0746211			1 BOLT
11	0920497			1 WASHER
12	33134418			1 SPACER
13	0920497			1 WASHER
14	353446X1	●	0920053 (1)	1 LOCK WASHER
15	0576064	●	353916X1 (1)	1 NUT
16	0096234			1 BOLT
17	0920497			1 WASHER
18	353446X1	●	0920053 (1)	1 LOCK WASHER

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com



FRONT AXLE

Frutteti 530 F-L-V 6530F




1	3304025M91	●D	3546622M91 (1)	1	AXLE
2	1423636M1	!	1	2	BUSH
3	1423630M1	●D	1423630M2 (1)	1	CLEVIS PIN
4	1423631M1			2	PRESSURE W
5	390949X1			1	PIN
6	339608X1			1	GREASER
7	3304027M91	◄		1	ARM
8	975208M1	!	7	2	BUSH
9	3304030M91	►		1	ARM
10	975208M1	!	9	2	BUSH
11	339608X1			2	GREASER
12	3000035X1			4	BOLT
13	1822489M1			4	WASHER
14	1440316X1			4	WASHER
15	1440201X1			4	NUT BSF
16	3304034M91			2	SPINDLE
17	392060X1			2	BUSH
18	393116X1			2	KEY
19	3304035M1	●D ◄	3304035M3 (1)	1	LEVER
20	3304036M1	●D ►	3304036M3 (1)	1	LEVER
24	394014X1			2	RING
25	339394X1			2	BEARING
26	1423655M2			2	HUB
27	339393X1			2	BEARING
28	390975X1			2	WASHER
29	1440252X1			2	NUT
30	391423X1			2	PIN
31	1433401M1			2	COVER
32	339608X1			2	GREASER
33	3304037M1			1	ROD

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com



DISTRIBUTOR

Frutteti 530 F-L-V 6530F




1	3303630M91	●○	3306467M97 (1)	1	DISTRIBUTOR
2	1427247M91	!	1	1	BODY
3	1825248M1	!	1	1	SPRING
4	1441267X1	!	1	1	SCREW
5	3301057M91	●○	3304561M92 (1)	1	VALVE
		!	1		
6		!	5	1	BUSH
		⇨	3301057M91		
7		!	5	1	VALVE
		⇨	3301057M91		
8		!	5	1	SPRING
		⇨	3301057M91		
9		!	5	1	SEAT
		⇨	3301057M91		
10	1441211X1	!	5	2	SEAL
11	1441514X1	!	1	1	SEAL
12	1442477X1	!	1	1	GASKET
13	3301059M1	!	1	1	NUT
14	3303341M1	!	1	1	LEVER
15	1441805X1	!	1	1	PIN
16	1442012X1	●○	1440399X1 (1)	1	PIN
		!	1		
17	1825257M1	●○	N.L.A. (1)	1	COVER
		!	1		
18	1441127X1	●○	3019926X1 (1)	1	O RING
		!	1		
19	391148X1	!	1	4	SCREW
20	1825258M1	!	1	1	VALVE
21	1825259M1	!	1	1	SPRING
22	1825260M1	!	1	1	SEAT
23	395593X1	!	1	1	PLUG
24	395592X1	!	1	1	GASKET
25	1825261M1	!	1	1	VALVE

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com




REDUCER

Frutteti 530 F-L-V 6530F




1	3305040M1	●D	3305040M4 (1)	1	SHAFT
		◇	84		
2	339761X1	◇	84	3	SCREW
3	1440314X1	◇	84	3	WASHER
4	3305041M1	●D	3305041M2 (1)	1	UNIVERSAL
		◇	84		
6	339820X1			1	CIRCLIP
7	339818X1			1	BEARING
8	339437X1			1	CIRCLIP
9	3305046M1			1	SHAFT
10	1442903X1			1	GASKET
11	3305063M1			1	WASHER
12	3006803X1			1	CIRCLIP
13	3304944M1			1	BEARING NE
14	3305062M1	●D	3305062M2 (1)	1	BUSH
15	3305060M1	▲	27	1	GEAR
16	3305093M2			1	SLEEVE
17	3305059M1			1	WASHER
18	392517X1			1	BUSH
19	3305055M1			2	BEARING NE
20	3305056M1			1	WASHER
21	3305054M1	▲	40	1	GEAR
22	2714111M1			1	WASHER
23	3305836M1			1	FLANGE
24	831789M1	◇	92	1	BEARING
25	3305053M1	◇	92	1	SHAFT
26	1443524X1			1	CIRCLIP
27	3305049M1			1	O RING
28	3305048M1	●D	3305048M2 (1)	1	COVER
29	339469X1			1	SEGMENT
30	339818X1			1	BEARING
31	339437X1			1	CIRCLIP

Download full manual at youfixthis.com
PREVIEW - YOUFIXTHIS.COM



DRAWBAR

Frutteti 530 F-L-V 6530F




1	1424437M2			1	BAR
2	1424438M1			1	BAR
3	3001915X1			2	SCREW
4	391414X1			2	WASHER
5	1440202X1			2	NUT BSF
6	1424441M91			1	CLEVIS PIN
7	1433140M1			1	CLIP
8	1424439M1			2	CLEVIS PIN
9	974303M1			2	PIN
10	3300157M91			1	PIN
11	1433140M1			1	CLIP
12	1424445M91			1	BEARER
13	3303349M91			4	CLEVIS PIN
14	3303352M91	●	3670719M91 (4)	4	PIN
15	1825504M1	●	1825504M4 (1)	1	BEARER
16	1825505M1	●	1825505M4 (1)	1	BEARER
17	390419X1			12	BOLT
18	391414X1			12	WASHER
19	1425086M2	A		1	DRAWBAR

A "SAE" TYPE

Download full manual at youfixthis.com

PREVIEW - YOUFIXTHIS.COM




1	3303415M91			1 STEERING W
2		!	1	1 CAP
		◇	254	
3	1441246X1			1 NUT BSF
4	1440476X1			2 CIRCLIP
5	3303670M1	●	3303670M2 (1)	1 SHAFT
6	3303374M92			1 PIPE
7	1440315X1			4 WASHER
8	339139X1			4 SCREW
9	3303677M2			1 SUPPORT
10	1440313X1	●	339374X1 (4)	4 WASHER
11	339123X1			4 SCREW
12		◇	144-146-148-150	1 DISTRIBUTOR
13	1426429M91	●	N.L.A. (3)	3 UNION
		➡	13200248/232C00633	
13	1426727M91	➡	13200249/232C00634	4 UNION
14	1443243X1	●	1442477X1 (3)	3 O RING
		!	13	
		➡	13200248/232V00633	
14	831497M1	!	13	4 GASKET
		➡	13200249/232C00634	
15	1426743M1	➡	13200248/232C00633	4 WASHER
16	3303836M91	●	3303836M92 (1)	1 UNION
		➡	13200248/232C00633	
17	1443243X1	●	1442477X1 (1)	1 GASKET
		!	16	
		➡	13200248/232C00633	
18	3303832M91	➡	13200021/23200087	1 PIPE
18	3304332M91		A	1 PIPE
18	3305960M91		B	1 PIPE

Download full manual at youfixthis.com

PREVIEW - YOUFIXTHIS.COM

Frutteti 530 F-L-V 6530F



1	1425351M2		132A00614/232A00690	1	SHAFT
1	3305053M1		96 B	1	SHAFT
1	3306331M3		132A00615/232A00691	1	SHAFT
2	3308392M1			1	SEAL
2	3308393M1		ITEM 2A	1	NEEDLE CAGE
3	831789M1			1	BEARING
4	339820X1			1	CIRCLIP
5	392184X1		132A00615/232A00691	1	SEAL
5	973454M1		B	1	SEAL
6	1440558X1			1	BEARING
6	339437X1		ITEM 6A	1	CIRCLIP
7	1440511X1			2	BEARING
8	1423507M1			1	SPACER
9	1423508M2		18	1	PINION
9	3302346M1		21 A	1	GEAR
10	1423509M2		24	1	GEAR
10	1423510M2		28 A	1	PINION
11	1423510M2		28	1	PINION
11	3302347M1		32 A	1	GEAR
12	1423511M2		35	1	GEAR
12	3303229M2		38 A	1	GEAR
13	1423512M2			2	SPACER
14	1424423M1			1	SHAFT
15	1440546X1			1	BEARING BALL
16	395568X1			1	BEARING
17	1423515M1			1	BUSH
18	392759X1		339820X1 (1)	1	CLIP
19	1423516M1			999	SHIM

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 11 of 280 pages

The full manual includes:

- All 280 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Landini Frutteti 530 F, Frutteti 530 L, Frutteti 530 V, Frutteti 530 F-L-V, 6530F Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual