



1	ZZ 90113	●	31171682 (1) ZZ90217 (1)	1	KIT
2		!	1 REF.1	1	CRANKSHAFT
3	68079	!	1 A	1	KIT
3	68079A	⧗	(-)0.25MM A	999	KIT
3	68079B	⧗	(-)0.50MM A	999	KIT
3	68079C	⧗	(-)0.75MM A	999	KIT
4	31137312	⧗ ◆ ▲	(+)0.19MM (+)0.0075"	999	WASHER
4	31137551	!	1 ● 31137311	2	WASHER
5	31137322	⧗ ◆ ▲	(+)0.19MM (+)0.0075"	999	WASHER
5	31137561	!	1 ● 31137321	2	WASHER
6	85043	!	1 A	1	KIT
6	85043A	⧗	(-)0.25MM A	999	KIT
6	85043B	⧗	(-)0.75MM A	999	KIT
6	85043B	⧗	(-)0.50MM A	999	KIT
7	31171682	!	1 28	1	GEAR
8	0500012	!	1	1	KEY
9	ZZ 90009	●	ZZ90009 (6) M7BJ0015	6	KIT

Download full manual at youfixthis.com

PREVIEW - YOUFIXTHIS.COM

Large 13000

FRONT AXLE 2 WHEEL DRIVE- AXLE SUPPORT




1	1425509M92		A	1 AXLE
1	3309314M92		B	1 BEARER
2	1425518M93	◄		1 ARM
3	1425520M1	!	2	2 BUSH
4	1425516M93	►		1 SUPPORT
5	1425520M1	!	4	2 BUSH
6	339608X1			2 GREASER
7	1442949X1			4 SCREW
8	339760X1			4 NUT
9	1440318X1			4 WASHER
10	1425526M1			4 SPACER
11	1425522M94	◄		1 SPINDLE
11	1425530M94			1 SPINDLE
12	1425528M1	▼		2 WASHER
13	1425527M1	▲		2 WASHER
14	1425534M2	◄		1 ARM
15	1425535M2	►		1 ARM
16	392341X1			2 SCREW
17	1440316X1			2 WASHER
18	394977X1			2 NUT
19	982121M1			2 WASHER
20	391438X1			2 PIN
21	1442008X1			2 BEARING TAPER
22	1440637X1			2 BEARING TAPER
23	392215X1			2 GASKET
24	1425913M2			2 HUB
25	1425529M1			2 HELMET
26	1425531M1			2 GASKET
27	339123X1			6 SCREW
28	339608X1			2 GREASER
29	1425521M1			1 STEM
30	1824415M1			1 SHAFT
31	1824414M1			1 CLAMP

Download full manual at youfixthis.com
PREVIEW - YOUFIXTHIS.COM



Large 13000


BATTERY BATTERY CASE



1	3534412M91	●	E3653993M1 (1)	1	BATTERY
2	3301439M92		A	1	SUPPORT
2	3308231M91		B	1	SUPPORT
3	1427490M1	!	2	2	DAMPER
			A		
4	3300970M2	●	3300970M1 (2)	2	GROMMET
5	339401X1			2	SCREW
6	1440314X1			4	WASHER
7	390734X1			4	WASHER
8	1427526M1	●	N.L.A. (1)	1	SUPPORT
			A		
9	339123X1		A	2	SCREW
10	390972X1		A	2	WASHER
11	3301319M1			1	GASKET
12	339814X1			2	SCREW
13	1425775M2			2	RING
14	3308733M91	●	N.L.A. (1)	1	FRAME
			B		
			C		
14	3534518M91		D	1	FRAME ASSY
15	3308740M1		B	1	LID
16	394367X1		B	2	LOCKNUT
17	3308745M1	●	3308791M3 (2)	2	ROD
			B		
			C		
17	3308791M1	●	3308791M3 (2)	2	STEADY
			D		
18	1820587M2		D	1	DAMPER
18	1825476M1		B	1	PLATE
			C		
19	3537831M91	●	3539361M91 (1)	1	CABLE
		➡	R 37203		

Download full manual at youfixthis.com
PREVIEW - YOUFIXTHIS.COM


FRONT AXLE 4 WHEEL DRIVE- DIFFERENTIAL LOCK MECHANISM



1		⇳	71/6	1	SUPPORT
2	3535556M91			1	PIPE
3	3535560M91	●	3535560M92 (1)	1	UNION
4	3427458M1	➡|	2977 A	1	GUIDE
4	3427839M1	|➡	2978 A	1	GUIDE
5	3427313M1				1	SPRING
6	3427447M2	➡|	2977 A	1	SLEEVE
6	3427838M1	|➡	2978 A	1	SLEEVE
7	3427443M1				1	WASHER
8	3427460M1				1	PISTON
9	3427444M1				1	DOWEL
10	359236X1				1	O RING
11	3019927X1				1	O RING
12	3427463M1				1	WASHER
13	1442697X1				1	CIRCLIP
14	3015040X1	!	3		1	RING
15	3300755M91	●	N.L.A. (2)		2	SUPPORT
16	3536649M91				1	PIPE
17	1426275M1				1	UNION
18	2411105	●	376590X1 (1)		1	WASHER
19	1825173M1				1	CLIP
20	392370X1				1	NUT BSF
21	36844116	●	733868M1 (4)		4	BRIDLE
22	36511123	●	733869M1 (2)		2	PLATE
23	1442394X1				2	SCREW

!	THIS IS A COMPONENT OF AN ASSEMBLY
➡|	FROM SERIAL OR ENGINE NUMBER
|➡	UP TO SERIAL OR ENGINE NUMBER
⇳	SEE PAGE - REFERENCE NUMBER
A	FRONT AXLE SERIAL NUMBER.


Download full manual at youfixthis.com
PREVIEW - YOUFIXTHIS.COM



Large 13000

HYDRAULIC CYLINDER- PALLET HANDLER

4-DA30-006-A




1		⇳	104/1	1	CYLINDER
2	1425377M1	●●	1425377M2 (2)	2	CLEVIS PIN
3	1425394M1			2	WASHER
4	391446X1			2	PIN
5	1425378M1			2	CLEVIS PIN
6	1425432M1			4	WASHER
7	339039X1			4	PIN
8	1425330M2			1	SHAFT
9	1425334M1			2	WASHER
10	391274X1			2	NUT BSF
11	339040X1			2	PIN
12	392283X1			2	BLOCK
13	392210X1			2	RING
14	1427441M1			2	BUSH
15	1425336M1			2	SPACER
16	1425338M1	▶		1	PROTECTOR
17	1426681M91			1	PIPE
18	1425344M1	!	17	2	BUSH
19	390898X1	!	17	2	RING
20	1425339M92			1	PLATE
21	339139X1			4	SCREW
22	1426682M91	●●	1426682M93 (1)	1	LEVER
23	392212X1			1	KEY
24	339475X1	●●	391927X1 (1)	1	BOLT
25	1426683M1			1	GASKET
26	1425347M1	◀		1	PROTECTOR
27	1425440M91	●●	1425440M92 (1)	1	LEVER
28	390799X1			1	SCREW
29	339402X1			1	NUT BSF
30	1441738X1			1	DOWEL

Download full manual at youfixthis.com
PREVIEW - YOUFIXTHIS.COM

Large 13000


T-0637-14M-A




1	2871A141	3477851M91 (1) U139343P A	1	ALTERNATOR
2	31151582	31151585 (1) U139343P B	1	PULLEY
2	31151585	U139343P C	1	PULLEY
2	31151586	U139343P D	1	PULLEY
3	2614B667	U139344P 2614B167	1	V BELT
3	2614B669	U139343P 2614B169	1	V BELT
4	0096231	0746258 (1) U139343P	1	SETSCREW
5	0576002	353916X1 (1) U139343P	1	NUT
6	0920003	390972X1 (1) U139343P	1	WASHER
7	0920053	U139343P	1	WASHER
8	33421127	U708999K	1	SLEEVE
9	0096234	U709000K U139343P	1	SETSCREW
9	0746261	U708999K	1	BOLT
10	0576002	353916X1 (1) U139343P	1	NUT
11	0920003	390972X1 (2) U709000K	2	WASHER
11	0920497	U708999K	2	WASHER
12	0920053		1	WASHER
13	33421127	U708999K	1	SLEEVE
14	38162136	U708999K	1	SUPPORT
14	3827H002	U709000K U139343P	1	SUPPORT

Download full manual at youfixthis.com

PREVIEW - YOUFIXTHIS.COM



Large 13000




33	1440315X1			1 WASHER
34	1440200X1			1 NUT BSF
35	3426773M2	●	3426773M3 (2)	2 UNIVERSAL
36	391232X1	!	35	1 NUT
37	392842X1			2 NUT BSF
38	1425533M91			1 BEARER
39	2714131M3	!	38 A	1 BUSH
40	339608X1			2 GREASER
41	391889X1			4 SCREW
42	391414X1			4 WASHER
43	3301053M1			2 SHIM
44	2714131M3			1 BUSH

!	THIS IS A COMPONENT OF AN ASSEMBLY
A	UP TO SERIAL NO U 42014,
B	FROM SERIAL U 42015
▲	TOP
▼	LOWER COMPONENT
◄	LEFT HAND
►	RIGHT HAND


Download full manual at youfixthis.com

PREVIEW - YOUFIXTHIS.COM



TRACTOR CAB - RADIO INSTALLATION

4-1793-001-A



1	3310585M91		1	KIT,PLATE
2		! 1	1	PLATE
		⛟ REF.N.1		
3		! 1	1	PLATE
		⛟ REF.N.1		
4	3000025X1		1	SCREW
5	3532041M1		1	DECAL
6	3537507M92	N	1	HARNESS
7	3389655M1	N	2	GRILLE
8	3015005X1	N	8	SCREW
9	1441494X1	N	8	NUT BSF

! THIS IS A COMPONENT OF AN ASSEMBLY

⛟ NOT SERVICED, ORDER

N FROM SERIAL R 15189.


Download full manual at youfixthis.com

PREVIEW - YOUFIXTHIS.COM




FRONT AXLE 4 WHEEL DRIVE- DIFFERENTIAL

4-AK04-035-A



1	3426036M91	▲	9/31		1	KIT
2	1824241M93		A		1	DIFFERENTIAL
2	3426071M93		B		1	KIT
3	3426072M3	!	2 B		1	HOUSING
4	3426074M92	!	2 B		1	DIFFERENTIAL
5	3426073M2	!	2 B		1	HOUSING
6	3426075M2	!	2 B		1	PIN
7	1442901X1	!	2 B		8	SCREW
8	3426929M1				8	BOLT
9	1441250X1	●	3765690M1	(1)	1	BEARING
10	3426003M91	●	N.L.A.	(2)	2	DRIVE SHAFT
11	3310462M1	!	10		1	SHAFT
12	3310464M1	!	10		1	SHAFT
13	3310463M1	!	10		1	UNIVERSAL
14	1429021M1	!	10		2	CROSSPIECE
15	1429022M1	!	10		8	CIRCLIP
16	3000021X1				2	SCREW
17	339394X1				1	BEARING
18	366434X1				1	O RING
19	3426024M1				1	BUSH
20	391316X1				1	SEAL
21	3427289M1	●▼▲	3428923M1 0,10MM.	(999)	999	SHIM
21	3427290M1	●▼▲	3428924M1 0,15MM.	(999)	999	SHIM
21	3427291M1	●▼▲	3428925M1 0,30MM.	(999)	999	SHIM


Download full manual at youfixthis.com
PREVIEW - YOUFIXTHIS.COM



Large 13000


STEERING CYLINDER- 2 WHEEL DRIVE

4-1316-016 -A



1	1425552M91	◇	81/10	1	RAM
		◇	83/10		
2	1425553M91	!	1	1	BODY
3	1606844M1	!	1	1	PISTON
4	1442527X1	!	1	1	O RING
5	338854X1	●	372962X1 (1)	1	O RING
		!	1		
6	1606780M1	!	1	1	RING
7	1033681M1	!	1	1	RING
8	1442526X1	!	1	1	NUT BSF
9		!	1	1	ROD
		⛽	REF.N.1		
10	1749562M1	!	1	1	SEAL
11	1441847X1	!	1	1	SEAL
12	1748139M2	!	1	1	BUSH
13	1748141M1	!	1	1	CLIP
14	1442528X1	!	1	1	SEAL
15	3426660M1			2	TOGGLE
16	339075X1	!	15	2	NUT BSF
17	182304M1	!	15	2	COLLAR
18	339246X1	!	15	2	BOLT
19	1440314X1	!	15	2	WASHER
20	339402X1	!	15	2	NUT BSF
21	1425908M1			1	BEARER
22	391269X1			3	SCREW
23	391414X1			3	WASHER
24	394202X1	●	3553651M1 (1)	1	UNION
25	1440702X1			2	SEAL
26	3301939M91			1	PIPE
27	1424959M92	●	1424959M94 (1)	1	UNION
28	1441082X1			1	RING
29	3019914X1	!	27	1	O RING


Download full manual at youfixthis.com
PREVIEW - YOUFIXTHIS.COM



DRAWBAR

Large 13000

4-1634-028 -A



1	339034X1	4	NUT BSF
2	339377X1	4	LOCK WASHER
3	1426056M91	1	PIN
4	1425547M91	2	CLEVIS PIN
5	974303M1	2	PIN
6	1425539M4	1	DRAGBAR
7	1425540M1	1	BAIL
8	391332X1	2	SCREW
9	1440318X1	2	WASHER
10	3009747X1	2	NUT
11	1425542M91	1	CLEVIS PIN
12	974303M1	1	PIN
13	1425543M92	1	BEARER
14	392301X1	4	STUD
15	1440318X1	4	WASHER
16	3009747X1	4	NUT
17	1427443M1	1	CLEVIS PIN
18	1425549M91	1	BEARER
19	339805X1	4	BOLT


Download full manual at youfixthis.com

PREVIEW - YOUFIXTHIS.COM



TRACTOR CAB - CAB INSULATION

4-1810-008-A




1	3301769M91	●	N.L.A. (1) C	1	ROOF
1	3530634M1	●	N.L.A. (1) D M	1	ROOF
1	3537500M1		N	1	ROOF
2	392403X1	●	3015126X1 (22) D	22	SCREW
2	392403X1	●	3015126X1 (30) C	30	SCREW
3	1427000M1		C	30	WASHER
3	1427000M1		D	22	WASHER
4	3301823M91	● ◀	N.L.A. (1) C	1	CLADDING
4	3531744M91	▶	C	1	FACING
4	3532042M1	▶	D	1	FACING
4	3532043M1	● ◀	N.L.A. (1) D M	1	FACING
4	3536996M1	●	3647959M1 (1) N	1	FACING
5	3301825M91	⇉ ◀	23400095	1	FACING
5	3301826M91	● ⇉ ▶	N.L.A. (1) 23400095	1	FACING
5	3306127M91	● ⇉ ▶	N.L.A. (1) 23400096	1	FACING
5	3306127M91	● ▶	N.L.A. (1) C	1	FACING

Download full manual at youfixthis.com
PREVIEW - YOUFIXTHIS.COM

Large 13000


T-0572-18M-A



1	37161177	●	37161175	1 CRANKCASE
		●	37161174	
2	2418F436	●	2415361	1 SEAL
3	36814135	●	3681P032 (1)	1 UNIVERSAL
		●	36814124	
4	0746255	●	2183205 (3)	3 SETSCREW
5	0920053			3 WASHER
6	0746255	●	2183205 (5)	5 SETSCREW
7	0920053			5 WASHER
8	0096237			1 BOLT
9	0920053			1 WASHER
10	31416303			1 CAMSHAFT
11	31171138	▲	56	1 GEAR
12	0500012			1 KEY
13	33153128			1 WASHER
14	33115408			1 WASHER
15	31733121			1 WASHER
16	2182122			1 SETSCREW
17	33153121			1 WASHER
18	2116053	●	0610844	1 PIN
19	41115057	►		1 GEAR
		▲	37	
20		!	19	1 GEAR
		⛟	REF.19	
21	2511613	!	19	1 BUSH
22	32718522			1 HUB
23	0350553			1 DOWEL
24	0826510			2 STUD
25	2211224			2 NUT
26	32413122			1 PLATE
27	41115056	◄		1 GEAR
		▲	37	

PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com



LIFT DISTRIBUTOR

Large 13000

4-AP38-022-A



1	3306216M93			1	DISTRIBUTOR
2	1425362M91	●	3306216M93 (1)	1	DISTRIBUTOR
		!	1		
3	1825248M1	!	1	1	SPRING
4	1441267X1	!	1	1	SCREW
5	3304561M92	!	1	1	VALVE
6		!	5	1	THIMBLE
		▰	REF.N.5		
7		!	5	1	VALVE
		▰	REF.N.5		
8		!	5	1	SPRING
		▰	REF.N.5		
9		!	5	1	CUP
		▰	REF.N.5		
10	1441211X1	!	5	2	SEAL
11	762026M1	!	1	1	O RING
12	1442477X1	!	1	1	GASKET
13	3301059M1	!	1	1	NUT
14	1825256M1	!	1	1	LEVER
15	1441805X1	!	1	1	PIN
16	1442012X1	●	1440399X1 (1)	1	PIN
		!	1		
17	1825257M1	●	N.L.A. (1)	1	COVER
		!	1		
18	3019926X1	!	1	1	O RING
19	391148X1	!	1	4	SCREW
20	395593X1	!	1	1	PLUG
21	395592X1	!	1	1	GASKET
22	1825261M1	!	1	1	VALVE
23	1825262M1	!	1	1	SPRING
24	1425433M2	!	1	1	SEAT
25	762026M1	!	1	1	O RING
26	3019914X1	!	1	1	O RING
27	361031X1	!	1	2	BALL

Download full manual at youfixthis.com
PREVIEW - YOUFIXTHIS.COM

PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com

ACCESSORIES AND APPLICATION MISCELLANEOUS


Large 13000

ROCKER SHAFT

T-0569-16M-A



48	2511425	!	46	1	BUSH
49	31744123	!	1	1	SPRING
50	41151482	●	4115R305 (1)	1	ROCKERARM
		!	1		
		●	41151468		
		▶			
51		!	50	1	LEVER
		⛟	REF.50		
52	2511425	!	50	1	BUSH
53	37521471	!	1	1	SUPPORT
		⅄	37521431		
54	41151481	●	4115R306 (1)	1	ROCKERARM
		!	1		
		●	41151467		
		▶			
55		!	54	1	LEVER
		⛟	REF.54		
56	2511425	!	54	1	BUSH
57	0720579	●	32114145 (12)	12	SCREW
		!	1		
58	0576052	!	1	12	NUT
59	33117434	!	1	1	WASHER
60	0170151	!	1	1	CIRCLIP
61	2215274			4	STUD
62	0576054			4	NUT
63	33116111			4	WASHER
64	0096636			2	BOLT
65	33116111			2	WASHER
66	33811113	●	376525X1 (1)	1	OLIVE
67	31434307			12	ROD
68	31434163	●	3142U031 (12)	12	TAPPET
69	37186471	➡	U711699L	1	COVER



52	3302307M1	●○ !	N.L.A. (1) 1 D	1	INDICATOR
52	3530583M1	!	1 E	1	GLASS
53	3302249M1	●○ !	N.L.A. (2) 1	2	GASKET
54	3302248M1	!	1	2	GASKET
55	1427879M91	!	1 E	1	HOUSING
55	3302193M91	!	1 D	1	HOUSING
56	3310795M1	!	1 C E	1	BLEEDER
57	3310796M1	!	56 C E	1	UNION
58	3310797M1	!	56 C E	1	LEAD
59	3530490M91	! ●○	56 3000483X1 C E	2	TIE
60	1696477M1	!	56	1	CLIP

! THIS IS A COMPONENT OF AN ASSEMBLY

●○ REPAIRS AND REPLACES

A SWITCH WASHER

B SWITCH WIPER

C KIT HEATER 3301746M92.,

D UP TO SERIAL NO 13400248 / 23400510.,


E FROM SERIAL 13400249 / 23400511.

Download full manual at youfixthis.com

PREVIEW - YOUFIXTHIS.COM


Large 13000

AUXILIARY DISTRIBUTOR




1	3531626M91	●	N.L.A. (1)	1 DISTRIBUTOR
		◇	108/1	
			A	
			A	
2		!	1	1 BODY
		▰	REF.N.1	
3	3310694M91	!	1	1 BODY
4	3310695M1	!	3	1 RING
5	1001833M1	!	3	1 O RING
6	3310697M91	●	N.L.A. (1)	1 BODY
		!	1	
7	1442589X1	!	6	1 O RING
8	3310699M1	!	1	1 GASKET
9	3310700M1	!	1	1 BALL
10	1441941X1	!	1	1 RING
11	3310757M91			999 KIT
12	3310704M91	!	1	1 GUIDE
13	3310705M1	!	12	1 GASKET
14	195562M1	!	12	1 O RING
15	3310707M1	!	1	1 SPRING
16	3310708M1	!	1	1 SUPPORT
17	831617M1	!	11	2 RING
18	851134M1	!	11	1 O RING
19	3310711M1	!	11	1 GASKET
20	1441213X1	!	11	1 O RING
21	3310713M1	!	11	1 GASKET
22	3310703M91	!	1	2 KIT
23	3310714M1	!	1	1 SPACER
24	3310702M1	!	1	1 SPACER
25	391036X1	!	1	2 LOCK WASHER
26	390989X1	!	1	2 SCREW
27	3310731M1	!	1	1 HOLDER
28	1442692X1	!	1	2 BOLT
29	3310733M1	●	3310733M2 (1)	1 CLEVIS PIN
		!	1	

Download full manual at youfixthis.com
PREVIEW - YOUFIXTHIS.COM



HYDRAULIC PUMP

4-AP32-053-A



1	3301295M91	●	3549613M91 (2)	2	PUMP
		◇	94/1		
			A		
2		!	1	1	PISTON
		▰	REF.N.1		
3		!	1	1	GEAR
		▰	REF.N.1		
4		!	2	4	THIMBLE
		▰	REF.N.2		
5	1426706M1	!	1	1	COVER
6	1440672X1	!	1	2	PIN
7	1426707M1	●	N.L.A. (1)	1	COVER
		!	1		
8	3015039X1	!	1	16	SCREW
9	1440314X1	!	1	16	WASHER
10	1426708M91			999	KIT
11	1427541M1	!	10	1	GASKET
13	390936X1	!	1	1	CIRCLIP
14	393106X1	!	1	1	KEY DOOR
15	339070X1	!	1	1	NUT
16	1426710M1	!	1	1	WASHER

! THIS IS A COMPONENT OF AN ASSEMBLY

◇ SEE PAGE - REFERENCE NUMBER

▰ NOT SERVICED, ORDER

A TUROLLA TYPE

Download full manual at youfixthis.com

PREVIEW - YOUFIXTHIS.COM

PREVIEW ONLY

You're viewing 18 of 340 pages

The full manual includes:

- All 340 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Landini Large 13000 Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual