


445D 3 CYL TRACTOR LOADER (9/92-10/00) - Wheels and Weights

01A01 FRONT WHEEL ASSEMBLY

Ref	Part Number	Qty	Description
1	82005056	2	Rim, 5.50x16, 6 Bolt, 345C & D,445C & D, Start Year: 12/01/1988
1	E0NN1007LA	2	Rim, 8.00x16, 6 Bolt, 345C & D,445C, Start Year: 12/01/1988
1	D4NN1007D12Z	2	Rim, 8.00x16, 8 Bolt, 545C & D, Start Year: 12/01/1988
1	83946635	2	Rim, 5.50x16, 8 Bolt, 545C (Replaces D4NN1007A), Start Year: 12/01/1988
1	82006614	2	Rim, 9.75x16.5, 8 Bolt, W/4WD, Start Year: 12/01/1988
1	E5NN1007KA29Z	2	Rim, 8"x16", 6 Bolt, Solid Disc, H.D., Start Year: 12/01/1988
2	83948358	2	Retainer Assy., Start Year: 12/01/1988
2A	312565	2	Shield, Start Year: 12/01/1988
3	512725	2	Cone Assy., Inner, Start Year: 12/01/1988
4	313020	2	Hub Assy., 6 Bolt, Start Year: 12/01/1988
4	D8NN1104DA	2	Hub Assy., 8 Bolt, Start Year: 12/01/1988
5	81812302	2	Cup, Inner, Start Year: 12/01/1988
6	81816580	12	Bolt, 1/2"-20 x 1-3/4", Front Wheel Hub, Start Year: 12/01/1988
6	E5NN1117AA	16	Bolt, Wheel, 5/8"-18 x 2-3/8", Start Year: 12/01/1988
7	273610	2	Cup, Outer, Start Year: 12/01/1988
8	81812303	2	Cone Assy., Outer, Start Year: 12/01/1988
9	81815739	12	Nut, 1/2"-20, Front Wheel Bolt, 445C & D, Start Year: 12/01/1988
9	81815912	16	Nut, 5/8"-18, Start Year: 12/01/1988
9	E0NN1012AA	16	Nut, M18 x 1.5 , FWD, Start Year: 12/01/1988
10	BB1195	2	Washer, Front Hub Grease Retainer, 345C & D,445C,545C, NHNA Only., Start Year: 12/01/1988
11	280172	AR	Nut, Slotted, G2, 7/8"-14, Start Year: 12/01/1988
12	88350	2	Pin,Split (Cotter), 5/32" x 1-1/2", Start Year: 12/01/1988
13	249127	2	Cap, Hub, Start Year: 12/01/1988
14	E0NN1A042AA	16	Adapter, For Tapered Holes, 4WD, Start Year: 12/01/1988



The power steering pump illustrated in this figure is used in both non-emissionized & emissionized engines

445D 3 CYL TRACTOR LOADER (9/92-10/00) - Wheels and Weights

06A01 CYLINDER BLOCK & HEAD

Ref	Part Number	Qty	Description
1	81875257	1	Engine Assy., Non-Emissionized, 545D, NH-E Only., Years: 09/01/1992-04/21/1998
1	81875258	1	Engine Assy., Non-Emissionized, 445D, NH-E Only., Years: 09/01/1992-04/21/1998
1	87801544	1	Engine Assy., Emissionized, 345D, 445D, Start Year: 04/22/1998
1	87801545	1	Engine Assy., Emissionized, 545D, Start Year: 04/22/1998
1	87801407	1	Engine Assy., Emissionized, Turbo, ASN A442030
1A	E6NN6009XC	1	Block Assy., Short, 345C & D, 445C & D, Years: 12/01/1988-03/31/1994
1A	E6NN6009YC	1	Block Assy., Short, 545C & D, Years: 12/01/1988-03/31/1994
1A	87840503	1	Block Assy., Short, 545D, Years: 04/01/1994-04/21/1998
1A	87840502	1	Block Assy., Short, 345D, 445D, Years: 04/01/1994-04/21/1998
1A	87801546	1	Block Assy., Short, Emissionized, 345D, 445D, 545D, Start Year: 04/22/1998
1A	87801418	1	Block Assy., Short, Emissionized, Turbo, ASN A442030
1B	87802107	1	Head Assy., Non-Emissionized, 345C & D, 445C & D, Start Year: 12/01/1988
1B	87800093	1	Head Assy., Non-Emissionized, 545 & D, Start Year: 12/01/1988
1B	87801330	1	Head Assy., Emissionized, 345D, 445D, 545D, Start Year: 05/01/1998
2	D4NN6056A	3	Insert, Intake Valve, Standard, Start Year: 12/01/1988
2	87802103	AR	Insert, Intake Valve, .010", O/S, Start Year: 12/01/1988
2	87802104	AR	Insert, Intake Valve Seat, .020", O/S, Start Year: 12/01/1988
2	87802105	AR	Insert, Intake Valve, .030" O/S, Start Year: 12/01/1988
3	83909432	3	Insert, Exhaust Valve, Std, 345C & D, 445C & D, Start Year: 12/01/1988
3	D4NN6057B	AR	Insert, Exh. Valve, .010" O/S, 345C & D, 445C & D, Start Year: 12/01/1988
3	D4NN6057C	AR	Insert, Exh. Valve, .020" O/S, 345C & D, 445C & D, Start Year: 12/01/1988
3	87800559	AR	Insert, Exh. Valve, .030" O/S, 345C, 445C, NHNA Only., Start Year: 12/01/1988
3	E9NN6057DA	3	Insert, Exh. Valve, Std., 545C & D, Start Year: 12/01/1988
3	E9NN6057EA	AR	Insert, Exhaust Valve, .010" (.254mm) O/S, Start Year: 12/01/1988
3	C9NN6057L	AR	Insert, Exh. Valve, .020" O/S, 545C & D, Start Year: 12/01/1988
3	87800557	AR	Insert, Exh. Valve, .030" O/S, 545C & D, Start Year: 12/01/1988
4	83957025	3	Plug, 1.75" (44.5mm), Start Year: 12/01/1988
4	83957026	1	Plugs, 1.81" (46mm), Start Year: 12/01/1988
5	83957021	1	Plug, 1.13" (28.7mm), Start Year: 12/01/1988
5	83957022	1	Plugs, 1.18" (30mm), Start Year: 12/01/1988
6	9712608	1	Sender Assy., Water Temperature Indicator, Start Year: 12/01/1988
7	87802206	10	Bolt, 9/16"-12 x 5 1/32", Start Year: 12/01/1988
8	87801653	1	Gasket, Start Year: 12/01/1988
9	C7NN8594B	1	Connection, Start Year: 12/01/1988
10	D8NN8575AA	1	Thermostat, Standard, 168°, Start Year: 12/01/1988
11	E9NN8255AA	1	Gasket, Start Year: 12/01/1988
12	42967S36	1	Screw, Cap, HH, G8, Self-Locking, 5/16"-18 x 2-3/8", Start Year: 12/01/1988
13	F0NN6010BD	1	Block Assy., Cylinder, Non-Emissionized, Start Year: 12/01/1988
13	87800156	1	Block Assy., Cylinder, Emissionized, Start Year: 05/01/1998
13	87802719	1	Block Assy., Cylinder, Emissionized, Turbo, ASN A442030
14	379548S	8	Bolt, 9/16"-12 x 4.45", Start Year: 12/01/1988
15	87800499	4	Bearing, Camshaft, Front, 60.88mm (2.397") ID
15	87301590	4	Bearing, Camshaft, Front, 60.22mm (2.371") ID, Start Year: 12/01/1988
16	E2NN6784AA	1	Tube, 4.04", Start Year: 12/01/1988

Meeting the U.S. Environmental Protection Agency regulation, the engines in the Utility Tractor Loaders have been emissionized beginning with serial number A442030, effective 5/12/98.

445D 3 CYL TRACTOR LOADER (9/92-10/00) - Wheels and Weights


07B01 6 X 4 MANUAL REVERSING TRANSMISSION GEARS


Ref	Part Number	Qty	Description
1	C7NN7017V	1	Shaft, Input, with/I.P.T.O., Start Year: 01/01/1978
2	86511837	1	Bearing, Ball, M40, Start Year: 01/01/1978
3	508E7064A	1	Ring, Snap, Inner, Start Year: 01/01/1978
4	C5NN7N064A	1	Ring, Snap, Outer, Start Year: 01/01/1978
5	82001825	1	Bearing Assy., Main, Start Year: 01/01/1978
6	C5NN7N053B	1	Plate, Start Year: 01/01/1978
7	C5NN7N108A	1	Straddle, Start Year: 01/01/1978
8	280980	3	Nut, Lock, GC, 7/16"-14, Start Year: 01/01/1978
9	46055S36	1	Screw, Cap, HH, G5, Self-Locking, 7/16"-14 x 1-5/8", Start Year: 01/01/1978
9	380549S	2	Bolt, 7/16"-14 x 3-1/4", Start Year: 01/01/1978
9	380550S	1	Bolt, 7/16"-14 x 3-3/4", Start Year: 01/01/1978
10	D1NN772B	1	Shaft, with/I.P.T.O., Start Year: 01/01/1978
11	83908455	1	Bearing, 90 x 50 x 20, Start Year: 01/01/1978
12	957E732	1	Ring, Snap, Small, with/I.P.T.O., Start Year: 01/01/1978
13	C5NN7N064A	1	Ring, Snap, Large, with/I.P.T.O., Start Year: 01/01/1978
14	957E727A	1	Oil Seal Assy., with/I.P.T.O., Start Year: 01/01/1978
15	D9NNC729BA	1	Seal, Oil, with/I.P.T.O., Start Year: 01/01/1978
16	C7NN7N054C	1	Plate Assy., Incl. Ref., 17, Start Year: 01/01/1978
17	73269S	2	Pin, Dowel, 3/8" x 11/16", Start Year: 01/01/1978
18	E6NN7N057AA	1	Gasket, Start Year: 01/01/1978
19	9846677	17	Screw, Cap, HH, CL 10.9, M10 x 1.5 x 25, Start Year: 01/01/1978
20	D9NNC729BA	1	Seal, Oil, Start Year: 01/01/1978
21	81804648	1	Gasket, Start Year: 01/01/1978
22	D5NN7050A	1	Retainer, with/I.P.T.O., Start Year: 01/01/1978
23	46007S36	5	Screw, Cap, HH, G5, Self-Locking, 3/8"-16 x 7/8", Start Year: 01/01/1978
24	86691	1	Cup, Start Year: 01/01/1978
25	E6NN7C095CA	1	Shaft, Main, Rear, 17T & 20T, Start Year: 08/01/1987
26	C7NN7N431B	1	Cone Assy., Outer, Start Year: 01/01/1978
27	C5NN7N044A	1	Bearing, Cup & Cone, Start Year: 01/01/1978
28	E6NN7N101CA	1	Gear Assy., 2nd Speed, 43T, Start Year: 08/01/1987
29	E6NN7N072BA	1	Coupling, 28T, Gear Shift, Start Year: 08/01/1987
30	E6NN7N107AA	1	Gear Assy., 1st & 3rd, Reverse, 33T, Start Year: 08/01/1987
31	81804625	3	Washer, Start Year: 01/01/1978
32	C5NN7033D	2	Washer, 2 x 2.58 x .05, Start Year: 01/01/1978
33	E6NN7N413AA	1	Gear Assy., 2nd & 5th, 35T, Start Year: 08/01/1987
34	E6NN7N072AA	1	Connector & Coupling, Start Year: 08/01/1987
35	E6NN7N105AA	1	Gear Assy., 2nd & 4th, 25T, Start Year: 08/01/1987
36	C5NN7033F	1	Washer, 2-1/4" OD, Start Year: 01/01/1978
37	C5NN7033C	1	Washer, 2-1/2" OD, Start Year: 01/01/1978
38	C5NN7N034B	1	Washer, .110", thick, Start Year: 01/01/1978
39	86503781	1	Ring, Snap, #156, Ext, Start Year: 01/01/1978
40	25121	1	Ring, Snap, #100, Ext, Coupling & Shaft Assy, Start Year: 01/01/1978
41	E6NN7N071AA	1	Coupling & Shaft, Output, Start Year: 08/01/1987
42	C9NN7A385A	1	Washer, 1.755" ID, Start Year: 01/01/1978





445D 3 CYL TRACTOR LOADER (9/92-10/00) - Wheels and Weights

15B01 WINDOWS, 445D, 545D

Ref	Part Number	Qty	Description
	E9NN94422A12AB	1	Window Assy., Rear, L/Wiper, One position handle., See 15B07 for Rear Wiper Kit., Start Year: 09/01/1992
1	81875338	1	Glass, Start Year: 09/01/1992
1	SEK930906	1	Glass, W/Hole for Rear Wiper, Start Year: 09/01/1992
2	SEK39034	1	Strip, Weather, Start Year: 09/01/1992
3	83990440	1	Plug, 10mm, Start Year: 09/01/1992
4	E2NN94000R70AA	AR	Hinge, Two included W/Rear Window, Start Year: 09/01/1992
5	E2NN94000R72AA	AR	Bushing, Start Year: 09/01/1992
6	E2NN94440N25AA	AR	Washer, Start Year: 09/01/1992
7	86511828	AR	Screw, Pan Hd, CL 4.8, M6 x 1 x 12, Start Year: 09/01/1992
8	E2NN94440A00AA	AR	Bracket, Start Year: 09/01/1992
9	83961985	AR	Bushing, Start Year: 09/01/1992
10	E9NN94422R50AB	1	Handle Assy., One Position, Includes: Ref. 11 thru 17, Start Year: 09/01/1992
10	SEK49307	1	Handle Assy., Two Position
11	NSS	1	Handle, Start Year: 09/01/1992
12	NSS	1	Plate, Start Year: 09/01/1992
13	NSS	1	Screw, Set, Start Year: 09/01/1992
14	NSS	1	Nut, Start Year: 09/01/1992
15	NSS	1	Cap, Start Year: 09/01/1992
16	NSS	1	Bushing, Start Year: 09/01/1992
17	NSS	1	Washer, Start Year: 09/01/1992
18	E3NN94032N16AA	2	Gasket, Start Year: 09/01/1992
19	E3NN94032N15AA	1	Plate, Start Year: 09/01/1992
20	SEK912062	2	Bushing, Start Year: 09/01/1992
21	86511831	2	Screw, Pan Hd, CL 4.8, M6 x 1 x 25, Start Year: 09/01/1992
22	353308	2	Nut, Lock, M6 x 1, CL 8, Start Year: 09/01/1992
23	E2NN94440N22AA	2	Cap, Start Year: 09/01/1992
24	E2NN94000R61AA	1	Strip, Weather, Side Window, Start Year: 09/01/1992
25	E2NN9444000AA	2	Regulator, Start Year: 09/01/1992
26	86511830	2	Screw, Pan Hd, CL 4.8, M6 x 1 x 20, Start Year: 09/01/1992
27	E3NN94032N13AA	1	Latch, Start Year: 09/01/1992
28	E663208S85	6	Ring, Circlip, M6, Hinge Pin, Start Year: 09/01/1992
29	F1NN94000R79AA	6	Pin, Start Year: 09/01/1992
30	E3NN94032N12AB	4	Pin, 6 x 26, Start Year: 09/01/1992
31	E2NN94303A24AA	2	Latch Assy., Side Windows, Start Year: 09/01/1992
32	E2NN94440N26AA	2	Ball, Start Year: 09/01/1992
33	SEK930692	2	Glass, LH & RH, Start Year: 09/01/1992
34	F1NN94502N26AA	1	Glass, Rear, Fixed, Start Year: 09/01/1992
35	SEK930211	2	Glass, Lower Front, LH & RH, Start Year: 09/01/1992
36	85999176	1	Windshield, Start Year: 09/01/1992
37	F1NN94422N49AA	1	Seal, Start Year: 09/01/1992
38	F1NN94410A64AA	1	Cover, Clear Plastic, Start Year: 09/01/1992
39	SEK912067	3	Washer, Plastic, Start Year: 09/01/1992
40	86511829	3	Screw, Pan Hd, CL 4.8, M6 x 1 x 16, Start Year: 09/01/1992








445D 3 CYL TRACTOR LOADER (9/92-10/00) - Wheels and Weights

01A01 FRONT WHEEL ASSEMBLY

Ref	Part Number	Qty	Description
1	82005056	2	Rim, 5.50x16, 6 Bolt, 345C & D,445C & D, Start Year: 12/01/1988
1	E0NN1007LA	2	Rim, 8.00x16, 6 Bolt, 345C & D,445C, Start Year: 12/01/1988
1	D4NN1007D12Z	2	Rim, 8.00x16, 8 Bolt, 545C & D, Start Year: 12/01/1988
1	83946635	2	Rim, 5.50x16, 8 Bolt, 545C (Replaces D4NN1007A), Start Year: 12/01/1988
1	82006614	2	Rim, 9.75x16.5, 8 Bolt, W/4WD, Start Year: 12/01/1988
1	E5NN1007KA29Z	2	Rim, 8"x16", 6 Bolt, Solid Disc, H.D., Start Year: 12/01/1988
2	83948358	2	Retainer Assy., Start Year: 12/01/1988
2A	312565	2	Shield, Start Year: 12/01/1988
3	512725	2	Cone Assy., Inner, Start Year: 12/01/1988
4	313020	2	Hub Assy., 6 Bolt, Start Year: 12/01/1988
4	D8NN1104DA	2	Hub Assy., 8 Bolt, Start Year: 12/01/1988
5	81812302	2	Cup, Inner, Start Year: 12/01/1988
6	81816580	12	Bolt, 1/2"-20 x 1-3/4", Front Wheel Hub, Start Year: 12/01/1988
6	E5NN1117AA	16	Bolt, Wheel, 5/8"-18 x 2-3/8", Start Year: 12/01/1988
7	273610	2	Cup, Outer, Start Year: 12/01/1988
8	81812303	2	Cone Assy., Outer, Start Year: 12/01/1988
9	81815739	12	Nut, 1/2"-20, Front Wheel Bolt, 445C & D, Start Year: 12/01/1988
9	81815912	16	Nut, 5/8"-18, Start Year: 12/01/1988
9	E0NN1012AA	16	Nut, M18 x 1.5 , FWD, Start Year: 12/01/1988
10	BB1195	2	Washer, Front Hub Grease Retainer, 345C & D,445C,545C, NHNA Only., Start Year: 12/01/1988
11	280172	AR	Nut, Slotted, G2, 7/8"-14, Start Year: 12/01/1988
12	88350	2	Pin,Split (Cotter), 5/32" x 1-1/2", Start Year: 12/01/1988
13	249127	2	Cap, Hub, Start Year: 12/01/1988
14	E0NN1A042AA	16	Adapter, For Tapered Holes, 4WD, Start Year: 12/01/1988



445D 3 CYL TRACTOR LOADER (9/92-10/00) - Wheels and Weights

05A03 HYDRAULIC LIFT CYLINDER

Ref	Part Number	Qty	Description
1	E0NN477AB	1	Cylinder Assy., Incl. Ref. 2 thru 23, Start Year: 12/01/1988
2	D3NN916K	1	Plug, Start Year: 12/01/1988
3	89827059	2	O-Ring, .551" ID x .070" Thk, Start Year: 12/01/1988
4	D3NNK841A	1	Spring, Start Year: 12/01/1988
5	E0NN925AA	1	Valve, Unload, Start Year: 12/01/1988
6	9992298	1	O-RING, 90 Duro, .489" ID x .070" Thk, Start Year: 12/01/1988
7	E0NN482AB	AR	Bushing, White, Start Year: 12/01/1988
7	E0NN482BB	AR	Bushing, Blue, Start Year: 12/01/1988
7	E0NN482CB	AR	Bushing, Yellow, Start Year: 12/01/1988
7	E0NN482DB	AR	Bushing, Green, Start Year: 12/01/1988
7	E0NN482EB	AR	Bushing, Orange, Start Year: 12/01/1988
7	E0NN482FB	AR	Bushing, Blue/White, Start Year: 12/01/1988
7	E0NN482GB	AR	Bushing, Green/White, Start Year: 12/01/1988
7	E0NN482HB	AR	Bushing, Red/White, Start Year: 12/01/1988
8	E0NNF947FA	1	Plug, Start Year: 12/01/1988
9	272217	1	O-Ring, 90 Duro, .426" ID x .070" Thk, Start Year: 12/01/1988
10	E0NN481AB	AR	Bushing, Blue/White, Start Year: 12/01/1988
10	E0NN481BB	AR	Bushing, White, Start Year: 12/01/1988
10	E0NN481CB	AR	Bushing, Blue, Start Year: 12/01/1988
10	E0NN481DB	AR	Bushing, Yellow, Start Year: 12/01/1988
10	E0NN481EB	AR	Bushing, Green, Start Year: 12/01/1988
10	E0NN481FB	AR	Bushing, Orange, Start Year: 12/01/1988
10	E0NN481GB	AR	Bushing, Green/White, Start Year: 12/01/1988
11	D3NNF947A	1	Plug, Start Year: 12/01/1988
12	9992298	4	O-RING, 90 Duro, .489" ID x .070" Thk, Start Year: 12/01/1988
13	E0NNN958AA	1	Spring, Start Year: 12/01/1988
14	E0NNJ997AB	AR	Bushing, Blue/White, Start Year: 12/01/1988
14	E0NNJ997BB	AR	Bushing, White, Start Year: 12/01/1988
14	E0NNJ997CB	AR	Bushing, Blue, Start Year: 12/01/1988
14	E0NNJ997DB	AR	Bushing, Yellow, Start Year: 12/01/1988
14	E0NNJ997EB	AR	Bushing, Green, Start Year: 12/01/1988
14	E0NNJ997FB	AR	Bushing, Orange, Start Year: 12/01/1988
14	E0NNJ997GB	AR	Bushing, Green/White, Start Year: 12/01/1988
14A	E0NNF928BA	1	Bushing, Spool, Start Year: 12/01/1988
15	E0NN488CA	AR	Bushing, White, Start Year: 12/01/1988
15	E0NN488BA	AR	Bushing, Blue, Start Year: 12/01/1988
15	E0NN488AA	AR	Bushing, Yellow, Start Year: 12/01/1988
15	E0NN488DA	AR	Bushing, Green, Start Year: 12/01/1988
15	E0NN488EA	AR	Bushing, Orange, Start Year: 12/01/1988
16	E4NN924BA	1	Spring, Start Year: 12/01/1988
18	D5NN984A	1	Valve Assy., Start Year: 12/01/1988
19	C5NNN917A		Seal, Start Year: 12/01/1988
20	957E837	2	Ring, Dowel, Start Year: 12/01/1988
21	502046	3	Plug, Pipe, 1/8"-27, Start Year: 12/01/1988

445D 3 CYL TRACTOR LOADER (9/92-10/00) - Wheels and Weights

05H05 UNLOAD VALVE

Ref	Part Number	Qty	Description
	E9NNR838AA	1	Valve Assy., Incl. Ref. 1 thru 21, less Engine Mounted Auxiliary Pump, Start Year: 09/01/1992
	E0NNR838AC	1	Valve Assy., Incl. Ref. 1 thru 21, with Engine Mounted Auxiliary Pump, Start Year: 09/01/1992
1	NSS	1	Housing, Start Year: 09/01/1992
2	C7NNF917A	1	Plug, Start Year: 09/01/1992
3	128825	1	O-Ring, 8-1, 90 Duro, .644" ID x .087" Thk, Start Year: 09/01/1992
4	C7NNF947A	1	Plug, Start Year: 09/01/1992
5	167269	1	O-Ring, 10-1, 90 Duro, .755" ID x .097" Thk, Start Year: 09/01/1992
6	E2NNR841BA	1	Spool Assy, Includes: Ref 7 thru 10, Start Year: 09/01/1992
7	E0NNR848AA	1	Spring, Start Year: 09/01/1992
8	E0NNR849AA	1	Seat, Start Year: 09/01/1992
9	NSS	1	Plug, Start Year: 09/01/1992
10	NSS	1	Ball, Start Year: 09/01/1992
11	E1NNE996AC	1	Filter, Start Year: 09/01/1992
12	E0NNK841AA	1	Spring, Start Year: 09/01/1992
13	E0NNR844AB	1	Plug, Start Year: 09/01/1992
14	382299S	1	Ball, Start Year: 09/01/1992
15	82002382	1	Ring, Start Year: 09/01/1992
16	83926347	6	Seal (Replaces E0NNR847AA), Start Year: 09/01/1992
17	E0NNR847BA	1	Seal, Start Year: 09/01/1992
18	E0NNR847CA	1	Seal, Start Year: 09/01/1992
19	382299S	1	Ball, with Engine Mounted Auxiliary Pump, Start Year: 09/01/1992
20	E0NNR845AA	1	Guide, with Engine Mounted Auxiliary Pump, Start Year: 09/01/1992
21	E1NNR846AA	1	Spring, with Engine Mounted Auxiliary Pump, Start Year: 09/01/1992

445D 3 CYL TRACTOR LOADER (9/92-10/00) - Wheels and Weights


07B02 8 X 2 TRANSMISSION GEARS, D-SERIES, 1-95/

Ref	Part Number	Qty	Description
1	E2NN7017BA	1	Shaft, Input, 34T, Start Year: 01/01/1995
2	86511837	1	Bearing, Ball, M40, Start Year: 01/01/1995
3	508E7064A	1	Ring, Snap, Inner, Start Year: 01/01/1995
4	C5NN7N064A	1	Ring, Snap, Outer, Start Year: 01/01/1995
5	C5NN7N053A	1	Plate, Start Year: 01/01/1995
6	46051S36	4	Screw, Cap, HH, G5, Self-Locking, 7/16"-14 x 1-1/8", Start Year: 01/01/1995
11	D1NN772B	1	Shaft, Start Year: 01/01/1995
12	83908455	1	Bearing, 90 x 50 x 20, Start Year: 01/01/1995
13	957E732	1	Ring, Snap, Small, Start Year: 01/01/1995
13A	C5NN7N064A	1	Ring, Snap, Large, Start Year: 01/01/1995
14	957E727A	1	Oil Seal Assy., Start Year: 01/01/1995
15	D9NNC729BA	1	Seal, Oil, Start Year: 01/01/1995
16	D5NN7050A	1	Retainer, Start Year: 01/01/1995
17	81804648	1	Gasket, Start Year: 01/01/1995
18	46007S36	5	Screw, Cap, HH, G5, Self-Locking, 3/8"-16 x 7/8", Start Year: 01/01/1995
19	C7NN7N054C	1	Plate Assy., Incl. Ref. 20, Start Year: 01/01/1995
20	73269S	2	Pin, Dowel, 3/8" x 11/16", Start Year: 01/01/1995
21	E6NN7N057AA	1	Gasket, Start Year: 01/01/1995
22	46009S36	7	Screw, Cap, HH, G5, Self-Locking, 3/8"-16 x 1-1/8", Start Year: 01/01/1995
23	86691	1	Bearing, Cup, Start Year: 01/01/1995
24	E6NN7C095CA	1	Shaft, Main, Rear, 17T & 20T, Start Year: 01/01/1995
25	C7NN7N431B	1	Bearing, Cone, Start Year: 01/01/1995
26	C5NN7N044A	1	Bearing, Cup & Cone, Start Year: 01/01/1995
27	E6NN7N101AA	1	Gear Assy., 2nd, Start Year: 01/01/1995
28	E6NN7N072BA	1	Coupling, 28T, Gear Shift, Start Year: 01/01/1995
29	E6NN7N012AA	1	Gear, 28T & 32T, Reverse, Start Year: 01/01/1995
30	81804625	2	Washer, Start Year: 01/01/1995
31	E6NN7N100AA	1	Gear, 28T & 46T, 1st Speed, Start Year: 01/01/1995
32	E6NN7N072AA	1	Coupling, 28T, Gear Shift, Start Year: 01/01/1995
33	E6NN7N315AA	1	Gear Assy., 3rd, Start Year: 01/01/1995
34	C5NN7N034B	1	Washer, Start Year: 01/01/1995
35	86503781	1	Ring, Snap, #156, Ext, Start Year: 01/01/1995
36	82001825	1	Bearing Assy., Start Year: 01/01/1995
37	E6NN7061AA	1	Coupling & Shaft Assy., Start Year: 01/01/1995
38	C9NN7A385A	1	Washer, 1-3/4", Start Year: 01/01/1995
40	E6NN7145AA	1	Gear, 49T, Output Shaft, Start Year: 01/01/1995
42	C5NN7086A	1	Gasket, Start Year: 01/01/1995
43	C5NN7049E	1	Retainer, Start Year: 01/01/1995
44	379304S2	2	Pin, 1/2" x 13/16", Start Year: 01/01/1995
45	46009S36	10	Screw, Cap, HH, G5, Self-Locking, 3/8"-16 x 1-1/8", Start Year: 01/01/1995
47	C5NN7N135A	AR	Shim, .003", Start Year: 01/01/1995
47	81804789	AR	SHIM, .005" Thk, Start Year: 01/01/1995
47	81804790	AR	SHIM, .012" Thk, Start Year: 01/01/1995
48	C9NN7085B	1	Retainer Assy., Incl. Ref. 49 & 50, Start Year: 01/01/1995

445D 3 CYL TRACTOR LOADER (9/92-10/00) - Wheels and Weights

07L02 TRANSMISSION REAR COVER, 8 X 8

Ref	Part Number	Qty	Description
1	K3660221551	1	Cover, Rear w/Fine Thread, Years: 01/01/1988-07/31/1989
1	K3660221552	1	Cover, Rear w/Coarse Thread, Used After Transmission Date Code 9G06, Start Year: 01/01/1990
2	K3620021241	4	Plug, Start Year: 01/01/1988
3	K0113351030	9	Bolt, M10 x 1.25 x 30, Start Year: 01/01/1988
3	K0112351035	9	Bolt, M10 x 1.5 x 35, Start Year: 01/01/1990
4	K0501201320	2	Pin, Knock, Start Year: 01/01/1988
5	K3660221561	1	Retainer, Start Year: 01/01/1988
6	K0481150900	1	O-Ring, Start Year: 01/01/1988
7	K3660221571		AR Shim, 0.1mm, Start Year: 01/01/1988
8	K3660221581		AR Shim, 0.3mm, Start Year: 01/01/1988
9	K3660221591		AR Shim, 0.8mm, Start Year: 01/01/1988
10	K3660221611		AR Shim, 0.05mm, Start Year: 01/01/1988
11	K0113351025	4	Bolt, M10 x 1.25 x 25, Years: 01/01/1988-07/31/1989
11	K0112351030	4	Bolt, M10 x 1.5 x 30, Start Year: 01/01/1990
12	K3660221631	1	Retainer, Start Year: 01/01/1988
13	SBA052300950	1	O-Ring, Start Year: 01/01/1988
14	K3660221641		AR Shim, 0.1mm, Start Year: 01/01/1988
15	K3660221651		AR Shim, 0.3mm, Start Year: 01/01/1988
16	K3660221661		AR Shim, 0.8mm, Start Year: 01/01/1988
17	K3660221671		AR Shim, 0.05mm, Start Year: 01/01/1988
18	K0113351025	4	Bolt, M10 x 1.25 x 25, Years: 01/01/1988-07/31/1989
18	K0112351030	4	Bolt, M10 x 1.5 x 30, Start Year: 01/01/1990



445D 3 CYL TRACTOR LOADER (9/92-10/00) - Wheels and Weights

11C06 IMPLEMENT LAMP, L/CAB, NA ONLY (3-90/)

Ref	Part Number	Qty	Description
	82005479	1	Lamp, Implement, Incl. Ref. 1 thru 21, Start Year: 03/01/1990
1	E1NN15N495AA	1	Bezel, Start Year: 03/01/1990
2	E610248S72	2	Screw, Self-Tapping, Pan Hd, #8 x M19, Start Year: 03/01/1990
3	E3NN13N013AA	1	Lens, Start Year: 03/01/1990
4	E1NN13N356AA	1	Lens, Gasket, Start Year: 03/01/1990
5	9703399	1	Bulb Assy., Start Year: 03/01/1990
6	E1NN15N573AA	1	Reflector, Start Year: 03/01/1990
7	E1NN15N494AA	1	Holder, Bulb, Start Year: 03/01/1990
8	E1NN15N493AA	1	Spring, Retainer, Start Year: 03/01/1990
9	E3NN14N000AA	1	Wire Assy., Single, Start Year: 03/01/1990
10	E3NN15N550AA	1	Switch Assy., Start Year: 03/01/1990
11	E3NN15N322AA	1	Handle, Start Year: 03/01/1990
12	E610247S76	1	Screw, Self-Tapping, Pan Hd, #8 x M16, Start Year: 03/01/1990
13	E1NN13N357AA	1	Grommet, Start Year: 03/01/1990
14	E9NN15N303BA	1	Wire Assy., Start Year: 03/01/1990
15	E3NN15N569AA	1	Bracket, Start Year: 03/01/1990
16	386045	1	BOLT, Hex, M8 x 45, 8.8, Start Year: 03/01/1990
17	86629542	2	Nut, Lock, CL 8, M8 x 1.25, Start Year: 03/01/1990
18	43128	1	BOLT, Hex, M8 x 30, 8.8, Start Year: 03/01/1990
19	359840S8	1	Washer, Flat, 5/16", Start Year: 03/01/1990
20	E3NN15N321AA	2	Isolator, Start Year: 03/01/1990
21	E9NN15N569CA	1	Bracket, Start Year: 03/01/1990
22	513917	1	Grommet, Start Year: 03/01/1990
23	87670	1	Bolt, Cap, HH, G5, 1/2"-13 x 1-1/4", Start Year: 03/01/1990
24	281038	1	Washer, Lock, Ext T, 1/2", Start Year: 03/01/1990
25	44735S36	1	Washer, 1/2", Start Year: 03/01/1990
26	88871	1	Nut, Lock, GC, 1/2"-13, Start Year: 03/01/1990

14A03 PLATFORM, 345D, 445D, 545D



445D 3 CYL TRACTOR LOADER (9/92-10/00) - Wheels and Weights

16A01 DECALS, IDENTIFICATON

Ref	Part Number	Qty	Description
1	E8NN8N000BA	1	Decal, "FORD", RH, Years: 03/01/1989-08/31/1992
1	E8NN8N079AA	1	Decal, "FORD", LH, Years: 03/01/1989-08/31/1992
1	F2NN8N000CA	2	Decal, "FORD", Start Year: 09/01/1992
1	86521462	2	Decal, "New Holland", Black, 4" x 31", Start Year: 06/01/1997
2	E8NN16N650FA	4	Decal, 345C, Years: 03/01/1989-08/31/1992
2	86537247	4	Decal, 345D, Years: 09/01/1992-06/18/1997
2	86537247	4	Decal, 345D, Start Year: 06/19/1997
2	E8NN16N650EA	4	Decal, 445C, Years: 03/01/1989-08/31/1992
2	86537248	4	Decal, 445D, Years: 09/01/1992-06/18/1997
2	86537248	4	Decal, 445D, Start Year: 06/19/1997
2	E8NN16N650DA	4	Decal, 545C, Years: 03/01/1989-08/31/1992
2	86537249	4	Decal, 545D, Start Year: 09/01/1992
2	86537249	4	Decal, 545D, Start Year: 06/19/1997
3	E9NN16N650CA	2	Decal, "FORD", Years: 03/01/1989-06/18/1998
3	86537255	2	Decal, "New Holland", Black, 2-3/4" x 19", Start Year: 06/19/1998
4	E7TB8C020BB	1	Plate, FORD, See Figure 14B01, Years: 12/01/1988-06/18/1998
4	86520543	1	Plate, NH Leaf Logo, Start Year: 06/19/1998
5	86537246	2	Decal, "FORD", Emissionized Engine, ASN A442030
6	F0NN16605AA	2	Decal, Turbo

PREVIEW ONLY

You're viewing 18 of 430 pages

The full manual includes:

- All 430 pages, complete
 - Searchable PDF (find any keyword)
 - No watermarks
 - Instant download
 - Print-ready quality
-

GET FULL MANUAL NOW

**Ford 445D, 445D 3 CYL TRACTOR LOADER, 345C, 345D, 445C,
545C, 545D Parts Catalog**



Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual